

*Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)*



## M Commands

---

This chapter describes the Cisco NX-OS Ethernet and virtual Ethernet commands that begin with M.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## mac address-table aging-time

To configure the aging time for entries in the MAC address table, use the **mac address-table aging-time** command. To return to the default settings, use the **no** form of this command.

**mac address-table aging-time** *seconds* [**vlan** *vlan-id*]

**no mac address-table aging-time** [**vlan** *vlan-id*]

Syntax Description	<i>seconds</i>	Aging time for MAC address table entries. The range is from 0 to 1000000 seconds. The default is 300 seconds. Entering 0 disables MAC address aging.
	<b>vlan</b> <i>vlan-id</i>	(Optional) Specifies the VLAN to which the changed aging time should be applied.

**Command Default** 300 seconds

**Command Modes** Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
	4.2(1)N1(1)	The command syntax is changed to <b>mac address-table aging-time</b> .

**Usage Guidelines** Enter 0 seconds to disable the aging process.

The age value may be rounded off to the nearest multiple of 5 seconds. If the system rounds the value to a different value from that specified by the user (from the rounding process), the system returns an informational message.

When you use this command in EXEC mode, the age values of all VLANs for which a configuration has not been specified are modified and those VLANs with specifically modified aging times are not modified. When you use the **no** form of this command without the VLAN parameter, only those VLANs that have not been specifically configured for the aging time reset to the default value. Those VLANs with specifically modified aging times are not modified.

When you use this command and specify a VLAN, the aging time for only the specified VLAN is modified. When you use the **no** form of this command and specify a VLAN, the aging time for the VLAN is returned to the current global configuration for the aging time, which may or may not be the default value of 300 seconds depending if the global configuration of the switch for the aging time has been changed.

The aging time is counted from the last time that the switch detected the MAC address.

**Examples** This example shows how to change the length of time an entry remains in the MAC address table to 500 seconds for the entire switch:

```
switch(config)# mac address-table aging-time 500
```

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show mac address-table</b>	Displays information about the MAC address table.
	<b>show mac address-table aging-time</b>	Displays information about the MAC address aging time.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## mac address-table notification

To configure a log message notification of MAC address table events, use the **mac address-table notification** command. To disable log message notifications, use the **no** form of this command.

**mac address-table notification** { **mac-move** | **threshold** [**limit** *percentage* **interval** *seconds*] }

**no mac address-table notification** { **mac-move** | **threshold** }

### Syntax Description

<b>mac-move</b>	Sends a notification message if the MAC address is moved.
<b>threshold</b>	Sends a notification message if the MAC address table threshold is exceeded.
<b>limit</b> <i>percentage</i>	(Optional) Specifies the percentage limit (1 to 100) beyond which threshold notifications are enabled.
<b>interval</b> <i>seconds</i>	(Optional) Specifies the minimum time in seconds (10 to 10000) between two notifications.

### Command Default

None

### Command Modes

Global configuration mode

### Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.
4.2(1)N1(1)	The command syntax is changed to <b>mac address-table notification</b> .

### Examples

This example shows how to configure a log message notification when the threshold exceeds 45 percent, restricting the update interval to once every 1024 seconds:

```
switch(config)# mac address-table notification threshold limit 45 interval 1024
```

### Related Commands

Command	Description
<b>show mac address-table</b>	Displays information about the MAC address table.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## mac address-table static

To configure a static entry for the MAC address table, use the **mac address-table static** command. To delete the static entry, use the **no** form of this command.

```
mac address-table static mac-address vlan vlan-id { drop | interface { ethernet slot/port | port-channel number[.subinterface-number] } } [auto-learn]
```

```
no mac address-table static mac-address { vlan vlan-id }
```

### Syntax Description

<i>mac-address</i>	MAC address to add to the table. Use the format EEEE.EEEE.EEEE.
<b>vlan</b> <i>vlan-id</i>	Specifies the VLAN to apply the static MAC address. The VLAN ID range is from 1 to 4094.
<b>drop</b>	Drops all traffic that is received from and going to the configured MAC address in the specified VLAN.
<b>interface</b>	Specifies the interface. The type can be either Ethernet or EtherChannel.
<b>ethernet</b> <i>slot/port</i>	Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.
<b>port-channel</b> <i>number</i>	Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.
<i>.subinterface-number</i>	(Optional) EtherChannel number followed by a dot (.) indicator and the subinterface number.
<b>auto-learn</b>	(Optional) Allows the switch to automatically update this MAC address.

### Command Default

None

### Command Modes

Global configuration mode

### Command History

Release	Modification
4.0(0)N1(1a)	This command was introduced.
4.2(1)N1(1)	The command syntax is changed to <b>mac address-table static</b> .

### Usage Guidelines

You cannot apply the **mac address-table static** *mac-address* **vlan** *vlan-id* **drop** command to a multicast MAC address.

When you install a static MAC address, it is associated with a port. If the same MAC address is seen on a different port, the entry is updated with the new port if you enter the **auto-learn** keyword.

### Examples

This example shows how to add a static entry to the MAC address table:

```
switch(config)# mac address-table static 0050.3e8d.6400 vlan 3 interface ethernet 1/4
```

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

Related Commands	Command	Description
	<b>show mac address-table</b>	Displays information about the MAC address table.

*Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)*

## management

To configure a switch virtual interface (SVI) that should be used for in-band management, use the **management** command. To remove the in-band management access to a VLAN interface IP address, use the **no** form of this command.

**management**

**no management**

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** Interface configuration mode  
Switch profile configuration mode

Command History	Release	Modification
	5.1(3)N1(1)	This command was introduced.

**Usage Guidelines** You can use this command on a VLAN interface.

**Examples** This example shows how to configure a VLAN interface to allow in-band management access:

```
switch# configure terminal
switch(config)# interface vlan 5
switch(config-if)# management
switch(config-if)#
```

This example shows how to remove the in-band management access to a VLAN interface:

```
switch# configure terminal
switch(config)# interface vlan 5
switch(config-if)# no management
switch(config-if)#
```

Related Commands	Command	Description
	<b>show running-config interface</b>	Displays the running configuration information for an interface.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## monitor erspan origin ip-address

To configure the Encapsulated Remote Switched Port Analyzer (ERSPAN) origin IP address, use the **monitor erspan origin ip-address** command. To remove the ERSPAN origin IP address configuration, use the **no** form of this command.

**monitor erspan origin ip-address** *ip-address* [**global**]

**no monitor erspan origin ip-address** *ip-address* [**global**]

Syntax Description	<i>ip-address</i>	IP address.
	<b>global</b>	(Optional) Specifies the default virtual device context (VDC) configuration across all VDCs.

**Command Default** None

**Command Modes** Global configuration mode

Command History	Release	Modification
	5.1(3)N1(1)	This command was introduced.

**Usage Guidelines** When you change the origin IP address in the default VDC, it impacts all the sessions. This command does not require a license.

**Examples** This example shows how to configure the ERSPAN origin IP address:

```
switch# configure terminal
switch(config)# monitor erspan origin ip-address 10.1.1.1 global
switch(config)#
```

This example shows how to remove the ERSPAN IP address:

```
switch# configure terminal
switch(config)# no monitor erspan origin ip-address 10.1.1.1 global
switch(config)#
```

Related Commands	Command	Description
	<b>monitor session</b>	Configures a SPAN or an ERSPAN session.



[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## monitor session

To create a new Ethernet Switched Port Analyzer (SPAN) or an Encapsulated Remote Switched Port Analyzer (ERSPAN) session configuration for analyzing traffic between ports or add to an existing session configuration, use the **monitor session** command. To clear SPAN or ERSPAN sessions, use the **no** form of this command.

**monitor session** {*session-number* [**shut** | **type** {**local** | **erspan-source**} | **all shut**}

**no monitor session** {*session-number* | **all**} [**shut**]

Syntax Description		
	<i>session-number</i>	SPAN session to create or configure. The range is from 1 to 18.
	<b>all</b>	Specifies to apply configuration information to all SPAN sessions.
	<b>shut</b>	(Optional) Specifies that the selected session will be shut down for monitoring.
	<b>type</b>	(Optional) Specifies the type of session to configure.
	<b>local</b>	Specifies the session type to be local.
	<b>erspan-source</b>	Creates an ERSPAN source session.

**Command Default** None

**Command Modes** Global configuration mode

Command History	Release	Modification
	4.0(0)N1(1a)	This command was introduced.
	4.2(1)N1(1)	The <b>monitor session</b> { <i>session-number</i>   <b>all</b> } <b>suspend</b> command has been dropped.  The <b>monitor session</b> { <i>session-number</i>   <b>all</b> } <b>shut</b> and <b>monitor session</b> { <i>session-number</i>   <b>all</b> } <b>type</b> commands have been added.
	5.0(2)N2(1)	Limit on the number of egress (TX) sources in a monitor session has been lifted.
	5.1(3)N1(1)	Support for ERSPAN was added.

**Usage Guidelines** To ensure that you are working with a completely new session, you can clear the desired session number or all SPAN sessions.



### Note

The Cisco Nexus 5000 Series switch supports two active SPAN sessions. The Cisco Nexus 5548 Switch supports four active SPAN sessions. When you configure more than two SPAN sessions, the first two sessions are active. During startup, the order of active sessions is reversed; the last two sessions are

## Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

active. For example, if you configured ten sessions 1 to 10 where 1 and 2 are active, after a reboot, sessions 9 and 10 will be active. To enable deterministic behavior, explicitly suspend the sessions 3 to 10 with the **monitor session session-number shut** command.



### Note

Beginning with Cisco NX-OS Release 5.0(2)N2(1), the limit on the number of egress (TX) sources in a monitor session has been lifted. Port-channel interfaces can be configured as egress sources.

After you create an ERSPAN session, you can describe the session and add interfaces and VLANs as sources and destinations.

### Examples

This example shows how to create a SPAN session:

```
switch# configure terminal
switch(config)# monitor session 2
switch(config)#
```

This example shows how to enter the monitor configuration mode for configuring SPAN session number 9 for analyzing traffic between ports:

```
switch(config)# monitor session 9 type local
switch(config-monitor)# description A Local SPAN session
switch(config-monitor)# source interface ethernet 1/1
switch(config-monitor)# destination interface ethernet 1/2
switch(config-monitor)# no shutdown
```

This example shows how to configure any SPAN destination interfaces as Layer 2 SPAN monitor ports before activating the SPAN session:

```
switch(config)# interface ethernet 1/2
switch(config-if)# switchport
switch(config-if)# switchport monitor
switch(config-if)# no shutdown
```

This example shows how to configure a typical SPAN destination trunk interface:

```
switch(config)# interface Ethernet1/2
switch(config-if)# switchport
switch(config-if)# switchport mode trunk
switch(config-if)# switchport monitor
switch(config-if)# switchport trunk allowed vlan 10-12
switch(config-if)# no shutdown
```

This example shows how to create an ERSPAN session:

```
switch# configure terminal
switch(config)# monitor session 1 type erspan-source
switch(config-erspan-src)#
```

### Related Commands

Command	Description
<b>description (SPAN, ERSPAN)</b>	Adds a description to identify the SPAN session.
<b>destination (ERSPAN)</b>	Configures the destination IP port for an ERSPAN packet.
<b>erspan-id (ERSPAN)</b>	Sets the flow ID for an ERSPAN session.

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

<b>Command</b>	<b>Description</b>
<b>ip dscp (ERSPAN)</b>	Sets the DSCP value for an ERSPAN packet.
<b>ip prec (ERSPAN)</b>	Sets the IP precedence value for an ERSPAN packet.
<b>ip ttl (ERSPAN)</b>	Sets the time-to-live (TTL) value for an ERSPAN packet.
<b>mtu (ERSPAN)</b>	Sets the maximum transmission value (MTU) for ERSPAN packets.
<b>show monitor session</b>	Displays SPAN session configuration information.
<b>source (SPAN, ERSPAN)</b>	Adds a SPAN source port.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## mst (STP)

To configure the Multiple Spanning Tree (MST) designated bridge and root bridge priority, use the **mst** command. To revert to the default settings, use the **no** form of this command.

```
mst instance-id [{designated | root} priority priority-value]
```

```
no mst instance-id [{designated | root} priority priority-value]
```

### Syntax Description

<i>instance-id</i>	MST instance. The range is from 0 to 4094.
<b>designated</b>	(Optional) Sets the designated bridge priority for the spanning tree.
<b>root</b>	(Optional) Sets the root bridge priority for the spanning tree.
<b>priority</b> <i>priority-value</i>	(Optional) Specifies the STP-bridge priority; the valid values are 0, 4096 , 8192 , 12288, 16384, 20480, 24576, 28672, 32768, 36864, 40960, 45056, 49152, 53248, 57344, 61440. All other values are rejected.

### Command Default

None

### Command Modes

Spanning-tree pseudo configuration mode

### Command History

Release	Modification
5.1(3)N1(1)	This command was introduced.

### Usage Guidelines

You can enter the *instance-id* argument as a single instance or a range of instances, for example, 0-3,5,7-9.

This command does not require a license.

### Examples

This example shows how to configure a spanning-tree domain:

```
switch# configure terminal
switch(config)# spanning-tree pseudo-information
switch(config-pseudo)# mst 2 designated priority 8192
switch(config-pseudo)# mst 2 root priority 4096
switch(config-pseudo)#
```

### Related Commands

Command	Description
<b>show running-config spanning-tree</b>	Displays the running configuration information of the Spanning Tree Protocol (STP).

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

<b>Command</b>	<b>Description</b>
<b>show spanning-tree</b>	Displays the configuration information of the STP.
<b>spanning-tree pseudo-information</b>	Configures spanning tree pseudo information parameters.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## mvr group

To configure a Multicast VLAN Registration (MVR) group for an interface, use the **mvr group** command. To remove the MVR group from an interface, use the **no** form of this command.

```
mvr group {group_IP_address | IP_prefix/length} [count count_value] [vlan vlan_ID [...vlan
vlan_ID]]
```

```
no mvr group {group_IP_address | IP_prefix/length} [count count_value] [vlan vlan_ID [...vlan
vlan_ID]]
```

### Syntax Description

<i>group_IP_address</i>	Group IP address in the format <i>A.B.C.D</i> .
<i>IP_prefix/length</i>	IP prefix and network mask length in the format <i>x.x.x.x/m</i> .
<b>count</b> <i>count_value</i>	Specifies the count value. The range is from 1 to 64.
<b>vlan</b> <i>vlan_ID</i>	Specifies the global default MVR VLAN. The range is from 1 to 4094.

### Command Default

None

### Command Modes

Interface configuration mode  
Virtual Ethernet interface configuration mode

### Command History

Release	Modification
5.1(3)N1(1)	This command was introduced.

### Usage Guidelines

You can use this command on the following interfaces:

- Ethernet interface
- Virtual Ethernet interface

Before you use a virtual Ethernet interface, you must enable the Cisco Virtual Machine Fabric Extender (VM-FEX) on the switch by using the **feature vmfex** command.

This command does not require a license.

### Examples

This example shows how to configure an MVR VLAN group for an interface:

```
switch# configure terminal
switch(config)# interface ethernet 1/5
switch(config-if)# mvr group 192.0.2.1/12 vlan 1
switch(config-if)#
```

***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>feature vmfex</b>	Enables VM-FEX on the switch.
	<b>interface vethernet</b>	Configures a virtual Ethernet interface on the switch.
	<b>show mvr</b>	Displays information about MVRs.
	<b>show running-config</b>	Displays the running system configuration information.

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## mvr type

To configure a Multicast VLAN Registration (MVR) port type for an interface, use the **mvr type** command. To remove the MVR port type for an interface, use the **no** form of this command.

```
mvr type {source | receiver}
```

```
no mvr type {source | receiver}
```

### Syntax Description

<b>source</b>	Specifies the MVR source port.
<b>receiver</b>	Specifies the MVR receiver port.

### Command Default

None

### Command Modes

Interface configuration mode  
Virtual Ethernet interface configuration mode

### Command History

Release	Modification
5.1(3)N1(1)	This command was introduced.

### Usage Guidelines

You can use this command on the following interfaces:

- Ethernet interface
- Virtual Ethernet interface

Before you use a virtual Ethernet interface, you must enable the Cisco Virtual Machine Fabric Extender (VM-FEX) on the switch by using the **feature vmfex** command.

This command does not require a license.

### Examples

This example shows how to configure an MVR source port for an interface:

```
switch# configure terminal
switch(config)# interface ethernet 1/5
switch(config-if)# mvr type source
switch(config-if)#
```

### Related Commands

Command	Description
<b>feature vmfex</b>	Enables VM-FEX on the switch.
<b>interface vethernet</b>	Configures a virtual Ethernet interface on the switch.
<b>show mvr</b>	Displays information about MVRs.
<b>show running-config</b>	Displays the running system configuration information.



***Send comments to [nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)***

[Send comments to nexus5k-docfeedback@cisco.com](mailto:nexus5k-docfeedback@cisco.com)

## mvr vlan

To configure a Multicast VLAN Registration (MVR) VLAN for an interface, use the **mvr vlan** command. To remove the MVR VLAN from an interface, use the **no** form of this command.

```
mvr vlan vlan_ID
```

```
no mvr vlan vlan_ID
```

<b>Syntax Description</b>	<i>vlan_ID</i>	MVR VLAN ID. The range is from 1 to 4094.
---------------------------	----------------	---

<b>Command Default</b>	None	
------------------------	------	--

<b>Command Modes</b>	Interface configuration mode Virtual Ethernet interface configuration mode	
----------------------	---	--

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	5.1(3)N1(1)	This command was introduced.

**Usage Guidelines**

You can use this command on the following interfaces:

- Ethernet interface
- Virtual Ethernet interface

Before you use a virtual Ethernet interface, you must enable the Cisco Virtual Machine Fabric Extender (VM-FEX) on the switch by using the **feature vmfex** command.

This command does not require a license.

**Examples**

This example shows how to configure an MVR VLAN for an interface:

```
switch# configure terminal
switch(config)# interface ethernet 1/5
switch(config-if)# mvr vlan 1
switch(config-if)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>feature vmfex</b>	Enables VM-FEX on the switch.
	<b>interface vethernet</b>	Configures a virtual Ethernet interface on the switch.
	<b>show mvr</b>	Displays information about MVRs.
	<b>show running-config</b>	Displays the running system configuration information.