



# Micro-Burst Monitoring Overview

---

The micro-burst monitoring feature allows you to monitor traffic on a per-port basis for both ingress and egress ports and to detect unexpected data bursts within a very small time window (micro-seconds). This allows you to detect flows in the network that are at risk of data loss, and that may require extra bandwidth.

A micro-burst occurs when a specific amount of data (in bytes) is exceeded in a given time interval. The micro-burst monitoring feature allows you to specify these limits as absolute values (for data and burst size) or as a percentage of the link speed. When these thresholds are exceeded the system generates a Syslog alarm message.

- [Micro-Burst Monitoring, on page 1](#)

## Micro-Burst Monitoring

### Information About Micro-Burst Monitoring

#### How to Use Micro-Burst Monitoring

The micro-burst monitoring feature monitors bursts in real time. The monitoring process also provides an overview of data path issues, and is helpful in identifying potential capacity issues in a network. Syslog messages are generated with the burst exceeds the configured value.

Micro-burst monitoring provides real-time burst information that is used to:

- monitor network micro bursts
- trigger to congestion detection and latency processes

#### Guidelines and Limitations for Micro-Burst Monitoring

- Micro-burst detection is performed on a per-link basis and port channels are not be taken into consideration.
- Micro-burst detection is supported on Ethernet ports only, and is not supported on Fabric Extender Technology (FEX), Port Channels, Virtual Ethernet (VETH), or Virtual Fibre Channel (VFC) ports.

# How to Configure Micro-Burst Monitoring

## Configuring Micro-Burst Monitoring

To configure micro-burst monitoring, you first set micro-burst threshold values for an interface and then configure the maximum number of micro-bursts allowed on the interface. You configure ingress and egress port settings separately.

### Procedure

|               | Command or Action   | Purpose  |
|---------------|---|--|
| <b>Step 1</b> | <b>configure terminal</b><br><b>Example:</b><br><pre>switch# configure terminal switch(config)#</pre>   | Enters global configuration mode.  |
| <b>Step 2</b> | <b>interface ethernet <i>slot/port</i></b><br><b>Example:</b><br><pre>switch(config)# interface ethernet 1/1</pre>  | Enters interface configuration mode.   |
| <b>Step 3</b> | <b>burst threshold ingress limit <i>percent interval interval_time</i></b><br><b>Example:</b><br><pre>switch(config-if)# burst threshold ingress limit 60 interval 10000000</pre> | Configures micro-burst threshold values for ingress traffic on the interface.  |
| <b>Step 4</b> | <b>burst threshold egress size <i>max_bytes interval interval_time</i></b><br><b>Example:</b><br><pre>switch(config-if)# burst threshold egress size 500000 interval 16000</pre>  | Configures micro-burst threshold values for egress traffic on the interface.   |
| <b>Step 5</b> | <b>burst maximum egress burst-count <i>max_bytes</i></b><br><b>Example:</b><br><pre>switch(config-if)# burst maximum egress burst-count 50000</pre>                               | Configures the maximum number of micro-bursts allowed within a time interval before generating an interrupt on a port in the egress direction. This time interval is equal to 10 multiplied by the micro-burst threshold interval (in seconds).  |
| <b>Step 6</b> | <b>burst maximum ingress burst-count <i>max_bytes</i></b><br><b>Example:</b><br><pre>switch(config-if)# burst maximum ingress burst-count 600000</pre>                            | Configures the maximum number of micro-bursts allowed within a time interval before generating an interrupt on a port in the ingress direction. This time interval is equal to 10 multiplied by the micro-burst threshold interval (in seconds). |
| <b>Step 7</b> | <b>exit</b><br><b>Example:</b><br><pre>switch(config-if)# exit</pre>  | Updates the configuration and exits interface configuration mode.  |

|               | Command or Action   | Purpose  |
|---------------|---|--|
| <b>Step 8</b> | <b>clear burst-counters [interface {all   ethernet interface}] {both   egress   ingress }</b><br><br><b>Example:</b><br><pre>switch# clear burst-counters interface all</pre> | Clears the micro-burst counters on all interfaces or only on ethernet interfaces. Additionally, the command is applicable to clear counters for both egress and ingress or either egress or ingress traffic. |
| <b>Step 9</b> | <b>(Optional) copy running-config startup-config</b><br><br><b>Example:</b><br><pre>switch(config)# copy running-config startup-config</pre>                                  | Saves the change persistently through reboots and restarts by copying the running configuration to the startup configuration.  |

## Verifying Micro-Burst Monitoring

To display micro-burst monitoring information, enter the following show command:

| Command                              | Purpose  |
|--------------------------------------|--|
| <b>show interface burst-counters</b> | Displays micro-burst counters information for all interfaces where micro-burst monitoring is configured. |

## Example for Micro-Burst Monitoring

### Configuration Example for Micro-Burst Monitoring

The following example shows how to configure micro-burst monitoring on an Ethernet interface:

```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# burst threshold egress limit 50 interval 30
switch(config-if)# burst threshold ingress size 500000 interval 16000
switch(config-if)# burst maximum egress burst-count 50000
switch(config-if)# burst maximum ingress burst-count 600000
switch(config-if)# exit
switch(config)# copy running-config startup-config
```

