



## F Commands

---

- [fast-external-falover](#), on page 3
- [fast-flood enable](#), on page 4
- [fast-flood interval](#), on page 5
- [feature-set](#), on page 6
- [feature](#), on page 7
- [feature bash-shell](#), on page 8
- [feature bfd](#), on page 9
- [feature bgp](#), on page 10
- [feature cts](#), on page 11
- [feature dhcp](#), on page 12
- [feature eigrp](#), on page 13
- [feature evmed](#), on page 14
- [feature glbp](#), on page 15
- [feature hsrp](#), on page 16
- [feature interface-vlan](#), on page 17
- [feature isis](#), on page 18
- [feature lacp](#), on page 19
- [feature ldap](#), on page 20
- [feature lldp](#), on page 21
- [feature msdp](#), on page 22
- [feature ntp](#), on page 23
- [feature nv overlay](#), on page 24
- [feature nxapi](#), on page 25
- [feature ospf](#), on page 26
- [feature ospfv3](#), on page 27
- [feature password encryption aes](#), on page 28
- [feature pim](#), on page 29
- [feature poap](#), on page 30
- [feature pong](#), on page 31
- [feature private-vlan](#), on page 32
- [feature privilege](#), on page 33
- [feature rip](#), on page 34
- [feature scheduler](#), on page 35

- feature scp-server, on page 36
- feature sftp-server, on page 37
- feature ssh, on page 38
- feature tacacs+, on page 39
- feature telnet, on page 40
- feature udd, on page 41
- feature vn-segment-vlan-based, on page 42
- feature vpc, on page 43
- feature vrrp, on page 44
- feature vtp, on page 45
- fex, on page 46
- fex associate, on page 47
- fex management-instance fabric, on page 48
- fex pinning redistribute, on page 49
- fileys delete, on page 50
- filter, on page 51
- filter access-group, on page 52
- filter vlan, on page 53
- filter vlan include-untagged, on page 54
- find, on page 55
- fips mode enable, on page 56
- flowcontrol, on page 57
- flowcontrol hardware, on page 58
- flush-routes (bgp), on page 59
- flush-routes (eigrp), on page 60
- flush-routes (isis), on page 61
- flush-routes (ospf), on page 62
- flush-routes (ospfv3), on page 63
- flush-routes (rip), on page 64
- forceshut reset-reason, on page 65
- format bootflash, on page 66
- format bootflash check-filesystem, on page 67
- format logflash, on page 68
- format logflash check-filesystem, on page 69
- format usb1, on page 70
- format usb2, on page 71
- forwarder preempt, on page 72
- forwarding interface statistics mode, on page 73
- forwarding layer-2 fl exclude supervisor, on page 74
- fragments, on page 75
- from, on page 76

# fast-external-fallover

[no] fast-external-fallover

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>fast-external-fallover</b> Immediately reset the session if the link to a directly connected BGP peer goes down
<b>Command Modes</b>	• /exec/configure/router-bgp

# fast-flood enable

[no] fast-flood enable

Syntax Description	
<b>no</b>	Negate a command or set its defaults
<b>fast-flood</b>	Fast flood the LSP's
<b>enable</b>	Turn on fast-flooding
<i>level</i>	IS-IS level
<b>level-1 value: 1</b>	Configure Fast flood level-1 interval
<b>level-2 value: 2</b>	Configure Fast flood level-2 interval
Command Modes	<ul style="list-style-type: none"> <li>• /exec/configure/router-isis/router-isis-vrf-common</li> </ul>

# fast-flood interval

[no] fast-flood interval *interval*

---

## Syntax Description

<b>no</b>	Negate a command or set its defaults
<b>fast-flood</b>	Fast flood the LSP's
<b>interval</b>	Duration/interval of the fast-flood timer.
<i>level</i>	IS-IS level
	<b>level-1 value: 1</b> Configure SPF level-1 interval
	<b>level-2 value: 2</b> Configure SPF level-2 interval
<i>interval</i>	Type: uinteger min: 1 max: 3000 default: 1 Specify the value (ms)

---

## Command Modes

- /exec/configure/router-isis/router-isis-vrf-common

# feature-set

**feature-set** *fs*

---

**Syntax Description**

---

**feature-set** Enable  
feature-set

---

*fs* Type: userdef  
allow feature-set

---

---

**Command Modes**

• /exec/configure

# feature

[no] **feature** *arg1*

---

**Syntax Description**

---

**no** Negate a command or set its defaults

---

**feature** Feature name

---

*arg1* Type: string

length: 32

Enter feature name

---

---

**Command Modes**

- /exec/configure/rolefeaturegrp

# feature bash-shell

[no] feature "bash-shell"

<b>Syntax Description</b>	<b>no</b>	Negate a command or set its defaults
	<b>feature</b>	Command to enable/disable features
	<b>bash-shell</b>	Enable/Disable bash-shell
<b>Command Modes</b>		• /exec/configure



# feature bfd

[no] feature bfd

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>bfd</b> bfd
<b>Command Modes</b>	• /exec/configure

# feature bgp

[no] feature bgp

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>bgp</b> Enable/Disable Border Gateway Protocol (BGP)
<b>Command Modes</b>	• /exec/configure

# feature cts

[no] feature cts

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>cts</b> Enable/Disable CTS <i>Not available in this release.</i>
<b>Command Modes</b>	• /exec/configure

# feature dhcp

[no] feature dhcp

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>dhcp</b> Enable/Disable DHCP Manager
<b>Command Modes</b>	• /exec/configure

# feature eigrp

[no] feature eigrp

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>eigrp</b> Enable/Disable Enhanced Interior Gateway Routing Protocol (EIGRP)
<b>Command Modes</b>	• /exec/configure

# feature evmed

[no] feature evmed

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>evmed</b> Enable/Disable Generic event detectors
<b>Command Modes</b>	• /exec/configure

# feature glbp

[no] feature glbp

---

**Syntax Description**

**no** Negate a command or set its defaults

---

**feature** Command to enable/disable features

---

**glbp** Enable/Disable Gateway Load Balancing Protocol (GLBP) *Not available in this release.*

---

---

**Command Modes**

• /exec/configure

# feature hsrp

[no] feature hsrp

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>hsrp</b> Enable/Disable Hot Standby Router Protocol (HSRP)
<b>Command Modes</b>	• /exec/configure



# feature interface-vlan

[no] feature interface-vlan

<b>Syntax Description</b>	<b>no</b>	Negate a command or set its defaults
	<b>feature</b>	Command to enable/disable features
	<b>interface-vlan</b>	Enable/Disable interface vlan

**Command Modes**      • /exec/configure

# feature isis

[no] feature isis

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>isis</b> Enable/Disable IS-IS Unicast Routing Protocol (IS-IS)
<b>Command Modes</b>	• /exec/configure

# feature lacp

[no] feature lacp

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>lacp</b> Enable/Disable LACP
<b>Command Modes</b>	• /exec/configure

# feature ldap

[no] feature "ldap"

---

**Syntax Description**

---

**no** Negate a command or set its defaults

---

**feature** Command to enable/disable features

---

**ldap** Enable/Disable ldap

---

---

**Command Modes**

• /exec/configure

# feature lldp

[no] feature lldp

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>lldp</b> Enable/Disable LLDP
<b>Command Modes</b>	• /exec/configure

# feature msdp

[no] feature msdp

---

**Syntax Description**

---

**no** Negate a command or set its defaults

---

**feature** Command to enable/disable features

---

**msdp** Enable/Disable Multicast Source Discovery Protocol (MSDP)

---

---

**Command Modes**

• /exec/configure

# feature ntp

[no] feature ntp

<b>Syntax Description</b>	<b>no</b> Negate a command or set its default
	<b>feature</b> Command to enable/disable features
	<b>ntp</b> Enable/Disable NTP
<b>Command Modes</b>	• /exec/configure

# feature nv overlay

[no] feature nv overlay

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>nv</b> Enable/Disable VxLAN <i>Available only in the 9300 series.</i>
	<b>overlay</b> Enable/Disable VxLAN <i>Available only in the 9300 series.</i>
<b>Command Modes</b>	• /exec/configure



# feature nxapi

[no] feature "nxapi"

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>nxapi</b> Enable/Disable nxapi
<b>Command Modes</b>	• /exec/configure

# feature ospf

[no] feature ospf

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>ospf</b> Enable/Disable Open Shortest Path First Protocol (OSPF)
<b>Command Modes</b>	• /exec/configure

# feature ospfv3

[no] feature ospfv3

---

**Syntax Description**

**no** Negate a command or set its defaults

---

**feature** Command to enable/disable features

---

**ospfv3** Enable/Disable Open Shortest Path First Version 3 Protocol (OSPFv3)

---

---

**Command Modes**

• /exec/configure

# feature password encryption aes

[no] feature password encryption aes

<b>Syntax Description</b>	<b>no</b>	Negate a command or set its defaults
	<b>feature</b>	Enable the feature
	<b>password</b>	Credential(s) for the user(s)/device(s)
	<b>encryption</b>	Strong encryption for credential(s)
	<b>aes</b>	Encrypt using AES encryption standard
<b>Command Modes</b>		• /exec/configure

# feature pim

[no] feature pim

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>pim</b> Enable/Disable Protocol Independent Multicast (PIM)
<b>Command Modes</b>	• /exec/configure

# feature poap

[no] feature poap

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>poap</b> Enable/Disable POAP
<b>Command Modes</b>	• /exec/configure

# feature pong

[no] feature pong

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>pong</b> Enable/Disable Pong <i>Not available in this release.</i>
<b>Command Modes</b>	• /exec/configure

# feature private-vlan

[no] feature private-vlan

Syntax Description	
<b>no</b>	Negate a command or set its defaults
<b>feature</b>	Command to enable/disable features
<b>private-vlan</b>	Enable/Disable private-vlan <i>Not available in this release.</i>

  

Command Modes	
	• /exec/configure



# feature privilege

[no] feature privilege

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>privilege</b> Enable/Disable IOS type privilege level support
<b>Command Modes</b>	• /exec/configure

# feature rip

[no] feature rip

---

**Syntax Description**

---

**no** Negate a command or set its defaults

---

**feature** Command to enable/disable features

---

**rip** Enable/Disable Routing Information Protocol (RIP)

---

---

**Command Modes**

• /exec/configure

# feature scheduler

[no] feature scheduler

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>scheduler</b> Enable/Disable scheduler
<b>Command Modes</b>	• /exec/configure

# feature scp-server

[no] feature "scp-server"

<b>Syntax Description</b>	<b>no</b>	Negate a command or set its defaults
	<b>feature</b>	Command to enable/disable features
	<b>scp-server</b>	Enable/Disable SCP server
<b>Command Modes</b>		• /exec/configure

# feature sftp-server

[no] feature "sftp-server"

<b>Syntax Description</b>	<b>no</b>	Negate a command or set its defaults
	<b>feature</b>	Command to enable/disable features
	<b>sftp-server</b>	Enable/Disable SFTP server

**Command Modes**      • /exec/configure

# feature ssh

[no] feature "ssh"

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>ssh</b> Enable/Disable ssh
<b>Command Modes</b>	• /exec/configure

# feature tacacs+

[no] feature "tacacs+"

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>tacacs+</b> Enable/Disable tacacs+
<b>Command Modes</b>	• /exec/configure

# feature telnet

[no] feature "telnet"

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>telnet</b> Enable/Disable telnet
<b>Command Modes</b>	• /exec/configure



# feature udd

[no] feature udd

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>udd</b> Enable/Disable UDLD
<b>Command Modes</b>	• /exec/configure

# feature vn-segment-vlan-based

[no] feature vn-segment-vlan-based

Syntax Description		
	<b>no</b>	Negate a command or set its defaults
	<b>feature</b>	Command to enable/disable features
	<b>vn-segment-vlan-based</b>	Enable/Disable VLAN based VN segment <i>Available only in the 9300 series.</i>
Command Modes		<ul style="list-style-type: none"><li>• /exec/configure</li></ul>

# feature vpc

[no] feature vpc

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>vpc</b> Enable/Disable VPC (Virtual Port Channel)
<b>Command Modes</b>	• /exec/configure

# feature vrrp

[no] feature vrrp

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>vrrp</b> Enable/Disable Virtual Router Redundancy Protocol (VRRP)
<b>Command Modes</b>	• /exec/configure

# feature vtp

[no] feature vtp

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>feature</b> Command to enable/disable features
	<b>vtp</b> Enable/Disable VTP
<b>Command Modes</b>	• /exec/configure

# fex

[no] fex *chas\_no*

---

**Syntax Description**

---

**no** Negate the command

---

**fex** FEX configuration

---

*chas\_no* Type: integer  
min: 101 max: 199  
FEX number

---

---

**Command Modes**

• /exec/configure

# fex associate

**fex associate** *chassis\_no* [**chassis-serial** *serial\_no* [**module-serial** *mod\_serial*] [**module-slot** {**left**|**right**}]]|**no fex associate** [*chassis\_no*]

Syntax Description		
<b>no</b>		Negate a command or set its defaults
<b>fex</b>		Configure FEX fabric
<b>associate</b>		Associate the port to a FEX
<i>chassis_no</i>	Type: uinteger	min: 101 max: 199 FEX number
<b>chassis-serial</b>		Chassis serial number
<i>serial_no</i>	Type: string	length: 20 Serial number
<b>module-serial</b>		Module serial number
<i>mod_serial</i>	Type: string	length: 20 Module serial number
<b>module-slot</b>		Module Slot
<b>left</b>		Left IO module slot
<b>right</b>		Right IO module slot

## Command Modes

- /exec/configure/if-eth-base
- /exec/configure/if-eth-l2-non-member
- /exec/configure/if-ethernet-all
- /exec/configure/if-port-channel

## fex management-instance fabric

**fex management-instance** *inst fabric fabric\_no|no* **fex management-instance**

Syntax	Description
<b>no</b>	Negate a command or set its defaults
<b>fex</b>	FEX configuration
<b>management-instance</b>	Management instance configuration
<i>inst</i>	Type: string length: 40 Management Instance
<b>fabric</b>	Left fabric or Right fabric
<i>fabric_no</i>	Type: uinteger min: 1 max: 2 Fabric number

**Command Modes** • /exec/configure



# fex pinning redistribute

**fex pinning redistribute** *rchas\_id*

<b>Syntax Description</b>	<b>fex</b>	FEX control commands
	<b>pinning</b>	Pinning redistribution
	<b>redistribute</b>	Redistribute FEX ports to fabric ports
	<i>rchas_id</i>	Type: uinteger min: 101 max: 199 FEX number
<b>Command Modes</b>		• /exec

# filesys delete

**filesys delete** *s0*

---

**Syntax Description**

---

**filesys** file system command

---

**delete** delete a file on file system

---

*s0* Type: string  
file name

---

---

**Command Modes**

• /exec

# filter

**[no] filter** [{**subject-name** *s0*|**altname-email** *s1*|**altname-upn** *s2*}]

## Syntax Description

<b>no</b>	Negate a command or set its defaults
<b>filter</b>	Configure mapping filter
<b>subject-name</b>	Subject name of the certificate
<i>s0</i>	Type: string length: 64 Subject name
<b>altname-email</b>	Email id as an alternate name
<i>s1</i>	Type: string length: 64 Email id
<b>altname-upn</b>	User principal name as an alternate name
<i>s2</i>	Type: string length: 64 User principal name

## Command Modes

- /exec/configure/certmap-filter

# filter access-group

[no] **filter access-group** *acl-name*

Syntax	Description
<b>no</b>	Negate a command or set its defaults
<b>filter</b>	Filter configuration
<b>access-group</b>	access control group
<i>acl-name</i>	Type: string access control list name

Command Modes	
	<ul style="list-style-type: none"> <li>• /exec/configure/monitor-local-src</li> <li>• /exec/configure/config-monitor</li> <li>• /exec/configure/config-monitor-erspan-src</li> </ul>

# filter vlan

[no] filter vlan *vlan\_mrange* [include-untagged]

## Syntax Description

<b>no</b>	Negate a command or set its defaults
<b>filter</b>	Filter configuration
<b>vlan</b>	Vlan type
<i>vlan_mrange</i>	Type: vlan-mrange
<b>include-untagged</b>	Include untagged frames on port with Layer 3 subinterfaces <i>Not available in this release.</i>

## Command Modes

- /exec/configure/monitor-local-src
- /exec/configure/config-monitor
- /exec/configure/config-monitor-erspan-src

# filter vlan include-untagged

[no] filter vlan include-untagged

## Syntax Description

<b>no</b>	Negate a command or set its defaults
<b>filter</b>	Filter configuration
<b>vlan</b>	Vlan type
<b>include-untagged</b>	Include untagged frames on port with Layer 3 subinterfaces <i>Not available in this release.</i>

## Command Modes

- /exec/configure/config-monitor

# find

**find** *s0*

---

**Syntax Description**

**find** Find a file below the current directory

---

*s0* Type: string

length: 64

Enter the filename prefix to search

---

---

**Command Modes**

• /exec

# fips mode enable

[no] fips mode enable

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>fips</b> Enable/Disable FIPS mode <i>Not available in this release.</i>
	<b>mode</b> FIPS mode
	<b>enable</b> Enable/Disable FIPS mode
<b>Command Modes</b>	• /exec/configure



# flowcontrol

**flowcontrol** {**receive** *rx\_flowctrl*|**send** *tx\_flowctrl*}|**no flowcontrol** {**receive** [*rx\_flowctrl*]|**send** [*tx\_flowctrl*]}

## Syntax Description

<b>no</b>	Negate a command or set its defaults
<b>flowcontrol</b>	Configure interface flowcontrol <i>Not available in this release.</i>
<b>receive</b>	Receive pause frames
<i>rx_flowctrl</i>	Receive flow control
	<b>on value: 0x2</b> Receive ON
	<b>off value: 0x0</b> Receive OFF
	<b>desired value: 0x8</b> Receive desired
<b>send</b>	Send pause frames
<i>tx_flowctrl</i>	Send flow control
	<b>on value: 0x1</b> Send ON
	<b>off value: 0x0</b> Send OFF
	<b>desired value: 0x4</b> Send desired

## Command Modes

- /exec/configure/if-ethernet-all
- /exec/configure/if-eth-non-member
- /exec/configure/if-port-channel

# flowcontrol hardware

[no] flowcontrol hardware

---

<b>Syntax Description</b>	<b>no</b>	Negate a command or set its defaults
---------------------------	-----------	--------------------------------------

---

	<b>flowcontrol</b>	Set flow control
--	--------------------	------------------

---

	<b>hardware</b>	Set hardware flowcontrol
--	-----------------	--------------------------

---

<b>Command Modes</b>	• /exec/configure/com1
----------------------	------------------------

# flush-routes (bgp)

[no] flush-routes

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>flush-routes</b> Flush routes in RIB upon controlled restart
<b>Command Modes</b>	• /exec/configure/router-bgp

# flush-routes (eigrp)

[no] flush-routes

<b>Syntax Description</b>	<b>no</b>	Negate a command or set its defaults
	<b>flush-routes</b>	Flush routes in RIB during restart
<b>Command Modes</b>	• /exec/configure/router-eigrp	

# flush-routes (isis)

[no] flush-routes

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>flush-routes</b> Flush routes on non-graceful controlled restart
<b>Command Modes</b>	• /exec/configure/router-isis

# flush-routes (ospf)

[no] flush-routes

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>flush-routes</b> Flush routes on a non-graceful controlled restart
<b>Command Modes</b>	• /exec/configure/router-ospf

## flush-routes (ospfv3)

[no] flush-routes

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>flush-routes</b> Flush routes on a non-graceful controlled restart
<b>Command Modes</b>	• /exec/configure/router-ospf3

# flush-routes (rip)

[no] flush-routes

<b>Syntax Description</b>	<b>no</b>	Negate a command or set its defaults
	<b>flush-routes</b>	Flush routes in RIB during restart
<b>Command Modes</b>	• /exec/configure/router-rip	



## forceshut reset-reason

**forceshut** [{**module** *module*|*s0* *santa-cruz-range*|**zone** *zonenum* *subzone*}] **reset-reason**  
*reset\_reason\_string*

Syntax Description		
<b>forceshut</b>		Force the entire switch to shut down
<b>module</b>		Optional. Module to be forceshut(optional arg)
<i>module</i>		Type: integer please enter the module number
<i>s0</i>		Type: xbar-str Power off a specific xbar
<i>santa-cruz-range</i>		Type: integer please enter the xbar number
<b>zone</b>		Optional. Zone to be forceshut(optional arg)
<i>zonenum</i>		Type: integer min: 1 max: 2 please enter the zone number
<i>subzone</i>		Type: integer min: 1 max: 7 please enter the subzone number
<b>reset-reason</b>		Shut down (with reset-reason)
<i>reset_reason_string</i>		Type: string please enter reset_reason_string in quotes

**Command Modes**      • /exec

# format bootflash

**format bootflash :**

---

**Syntax Description**

---

**format**    Format disks

---

**bootflash:**    Format  
bootflash:

---

---

**Command Modes**

• /exec

# format bootflash check-filesystem

**format bootflash : check-filesystem**

<b>Syntax Description</b>	<b>format</b>	Format disks
	<b>bootflash:</b>	Format bootflash:
	<b>check-filesystem</b>	Format bootflash: and fix any errors in file system
<b>Command Modes</b>		• /exec

# format logflash

**format logflash :**

---

**Syntax Description**

---

**format** Format disks

---

**logflash:** Format  
logflash:

---

---

**Command Modes**

• /exec

# format logflash check-filesystem

**format logflash : check-filesystem**

Syntax Description		
	<b>format</b>	Format disks
	<b>logflash:</b>	Format logflash:
	<b>check-filesystem</b>	Format logflash: and fix any errors in file system
Command Modes		<ul style="list-style-type: none"><li>• /exec</li></ul>

# format usb1

**format usb1:**

---

**Syntax Description**

---

**format** Format disks

---

**usb1:** Format usb1:

---

---

**Command Modes**

• /exec

# format usb2

**format usb2:**

---

**Syntax Description**

---

**format** Format disks

---

**usb2:** Format usb2:

---

---

**Command Modes**

• /exec

# forwarder preempt

[no] forwarder preempt [delay minimum *min-delay*]

Syntax Description	
<b>no</b>	Negate a command or set its defaults
<b>forwarder</b>	Forwarder Configuration
<b>preempt</b>	Overthrow lower priority designated routers
<b>delay</b>	Wait before preempting
<b>minimum</b>	Delay at least this long
<i>min-delay</i>	Type: integer min: 0 max: 3600 Number of seconds for minimum delay
<b>Command Modes</b>	<ul style="list-style-type: none"> <li>• /exec/configure/if-eth-any/glbp</li> </ul>



## forwarding interface statistics mode

[no] {platform|hardware} forwarding interface statistics mode {mpls|default} [module *module-num*]

Syntax Description	
<b>no</b>	Negate a command or set its defaults
<b>platform</b>	Platform configuration commands
<b>hardware</b>	Hardware Internal Information
<b>forwarding</b>	Hardware forwarding
<b>interface</b>	Interface <i>Not available in this release.</i>
<b>statistics</b>	Statistics
<b>mode</b>	Statistics mode
<b>mpls</b>	Mpls mode
<b>default</b>	Default mode
<b>module</b>	Specify a module number
<i>module-num</i>	Type: integer Specify a module number
<b>Command Modes</b>	• /exec/configure

## forwarding layer-2 f1 exclude supervisor

[no] {platform|hardware} forwarding layer-2 f1 exclude supervisor

### Syntax Description

<b>no</b>	Negate a command or set its defaults
<b>platform</b>	Platform configuration commands
<b>hardware</b>	Hardware Internal Information
<b>forwarding</b>	Forwarding information
<b>layer-2</b>	L2 only mode <i>Not available in this release.</i>
<b>f1</b>	N7K-F132XP-15 module <i>Not available in this release.</i>
<b>exclude</b>	Exclude supervisor from getting copies of ARP and multicast packets
<b>supervisor</b>	Supervisor module

### Command Modes

- /exec/configure

# fragments

[no] fragments *opt\_type*

<b>Syntax Description</b>	<b>no</b> Negate a command or set its defaults
	<b>fragments</b> Optimize fragments rule installation
	<i>opt_type</i> frag_op_type
	<b>deny-all value: 3</b> Drop all fragments
	<b>permit-all value: 2</b> Allow all fragments
<b>Command Modes</b>	<ul style="list-style-type: none"><li>• /exec/configure/ipacl</li><li>• /exec/configure/ipv6acl</li></ul>

# from

**[no]** {**from** *frm-list* **to** *to-val*|**default** {*value*|**copy**|**ignore**}}

## Syntax Description

**no** Negate a command or set its defaults

**from** Map values from this

*frm-list* Type: integer-mrange

Original list of values which are to be mapped

**to** Map values to this

*to-val* Type: uinteger

min: 0 max: 63

New mapped value

**default** map default values

*value* Type: uinteger

min: 0 max: 63

default value to be set

**copy** Do a default copy

**ignore** Ignore any unspecified values

## Command Modes

- /exec/configure/table-map