



## APPENDIX

## C

# Unsupported Commands in Cisco IOS Release 12.2(25)SECFX

This appendix lists some of the command-line interface (CLI) commands that appear when you enter the question mark (?) at the Catalyst 3560 switch prompt but are not supported in this release, either because they are not tested or because of Catalyst 3560 hardware limitations. This is not a complete list. The unsupported commands are listed by software feature and command mode.

## Access Control Lists

### Unsupported Privileged EXEC Commands

```
access-enable [host] [timeout minutes]  
access-template [access-list-number | name] [dynamic-name] [source] [destination] [timeout minutes]  
clear access-template [access-list-number | name] [dynamic-name] [source] [destination].
```

### Unsupported Global Configuration Commands

```
access-list rate-limit acl-index {precedence | mask prec-mask}  
access-list dynamic extended
```

## ARP Commands

### Unsupported Global Configuration Commands

```
arp ip-address hardware-address smds  
arp ip-address hardware-address srp-a  
arp ip-address hardware-address srp-b
```

## Unsupported Interface Configuration Commands

**arp probe**  
**ip probe proxy**

## Unsupported Debug Commands

**debug platform cli-redirection main**

## FallBack Bridging

## Unsupported Privileged EXEC Commands

**clear bridge [bridge-group] multicast [router-ports | groups | counts] [group-address] [interface-unit] [counts]**  
**clear vlan statistics**  
**show bridge [bridge-group] circuit-group [circuit-group] [src-mac-address] [dst-mac-address]**  
**show bridge [bridge-group] multicast [router-ports | groups] [group-address]**  
**show bridge vlan**  
**show interfaces crb**  
**show interfaces {ethernet | fastethernet} [interface | slot/port] irb**  
**show subscriber-policy range**

## Unsupported Global Configuration Commands

**bridge bridge-group acquire**  
**bridge bridge-group address mac-address {forward | discard} [interface-id]**  
**bridge bridge-group aging-time seconds**  
**bridge bridge-group bitswap\_l3\_addresses**  
**bridge bridge-group bridge ip**  
**bridge bridge-group circuit-group circuit-group pause milliseconds**  
**bridge bridge-group circuit-group circuit-group source-based**  
**bridge cmf**  
**bridge crb**  
**bridge bridge-group domain domain-name**  
**bridge irb**  
**bridge bridge-group mac-address-table limit number**  
**bridge bridge-group multicast-source**

```
bridge bridge-group protocol dec
bridge bridge-group route protocol
bridge bridge-group subscriber policy policy
subscriber-policy policy [[no | default] packet [permit | deny]]
```

## Unsupported Interface Configuration Commands

```
bridge-group bridge-group cbus-bridging
bridge-group bridge-group circuit-group circuit-number
bridge-group bridge-group input-address-list access-list-number
bridge-group bridge-group input-lat-service-deny group-list
bridge-group bridge-group input-lat-service-permit group-list
bridge-group bridge-group input-lsap-list access-list-number
bridge-group bridge-group input-pattern-list access-list-number
bridge-group bridge-group input-type-list access-list-number
bridge-group bridge-group lat-compression
bridge-group bridge-group output-address-list access-list-number
bridge-group bridge-group output-lat-service-deny group-list
bridge-group bridge-group output-lat-service-permit group-list
bridge-group bridge-group output-lsap-list access-list-number
bridge-group bridge-group output-pattern-list access-list-number
bridge-group bridge-group output-type-list access-list-number
bridge-group bridge-group sse
bridge-group bridge-group subscriber-loop-control
bridge-group bridge-group subscriber-trunk
bridge bridge-group lat-service-filtering
frame-relay map bridge dlci broadcast
interface bvi bridge-group
x25 map bridge x.121-address broadcast [options-keywords]
```

## HSRP

## Unsupported Global Configuration Commands

```
interface Async
interface BVI
interface Dialer
```

## IGMP Snooping Commands

```
interface Group-Async
interface Lex
interface Multilink
interface Virtual-Template
interface Virtual-Tokenring
```

## Unsupported Interface Configuration Commands

```
mtu
standby mac-refresh seconds
standby use-bia
```

## IGMP Snooping Commands

### Unsupported Global Configuration Commands

```
ip igmp snooping source-only-learning
ip igmp snooping tcn
```

## Interface Commands

### Unsupported Privileged EXEC Commands

```
show interfaces [interface-id | vlan vlan-id] [crb | fair-queue | irb | mac-accounting | precedence | irb
| random-detect | rate-limit | shape]
```

### Unsupported Global Configuration Commands

```
interface tunnel
```

## Unsupported Interface Configuration Commands

**switchport broadcast level**  
**switchport multicast level**  
**switchport unicast level**



Note

These commands have been replaced by the **storm-control {broadcast | multicast | unicast} level level [level]** interface configuration command.

**transmit-interface type number**

## IP Multicast Routing

### Unsupported Global Configuration Commands

**ip pim register-rate-limit**

## IP Multicast Routing

### Unsupported Privileged EXEC Commands

**clear ip rtp header-compression [type number]**

The **debug ip packet** command displays packets received by the switch CPU. It does not display packets that are hardware-switched.

The **debug ip mcache** command affects packets received by the switch CPU. It does not display packets that are hardware-switched.

The **debug ip mpacket [detail] [access-list-number [group-name-or-address]** command affects only packets received by the switch CPU. Because most multicast packets are hardware-switched, use this command only when you know that the route will forward the packet to the CPU.

**debug ip pim atm**

**show frame-relay ip rtp header-compression [interface type number]**

The **show ip mcache** command displays entries in the cache for those packets that are sent to the switch CPU. Because most multicast packets are switched in hardware without CPU involvement, you can use this command, but multicast packet information is not displayed.

The **show ip mpacket** commands are supported but are only useful for packets received at the switch CPU. If the route is hardware-switched, the command has no effect because the CPU does not receive the packet and cannot display it.

**show ip pim vc [group-address | name] [type number]**

**show ip rtp header-compression [type number] [detail]**

## Unsupported Global Configuration Commands

```
ip pim accept-rp {address | auto-rp} [group-access-list-number]
ip pim message-interval seconds
```

## Unsupported Interface Configuration Commands

```
frame-relay ip rtp header-compression [active | passive]
frame-relay map ip ip-address dlci [broadcast] compress
frame-relay map ip ip-address dlci rtp header-compression [active | passive]
ip igmp helper-address ip-address
ip multicast helper-map {group-address | broadcast} {broadcast-address | multicast-address}
extended-access-list-number
ip multicast rate-limit {in | out} [video | whiteboard] [group-list access-list] [source-list access-list]
kbps
ip multicast ttl-threshold ttl-value (instead, use the ip multicast boundary access-list-number
interface configuration command)
ip multicast use-functional
ip pim minimum-vc-rate pps
ip pim multipoint-signalling
ip pim nbma-mode
ip pim vc-count number
ip rtp compression-connections number
ip rtp header-compression [passive]
```

## IP Unicast Routing

### Unsupported Privileged EXEC or User EXEC Commands

```
clear ip accounting [checkpoint]
clear ip bgp address flap-statistics
clear ip bgp prefix-list
debug ip cef stats
show cef [drop | not-cef-switched]
show ip accounting [checkpoint] [output-packets | access-violations]
show ip bgp dampened-paths
show ip bgp inconsistent-as
```

**show ip bgp regexp *regular expression***  
**show ip prefix-list *regular expression***

## Unsupported Global Configuration Commands

**ip accounting-list *ip-address wildcard***  
**ip as-path access-list**  
**ip accounting-transits *count***  
**ip cef accounting [per-prefix] [non-recursive]**  
**ip cef traffic-statistics [load-interval *seconds*] [update-rate *seconds*]]**  
**ip flow-aggregation**  
**ip flow-cache**  
**ip flow-export**  
**ip gratuitous-arps**  
**ip local**  
**ip prefix-list**  
**ip reflexive-list**  
**router egp**  
**router isis**  
**router iso-igrp**  
**router mobile**  
**router odr**  
**router static**

## Unsupported Interface Configuration Commands

**ip accounting**  
**ip load-sharing [per-packet]**  
**ip mtu *bytes***  
**ip verify**  
**ip unnumbered *type number***  
All **ip security** commands

## Unsupported BGP Router Configuration Commands

```
address-family vpnv4
default-information originate
neighbor advertise-map
neighbor allowas-in
neighbor default-originate
neighbor description
network backdoor
table-map
```

## Unsupported VPN Configuration Commands

All

## Unsupported Route Map Commands

```
match route-type
set as-path {tag | prepend as-path-string}
set automatic-tag
set dampening half-life reuse suppress max-suppress-time
set default interface interface-id [interface-id.....]
set interface interface-id [interface-id.....]
set ip default next-hop ip-address [ip-address.....]
set ip destination ip-address mask
set ip precedence value
set ip qos-group
set metric-type internal
set origin
set metric-type internal
set tag tag-value
```

## MAC Address Commands

## Unsupported Privileged EXEC Commands

```
show mac-address-table
show mac-address-table address
```

```
show mac-address-table aging-time  
show mac-address-table count  
show mac-address-table dynamic  
show mac-address-table interface  
show mac-address-table multicast  
show mac-address-table notification  
show mac-address-table static  
show mac-address-table vlan  
show mac address-table multicast
```



**Note** Use the **show ip igmp snooping groups** privileged EXEC command to display Layer 2 multicast address-table entries for a VLAN.

## Unsupported Global Configuration Commands

```
mac-address-table aging-time  
mac-address-table notification  
mac-address-table static
```

## Miscellaneous

### Unsupported Global Configuration Commands

```
errdisable detect cause dhcp-rate-limit  
errdisable recovery cause dhcp-rate-limit  
errdisable recovery cause unicast flood  
service compress-config
```

### Unsupported Privileged EXEC Commands

```
show cable-diagnostics prbs  
test cable-diagnostics prbs
```

## MSDP

### Unsupported Privileged EXEC Commands

```
show access-expression
show exception
show location
show pm LINE
show smf [interface-id]
show subscriber-policy [policy-number]
show template [template-name]
```

### Unsupported Global Configuration Commands

**ip msdp default-peer** *ip-address | name [prefix-list list]* (Because BGP/MBGP is not supported, use the **ip msdp peer** command instead of this command.)

## NetFlow Commands

### Unsupported Global Configuration Commands

```
ip flow-aggregation cache
ip flow-cache entries
ip flow-export
```

## Network Address Translation (NAT) Commands

### Unsupported User EXEC Commands

```
clear ip nat translation
show ip nat statistics
show ip nat translations
```

### Unsupported Global Configuration Commands

```
ip nat inside destination
ip nat inside source
```

**ip nat outside source**  
**ip nat pool**

## Unsupported Interface Configuration Commands

**ip nat**

## QoS

## Unsupported Global Configuration Commands

**priority-list**

## Unsupported Interface Configuration Commands

**priority-group**

## RADIUS

## Unsupported Global Configuration Commands

**aaa nas port extended**  
**radius-server attribute nas-port**  
**radius-server configure**  
**radius-server extended-portnames**

## SNMP

## Unsupported Global Configuration Commands

**snmp-server enable informs**  
**snmp-server ifindex persist**

# Spanning Tree

## Unsupported Global Configuration Command

**spanning-tree pathcost method {long | short}**

## Unsupported Interface Configuration Command

**spanning-tree stack-port**

# VLAN

## Unsupported Global Configuration Commands

**vlan internal allocation policy {ascending | descending}**

## Unsupported User EXEC Commands

**show running-config vlan**

**show vlan ifindex**

# VTP

## Unsupported Privileged EXEC Commands

**vtp {password *password* | pruning | version *number*}**



**Note** This command has been replaced by the **vtp** global configuration command.