



Radio Resource Management Commands

- [airtime-fairness dot11 mode \(apgroup\)](#), on page 3
- [airtime-fairness dot11 optimization \(apgroup\)](#), on page 4
- [airtime-fairness dot11 policy](#), on page 5
- [airtime-fairness policy \(wlan\)](#), on page 6
- [ap dot11 rf-profile](#), on page 7
- [ap dot11 rrm](#), on page 8
- [ap dot11 rrm ccx](#), on page 11
- [ap dot11 rrm channel](#), on page 12
- [ap dot11 24ghz rrm channel cleanair-event rogue-contribution](#), on page 13
- [ap dot11 24ghz or 5ghz rrm channel dca add](#), on page 14
- [ap dot11 24ghz or 5ghz rrm channel dca remove](#), on page 15
- [ap dot11 5ghz rrm channel dca chan-width width-max](#), on page 16
- [ap dot11 rrm coverage](#), on page 17
- [ap dot11 rrm group-member](#), on page 19
- [ap dot11 rrm monitor](#), on page 20
- [ap dot11 rrm profile](#), on page 21
- [ap dot11 rrm tpc-threshold](#), on page 22
- [ap dot11 rrm txpower](#), on page 23
- [ap dot11 airtime-fairness mode](#), on page 24
- [ap dot11 airtime-fairness policy-name](#), on page 25
- [ap group](#), on page 27
- [ap name dot11 airtime-fairness mode](#), on page 28
- [ap name dot11 airtime-fairness optimization](#), on page 29
- [ap name no dot11 airtime-fairness wlan-name policy-name](#), on page 30
- [ap name dot11 airtime-fairness wlan-name policy](#), on page 31
- [band-select client](#), on page 32
- [band-select cycle](#), on page 33
- [band-select expire](#), on page 34
- [band-select probe-response](#), on page 35
- [channel](#), on page 36
- [channel foreign](#), on page 37
- [channel width](#), on page 38
- [coverage](#), on page 39

- coverage exception, on page 40
- coverage level, on page 41
- clear wireless airtime-fairness statistics, on page 42
- dot11n-only, on page 43
- load-balancing, on page 44
- high-density clients count, on page 45
- high-density clients wlan, on page 46
- high-density multicast data-rate, on page 47
- high-density rx-sop threshold, on page 48
- rate, on page 49
- rate mcs, on page 50
- trap threshold, on page 51
- tx-power, on page 52
- tx-power v1 threshold, on page 53
- no ap dot11 airtime-fairness policy-name, on page 54
- remote-lan, on page 55
- rf-profile dot11 24ghz, on page 56
- rf-profile dot11 5ghz, on page 57
- show ap airtime-fairness ap-group, on page 58
- show ap airtime-fairness (ap), on page 59
- show ap airtime-fairness (per radio), on page 60
- show ap airtime-fairness policy (all), on page 61
- show ap airtime-fairness wlan, on page 62
- show ap dot11 24ghz , on page 63
- show ap dot11 5ghz, on page 65
- show ap dot11 airtime-fairness (radio bands), on page 67
- show ap dot11 24ghz rf-profile summary, on page 68
- show ap dot11 5ghz rf-profile summary, on page 69
- show ap name dot11 airtime-fairness summary, on page 70
- show ap name dot11 airtime-fairness policy statistics, on page 71
- show ap name dot11 airtime-fairness wlan name statistics, on page 72
- show ap rf-profile summary, on page 73
- show ap rf-profile name, on page 74
- show wireless mobility controller ap, on page 76
- shutdown, on page 77
- wlan, on page 78

airtime-fairness dot11 mode (apgroup)

To configure ATF for an AP group, use the **airtime-fairness dot11 mode** command in ap group submode. Use the **no** form of the command to disable ATF for a AP group.

```
airtime-fairness dot11 {24ghz|5ghz} mode {enforce-policy|monitor}
```

```
no airtime-fairness dot11 {24ghz|5ghz} mode {enforce-policy|monitor}
```

Syntax	Description
24ghz	Configures 802.11b parameters
5ghz	Configures 802.11a parameters
enforce-policy	Configure airtime-fairness in enforce-policy mode
monitor	Configure airtime-fairness in monitor mode

Command Default None

Command Modes config apgroup

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

Usage Guidelines None

This example shows how to configure ATF for an AP group.

```
Switch#configure terminal
Switchconfig# ap group testap
Switchconfig-apgroup# airtime-fairness dot11 24ghz mode monitor
```

airtime-fairness dot11 optimization (apgroup)

To configure ATF optimization for an AP group, use the **airtime-fairness dot11 optimization** command. Use the **no** form of the command to disable ATF for a AP group

airtime-fairness dot11 {24ghz|5ghz} optimization

no airtime-fairness dot11 {24ghz|5ghz} optimization

Syntax Description	24ghz	Configures 802.11b parameters
	5ghz	Configures 802.11a parameters
Command Default	None	
Command Modes	config apgroup	
Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.
Usage Guidelines	None	

This example shows how to configure ATF optimization for an AP group.

```
Switch#configure terminal
Switchconfig# ap group testap
Switchconfig-apgroup# airtime-fairness dot11 24ghz optimization
```

airtime-fairness dot11 policy

To override a globally applied policy on a WLAN AP group, use the **airtime-fairness dot11 policy** command. Use the **no** form of the command to disable applied policy override.

airtime-fairness dot11 {24ghz|5ghz} **policy** *policy-name*

no airtime-fairness dot11 {24ghz|5ghz} **policy** *policy-name*

Syntax Description	24ghz	Configures 2.4 GHz airtime-fairness policy
	5ghz	Configures 5 GHz airtime-fairness policy
	<i>policy-name</i>	name of the airtime-fairness policy to assign

Command Default None

Command Modes config wlan apgroup

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

Usage Guidelines None

This example shows how to override applied policy on a WLAN AP group.

```
Switchconfig#ap group testapgroup
Switch(config-apgroup)# wlan testwlan
Switch(config-wlan-apgroup)# airtime-fairness dot11 24ghz policy testpolicy
```

airtime-fairness policy (wlan)

To configure the ATF policy for a WLAN, use the **airtime-fairness policy** command.

airtime-fairness policy *policy-name*

Syntax Description	<i>policy-name</i>	Enter the policy name.
Command Default	None	
Command Modes	config wlan	
Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.
Usage Guidelines	None	

This example shows how to configure the ATF policy for a WLAN.

```
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#wlan wlan-name
Switch(config-wlan)#airtime-fairness policy policy-name
```

ap dot11 rf-profile

To configure an RF-Profile for a selected band, use the **ap dot11 rf-profile** command. To delete an RF-Profile, use the **no** form of this command.

ap dot11 {24GHz | 5GHz} **rf-profile** *profile name*

Syntax Description	24ghz	Displays the 2.4-GHz band
	5ghz	Displays the 5-GHz band
	<i>profile name</i>	Name of the RF profile
Command Default	None	
Command Modes	Global configuration (config)	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1 This command was introduced.	
Usage Guidelines	None	

This example shows how to configure an RF profile for a selected band.

```
Switch#ap dot11 24GHz rf-profile doctest
```

ap dot11 rrm

To configure basic and advanced radio resource management settings for 802.11 devices, use the **ap dot11 rrm** command.

```
ap dot11 {24ghz|5ghz} rrm {ccx location-measurement sec|channel
{cleanair-event|dca|device|foreign|load|noise|outdoor-ap-dca}|coverage {data fail-percentage pct|data
packet-count count|data rssi-threshold threshold}|exception global percentage|level global
number|voice {fail-percentage percentage|packet-count number|rssi-threshold threshold}}
```

Syntax Description

ccx	Configures Advanced (RRM) 802.11 CCX options.
location-measurement	Specifies 802.11 CCX Client Location Measurements in seconds. The range is between 10 and 32400 seconds.
channel	Configure advanced 802.11-channel assignment parameters.
cleanair-event	Configures cleanair event-driven RRM parameters.
dca	Configures 802.11-dynamic channel assignment algorithm parameters.
device	Configures persistent non-WiFi device avoidance in the 802.11-channel assignment.
foreign	Enables foreign AP 802.11-interference avoidance in the channel assignment.
load	Enables Cisco AP 802.11-load avoidance in the channel assignment.
noise	Enables non-802.11-noise avoidance in the channel assignment.
outdoor-ap-dca	Configures 802.11 DCA list option for outdoor AP.
coverage	Configures 802.11 coverage Hole-Detection.

data fail-percentage <i>pct</i>	Configures 802.11 coverage failure-rate threshold for uplink data packets. The range is between 1 and 100
data packet-count <i>count</i>	Configures 802.11 coverage minimum-failure-count threshold for uplinkdata packets.
data rssi-threshold <i>threshold</i>	Configures 802.11 minimum-receive-coverage level for voice packets.
exception global <i>percentage</i>	Configures 802.11 Cisco APs coverage-exception level. The range is between 0 and 100 percent.
level global <i>number</i>	Configures 802.11 Cisco AP client-minimum-exception level between 1 and 75 clients.
voice	Configures 802.11 coverage Hole-Detection for voice packets.
fail-percentage <i>percentage</i>	Configures 802.11 coverage failure rate threshold for uplink voice packets.
packet-count <i>number</i>	Configures 802.11 coverage minimum-uplink-failure count threshold for voice packets.
rssi-threshold <i>threshold</i>	Configures 802.11 minimum receive coverage level for voice packets.

Command Default Disabled

Command Modes Interface configuration

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines This command applies for both 802.11a and 802.11b bands. But the appropriate commands must be chosen for configuring the parameter.

This example shows how to configure various RRM settings.

```
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#ap dot11 5ghz rrm ?
```

ccx	Configure Advanced(RRM) 802.11a CCX options
channel	Configure advanced 802.11a channel assignment parameters
coverage	802.11a Coverage Hole Detection
group-member	Configure members in 802.11a static RF group
group-mode	802.11a RF group selection mode
logging	802.11a event logging
monitor	802.11a statistics monitoring
ndp-type	Neighbor discovery type Protected/Transparent
profile	802.11a performance profile
tpc-threshold	Configures the Tx Power Control Threshold used by RRM for auto power assignment
txpower	Configures the 802.11a Tx Power Level

ap dot11 rrm ccx

To configure radio resource management CCX options for 2.4 GHz and 5GHz devices, use the **ap dot11 rrm ccx** command.

ap dot11 {24ghz|5ghz} **rrm ccx location-measurement** *interval*

Syntax Description	location-measurement <i>interval</i> Specifies the CCX client-location measurement interval value. The range is between 10 and 32400 seconds.				
Command Default	None.				
Command Modes	Interface configuration.				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XE 3.3SE</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XE 3.3SE	This command was introduced.
Release	Modification				
Cisco IOS XE 3.3SE	This command was introduced.				
Usage Guidelines	None.				

This example shows how to set CCX location-measurement interval for a 5-GHz device.

```
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#ap dot11 5ghz rrm ccx location-measurement 10
```

ap dot11 rrm channel

To enable radio resource management channel for 2.4 GHz and 5GHz devices, use the **ap dot11 rrm channel** command. To disable the radio resource management for 2.4 GHz and 5 GHz devices, use the **no** form of the command.

```
ap dot11 {24ghz|5ghz} rrm channel {cleanair-event|dca|device|foreign|load|noise}
no ap dot11 {24ghz|5ghz} rrm channel {cleanair-event|dca|device|foreign|load|noise}
```

Syntax Description	Parameter	Description
	cleanair-event	Specifies the cleanair event-driven RRM parameters
	dca	Specifies the 802.11 dynamic channel assignment algorithm parameters
	device	Specifies the persistent non-WiFi device avoidance in the 802.11-channel assignment.
	foreign	Enables foreign AP 802.11-interference avoidance in the channel assignment.
	load	Enables Cisco AP 802.11-load avoidance in the channel assignment.
	noise	Enables non-802.11-noise avoidance in the channel assignment.

Command Default None.

Command Modes Interface configuration.

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines None.

This example shows all the parameters available for **Channel**.

```
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#ap dot11 24ghz rrm channel ?
  cleanair-event  Configure cleanair event-driven RRM parameters
  dca             Config 802.11b dynamic channel assignment algorithm
                 parameters
  device         Configure persistent non-WiFi device avoidance in the 802.11b
                 channel assignment
  foreign        Configure foreign AP 802.11b interference avoidance in the
                 channel assignment
  load           Configure Cisco AP 802.11b load avoidance in the channel
                 assignment
  noise          Configure 802.11b noise avoidance in the channel assignment
```

ap dot11 24ghz rrm channel cleanair-event rogue-contribution

To configure cleanair event driven Radio Resource Management (RRM) rogue contribution parameters, use the `ap dot11 24ghz rrm channel cleanair-event rogue-contribution` command.

`ap dot11 24ghz rrm channel cleanair-event rogue-contribution duty-cycle threshold-value`

Syntax Description	duty-cycle	Sets event-driven RRM rogue contribution duty cycle.
	<i>threshold-value</i>	Custom ED-RRM rogue contribution duty cycle threshold value. Valid value ranges from 1 -99 percent.
Command Default	The rogue contribution duty cycle is not set.	
Command History	Release	Modification
	16.1	This command was introduced.
Usage Guidelines	This command sets event-driven RRM rogue contribution duty cycle.	

Example

This example shows how to configure cleanair event driven RRM rogue contribution parameters:

```
Cisco Controller(config)# ap dot11 24ghz rrm channel cleanair-event rogue-contribution
duty-cycle 1
```

ap dot11 24ghz or 5ghz rrm channel dca add

To add non-default radio resource management DCA channels to the DCA channel list for 2.4 GHz or 5 GHz devices, use the **ap dot11 {24ghz | 5ghz} rrm channel dca add** command. To remove a default channel from the DCA list, use the **no** form of the command. The DCA channel list contains standard channels matching your country of operation. For example, a regulatory default channel list contains channels 1, 6, and 11.

```
ap dot11 [{24ghz|5ghz}] rrm channel dca add number
no ap dot11 [{24ghz|5ghz}] rrm channel dca add number
```

Syntax Description	<i>number</i>	DCA channel number.
Command Default	None.	
Command Modes	Global configuration	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.
Usage Guidelines	None.	

This example shows how to add a non-default radio resource management DCA channel to the DCA list for a 2.4 GHz device, using the **ap dot11 24ghz rrm channel dca add 10** command:

```
Switch(config)# ap dot11 24ghz rrm channel dca add 10
```

ap dot11 24ghz or 5ghz rrm channel dca remove

To remove a default radio resource management DCA channels from the DCA channel list for 2.4 GHz or 5 GHz devices, use the **ap dot11 {24ghz | 5ghz} rrm channel dca remove *number*** command. To add a default DCA channel back to the DCA channel list, use the **no** form of the command.

```
ap dot11 [{24ghz|5ghz}] rrm channel dca remove number
no ap dot11 [{24ghz|5ghz}] rrm channel dca remove number
```

Syntax Description	<i>number</i>	Specifies the radio resource management DCA channel.
Command Default	None.	
Command Modes	Global configuration.	
Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.
Usage Guidelines	None.	

This example shows how to remove default radio resource management DCA channel from the DCA list for a 2.4 GHz device, using the **ap dot11 24ghz rrm channel dca remove** command:

```
Switch(config)#ap dot11 24ghz rrm channel dca remove 11
```

ap dot11 5ghz rrm channel dca chan-width width-max

To configure the maximum allowed channel bandwidth when the best option is selected, enter the **ap dot11 5ghz rrm channel dca** *width* command.

```
ap dot11 5ghz rrm channel dca {WIDTH_20MHz | WIDTH_40MHz }
```

Syntax Description

Specifies the maximum allowed channel bandwidth limit when the best option is selected

WIDTH_20MHz Sets the maximum channel bandwidth limit to 20 MHz.

WIDTH_40MHz Sets the maximum channel bandwidth limit to 40 MHz.

Command Default

The default channel width is 40.

Command Modes

Global configuration.

Usage Guidelines

None.

This example shows how to set the maximum allowed channel bandwidth limit to 40 MHz when the best option is selected, using the command:

```
Switch(config)#
```


ap dot11 rrm coverage

To enable 802.11 coverage hole detection, use the **ap dot11 rrm coverage** command.

```
ap dot11 {24ghz|5ghz} rrm coverage [{data {fail-percentage percentage|packet-count
count|rssi-threshold threshold}|exceptional global value|level global value|voice {fail-percentage
percentage|packet-count packet-count|rssi-threshold threshold}]
```

Syntax Description	Parameter	Description
	data	Specifies 802.11 coverage hole-detection data packets.
	fail-percentage <i>percentage</i>	Specifies 802.11 coverage failure-rate threshold for uplink data packets. The range is between 1 and 100
	packet-count <i>count</i>	Specifies 802.11 coverage minimum-failure-count threshold for uplink data packets.
	rssi-threshold <i>threshold</i>	Specifies 802.11 minimum-receive-coverage level for voice packets.
	exceptional global <i>value</i>	Specifies 802.11 Cisco APs coverage-exception level. The range is between 0 and 100 percent.
	level global <i>value</i>	Specifies 802.11 Cisco AP client-minimum-exception level between 1 and 75 clients.
	voice	Specifies 802.11 coverage Hole-Detection for voice packets.
	fail-percentage <i>percentage</i>	Specifies 802.11 coverage failure rate threshold for uplink voice packets.
	packet-count <i>packet-count</i>	Specifies 802.11 coverage minimum-uplink-failure count threshold for voice packets.
	rssi-threshold <i>threshold</i>	Specifies 802.11 minimum receive coverage level for voice packets.

Command Default None.

Command Modes Interface configuration.

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines If you enable coverage hole-detection, the switch automatically determines, based on data that is received from the access points, whether any access points have clients that are potentially located in areas with poor coverage.

If both the number and percentage of failed packets exceed the values that you entered in the **ap dot11 {24ghz | 5ghz} rrm coverage packet-count** and **ap dot11 {24ghz | 5ghz} rrm coverage fail-percentage** commands for a 5-second period, the client is considered to be in a pre-alarm condition. The switch uses this information to distinguish between real and false coverage holes and excludes clients with poor roaming logic. A coverage hole is detected if both the number and percentage of failed clients meet or exceed the values entered in the

ap dot11 {24ghz | 5ghz} rrm coverage level-global and **ap dot11 {24ghz | 5ghz} rrm coverage exceptional-global** commands over a 90-second period. The switch determines whether the coverage hole can be corrected and, if appropriate, mitigate the coverage hole by increasing the transmit power level for that specific access point.

This example shows how to set the RSSI-threshold for data in 5-GHz band.

```
Switch#configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
Switch(config)#ap dot11 5ghz rrm coverage data rssi-threshold -80
```

ap dot11 rrm group-member

To configure members in 802.11 static RF group, use the **ap dot11 rrm group-member** command. To remove the member, use the **no** form of the command.

```
ap dot11 {24ghz|5ghz} rrm group-member controller-name controller-ip
no ap dot11 {24ghz|5ghz} rrm group-member controller-name controller-ip
```

Syntax Description

<i>controller-name</i>	Specifies the name of the controller to be added.
<i>controller-ip</i>	Specifies the IP address of the controller to be added.

Command Default

None.

Command Modes

Interface configuration.

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

None.

This example shows how to add a controller in the 5-GHz automatic-RF group

```
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#ap dot11 5ghz rrm group-member ABC 10.1.1.1
```

ap dot11 rrm monitor

To monitor the 802.11-band statistics, use the **ap dot11 rrm monitor** command. To disable, use the **no** form of the command.

```
ap dot11 {24ghz|5ghz} rrm monitor {channel-list|{all|country|dca}|coverage|load|noise|signal}
no ap dot11 {24ghz|5ghz} rrm monitor {channel-list|coverage|load|noise|signal}
```

Syntax Description

channel-list	Sets the 802.11 noise/interference/rogue monitoring channel-list.
all	Specifies to monitor all the channels.
country	Specifies to monitor channels used in configured country code
dca	Specifies to monitor channels used by dynamic channel assignment.
coverage	Specifies 802.11 coverage measurement interval. The range is between 60 and 3600 in seconds
load	Specifies 802.11 load measurement interval. The range is between 60 and 3600 in seconds
noise	Specifies 802.11 noise measurement interval (channel scan interval). The range is between 60 and 3600 in seconds
signal	Specifies 802.11 signal measurement interval (neighbor packet frequency). The range is between 60 and 3600 in seconds

Command Default

None.

Command Modes

Interface Configuration

Command History

Release	Modification
Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines

None.

This example shows how to enable monitoring all the 5-GHz band channels.

```
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#ap dot11 5ghz rrm monitor channel-list all
```

ap dot11 rrm profile

To configure Cisco lightweight access point profile settings on supported 802.11 networks, use the **ap dot11 rrm profile** command.

```
ap dot11 {24ghz|5ghz} rrm profile {customize|foreign value|noise value|throughput value|utilization value}
```

Syntax Description	customize	Enables performance profiles.
	foreign value	Specifies the 802.11 foreign 802.11 interference threshold value. The range is between 0 and 100 percent.
	noise value	Specifies the 802.11 foreign noise threshold value. The range is between -127 and 0 dBm
	throughput value	Specifies the 802.11a Cisco AP throughput threshold value. The range is between 1000 and 10000000 bytes per second
	utilization value	Specifies the 802.11a RF utilization threshold value. The range is between 0 and 100 percent

Command Default Disabled.

Command Modes Interface configuration.

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines None.

This example shows how to set the threshold value for the noise parameter.

```
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#ap dot11 5ghz rrm profile noise -50
```

ap dot11 rrm tpc-threshold

To configure the tx-power control threshold used by RRM for auto power assignment, use the **ap dot11 rrm tpc-threshold** command. To disable, use the **no** form of the command.

```
ap dot11 {24ghz|5ghz} rrm tpc-threshold value
no ap dot11 {24ghz|5ghz} rrm tpc-threshold
```

Syntax Description	<i>value</i> Specifies the power value. The range is between -80 and -50.
---------------------------	---

Command Default	None.
------------------------	-------

Command Modes	Interface configuration.
----------------------	--------------------------

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines	None.
-------------------------	-------

This example shows how to configure the tx-power control threshold used by RRM for auto power assignment.

```
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#ap dot11 5ghz rrm tpc-threshold -60
```

ap dot11 rrm txpower

To configure the 802.11 tx-power level, use the **ap dot11 rrm txpower** command. To disable the 802.11 tx-power level, use the **no** form of the command.

```
ap dot11 {24ghz|5ghz} rrm txpower {auto|max powerLevel|min powerLevel|oncepower-level}
noap dot11 {24ghz|5ghz} rrm txpower {auto|max powerLevel|min powerLevel|oncepower-level}
```

Syntax Description	auto	Enables auto-RF.
	max <i>powerLevel</i>	Configures maximum auto-RF tx power. The range is between -10 to -30.
	min <i>powerLevel</i>	Configures minimum auto-RF tx power. The range is between -10 to -30.
	once	Enables one-time auto-RF.

Command Default None.

Command Modes Interface configuration.

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.
	Cisco IOS XE 3.3SE	The no form of the command is introduced.

Usage Guidelines None.

This example shows how to enables auto-RF once.

```
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#ap dot11 5ghz rrm txpower once
```

ap dot11 airtime-fairness mode

To enable AirTime-Fairness in Enforce policy or Monitor mode, use the **ap dot11 airtime-fairness mode** command. To disable Enforce policy or Monitor mode in AirTime Fairness, use the **no** form of the command.

ap dot11 {24ghz|5ghz} airtime-fairness mode {enforce-policy|monitor}

no ap dot11 {24ghz|5ghz} airtime-fairness mode {enforce-policy|monitor}

Syntax Description	24ghz	Configures 802.11b parameters
	5ghz	Configures 802.11a parameters
	enforce-policy	Configure airtime-fairness in enforce-policy mode
	monitor	Configure airtime-fairness in monitor mode
Command Default	None	
Command Modes	Global Configuration	
Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.
Usage Guidelines	None	

This example shows all the parameters available for **AirTime Fairness mode**.

```
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#ap dot11 24ghz airtime-fairness mode ?
  enforce-policy  Configure airtime-fairness in enforce-policy mode
  monitor         Configure airtime-fairness in monitor mode
```


ap dot11 airtime-fairness policy-name

To create a new Air Time Fairness (ATF) policy, use the **ap dot11 airtime-fairness policy-name** command.

ap dot11 airtime-fairness policy-name *policy-name* *policy-id*

Syntax Description	<i>policy-name</i>	Enter the ATF policy name.
	<i>policy-id</i>	Enter ATF policy ID to create new policy.
Command Default	None	
Command Modes	Global Configuration	
Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1 This command was introduced.	

Usage Guidelines All ATF policies require a policy weight value. To add the policy weight use the **policy weight** command in config-airtime-fairness policy mode. If no policy weight is added, default value of 10 is applied. For more information about adding policy weight, see [policy-weight, on page 25](#).

This example shows .

```
Switch#ap dot11 airtime-fairness policy-name testpolicy 12
```

policy-weight

To apply policy weight to an Air Time Fairness (ATF) policy, use the **policy-weight** command.

policy-weight *policy-weight*

Syntax Description	<i>policy-weight</i>	Policy weight for ATF policy. The range is from 5 to 100. Default is 10.
Command Default	None	
Command Modes	config-airtime-fairness policy	
Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1 This command was introduced.	

Usage Guidelines If you do not apply a policy to the WLAN, then the default policy (with ID 0) with the policy weight of 10 is applied automatically. For more information about ATF policy creation, see [ap dot11 airtime-fairness policy-name, on page 25](#).

This example shows how to apply policy weight to an ATF policy.

```
Switch#ap dot11 airtime-fairness policy-name testpolicy 12
Switch(config-airtime-fairness policy)# policy-weight 35
```

ap group

To configure an ap group, use the **ap group** command.

ap group *group-name*

Syntax Description	<i>group-name</i>	Name of the AP group.
Command Default	None	
Command Modes	Global configuration (config)	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.
Usage Guidelines	None	

This example shows how to configure an ap group.

```
Switchconfig# ap group docgroup
```

ap name dot11 airtime-fairness mode

To enable Air Time-Fairness in Enforce policy or Monitor mode for a specific AP, use the **ap namedot11 airtime-fairness mode** command. Use **no** form of the command to disable Air Time-Fairness from either of the two modes for a specific AP.

ap name *ap-name* **dot11** {24ghz|5ghz} **airtime-fairness mode** {enforce-policy|monitor}

ap name *ap-name* **no dot11** {24ghz|5ghz} **airtime-fairness mode** {enforce-policy|monitor}

Syntax Description		
	<i>ap-name</i>	Enter access point name
	24ghz	Configures 802.11b parameters
	5ghz	Configures 802.11a parameters
	enforce-policy	Configure airtime-fairness in enforce-policy mode
	monitor	Configure airtime-fairness in monitor mode

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

Usage Guidelines None

This example shows how to disable Air Time-Fairness from either enforce-policy or monitor mode for a specific AP.

```
Switch# ap name testap no dot11 24ghz airtime-fairness mode
```

ap name dot11 airtime-fairness optimization

To enable ATF optimization for a specific AP, use the **ap name dot11 airtime-fairness optimization** command. Use **no** to disable ATF optimization for a specific AP.

ap name *ap-name* dot11 {24ghz|5ghz} airtime-fairness optimization

ap name *ap-name* no dot11 {24ghz|5ghz} airtime-fairness optimization

Syntax Description	
<i>ap-name</i>	Enter access point name
24ghz	Configures 802.11b parameters
5ghz	Configures 802.11a parameters

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

This example shows how to enable ATF optimization for a specific AP.

```
Switch#ap name doctestap dot11 24ghz airtime-fairness optimization
```

ap name no dot11 airtime-fairness wlan-name policy-name

To disable the ATF policy override on WLAN specific to a WLAN, use the **ap name no dot11 airtime-fairness wlan-name** command.

ap name *ap-name* **no dot11** {24ghz|5ghz} **airtime-fairness wlan-name** *wlan-name*

Syntax Description		
	<i>ap-name</i>	Enter access point name
	24ghz	Configures 802.11b parameters
	5ghz	Configures 802.11a parameters
	wlan-name	Configure the airtime-fairness policy for this WLAN under Cisco AP
	<i>wlan-name</i>	Enter the wlan profile name

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

Usage Guidelines None

This example shows how to disable ATF policy override on WLAN specific to a WLAN .

```
Switch#ap name testap no dot11 24ghz airtime-fairness wlan-name testwlan
```

ap name dot11 airtime-fairness wlan-name policy

To override the ATF policy on WLAN specific to one AP, use the **ap name dot11 airtime-fairness wlan-name policy-name** command.

ap name *ap-name* **dot11** {**24ghz**|**5ghz**} **airtime-fairness** **wlan-name** *wlan-name* **policy-name** *policy-name*

Syntax Description		
	<i>ap-name</i>	Access Point name
	24ghz	Configures 802.11b parameters
	5ghz	Configures 802.11a parameters
	wlan-name	Configure the airtime-fairness policy for this wlan under Cisco
	<i>wlan-name</i>	Enter the wlan profile name
	policy-name	Configure airtime-fairness policy
	<i>policy-name</i>	Enter the airtime-fairness profile name

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

Usage Guidelines None

This example shows how to override the ATF policy on WLAN specific to one AP.

```
Switch# ap name testap dot11 24ghz airtime-fairness wlan-name testwlan policy-name testpolicy
```

band-select client

To configure the client threshold minimum dB for the selected band, use the **band-select client** command. To reset the client threshold minimum dB for the selected band, use the **no** form of this command.

band-select client { **mid-rssi** | **rssi** } *dBm value*

Syntax Description	mid-rssi	Minimum dBm of a client RSSI start to respond to probe
	rssi	Minimum dBm of a client RSSI to respond to probe
	<i>dBm value</i>	Minimum dBm of a client RSSI to respond to probe. Valid range is between -90 and -20 dBm.
Command Default	None	
Command Modes	config-rf-profile	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1 This command was introduced.	

Usage Guidelines This command is enabled only for 2.4-GHz band.

This example shows how to set the client threshold to minimum dB for a selected band.

```
Switch(config-rf-profile)#band-select client rssi -50
```


band-select cycle

To configure the band cycle parameters, use the **band-select cycle** command. To reset the threshold value, use the **no** form of this command.

band-select cycle { **count** | **threshold** } *value*

Syntax Description	Parameter	Description
	count	Sets the Band Select probe cycle count.
	<i>value</i>	Maximum number of cycles not responding. The range is between 1 and 10.
	threshold	Sets the time threshold for a new scanning cycle.
	<i>value</i>	Set the threshold value in milliseconds. The valid is between 1 and 1000.

Command Default None

Command Modes config-rf-profile

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines None

This example shows how to configure the probe cycle count in an RF profile for a selected band.

```
Switch(config-rf-profile)#band-select cycle count 5
```

band-select expire

To configure the expiry time for the RF profile for the selected band, use the **band-select expire** command. To reset the value, use the **no** form of this command.

```
band-select expire { dual-band | suppression } value
no band-select expire { dual-band | suppression }
```

Syntax Description	Parameter	Description
	dual-band	Configures the RF Profile Band Select Expire Dual Band.
	<i>value</i>	Setting the time to expire for pruning previously known dual-band clients. The range is between 10 and 300.
	suppression	Configures the RF Profile Band Select Expire Suppression.
	<i>value</i>	Setting the time to expire for pruning previously known 802.11b/g clients. The range is between 10 and 200.

Command Default None

Command Modes config-rf-profile

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines None

This example shows how to configure the time to expire for a dual-band of an RF profile in a selected band.

```
Switch(config-rf-profile)#band-select expire dual-band 15
```

band-select probe-response

To configure the probe responses to the clients for a selected band, use the **band-select probe-response** command. To disable the probe-response, use the **no** form of this command.

band-select probe-response

Syntax Description	probe-response	Probe responses to clients.
Command Default	None	
Command Modes	config-rf-profile	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.
Usage Guidelines	None	
	This example shows how to enable probe response to the clients.	
	<code>Switch(config-rf-profile)#band-select probe-response</code>	

channel

To configure a channel for the RF profile DCA channel list, use the **channel** command. To disable the channel, use the **no** form of this command.

channel { **add** | **remove** } *channel-number*

Syntax Description	add	Adds channel to the RF Profile DCA channel list.
	remove	Removes the channel from the RF Profile DCA channel list.
	<i>channel-number</i>	Channel number.
Command Default	None	
Command Modes	config-rf-profile	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1 This command was introduced.	
Usage Guidelines	None	

This example shows how to add a channel to the RF profile DCA channel list.

```
Switch(config-rf-profile)#channel add 3
```

channel foreign

To configure the RF Profile DCA foreign AP contribution, use the **channel foreign** command. To disable the DCA Foreign AP Contribution, use the **no** form of this command.

channel foreign

Syntax Description	foreign	Configures the RF Profile DCA foreign AP contribution.
Command Default	None	
Command Modes	config-rf-profile	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.
Usage Guidelines	None	

This example shows how to configure the RF profile DCA foreign AP contribution.

```
Switch(config-rf-profile)#channel foreign
```

channel width

To configure the RF Profile DCA channel bandwidth, use the **channel width** command. To revert to default value, use the **no** form of this command.

channel width {20 |40 |80 |best}

Syntax Description		
	20	Channel width in MHz
	40	Channel width in MHz
	80	Channel width in MHz
	160	Channel width in MHz
	best	Channel width in MHz

Command Default None

Command Modes config-rf-profile

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines This command is enabled only on 5-GHz band.

This example shows how to configure the channel bandwidth to 40 MHz.

```
Switch(config-rf-profile)#channel chan-width 40
```

coverage

To configure the voice and data coverage, use the **coverage** command. To reset the minimum RSSI value use the **no** form of this command.

coverage {**data** |**voice**} **rsi threshold** *value*

Syntax Description		
	data	Configure Coverage Hole Detection for data packets.
	voice	Configure Coverage Hole Detection for voice packets.
	<i>value</i>	Minimum RSSI value for the packets received by the access point. The valid range is between -90 and -60 dBm.

Command Default None

Command Modes config-rf-profile

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines None

This example shows how to configure the coverage hole detection for data packets.

```
Switch(config-rf-profile)#coverage data rssi threshold -85
```

coverage exception

To configure the Cisco AP coverage exception level, use the **coverage exception** command. To reset the exception-level percentage use the **no** form of this command.

coverage exception *exception-level*

Syntax Description	<i>exception-level</i>	Cisco AP coverage exception level with valid range between 0 and 100 percent.
---------------------------	------------------------	---

Command Default	None
------------------------	------

Command Modes	config-rf-profile
----------------------	-------------------

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines	None
-------------------------	------

This example shows how to set the Cisco AP coverage exception level.

```
Switch(config-rf-profile)#coverage exception 70
```


coverage level

To configure Cisco AP client minimum coverage level, use the **coverage level** command. To reset the coverage client value use the **no** form of this command.

coverage level *clients*

Syntax Description	<i>clients</i>	Minimum coverage level. Range is between 1 and 200 clients.
Command Default	None	
Command Modes	config-rf-profile	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.
Usage Guidelines	None	

This example shows how to configure the Cisco AP client minimum level.

```
Switch(config-rf-profile)#coverage level 180
```

clear wireless airtime-fairness statistics

To clear the wireless airtime-fairness statistics, use the **clear wireless airtime-fairness statistics** command.

clear clear wireless airtime-fairness statistics

Syntax Description	airtime-fairness	Clears the airtime-fairness statistics
---------------------------	-------------------------	--

Command Default	None
------------------------	------

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

This example shows how to clear the wireless airtime-fairness statistics.

```
Switch#clear wireless airtime-fairness statistics
```

dot11n-only

To enable 802.11n client only mode of the RF profile, use the **dot11n-only** command. To disable the 802.11n client only mode use the **no** form of this command.

dot11n-only

Syntax Description	dot11n-only	802.11n client only mode of the RF Profile.
Command Default	None	
Command Modes	config-rf-profile	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.
Usage Guidelines	None	

This example shows how to enable 802.11n client only mode of the RF Profile.

```
Switch(config-rf-profile) #dot11n-only
```

load-balancing

To configure the RF Profile Load Balance, use the **load-balancing** command. To reset RF profile load balance value, use the **no** form of this command.

load-balancing { **denial** | **window** } *value*

Syntax Description	denial	Configures the number of load balancing denial.
	<i>value</i>	Enter the load balancing denial count. The range is between 1 and 10.
window		Set Aggressive Load Balancing client window.
	<i>value</i>	Number of clients. The range is between 0 and 20.

Command Default None

Command Modes config-rf-profile

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines None

This example shows how to configure the number of load balancing denial.

```
Switch#load-balancing denial 4
```

high-density clients count

To configure the RF profile max clients, use the **high-density clients count** command. To reset the RF profile max clients use the **no** form of this command.

high-density clients count *value*

Syntax Description	<i>value</i>	Maximum client connections per AP radio. The range is between 0 and 200.
Command Default	None	
Command Modes	config-rf-profile	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.
Usage Guidelines	None	
	This example shows how to configure the RF profile max clients.	
	<code>Switch(config-rf-profile)#high-density clients count 25</code>	

high-density clients wlan

To configure the maximum clients per AP on a WLAN, use the **high-density clients wlan** command. To reset the count use the **no** form of this command.

high-density clients wlan *wlan name* **count** *count*

Syntax Description		
	<i>wlan name</i>	Enter the name of the WLAN to limit clients per AP.
	<i>count</i>	Maximum client connections per AP per WLAN. The range is between 0 and 200.

Command Default None

Command Modes config-rf-profile

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines None

This example shows how to configure the maximum clients per AP on a WLAN

```
Switch(config-rf-profile)#high-density clients wlan doctest count 20
```

high-density multicast data-rate

To configure the value for RF profile Multicast Data Rate, use the **high-density multicast data-rate** command. To reset the data rate to auto, use the **no** form of this command.

high-density multicast data-rate

{RATE_12M|RATE_18M|RATE_24M|RATE_36M|RATE_48M|RATE_54M|RATE_6M|RATE_9M}

Syntax Description	multicast	Configures the RF Profile multicast.
	data-rate	The value for RF Profile Multicast Data Rate.
	RATE_12M	802.11 12M Rate
	RATE_18M	802.11 18M Rate
	RATE_24M	802.11 24M Rate
	RATE_36M	802.11 36M Rate
	RATE_48M	802.11 48M Rate
	RATE_54M	802.11 54M Rate
	RATE_6M	802.11 6M Rate
	RATE_9M	802.11 9M Rate

Command Default None

Command Modes config-rf-profile

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines None

This example shows how to configure the value for RF profile Multicast Data Rate.

```
Switch(config-rf-profile) #high-density multicast data-rate RATE_9M
```

high-density rx-sop threshold

To configure the value for RF Profile Rx SOP threshold, use the **high-density rx-sop threshold** command. To revert the Rx SOP to auto, use the **no** form of this command.

high-density rx-sop threshold {auto |high |low |medium }

Syntax Description	Command	Description
	rx-sop	Configures the RF Profile Rx SOP threshold.
	threshold	Configures the value for RF Profile Rx SOP threshold.
	auto	Reverts radio receiver SOP threshold to auto.
	high	Sets radio receiver SOP threshold to high.
	low	Sets radio receiver SOP threshold to low.
	medium	Sets radio receiver SOP threshold to medium.

Command Default None

Command Modes config-rf-profile

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines None

This example shows how to configure radio receiver SOP threshold for an RF Profile to high.

```
Switch(config-rf-profile)#high-density rx-sop threshold high
```


rate

To configure 802.11 operational rates, use the **rate** command. To revert to the rate default state, use the **no** form of this command.

```
rate
{RATE_12M|RATE_18M|RATE_24M|RATE_36M|RATE_48M|RATE_54M|RATE_6M|RATE_9M} {disable|
mandatory|supported}
```

Syntax	Description
RATE_12M	802.11 12M Rate.
RATE_18M	802.11 18M Rate.
RATE_24M	802.11 24M Rate.
RATE_36M	802.11 36M Rate.
RATE_48M	802.11 48M Rate.
RATE_54M	802.11 54M Rate.
RATE_6M	802.11 6M Rate.
RATE_9M	802.11 9M Rate.
disable	Disables a rate.
mandatory	Configures a rate to mandatory.
supported	Configures a rate to supported.

Command Default None

Command Modes config-rf-profile

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines None

This example shows how to disable 802.11 9M operational rate.

```
Switch(config-rf-profile)#rate RATE_9M disable
```

rate mcs

To enable the RF profile MCS data rates, use the **rate mcs** command. To disable the RF profile MCS data rates use the **no** form of this command.

rate mcs *index-number*

Syntax Description	<i>index-number</i>	Enter index number of RF Profile MCS Data Rates. The range is between 0 and 31.
---------------------------	---------------------	---

Command Default	None
------------------------	------

Command Modes	config-rf-profile
----------------------	-------------------

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines	None
-------------------------	------

This example shows how to enable the RF Profile mcs data rate.

```
Switch(config-rf-profile) #rate mcs 5
```

trap threshold

To configure the RF Profile Trap Threshold parameters, use the **trap threshold** command. To revert to default value, use the **no** form of this command.

trap threshold {**clients** |**interference** |**noise** |**utilization** } *value*

Syntax Description	clients	interference	noise	utilization
	Configures the RF Profile Trap for Threshold Clients.			
	<i>value</i>	Number of clients that associate with an access point, after which the trap is sent. The range is between 1 and 200.		
	Configures the RF Profile Trap Threshold for Interference.			
	<i>value</i>	Configures the percentage value for Rf Profile Trap Threshold Interference. The range is between 0 and 100.		
	Configures the RF Profile Trap Threshold for Noise.			
	<i>value</i>	Configures the value for Rf Profile Trap Threshold Noise in dbm. The range is between -127 and 0.		
	Configures the RF Profile Trap Threshold for Utilization.			
	<i>value</i>	Configures the percentage value for RF Profile Trap Threshold Utilization. The range is between 0 and 100.		
Command Default	None			
Command Modes	config-rf-profile			
Command History	Release	Modification		
	Cisco IOS XE Denali 16.3.1 This command was introduced.			
Usage Guidelines	None			
	This example shows how to set the RF Profile Threshold Trap for the clients.			
	<code>Switch(config-rf-profile)#trap threshold clients 10</code>			

tx-power

To configure Tx Power levels, use the **tx-power** command. To revert to default value, use the **no** form of this command.

tx-power { **min** | **max** } *dBm value*

Syntax Description		
	max	Configures maximum Auto-RF transmit power.
	min	Configures maximum Auto-RF transmit power.
	<i>dBm value</i>	Enter value in dBm. The range is between -10 and 30.

Command Default None

Command Modes config-rf-profile

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines None

This example shows how to set the Tx power level to min.

```
Switch(config-rf-profile)#tx-power min -14
```

tx-power v1 threshold

To configure the Transmit Power Control (TPC) version 1 threshold, use the **tx-power v1 threshold** command. To revert to default dBm value, use the **no** form of this command.

tx-power v1 threshold *dBm value*

Syntax Description	<i>dBm value</i>	Transmit Power Control version 1 threshold value. The range is between –80 and –50 dBm.
Command Default	None	
Command Modes	config-rf-profile	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.
Usage Guidelines	None	
	This example shows how to set the TPCv1 threshold to –75dBm.	
	<code>Switch#tx-power v1 threshold -75</code>	

no ap dot11 airtime-fairness policy-name

To delete a AirTime Fairness policy, use the **no ap dot11 airtime-fairness policy-name** command.

no ap dot11 airtime-fairness policy-name *policy-name*

Syntax Description	<i>policy-name</i>	Enter the airtime-fairness policy name
---------------------------	--------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

Usage Guidelines	None
-------------------------	------

This example shows how to delete a AirTime Fairness policy.

```
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch# no ap dot11 airtime-fairness policy-name testpol
```

remote-lan

To configure an remote-lan to an ap group, use the **remote-lan** command. To delete the remote-lan from the ap group, use the **no** form of this command.

remote-lan *name*

Syntax Description	<i>name</i>	Enter the name of the remote-lan
Command Default	None	
Command Modes	config-apgroup	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.
Usage Guidelines	None	

This example shows how to configure an remote-lan to an ap group.

```
Switch(config-apgroup)#remote-lan rlantest
```

rf-profile dot11 24ghz

To assign the RF Profile to the 2.4GHz band AP group, use the **rf-profile dot11 24ghz** command.

rf-profile dot11 24ghz *name*

Syntax Description	<i>name</i>	Enter the name of the RF Profile to be assigned to the current AP group.
---------------------------	-------------	--

Command Default	None
------------------------	------

Command Modes	config-apgroup
----------------------	----------------

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines	None
-------------------------	------

This example shows how to assign the RF Profile to the 2.4GHz band AP group.

```
Switch(config-apgroup)#rf-profile dot11 24ghz doctest
```


rf-profile dot11 5ghz

To assign the RF Profile to the 5GHz band AP group, use the **rf-profile dot11 5ghz** command.

rf-profile dot11 5ghz *name*

Syntax Description	<i>name</i>	Enter the name of the RF Profile to be assigned to the current AP group.
Command Default	None	
Command Modes	config-apgroup	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1 This command was introduced.	
Usage Guidelines	None	

This example shows how to assign the RF Profile to the 5GHz band AP group.

```
Switch(config-apgroup)#rf-profile dot11 24ghz doc5test
```

show ap airtime-fairness ap-group

To view ATF configuration for a specific AP group, use the **show ap airtime-fairness ap-group** command.

show ap airtime-fairness ap-group *group-name*

Syntax Description	<i>group-name</i>	Enter AP-group name
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

This example shows ATF configuration for a specific AP group .

```
Switch#show ap airtime-fairness ap-group ?
Site Description:
Airtime-fairness 2.4GHz Mode:: Disable
Airtime-fairness 2.4GHz Optimization : n/a
Airtime-fairness 5GHz Mode:: Disable
Airtime-fairness 5GHz Optimization : n/a
```

WLAN ID	WLAN Name	Interface	ATF Policy(2.4GHz)	ATF Policy(5GHz)

show ap airtime-fairness (ap)

To view ATF configuration for a specific AP, use the **show ap airtime-fairness** command.

show ap name*ap-name* **airtime-fairness**

Syntax Description	<i>ap-name</i>	Enter access point name
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

This example shows how to view ATF configuration for a specific AP.

```
Switch# show ap name testap airtime-fairness
```

show ap airtime-fairness (per radio)

To view AP list with Air Time Fairness configuration per radio, use the **show ap airtime-fairness** command.

show ap airtime-fairness

Syntax Description	This command has no arguments or keywords.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Privileged EXEC
----------------------	-----------------

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

This example shows AP list with AirTime-Fairness per radio.

```
Switch#show ap airtime-fairness
```

show ap airtime-fairness policy (all)

To view all configured policies, use the **show ap airtime-fairness policy** command.

show ap airtime-fairness policy

Syntax Description	policy	Shows Airtime Fairness policy information
Command Default	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

This example shows all the configured airtime-fairness policies.

```
Switch#show ap airtime-fairness policy
Policy ID   Policy Name   Weight
-----
23          f             10
12          asd           10
13          pol           10
50          meaw         45
20          pocy         10
0           Default      10
```

show ap airtime-fairness wlan

To view the complete list of configured WLANs with Air Time Fairness policies applied, use the **show ap airtime-fairness wlan** command.

show ap airtime-fairness wlan

Syntax Description	wlan	Display airtime-fairness configuration for all wlangs
--------------------	------	---

Command Default	Privileged EXEC
-----------------	-----------------

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

This example shows the complete list of configured WLANs and ATF policies applied.

Switch#**show ap airtime-fairness wlan**

WLAN ID	Profile Name	ATF Profile Name	Weight
12	doctestlan	Default	10

show ap dot11 24ghz

To display the 2.4 GHz RRM parameters, use the **show ap dot11 24ghz** command.

```
show ap dot11 24ghz
{ccx|channel|coverage|group|l2roam|logging|monitor|profile|receiver|summary|txpower}
```

Syntax Description	Parameter	Description
	ccx	Displays the 802.11b CCX information for all Cisco APs.
	channel	Displays the configuration and statistics of the 802.11b channel assignment.
	coverage	Displays the configuration and statistics of the 802.11b coverage.
	group	Displays the configuration and statistics of the 802.11b grouping.
	l2roam	Displays 802.11b l2roam information.
	logging	Displays the configuration and statistics of the 802.11b event logging.
	monitor	Displays the configuration and statistics of the 802.11b monitoring.
	profile	Displays 802.11b profiling information for all Cisco APs.
	receiver	Displays the configuration and statistics of the 802.11b receiver.
	summary	Displays the configuration and statistics of the 802.11b Cisco APs.
	txpower	Displays the configuration and statistics of the 802.11b transmit power control.

Command Default None.

Command Modes Global configuration.

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines None.

This example shows how to display configuration and statistics of the 802.11b coverage.

```
Switch#show ap dot11 24ghz coverage
```

```
Coverage Hole Detection
 802.11b Coverage Hole Detection Mode      : Enabled
 802.11b Coverage Voice Packet Count      : 100 packet(s)
 802.11b Coverage Voice Packet Percentage : 50%
 802.11b Coverage Voice RSSI Threshold    : -80 dBm
 802.11b Coverage Data Packet Count       : 50 packet(s)
 802.11b Coverage Data Packet Percentage  : 50%
 802.11b Coverage Data RSSI Threshold     : -80 dBm
```

```
show ap dot11 24ghz
```

```
802.11b Global coverage exception level      : 25 %  
802.11b Global client minimum exception level : 3 clients
```


show ap dot11 5ghz

To display the 5GHz RRM parameters, use the **show ap dot11 5ghz** command.

```
show ap dot11 5ghz
{ccx|channel|coverage|group|l2roam|logging|monitor|profile|receiver|summary|txpower}
```

Syntax Description	Parameter	Description
	ccx	Displays the 802.11a CCX information for all Cisco APs.
	channel	Displays the configuration and statistics of the 802.11a channel assignment.
	coverage	Displays the configuration and statistics of the 802.11a coverage.
	group	Displays the configuration and statistics of the 802.11a grouping.
	l2roam	Displays 802.11a l2roam information.
	logging	Displays the configuration and statistics of the 802.11a event logging.
	monitor	Displays the configuration and statistics of the 802.11a monitoring.
	profile	Displays 802.11a profiling information for all Cisco APs.
	receiver	Displays the configuration and statistics of the 802.11a receiver.
	summary	Displays the configuration and statistics of the 802.11a Cisco APs.
	txpower	Displays the configuration and statistics of the 802.11a transmit power control.

Command Default None.

Command Modes Global configuration.

Command History	Release	Modification
	Cisco IOS XE 3.3SE	This command was introduced.

Usage Guidelines None.

This example shows configuration and statistics of 802.11a channel assignment.

```
Switch#show ap dot11 5ghz channel
```

```
Automatic Channel Assignment
Channel Assignment Mode      : AUTO
Channel Update Interval    : 12 Hours
Anchor time (Hour of the day) : 20
Channel Update Contribution : SNI..
Channel Assignment Leader   : web (9.9.9.2)
Last Run                    : 16534 seconds ago
DCA Sensitivity Level       : MEDIUM (15 dB)
DCA 802.11n Channel Width  : 40 Mhz
```

```
Channel Energy Levels
  Minimum           : unknown
  Average           : unknown
  Maximum           : unknown
Channel Dwell Times
  Minimum           : unknown
  Average           : unknown
  Maximum           : unknown
802.11a 5 GHz Auto-RF Channel List
Allowed Channel List      : 36,40,44,48,52,56,60,64,149,153,1
                          57,161
Unused Channel List      : 100,104,108,112,116,132,136,140,1
                          65
802.11a 4.9 GHz Auto-RF Channel List
Allowed Channel List      :
Unused Channel List      : 1,2,3,4,5,6,7,8,9,10,11,12,13,14,
                          15,16,17,18,19,20,21,22,23,24,25,26
DCA Outdoor AP option    : Disabled
```

show ap dot11 airtime-fairness (radio bands)

To view AP list with ATF configured radio bands, use the `show ap dot11 airtime-fairness` command.

```
show ap dot11 {24ghz|5ghz} airtime-fairness
```

Syntax Description	24ghz	Show 802.11b configuration
	5ghz	Show 802.11a configuration
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1 This command was introduced.	
Usage Guidelines	None	

This example shows how to view AP list with ATF configured radio bands.

```
Switch#show ap dot 24ghz airtime-fairness
```

show ap dot11 24ghz rf-profile summary

To display the 2.4GHz RF Profiles summary, use the **show ap dot11 24ghz rf-profile summary** command.

show ap dot11 24ghz rf-profile summary

Syntax Description	summary	Show RF Profiles summary.
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.
Usage Guidelines	None	

This example shows the 24GHz AP-Profile summary.

```
Switch(config-rf-profile)#show ap dot11 24ghz rf-profile summaryNumber of RF Profiles : 1
```

RF Profile Name	Band	Description	Applied	State
doctest	2.4 GHz		No	Down

show ap dot11 5ghz rf-profile summary

To display the 5GHz ap RF-Profiles, use the **show ap dot11 5ghz rf-profile summary** command.

show ap dot11 5ghz rf-profile summary

Syntax Description	summary	Show RF Profiles summary.
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.
Usage Guidelines	None	

This example shows how to display the 5GHz ap RF-Profile summary.

```
Switch#show ap dot11 5ghz rf-profile summary
Number of RF Profiles : 1
```

RF Profile Name	Band	Description	Applied	State
doc5test	5 GHz		No	Down

show ap name dot11 airtime-fairness summary

To view the ATF statistics for a specific AP, use the **show ap name dot11 airtime-fairness summary** command.

show ap name *ap-name* dot11 {24ghz|5ghz} airtime-fairness summary

Syntax Description		
	<i>ap-name</i>	Display the stats of 24GHz 5GHz airtime-fairness
	24ghz	Show 802.11b configuration
	5ghz	Show 802.11a configuration

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

Usage Guidelines None

This example shows how to view the ATF statistics for a specific AP.

```
Switch#show ap ame testap dot11 24ghz airtime-fairness summary
```

show ap name dot11 airtime-fairness policy statistics

To view statistics for each ATF policy, use the `show ap name dot11 airtime-fairness policy statistics` command.

`show ap name ap-name dot11 {24ghz|5hz} airtime-fairness policy policy-name statistics`

Syntax Description	<i>ap-name</i>	Enter access point name
	24ghz	Show 802.11b configuration
	5hz	Show 802.11a configuration
	<i>policy-name</i>	Enter policy name
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1	This command was introduced.

This example shows how to view statistics for each ATF policy.

```
Switch#show ap name testap dot11 24ghz airtime-fairness policy testpolicy statistics
```

show ap name dot11 airtime-fairness wlan name statistics

To view ATF statistics per WLAN active on specific AP, use the **show ap name dot11 airtime-fairness wlan name statistics** command.

show ap name dot11 {24ghz|5ghz} airtime-fairness wlan name *wlan-name* statistics

Syntax Description	name	Display airtime-fairness stats by profile name
	<i>wlan-name</i>	Enter WLAN name
	statistics	Display the stats of 24GHz 5GHz airtime-fairness
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Denali 16.2.1 This command was introduced.	

This example shows how to view ATF statistics per WLAN active on specific AP.

```
Switch#show ap name testap dot11 24ghz airtime-fairness wlan name testwlan statistics
```


show ap rf-profile summary

To display the ap RF-Profile summary, use the **show ap rf-profile summary** command.

show ap rf-profile summary

Syntax Description	summary	Show summary of RF Profiles
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.
Usage Guidelines	None	

This example shows how to display the ap RF-Profile summary .

```
Switch#show ap rf-profile summary
Number of RF Profiles : 1
```

RF Profile Name	Band	Description	Applied	State
doctest	2.4 GHz		No	Down

show ap rf-profile name

To display the selected ap RF-Profile details, use the **show ap rf-profile name** command.

show ap rf-profile name *profile-name* **detail**

Syntax Description		
	<i>profile-name</i>	Name of the RF-Profile.
	detail	Show detail of selected RF Profile.

Command Default None

Command Modes Privileged EXEC

Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.

Usage Guidelines None

This example shows how to display the details of the selected RF-Profile.

```
Switch#show ap rf-profile name doctest detail
Description :
AP Group Names :
RF Profile Name : doctest
Band : 2.4 GHz
802.11n client only : Disabled
Transmit Power Threshold v1: -70 dBm
Min Transmit Power: -10 dBm
Max Transmit Power: 30 dBm
Operational Rates
 802.11b 1M Rate : Mandatory
 802.11b 2M Rate : Mandatory
 802.11b 5.5M Rate : Mandatory
 802.11b 11M Rate : Mandatory
 802.11b 6M Rate : Mandatory
 802.11b 9M Rate : Supported
 802.11b 12M Rate : Supported
 802.11b 18M Rate : Supported
 802.11b 24M Rate : Supported
 802.11b 36M Rate : Supported
 802.11b 48M Rate : Supported
 802.11b 54M Rate : Supported
Max Clients : 200
Wlan name                               Max Clients
-----
Trap Threshold
  Clients: 12 clients
  Interference: 10%
  Noise: -70 dBm
  Utilization: 80%
Multicast Data Rate: auto
Rx SOP Threshold : auto
Band Select
```

```
Probe Response: Disabled
Cycle Count: 2 cycles
Cycle Threshold: 200 milliseconds
Expire Suppression: 20 seconds
Expire Dual Band: 60 seconds
Client RSSI: -80 dBm
Client Mid RSSI: -80 dBm
Load Balancing
Window: 5 clients
Denial: 3 count
Coverage Data
Data: -80 dBm
Voice: -80 dBm
Minimum Client Level: 3 clients
Exception Level: 25%
DCA Channel List : 1,5,9,13
DCA Foreign AP Contribution : Enabled
802.11n MCS Rates
MCS 0 : Enabled
MCS 1 : Enabled
MCS 2 : Enabled
MCS 3 : Enabled
MCS 4 : Enabled
MCS 5 : Enabled
MCS 6 : Enabled
MCS 7 : Enabled
MCS 8 : Enabled
MCS 9 : Enabled
MCS 10 : Enabled
MCS 11 : Enabled
MCS 12 : Enabled
MCS 13 : Enabled
MCS 14 : Enabled
MCS 15 : Enabled
MCS 16 : Enabled
MCS 17 : Enabled
MCS 18 : Enabled
MCS 19 : Enabled
MCS 20 : Enabled
MCS 21 : Enabled
MCS 22 : Enabled
MCS 23 : Enabled
MCS 24 : Enabled
MCS 25 : Enabled
MCS 26 : Enabled
MCS 27 : Enabled
MCS 28 : Enabled
MCS 29 : Enabled
MCS 30 : Enabled
MCS 31 : Enabled
State : Down
```

show wireless mobility controller ap

To display the list of access points which have joined the sub-domain, use the **wireless mobility controller ap** command.

show wireless mobility controller ap

Syntax Description	ap	Show joined Access Point in sub-domain.
Command Default	None	
Command Modes	Privileged EXEC	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.
Usage Guidelines	None	

This example shows how to list the access points which have joined the sub-domain.

```
Switch#show wireless mobility controller ap
Number of AP entries in the sub-domain      : 2
```

AP name	AP radio MAC	Controller IP	Location
bos2kk	00f2.8c42.f520	default-group	default-group
IosAP1	34ed.522f.7e60	default-group	default-group

shutdown

To close the RF Profile and disable the network, use the **shutdown** command. To disable shutdown execution, use the **no** form of this command.

shutdown

Syntax Description	shutdown	Shuts down the profile and disables network.
Command Default	None	
Command Modes	config-rf-profile	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.
Usage Guidelines	None	
	This example shows how to close a RF Profile and disable the network.	
	<code>Switch(config-rf-profile)#shutdown</code>	

wlan

To configure an WLAN to an ap group, use the **wlan** command. To delete the WLAN from the ap group, use the **no** form of this command.

wlan *wlan-name*

Syntax Description	<i>wlan-name</i>	Enter the name of the WLAN to be configured to an AP group.
Command Default	None	
Command Modes	config-apgroup	
Command History	Release	Modification
	Cisco IOS XE Denali 16.3.1	This command was introduced.
Usage Guidelines	None	
	This example shows how to configure an WLAN to an ap group.	
	Switch(config-apgroup)# wlan docwlan	