



## INDEX

---

### Numerics

- 10/100/1000 ports
  - cable lengths [2-4, B-6](#)
  - connecting to [2-38, B-43](#)
  - described [1-6](#)
- 10/100 ports
  - cable lengths [2-4, B-6](#)
  - connecting to [2-38, B-43](#)
  - described [1-6](#)
- 1000BASE-T ports [C-6](#)
- 100BASE-FX ports
  - cable lengths [2-4, B-6](#)
  - cable specifications [C-5](#)
  - connecting to [2-45, B-50](#)
  - described [1-6](#)

---

### A

- AC/DC power converter, connecting to [2-46 to 2-55, B-51 to B-61](#)
- AC power supply, connecting to [2-55](#)
- adapter pinouts, terminal
  - RJ-45-to-DB-25 [C-9](#)
  - RJ-45-to-DB-9 [C-8](#)
- adding modules to the switch [B-8](#)
- airflow, required clearance [2-4, B-7](#)
- alarm relay connections
  - connection procedures [2-35 to 2-37, B-40 to B-42](#)
  - power and relay connector [1-7](#)
- altitude [A-2 to A-3](#)
- auto-MDIX [1-6, 2-38, B-43, C-1, C-4](#)
- autonegotiation [1-6](#)

---

### C

- cables
  - crossover
    - four twisted-pair pinout, 1000BASE-T ports [C-6, C-8](#)
    - identifying [C-7](#)
    - two twisted-pair pinout, 10/100 ports [C-5](#)
    - using [C-1](#)
  - optical [C-5](#)
  - SFP module [C-4](#)
  - straight-through
    - four twisted-pair pinout, 1000BASE-T ports [C-6, C-7](#)
    - two twisted-pair pinout [C-5](#)
    - using [C-1](#)
- cabling
  - 10/100/1000 ports [2-38, B-43](#)
  - 10/100 ports [1-6](#)
  - auto-MDIX [1-6, 2-38, B-43, C-1, C-4](#)
  - pinouts [C-5](#)
  - See also connectors and cables
  - Cisco IOS command-line interface [1-18](#)
  - Cisco IP Phones, connecting to [2-38, B-43](#)
  - Cisco Network Assistant [1-17](#)
  - CiscoView [1-18](#)
  - clearance [2-4, B-7](#)
  - CLI [1-18](#)
  - command-line interface
    - See CLI
  - compact flash memory card
    - installing, removing [2-12, B-15](#)
    - overview [1-13](#)

## connecting

- to 10/100/1000 ports [2-38, B-43](#)
- to 100BASE-FX ports [2-45, B-50](#)
- to console port [2-14 to 2-15, B-17 to B-18](#)
- to DC power [2-18 to 2-24, B-21 to B-27](#)
- to external alarm devices [2-35 to 2-37, B-40 to B-42](#)
- to modules [2-10, B-13](#)
- to PC [2-14 to 2-15, B-17 to B-18](#)
- to power converter [2-46 to 2-55, B-51 to B-61](#)
- to power supply [2-55, B-61](#)
- to SFP modules [2-42 to 2-43, B-47 to B-48](#)
- to terminal [2-14 to 2-15, B-17 to B-18](#)

## connectors and cables

- 10/100/1000 [C-1 to C-2](#)
- console [C-4 to C-9](#)
- dual-purpose [C-4](#)
- SC connectors [C-3](#)
- SFP module ports [C-3](#)

## console port

- connecting to [2-14 to 2-15, B-17 to B-18](#)
- default characteristics [2-14, B-17](#)
- described [1-7](#)
- specifications [C-4 to C-9](#)

crossover cable [C-7](#)

## pinout

- four twisted-pair, 1000BASE-T ports [C-6, C-8](#)

**D**

- DC power, connecting to [2-18 to 2-24, B-21 to B-27](#)
- default characteristics of the console port [2-14, B-17](#)
- device manager
  - described [1-17](#)
  - to configure switch [2-58, B-65](#)
- diagnosing problems [3-1](#)
- dimensions [A-2 to A-3](#)

## dual-purpose ports

- connectors and cables [C-4](#)
- described [1-6](#)
- LEDs [1-13](#)
- duplex, troubleshooting [3-4](#)

**E**

- electrical noise, avoiding [2-4, B-7](#)
- environmental ranges [A-3](#)
- environmental temperatures [A-2](#)
- ESD, requirements [2-3, B-6](#)
- Ethernet and fiber cable troubleshooting [3-2](#)
- exposed DC power wire warning [2-19, 2-54, B-23, B-60](#)

**F**

- fiber-optic cables [C-3](#)
- front panel
  - 10/100 ports [1-6](#)
  - clearance [2-4, B-7](#)
  - console port [1-7](#)
  - described [1-2](#)
  - dual-purpose ports [1-6](#)
  - illustrated [1-3 to 1-4](#)
  - LEDs [1-7 to 1-13](#)
  - power and relay connector [1-7](#)
  - SFP module ports [1-6](#)
- functional ground lug warning [2-16, B-19](#)

**G**

- grounding procedures [2-15 to 2-17, B-19 to B-21](#)

---

**H**

## hazardous location

- attaching the power and relay connectors [B-26](#)
- connecting modules to the switch [B-5](#)
- connecting power and alarm circuits [B-38](#)
- connecting the ports [B-43](#)
- connecting the power convertor [B-51](#)
- grounding the switch [B-19](#)
- installation guidelines [B-5](#)
- installing compact flash memory card [B-5](#)
- installing the switch [B-28](#)
- running POST [B-27](#)

## hazardous location warnings

- ambient temperature [B-3](#)
- console cable [B-3](#)
- DC power [B-3](#)
- disconnecting the console cable [B-3](#)
- disconnecting the power and relay connector [B-3](#)
- disconnecting the wiring [B-4](#)
- nonhazardous area for installation [B-4](#)
- power and relay connector [B-3](#), [B-26](#)
- substitution of components [B-4](#)

HP OpenView [1-18](#)humidity [A-2](#)


---

**I**
IE-3000-4TC switch, illustrated [1-3](#)IE-3000-8TC switch, illustrated [1-3](#)IEM-3000-4SM module, illustrated [1-5](#)IEM-3000-8FM module, illustrated [1-4](#)IEM-3000-8SM module, illustrated [1-5](#)IEM-3000-8TM module, illustrated [1-4](#)industrial environment warning [B-4](#)

## installation

- assigning the IP address [D-2](#)
- attach the power and relay connector [2-23](#), [B-26](#)
- compact flash memory card [B-15](#)

DIN rail [2-26](#), [B-29](#)grounding procedures [2-15 to 2-17](#), [B-19 to B-21](#)guidelines [2-3](#), [B-5](#)hazardous location [B-1](#)package contents [2-5](#), [B-7](#)POST [2-24](#), [B-27](#)pre-installation information and guidelines [2-1 to 2-4](#), [B-1 to B-7](#)rack-mount [2-31 to 2-33](#), [B-35 to B-37](#)required clearance [2-4](#), [B-7](#)SFP modules [2-40 to 2-41](#), [B-45 to B-46](#)starting the terminal emulation software [D-1](#)verifying switch operation [2-13 to 2-24](#), [B-16 to B-27](#)wall [2-29](#), [B-29](#)wiring the relays [2-35 to 2-37](#), [B-40 to B-42](#)


---

**J**
jewelry removal warning [2-2](#), [B-2](#)


---

**L**

## LEDs

100BASE-FX ports [1-12](#)100BASE-X SFP [1-13](#)alarm [1-11](#)dual-purpose port [1-13](#)front panel [1-7 to 1-13](#)port status [1-12](#)POST results [3-1](#)power status [1-11](#)setup [1-10](#)system [1-11](#)troubleshooting with [3-2](#)lightning activity warning [2-2](#), [B-2](#)link status troubleshooting [3-3](#)

**M**

management options [1-17 to 1-18](#)

module

configurations [2-6, B-9](#)

connecting [2-10, B-13](#)

mounting

rack [2-31 to 2-33, B-35 to B-37](#)

MT-RJ connector [C-3](#)

See also 100BASE-FX ports

**N**

Network Assistant [2-58, B-65](#)

noise, electrical [2-4, B-7](#)

**O**

operating temperature [A-1](#)

**P**

patch cables, MT-RJ [2-5, B-8](#)

PC, connecting to switch [2-14 to 2-15, B-17 to B-18](#)

physical dimensions [A-2 to A-3](#)

pinouts [C-6](#)

10/100 ports [C-3](#)

adapters [C-7](#)

console port [C-9](#)

crossover cable [C-7](#)

crossover cables

four twisted-pair, 1000BASE-T ports [C-6, C-8](#)

two twisted-pair 10/100 ports [C-5](#)

RJ-45-to-DB-25 terminal adapter [C-9](#)

RJ-45-to-DB-9 terminal adapter [C-8](#)

SFP module [C-3](#)

straight-through cables

four twisted-pair 1000BASE-T ports [C-6, C-7](#)

two twisted-pair [C-5](#)

port and interface troubleshooting [3-3](#)

port connection procedures [2-38 to 2-46, B-43 to B-51](#)

ports

10/100/1000 [1-6, 1-13](#)

100BASE-FX

LEDs [1-12](#)

dual-purpose [1-6, 2-43 to 2-44, B-48 to B-49](#)

See 10/100 ports, 10/100/1000 ports, 100BASE-FX ports, 100BASE-LX ports, and console ports

POST

description [2-24, 2-55, 3-1, B-27, B-61](#)

LEDs [3-1](#)

results [2-24, 2-55, 3-1, B-27, B-61](#)

running at power on [3-1](#)

power

connecting to

AC [2-49, 2-56, B-55, B-63](#)

DC [2-18 to 2-24, B-21 to B-27](#)

requirements [A-2 to A-3](#)

power and alarm circuits

connecting [B-38](#)

sealed relay device [B-39](#)

power and relay connector

connecting to the switch [2-23, B-26](#)

described [1-7](#)

power converter

connecting the DC power clip [2-49, B-54](#)

described [1-15](#)

specifications [A-3](#)

power converter, connecting to

AC/DC [2-46 to 2-55, B-51 to B-61](#)

power on [2-24, B-27](#)

power supply

connecting the DC power clip [2-56, B-62](#)

power supply, connecting to

AC [2-55, B-61](#)

## procedures

- connecting to AC/DC power source [2-46 to 2-55, B-51 to B-61](#)
- connecting to AC power source [2-55, B-61](#)
- connecting to DC power [2-18 to 2-24, B-21 to B-27](#)
- installation [2-31 to 2-33, B-35 to B-37](#)
- port connection [2-38 to 2-46, B-43 to B-51](#)
- power on [2-24, B-27](#)

**R**

rack-mounting, procedures [2-31 to 2-33, B-35 to B-37](#)

rear panel, clearance [2-4, B-7](#)

## relays

- connecting to power and relay connector [1-7](#)
- described [1-7](#)
- wiring [2-35 to 2-37, B-40 to B-42](#)

removing SFP modules [2-41 to 2-42, B-46 to B-47](#)

removing the switch from a DIN rail or a rack [2-33 to 2-34, B-37 to B-38](#)

removing the switch from parallel and face-down mounted positions [2-33 to 2-34, B-37 to B-38](#)

RJ-45 connector, console port [C-4](#)

**S**

safety warnings [2-2 to 2-4, B-2 to B-4](#)

SC connector [C-3](#)

serial number location [3-6](#)

## SFP modules

- bale-clasp latch removal [2-41, B-46](#)
- cables [C-4](#)
- connecting to [2-42 to 2-43, B-47 to B-48](#)
- connectors [C-3](#)
- described [1-6](#)
- installation [2-40 to 2-41, B-45 to B-46](#)

Simple Network Management Protocol

See SNMP

SNMP [1-18](#)

software switch management [1-17 to 1-18](#)

specifications [A-1 to A-2](#)

speed, troubleshooting [3-4](#)

straight-through cable

pinout

four twisted-pair 1000BASE-T ports [C-6](#)

two twisted-pair 10/100 ports [C-5](#)

straight-through cable pinout

four twisted-pair 1000BASE-T ports [C-7](#)

SunNet Manager [1-18](#)

supply wires warning [B-3, B-59](#)

switch, power-on [2-24, B-27](#)

switch models [1-2](#)

system LED [1-11](#)

**T**

technical specifications [A-1 to A-2](#)

Telnet, and accessing the CLI [1-18](#)

temperature, operating [A-3](#)

terminal, connecting to a switch [2-14 to 2-15, B-17 to B-18](#)

terminal-emulation software [2-14, B-17](#)

## troubleshooting

bad or damaged cable [3-2](#)

connection problems [3-2](#)

diagnosing problems [3-1](#)

Ethernet and fiber cables [3-2](#)

link status [3-3](#)

ping end device [3-3](#)

port and interface settings [3-3](#)

POST [3-1](#)

serial number location [3-6](#)

spanning tree loops [3-4](#)

speed, duplex, and autonegotiation [3-4](#)

switch performance [3-4](#)

understanding POST results [3-1](#)

with LEDs [3-2](#)

troubleshooting spanning tree loops [3-4](#)

---

## V

- verifying package contents [2-5, B-7](#)
- verifying switch operation [2-13 to 2-24, B-16 to B-27](#)

---

## W

### warnings

- airflow restriction [2-3](#)
- ambient temperature [2-3](#)
- DC power [2-2](#)
- functional ground lug [2-16, B-19](#)
- industrial environment [B-4](#)
- installation [2-2 to 2-4, B-2 to B-4](#)
- jewelry removal [2-2, B-2](#)
- lightning activity [2-2, B-2](#)
- national laws and regulations [2-2](#)
- qualified personnel [2-2, B-2](#)
- restricted access areas [2-2, B-2](#)
- supply wires [B-3, B-59](#)
- wiring the relays [2-35 to 2-37, B-40 to B-42](#)