



# Configuring Settings for Faults, Events, and Logs

This chapter includes the following sections:

- [Configuring Settings for the Fault Collection Policy, page 1](#)
- [Configuring Fault Suppression, page 3](#)
- [Configuring Settings for the Core File Exporter, page 15](#)
- [Configuring the Syslog, page 17](#)
- [Viewing the Audit Logs, page 20](#)

## Configuring Settings for the Fault Collection Policy

### Global Fault Policy

The global fault policy controls the lifecycle of a fault in a Cisco UCS domain, including when faults are cleared, the flapping interval (the length of time between the fault being raised and the condition being cleared), and the retention interval (the length of time a fault is retained in the system).

A fault in Cisco UCS has the following lifecycle:

- 1 A condition occurs in the system and Cisco UCS Manager raises a fault. This is the active state.
- 2 When the fault is alleviated, it enters a flapping or soaking interval that is designed to prevent flapping. Flapping occurs when a fault is raised and cleared several times in rapid succession. During the flapping interval, the fault retains its severity for the length of time specified in the global fault policy.
- 3 If the condition reoccurs during the flapping interval, the fault returns to the active state. If the condition does not reoccur during the flapping interval, the fault is cleared.
- 4 The cleared fault enters the retention interval. This interval ensures that the fault reaches the attention of an administrator even if the condition that caused the fault has been alleviated and the fault has not been deleted prematurely. The retention interval retains the cleared fault for the length of time specified in the global fault policy.
- 5 If the condition reoccurs during the retention interval, the fault returns to the active state. If the condition does not reoccur, the fault is deleted.

## Configuring the Global Fault Policy

### Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, expand **All > Faults, Events, and Audit Log**.
- Step 3** Click **Settings**.
- Step 4** In the **Work** pane, click the **Global Fault Policy** tab.
- Step 5** In the **Global Fault Policy** tab, complete the following fields:

Name	Description
<b>Flapping Interval</b> field	<p>Flapping occurs when a fault is raised and cleared several times in rapid succession. To prevent this, Cisco UCS Manager does not allow a fault to change its state until this amount of time has elapsed since the last state change.</p> <p>If the condition reoccurs during the flapping interval, the fault returns to the active state. If the condition does not reoccur during the flapping interval, the fault is cleared. What happens at that point depends on the setting in the <b>Clear Action</b> field.</p> <p>Enter an integer between 5 and 3,600. The default is 10.</p>
<b>Initial Severity</b> field	<p>This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Info</b></li> <li>• <b>Condition</b></li> <li>• <b>Warning</b></li> </ul>
<b>Action on Acknowledgment</b> field	<p>Acknowledged actions are always deleted when the log is cleared. This option cannot be changed.</p>
<b>Clear Action</b> field	<p>The action Cisco UCS Manager takes when a fault is cleared. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Retain</b>—Cisco UCS Manager GUI displays the <b>Length of time to retain cleared faults</b> section.</li> <li>• <b>Delete</b>—Cisco UCS Manager immediately deletes all fault messages as soon as they are marked as cleared.</li> </ul>
<b>Clear Interval</b> field	<p>Whether Cisco UCS Manager automatically clears faults after a certain length of time. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Never</b>—Cisco UCS Manager does not automatically clear any faults.</li> <li>• <b>other</b>—Cisco UCS Manager GUI displays the <b>dd:hh:mm:ss</b> field.</li> </ul>

Name	Description
<b>dd:hh:mm:ss</b> field	The number of days, hours, minutes, and seconds that should pass before Cisco UCS Manager automatically marks that fault as cleared. What happens then depends on the setting in the <b>Clear Action</b> field.
<b>Length of Time to Retain Cleared Faults Section</b>	
<b>Retention Interval</b> field	If the <b>Clear Action</b> field is set to <b>Retain</b> , this is the length of time Cisco UCS Manager retains a fault once it is marked as cleared. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Forever</b>—Cisco UCS Manager leaves all cleared fault messages on the fabric interconnect regardless of how long they have been in the system.</li> <li>• <b>other</b>—Cisco UCS Manager GUI displays the <b>dd:hh:mm:ss</b> field.</li> </ul>
<b>dd:hh:mm:ss</b> field	The number of days, hours, minutes, and seconds that should pass before Cisco UCS Manager deletes a cleared fault message.

**Step 6** Click **Save Changes**.

## Configuring Fault Suppression

### Fault Suppression

Fault suppression allows you to suppress SNMP trap and Call Home notifications during a planned maintenance time. You can create a fault suppression task to prevent notifications from being sent whenever a transient fault is raised or cleared.

Faults remain suppressed until the time duration has expired, or the fault suppression tasks have been manually stopped by the user. After the fault suppression has ended, Cisco UCS Manager will send notifications for any outstanding suppressed faults that have not been cleared.

Fault suppression uses the following:

#### Fixed Time Intervals or Schedules

You can use the following to specify the maintenance window during which you want to suppress faults.

- Fixed time intervals allow you to create a start time and a duration when fault suppression is active. Fixed time intervals cannot be reused.
- Schedules are used for one time occurrences or recurring time periods and can be saved and reused.

### Suppression Policies

These policies define which causes and types of faults you want to suppress. Only one policy can be assigned to a task. The following policies are defined by Cisco UCS Manager:

- **default-chassis-all-maint**—Suppresses faults for the chassis and all components installed into the chassis, including all servers, power supplies, fan modules, and IOMs.  
This policy applies only to chassis.
- **default-chassis-phys-maint**—Suppresses faults for the chassis and all fan modules and power supplies installed into the chassis.  
This policy applies only to chassis.
- **default-fex-all-maint**—Suppresses faults for the FEX and all power supplies, fan modules, and IOMs in the FEX.  
This policy applies only to FEXes.
- **default-fex-phys-maint**—Suppresses faults for the FEX and all fan modules and power supplies in the FEX.  
This policy applies only to FEXes.
- **default-server-maint**—Suppresses faults for servers.  
This policy applies to chassis, organizations, and service profiles.




---

**Note** When applied to a chassis, only servers are affected.

---

- **default-iom-maint**—Suppresses faults for IOMs in a chassis or FEX.  
This policy applies only to chassis, FEXes, and IOMs.




---

**Important** FEX and IO Modules are not supported by Cisco UCS M-Series Servers.

---

### Suppression Tasks

You can use these tasks to connect the schedule or fixed time interval and the suppression policy to a component.




---

**Note** After you create a suppression task, you can edit the fixed time interval or schedule of the task in both the Cisco UCS Manager GUI and Cisco UCS Manager CLI. However, you can only change between using a fixed time interval and using a schedule in the Cisco UCS Manager CLI.

---

## Viewing Suppressed Faults

### Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, expand **All > Faults, Events, and Audit Log**.
- Step 3** Click **Faults**.
- Step 4** In the **Work** pane, choose the **suppressed** icon in the **Show:** field.  
To view only the suppressed faults, deselect the other icons in the **Show:** field.

## Configuring Fault Suppression for a Chassis

### Configuring Fault Suppression Tasks for a Chassis

#### Procedure

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment > Chassis**.
- Step 3** Click the chassis for which you want to create a fault suppression task.
- Step 4** In the **Work** pane, click the **General** tab.
- Step 5** In the **Actions** area, click **Start Fault Suppression**.  
**Tip** To configure fault suppression tasks for multiple chassis, use the Ctrl key to select multiple chassis in the **Navigation** pane. Right-click one of the selected chassis and choose **Start Fault Suppression**.
- Step 6** In the **Start Fault Suppression** dialog box, complete the following fields:

<b>Name</b> field	The name of the fault suppression task.  This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters other than - (hyphen), _ (underscore), : (colon), and . (period), and you cannot change this name after the object has been saved.
-------------------	--

<b>Select Fixed Time Interval/Schedule field</b>	<p>When the fault suppression task will run. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Fixed Time Interval</b>—Choose this option to specify the start time and duration for the fault suppression task. Specify the day and time the fault suppression task should start in the <b>Start Time</b> field. Click the down arrow at the end of this field to select the start time from a pop-up calendar. Specify the length of time this task should run in the <b>Task Duration</b> field. To specify that this task should run until it is manually stopped, enter 00:00:00:00 in this field.</li> <li>• <b>Schedule</b>—Choose this option to configure the start time and duration using a pre-defined schedule. Choose the schedule from the <b>Schedule</b> drop-down list. To create a new schedule, click <b>Create Schedule</b>.</li> </ul>
<b>Policy drop-down list</b>	<p>Choose the suppression policy from the drop-down list:</p> <ul style="list-style-type: none"> <li>• <b>default-chassis-all-maint</b>—Suppresses faults for the chassis and all components installed into the chassis, including all servers, power supplies, fan modules, and IOMs.</li> <li>• <b>default-chassis-phys-maint</b>—Suppresses faults for the chassis and all fan modules and power supplies installed into the chassis.</li> <li>• <b>default-server-maint</b>—Suppresses faults for servers. <b>Note</b> When applied to a chassis, only servers are affected.</li> <li>• <b>default-iom-maint</b>—Suppresses faults for IOMs in a chassis or FEX.</li> </ul> <p><b>Important</b> FEX and IO Modules are not supported by Cisco UCS M-Series Servers.</p>

**Step 7** Click **OK**.

## Deleting Fault Suppression Tasks for a Chassis

This procedure deletes all fault suppression tasks for a chassis. To delete individual tasks, use the **Delete** button on the **Suppression Tasks** dialog box. See [Viewing Fault Suppression Tasks for a Chassis](#), on page 7.

### Procedure

---

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
  - Step 2** On the **Equipment** tab, expand **Equipment > Chassis**.
  - Step 3** Click the chassis for which you want to delete all fault suppression tasks.
  - Step 4** In the **Work** pane, click the **General** tab.
  - Step 5** In the **Actions** area, click **Stop Fault Suppression**.
    - Tip** To delete fault suppression tasks for multiple chassis, use the Ctrl key to select multiple chassis in the **Navigation** pane. Right-click one of the selected chassis and choose **Stop Fault Suppression**.
  - Step 6** If the Cisco UCS Manager GUI displays a confirmation dialog box, click **Yes**.
- 

## Viewing Fault Suppression Tasks for a Chassis

### Procedure

---

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
  - Step 2** On the **Equipment** tab, expand **Equipment > Chassis**.
  - Step 3** Click the chassis for which you want to view fault suppression task properties.
  - Step 4** In the **Work** pane, click the **General** tab.
  - Step 5** In the **Actions** area, click **Suppression Task Properties**.  
In the **Suppression Tasks** dialog box, you can add new fault suppression tasks, delete existing fault suppression tasks, or modify existing fault suppression tasks.
- 

## Configuring Fault Suppression for a Shared Adapter

### Configuring Fault Suppression Tasks for a Shared Adapter

#### Procedure

---

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment > Chassis > Chassis Number > Shared Adapter**
- Step 3** Click the shared adapter for which you want to create a fault suppression task.
- Step 4** In the **Work** pane, click the **General** tab.
- Step 5** In the **Actions** area, click **Start Fault Suppression**.
- Step 6** In the **Start Fault Suppression** dialog box, complete the following fields:

<b>Name field</b>	<p>The name of the fault suppression task.</p> <p>This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters other than - (hyphen), _ (underscore), : (colon), and . (period), and you cannot change this name after the object has been saved.</p>
<b>Select Fixed Time Interval/Schedule field</b>	<p>When the fault suppression task will run. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Fixed Time Interval</b>—Choose this option to specify the start time and duration for the fault suppression task. <p>Specify the day and time the fault suppression task should start in the <b>Start Time</b> field. Click the down arrow at the end of this field to select the start time from a pop-up calendar.</p> <p>Specify the length of time this task should run in the <b>Task Duration</b> field. To specify that this task should run until it is manually stopped, enter 00:00:00:00 in this field.</p> </li> <li>• <b>Schedule</b>—Choose this option to configure the start time and duration using a pre-defined schedule. <p>Choose the schedule from the <b>Schedule</b> drop-down list. To create a new schedule, click <b>Create Schedule</b>.</p> </li> </ul>
<b>Policy drop-down list</b>	<p>The following suppression policy is selected by default:</p> <ul style="list-style-type: none"> <li>• <b>default-iom-maint</b>—Suppresses faults for IOMs in a chassis or FEX.</li> </ul>

**Step 7** Click **OK**.

---

## Deleting Fault Suppression Tasks for a Shared Adapter

This procedure deletes all fault suppression tasks for a shared adapter. To delete individual tasks, use the **Delete** button on the **Suppression Tasks** dialog box. See [Viewing Fault Suppression Tasks for an IOM](#).

### Procedure

---

- Step 1** In the **Navigation** pane, click the **Equipment** tab.
  - Step 2** On the **Equipment** tab, expand **Equipment > Chassis > Chassis Number > Shared Adapter**
  - Step 3** Click the shared adapter for which you want to delete all fault suppression tasks.
  - Step 4** In the **Work** pane, click the **General** tab.
  - Step 5** In the **Actions** area, click **Stop Fault Suppression**.
  - Step 6** If the Cisco UCS Manager GUI displays a confirmation dialog box, click **Yes**.
-



## Viewing Fault Suppression Tasks for a Shared Adapter

### Procedure

- 
- Step 1** In the **Navigation** pane, click the **Equipment** tab.
  - Step 2** On the **Equipment** tab, expand **Equipment > Chassis > Chassis Number > Shared Adapter**
  - Step 3** Click the shared adapter for which you want to view fault suppression task properties.
  - Step 4** In the **Work** pane, click the **General** tab.
  - Step 5** In the **Actions** area, click **Suppression Task Properties**.  
In the **Suppression Tasks** dialog box, you can add new fault suppression tasks, delete existing fault suppression tasks, or modify existing fault suppression tasks.
- 

## Configuring Fault Suppression for a Server

### Configuring Fault Suppression Tasks for a Server

#### Procedure

- 
- Step 1** In the **Navigation** pane, click the **Equipment** tab.
  - Step 2** On the **Equipment** tab, expand **Equipment > Chassis > Chassis Number > Cartridges > Cartridge Number > Servers**
  - Step 3** Click the server for which you want to create a fault suppression task.
  - Step 4** In the **Work** pane, click the **General** tab.
  - Step 5** In the **Actions** area, click **Start Fault Suppression**.  
**Tip** To configure fault suppression tasks for multiple servers, use the Ctrl key to select multiple servers in the **Navigation** pane. Right-click one of the selected servers and choose **Start Fault Suppression**.
  - Step 6** In the **Start Fault Suppression** dialog box, complete the following fields:

<b>Name</b> field	The name of the fault suppression task.  This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters other than - (hyphen), _ (underscore), : (colon), and . (period), and you cannot change this name after the object has been saved.
-------------------	--

<b>Select Fixed Time Interval/Schedule field</b>	<p>When the fault suppression task will run. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Fixed Time Interval</b>—Choose this option to specify the start time and duration for the fault suppression task.</li> </ul> <p>Specify the day and time the fault suppression task should start in the <b>Start Time</b> field. Click the down arrow at the end of this field to select the start time from a pop-up calendar.</p> <p>Specify the length of time this task should run in the <b>Task Duration</b> field. To specify that this task should run until it is manually stopped, enter 00:00:00:00 in this field.</p> <ul style="list-style-type: none"> <li>• <b>Schedule</b>—Choose this option to configure the start time and duration using a pre-defined schedule.</li> </ul> <p>Choose the schedule from the <b>Schedule</b> drop-down list. To create a new schedule, click <b>Create Schedule</b>.</p>
<b>Policy drop-down list</b>	<p>The following suppression policy is selected by default:</p> <ul style="list-style-type: none"> <li>• <b>default-server-maint</b>—Suppresses faults for servers.</li> </ul>

**Step 7** Click **OK**.

## Deleting Fault Suppression Tasks for a Server

This procedure deletes all fault suppression tasks for a server. To delete individual tasks, use the **Delete** button on the **Suppression Tasks** dialog box.

### Procedure

- 
- Step 1** In the **Navigation** pane, click the **Equipment** tab.
- Step 2** On the **Equipment** tab, expand **Equipment > Chassis > Chassis Number > Cartridges > Cartridge Number > Servers**
- Step 3** Click the server for which you want to delete all fault suppression tasks.
- Step 4** In the **Work** pane, click the **General** tab.
- Step 5** In the **Actions** area, click **Stop Fault Suppression**.
- Tip** To delete fault suppression tasks for multiple servers, use the Ctrl key to select multiple servers in the **Navigation** pane. Right-click one of the selected servers and choose **Stop Fault Suppression**.
- Step 6** If the Cisco UCS Manager GUI displays a confirmation dialog box, click **Yes**.
-

## Viewing Fault Suppression Tasks for a Server

### Procedure

- 
- Step 1** In the **Navigation** pane, click the **Equipment** tab.
  - Step 2** On the **Equipment** tab, expand **Equipment > Chassis > Chassis Number > Cartridges > Cartridge Number > Servers**
  - Step 3** Click the server for which you want to view fault suppression task properties.
  - Step 4** In the **Work** pane, click the **General** tab.
  - Step 5** In the **Actions** area, click **Suppression Task Properties**.  
In the **Suppression Tasks** dialog box, you can add new fault suppression tasks, delete existing fault suppression tasks, or modify existing fault suppression tasks.
- 

## Configuring Fault Suppression for a Service Profile

### Configuring Fault Suppression Tasks for a Service Profile

#### Procedure

- 
- Step 1** In the **Navigation** pane, click the **Servers** tab.
  - Step 2** On the **Servers** tab, expand **Servers > Service Profiles**.
  - Step 3** Click the service profile for which you want to create a fault suppression task.
  - Step 4** In the **Work** pane, click the **General** tab.
  - Step 5** In the **Actions** area, click **Start Fault Suppression**.  
**Tip** To configure fault suppression tasks for multiple service profiles, use the Ctrl key to select multiple service profiles in the **Navigation** pane. Right-click one of the selected service profiles and choose **Start Fault Suppression**.
  - Step 6** In the **Start Fault Suppression** dialog box, complete the following fields:

<b>Name</b> field	The name of the fault suppression task.  This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters other than - (hyphen), _ (underscore), : (colon), and . (period), and you cannot change this name after the object has been saved.
-------------------	--

<b>Select Fixed Time Interval/Schedule field</b>	<p>When the fault suppression task will run. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Fixed Time Interval</b>—Choose this option to specify the start time and duration for the fault suppression task. Specify the day and time the fault suppression task should start in the <b>Start Time</b> field. Click the down arrow at the end of this field to select the start time from a pop-up calendar. Specify the length of time this task should run in the <b>Task Duration</b> field. To specify that this task should run until it is manually stopped, enter 00:00:00:00 in this field.</li> <li>• <b>Schedule</b>—Choose this option to configure the start time and duration using a pre-defined schedule. Choose the schedule from the <b>Schedule</b> drop-down list. To create a new schedule, click <b>Create Schedule</b>.</li> </ul>
<b>Policy drop-down list</b>	<p>The following suppression policy is selected by default:</p> <ul style="list-style-type: none"> <li>• <b>default-server-maint</b>—Suppresses faults for servers.</li> </ul>

**Step 7** Click **OK**.

---

## Deleting Fault Suppression Tasks for a Service Profile

This procedure deletes all fault suppression tasks for a service profile. To delete individual tasks, use the **Delete** button on the **Suppression Tasks** dialog box. See [Viewing Fault Suppression Tasks for a Service Profile, on page 13](#).

### Procedure

---

**Step 1** In the **Navigation** pane, click the **Servers** tab.

**Step 2** On the **Servers** tab, expand **Servers > Service Profiles**.

**Step 3** Click the service profile for which you want to delete all fault suppression tasks.

**Step 4** In the **Work** pane, click the **General** tab.

**Step 5** In the **Actions** area, click **Stop Fault Suppression**.

**Tip** To delete fault suppression tasks for multiple service profiles, use the Ctrl key to select multiple service profiles in the **Navigation** pane. Right-click one of the selected service profiles and choose **Stop Fault Suppression**.

**Step 6** If the Cisco UCS Manager GUI displays a confirmation dialog box, click **Yes**.

---

## Viewing Fault Suppression Tasks for a Service Profile

### Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers > Service Profiles**.
- Step 3** Click the service profile for which you want to view fault suppression task properties.
- Step 4** In the **Work** pane, click the **General** tab.
- Step 5** In the **Actions** area, click **Suppression Task Properties**.  
In the **Suppression Tasks** dialog box, you can add new fault suppression tasks, delete existing fault suppression tasks, or modify existing fault suppression tasks.

## Configuring Fault Suppression for an Organization

### Configuring Fault Suppression Tasks for an Organization

#### Procedure

- Step 1** In the **Navigation** pane, click the **Servers** tab.
- Step 2** On the **Servers** tab, expand **Servers > Policies > *Organization\_Name***.
- Step 3** Click the organization for which you want to create a fault suppression task.
- Step 4** In the **Work** pane, click the **General** tab.
- Step 5** In the **Actions** area, click **Start Fault Suppression**.
- Step 6** In the **Start Fault Suppression** dialog box, complete the following fields:

<b>Name</b> field	The name of the fault suppression task.  This name can be between 1 and 16 alphanumeric characters. You cannot use spaces or any special characters other than - (hyphen), _ (underscore), : (colon), and . (period), and you cannot change this name after the object has been saved.
-------------------	--

<b>Select Fixed Time Interval/Schedule field</b>	<p>When the fault suppression task will run. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Fixed Time Interval</b>—Choose this option to specify the start time and duration for the fault suppression task.</li> </ul> <p>Specify the day and time the fault suppression task should start in the <b>Start Time</b> field. Click the down arrow at the end of this field to select the start time from a pop-up calendar.</p> <p>Specify the length of time this task should run in the <b>Task Duration</b> field. To specify that this task should run until it is manually stopped, enter 00:00:00:00 in this field.</p> <ul style="list-style-type: none"> <li>• <b>Schedule</b>—Choose this option to configure the start time and duration using a pre-defined schedule.</li> </ul> <p>Choose the schedule from the <b>Schedule</b> drop-down list. To create a new schedule, click <b>Create Schedule</b>.</p>
<b>Policy drop-down list</b>	<p>The following suppression policy is selected by default:</p> <ul style="list-style-type: none"> <li>• <b>default-server-maint</b>—Suppresses faults for servers.</li> </ul>

**Step 7** Click **OK**.

---

## Deleting Fault Suppression Tasks for an Organization

This procedure deletes all fault suppression tasks for an organization. To delete individual tasks, use the **Delete** button on the **Suppression Tasks** dialog box. See [Viewing Fault Suppression Tasks for an Organization](#), on page 15.

### Procedure

---

- Step 1** In the **Navigation** pane, click the **Servers** tab.
  - Step 2** On the **Servers** tab, expand **Servers > Policies > *Organization\_Name***.
  - Step 3** Click the organization for which you want to delete all fault suppression tasks.
  - Step 4** In the **Work** pane, click the **General** tab.
  - Step 5** In the **Actions** area, click **Stop Fault Suppression**.
  - Step 6** If the Cisco UCS Manager GUI displays a confirmation dialog box, click **Yes**.
-

## Viewing Fault Suppression Tasks for an Organization

### Procedure

- 
- Step 1** In the **Navigation** pane, click the **Servers** tab.
  - Step 2** On the **Servers** tab, expand **Servers > Policies > Organization\_Name**.
  - Step 3** Click the organization for which you want to view fault suppression task properties.
  - Step 4** In the **Work** pane, click the **General** tab.
  - Step 5** In the **Actions** area, click **Suppression Task Properties**.  
In the **Suppression Tasks** dialog box, you can add new fault suppression tasks, delete existing fault suppression tasks, or modify existing fault suppression tasks.
- 

# Configuring Settings for the Core File Exporter

## Core File Exporter

Cisco UCS uses the Core File Exporter to export core files as soon as they occur to a specified location on the network through TFTP. This functionality allows you to export the tar file with the contents of the core file.

## Configuring the Core File Exporter

### Procedure

- 
- Step 1** In the **Navigation** pane, click the **Admin** tab.
  - Step 2** On the **Admin** tab, expand **All > Faults, Events, and Audit Log**.
  - Step 3** Click **Settings**.
  - Step 4** In the **Work** pane, click the **TFTP Core Exporter** tab.
  - Step 5** On the **TFTP Core Exporter** tab, complete the following fields:

Name	Description
Admin State field	This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Enabled</b>—If an error causes the server to perform a core dump, Cisco UCS sends the core dump file via FTP to a given location. When this option is selected, Cisco UCS Manager GUI displays the other fields in this area that enable you to specify the FTP export options.</li> <li>• <b>Disabled</b>—Core dump files are not automatically exported.</li> </ul>

Name	Description
Description field	A user-defined description of the core file. Enter up to 256 characters. You can use any characters or spaces except ` (accent mark), \ (backslash), ^ (carat), " (double quote), = (equal sign), > (greater than), < (less than), or ' (single quote).
Port field	The port number to use when exporting the core dump file via TFTP.
Hostname field	The hostname or IPv4 or IPv6 address to connect with via TFTP. <b>Note</b> If you use a hostname rather than an IPv4 or IPv6 address, you must configure a DNS server. If the Cisco UCS domain is not registered with Cisco UCS Central or DNS management is set to <b>local</b> , configure a DNS server in Cisco UCS Manager. If the Cisco UCS domain is registered with Cisco UCS Central and DNS management is set to <b>global</b> , configure a DNS server in Cisco UCS Central.
Path field	The path to use when storing the core dump file on the remote system.

**Step 6** Click **Save Changes**.

---

## Disabling the Core File Exporter

### Procedure

---

- Step 1** In the **Navigation** pane, click the **Admin** tab.
  - Step 2** On the **Admin** tab, expand **All > Faults, Events, and Audit Log**.
  - Step 3** Click **Settings**.
  - Step 4** In the **Work** pane, click the **Settings** tab.
  - Step 5** In the **TFTP Core Exporter** area, click the **disabled** radio button in the **Admin State** field.
  - Step 6** Click **Save Changes**.
-



# Configuring the Syslog

## Procedure

- Step 1** In the **Navigation** pane, click the **Admin** tab.
- Step 2** On the **Admin** tab, expand **All > Faults, Events, and Audit Log**.
- Step 3** Click **Syslog**.
- Step 4** In the **Work** pane, click the **Syslog** tab.
- Step 5** In the **Local Destinations** area, complete the following fields:

Name	Description
<b>Console Section</b>	
<b>Admin State</b> field	Whether Cisco UCS displays Syslog messages on the console. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Enabled</b>—Syslog messages are displayed on the console as well as added to the log.</li> <li>• <b>Disabled</b>—Syslog messages are added to the log but not displayed on the console.</li> </ul>
<b>Level</b> field	If this option is <b>enabled</b> , select the lowest message level that you want displayed. Cisco UCS displays that level and above on the console. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Emergencies</b></li> <li>• <b>Alerts</b></li> <li>• <b>Critical</b></li> </ul>
<b>Monitor Section</b>	
<b>Admin State</b> field	Whether Cisco UCS displays Syslog messages on the monitor. This can be one of the following: <ul style="list-style-type: none"> <li>• <b>Enabled</b>—Syslog messages are displayed on the monitor as well as added to the log.</li> <li>• <b>Disabled</b>—Syslog messages are added to the log but not displayed on the monitor.</li> </ul> If <b>Admin State</b> is enabled, Cisco UCS Manager GUI displays the rest of the fields in this section.

Name	Description
Level drop-down list	<p>If this option is <b>enabled</b>, select the lowest message level that you want displayed. The system displays that level and above on the monitor. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Emergencies</b></li> <li>• <b>Alerts</b></li> <li>• <b>Critical</b></li> <li>• <b>Errors</b></li> <li>• <b>Warnings</b></li> <li>• <b>Notifications</b></li> <li>• <b>Information</b></li> <li>• <b>Debugging</b></li> </ul>
<b>File Section</b>	
Admin State field	<p>Whether Cisco UCS stores messages in a system log file on the fabric interconnect. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Enabled</b>—Messages are saved in the log file.</li> <li>• <b>Disabled</b>—Messages are not saved.</li> </ul> <p>If <b>Admin State</b> is enabled, Cisco UCS Manager GUI displays the rest of the fields in this section.</p>
Level drop-down list	<p>Select the lowest message level that you want the system to store. Cisco UCS stores that level and above in a file on the fabric interconnect. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Emergencies</b></li> <li>• <b>Alerts</b></li> <li>• <b>Critical</b></li> <li>• <b>Errors</b></li> <li>• <b>Warnings</b></li> <li>• <b>Notifications</b></li> <li>• <b>Information</b></li> <li>• <b>Debugging</b></li> </ul>

Name	Description
Name field	<p>The name of the file in which the messages are logged.</p> <p>This name can be up to 16 alphanumeric characters. You cannot use spaces or any special characters other than - (hyphen), _ (underscore), : (colon), and . (period). The default is messages.</p>
Size field	<p>The maximum size, in bytes, the file can be before Cisco UCS Manager begins to write over the oldest messages with the newest ones.</p> <p>Enter an integer between 4096 and 4194304.</p>

**Step 6** In the **Remote Destinations** area, complete the following fields to configure up to three external logs that can store messages generated by the Cisco UCS components:

Name	Description
Admin State field	<p>This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Enabled</b></li> <li>• <b>Disabled</b></li> </ul> <p>If <b>Admin State</b> is enabled, Cisco UCS Manager GUI displays the rest of the fields in this section.</p>
Level drop-down list	<p>Select the lowest message level that you want the system to store. The system stores that level and above in the remote file. This can be one of the following:</p> <ul style="list-style-type: none"> <li>• <b>Emergencies</b></li> <li>• <b>Alerts</b></li> <li>• <b>Critical</b></li> <li>• <b>Errors</b></li> <li>• <b>Warnings</b></li> <li>• <b>Notifications</b></li> <li>• <b>Information</b></li> <li>• <b>Debugging</b></li> </ul>
Hostname field	<p>The hostname or IP address on which the remote log file resides.</p> <p><b>Note</b> If you use a hostname rather than an IPv4 or IPv6 address, you must configure a DNS server. If the Cisco UCS domain is not registered with Cisco UCS Central or DNS management is set to <b>local</b>, configure a DNS server in Cisco UCS Manager. If the Cisco UCS domain is registered with Cisco UCS Central and DNS management is set to <b>global</b>, configure a DNS server in Cisco UCS Central.</p>

Name	Description
Facility drop-down list	This can be one of the following: <ul style="list-style-type: none"> <li>• Local0</li> <li>• Local1</li> <li>• Local2</li> <li>• Local3</li> <li>• Local4</li> <li>• Local5</li> <li>• Local6</li> <li>• Local7</li> </ul>

**Step 7** In the **Local Sources** area, complete the following fields:

Name	Description
Faults Admin State field	If this field is <b>Enabled</b> , Cisco UCS logs all system faults.
Audits Admin State field	If this field is <b>Enabled</b> , Cisco UCS logs all audit log events.
Events Admin State field	If this field is <b>Enabled</b> , Cisco UCS logs all system events.

**Step 8** Click **Save Changes**.

---

## Viewing the Audit Logs

You can view, export, print or refresh the audit logs displayed on this **Audit Logs** page.

### Procedure

---

- Step 1** In the **Navigation** pane, click the **Admin** tab.
  - Step 2** On the **Admin** tab, expand **All > Faults, Events, and Audit Log**.
  - Step 3** Click **Audit Logs**.
  - Step 4** The **Work** pane displays the audit logs.
-