



## Troubleshoot Infrastructure

---

- [Recovering the Corrupt BIOS on a Blade Server, on page 1](#)
- [Recovering the Corrupt BIOS on a Rack-Mount Server, on page 2](#)

### Recovering the Corrupt BIOS on a Blade Server

Sometimes, an issue with a server might require you to recover the corrupted BIOS. This procedure is not part of the normal maintenance of a server. After you recover the BIOS, the server boots with the running version of the firmware for that server. This radio button might dim if the BIOS does not require recovery or the option is not available for a particular server.

#### Before you begin



---

**Important** Remove all attached or mapped USB storage from a server before you attempt to recover the corrupt BIOS on that server. If an external USB drive is attached or mapped from vMedia to the server, BIOS recovery fails.

---

#### Procedure

---

- Step 1** In the **Navigation** pane, click **Equipment**.
- Step 2** Expand **Equipment** > **Chassis** > *Chassis Number* > **Servers**.
- Step 3** Choose the server for which you want to recover the BIOS.
- Step 4** In the **Work** pane, click the **General** tab.
- Step 5** In the **Actions** area, click **Recover Server**.
- Step 6** In the **Recover Server** dialog box, do the following:
- Click **Recover Corrupt BIOS**.
- Note** If this option is not available for a specific server, follow the instructions to update and activate the BIOS for a server.
- Click **OK**.
- Step 7** If a confirmation dialog box displays, click **Yes**.

**Step 8** In the **Recover Corrupt BIOS** dialog box, do the following:

a) Complete the following fields:

Name	Description
Version To Be Activated drop-down list	Choose the firmware version from the drop-down list to activate.

b) Click **OK**.

## Recovering the Corrupt BIOS on a Rack-Mount Server

Sometimes, an issue with a server might require you to recover the corrupted BIOS. This procedure is not part of the normal maintenance of a server. After you recover the BIOS, the server boots with the running version of the firmware for that server. This radio button might dim if the BIOS does not require recovery or the option is not available for a particular server.

### Before you begin



**Important** Remove all attached or mapped USB storage from a server before you attempt to recover the corrupt BIOS on that server. If an external USB drive is attached or mapped from vMedia to the server, BIOS recovery fails.

### Procedure

**Step 1** In the **Navigation** pane, click **Equipment**.

**Step 2** Expand **Equipment > Rack Mounts > Servers**.

**Note** For Cisco UCS C125 M5 Servers, expand **Equipment > Rack Mounts > Enclosures > Rack Enclosure *rack\_enclosure\_number* > Servers**.

**Step 3** Choose the server for which you want to recover the BIOS.

**Step 4** In the **Work** pane, click the **General** tab.

**Step 5** In the **Actions** area, click **Recover Server**.

**Step 6** In the **Recover Server** dialog box, click **Recover Corrupt BIOS**, then click **OK**.

**Step 7** If a confirmation dialog box displays, click **Yes**.

**Step 8** In the **Recover Corrupt BIOS** dialog box, specify the version to be activated, then click **OK**.