



## Audit Logs

---

- [Audit Logs, on page 1](#)
- [Viewing the Audit Logs, on page 1](#)

## Audit Logs

Audit Logs record system events that occurred, where they occurred, and which users initiated them.

## Viewing the Audit Logs

You can view, export, print, or refresh the audit logs displayed on the **Audit Logs** page.

### Procedure

---

- Step 1** In the **Navigation** pane, click **Admin**.
- Step 2** Expand **All > Faults, Events, and Audit Log**.
- Step 3** In the work pane, click the **Audit Logs** tab.
- Step 4** The **Work** pane displays the audit logs.

Name	Description
<b>ID</b> column	The unique identifier associated with the message.
<b>Affected Object</b> column	The component that is affected by this issue. Click the object name to view the properties for this object.
<b>Trig</b> column	The user role associated with the user that triggered the event.
<b>User</b> column	The type of user.
<b>Session ID</b> column	The session ID associated with the session during which the event occurred.
<b>Created at</b> column	The day and time that the fault occurred.

Name	Description
Indication column	This can be one of the following: <ul style="list-style-type: none"><li>• <b>Creation</b>—A component was added to the system.</li><li>• <b>Modification</b>—An existing component was changed.</li></ul>
Description column	More information about the fault.
Modified Properties column	The system properties that were changed by the event.

---