



## CLI Commands

---

- [Delete Commands, on page 1](#)
- [File Commands, on page 4](#)
- [License Manager Commands, on page 11](#)
- [Run and Set commands, on page 16](#)
- [Show Commands, on page 54](#)
- [Unset Commands, on page 83](#)
- [Utils Commands, on page 85](#)

## Delete Commands

### delete account

This command allows you to delete an administrator account.

#### Command Syntax

**delete account** *account-name*

#### Syntax Description

Parameters	Description
<i>account-name</i>	The name of an administrator account

#### Requirements

Command privilege level: 4

Allowed during upgrade: No

### delete dns

This command allows you to delete the IP address for a DNS server.

**Command Syntax****delete dns** *ip-address***Syntax Description**

Parameters	Description
<i>ip-address</i>	The IP address of the DNS server that you want to delete.

**Usage Guidelines**

The system asks whether you want to continue to execute this command.



**Caution** If you continue, this command causes a temporary loss of network connectivity.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**delete dscp**

This command deletes a DSCP port tag.

**Command Syntax****delete dscp** [*port-tag*]**Syntax Description**

Parameters	Description
[ <i>port-tag</i> ]	Represents a DSCP port tag, which is a string that is mapped to a TCP or UDP port to identify the application that uses the port. This value is for the portTag field displayed when you use the command show dscp defaults. The set of port tags is predefined.

**Usage Guideline**

After you delete an enabled port tag, DSCP marking on that port tag stops. You can recreate a deleted port tag when you use the set dscp marking command; enter the name of the port tag that you previously deleted.



**Tip** Use the command **show dscp defaults** to list the configured port tags

**Command Mode**

Administrator (admin:)

## delete ipsec

This command allows you to delete IPsec policies and associations.

### Command Syntax

**delete ipsec policy** {**ALL**| *policy-name*}

**association** *policy-name* {**ALL**| *association-name*}

### Syntax Description

Parameters	Description
<i>policy-name</i>	An IPsec policy.
<i>association-name</i>	An IPsec association

### Requirements

Command privilege level: 1

Allowed during upgrade: No

## delete process

This command allows you to delete a particular process.

### Command Syntax

**delete process** *process-id* [**force** | **terminate** | **crash**]

### Syntax Description

Parameters	Description
<i>process-id</i>	The process ID number.
<b>force</b>	(Optional) Tells the process to stop.
<b>terminate</b>	(Optional) Tells the operating system to terminate the process.
<b>crash</b>	(Optional) Crashes the process and produces a crash dump.

### Usage Guidelines

Use the **force** option only if the command alone does not delete the process and use the **terminate** option only if **force** does not delete the process.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

## delete smtp

This command allows you to delete the SMTP host.

### Command Syntax

**delete smtp**

### Requirements

Command privilege level: 1

Allowed during

## File Commands

### file check

This command checks the /usr directory tree to see whether any files or directories have been added, removed, or changed in size since the last fresh installation or upgrade and displays the results.

### Command Syntax

**file check** [*detection-size-kb*]

### Syntax Description

Parameters	Description
[ <i>detection-size-kb</i> ]	Specifies the minimum file size change that is required for the command to display the file as changed. Default value: 100 KB.

### Usage Guidelines

The command notifies you about a possible impact to system performance and asks you whether you want to continue. The display includes both deleted and new files.



### Caution

This command can affect system performance. We recommend that you use the command during off-peak hours.

### Requirements

Command privilege level: 0

Allowed during upgrade: No

## file delete

This command deletes one or more files.

### Command Syntax

**file delete** {**activelog**|**inactivelog**|**install**} *directory/filename* [**detail**] [**noconfirm**]

### Syntax Description

Parameters	Description
<b>activelog</b>	A log on the active side.
<b>inactivelog</b>	A log on the inactive side.
<b>install</b>	An installation log.
<i>directory/filename</i>	The path and filename of the files to delete. You can use the wildcard character (*) for "filename".
<b>detail</b>	(Optional) Shows a listing of deleted files with the date and time.
<b>noconfirm</b>	(Optional) Deletes files without asking you to confirm each deletion.

### Usage Guidelines



**Caution** You cannot recover a deleted file except possibly by using the Disaster Recovery System.

You get prompted for confirmation after entering the command. You cannot delete directories or files that are in use.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

### Example

The following example deletes the install log:

```
file delete install install.log
```

## file dump

This command dumps the contents of a file to the screen, a page at a time.

### Command Syntax

**file dump** {**activelog** |**inactivelog** |**install** } *directory/filename* [**detail**] [**hex**] [**recent**] [**regexexpression**]

**Syntax Description**

Parameters	Description
<b>activelog</b>	A log on the active side.
<b>inactivelog</b>	A log on the inactive side.
<b>install</b>	An installation log
<i>directory/filename</i>	The path and "filename" of the file to dump. You can use the wildcard character (*) for filename as long as it resolves to one file.
<b>detail</b>	(Optional) Displays listing with the date and time.
<b>hex</b>	(Optional) Displays output in hexadecimal.
<b>recent</b>	(Optional) Displays the most recently modified file in the directory.
<b>regex</b> <i>expression</i>	(Optional) Displays only the lines in the file that match the regular expression

**Requirements**

Command privilege level: 1 for logs

Allowed during upgrade: Yes

**Example**

This command dumps contents of file \_cdrIndex.idx:

```
file dump activelog cm/cdr/_cdrIndex.idx
```

**file get**

This command sends a log to another system using SFTP.

**Command Syntax**

```
file get {activelog |inactivelog |install|partBsalog|salog } directory/filename [reltime|abstime]  
[match][recurs]
```

**Syntax Description**

Parameters	Description
<b>activelog</b>	A log on the active side.
<b>inactivelog</b>	A log on the inactive side.
<b>install</b>	An installation log.

Parameters	Description
<b>partBsalog</b>	The partBsalog log directory.
<b>salog</b>	The salog log directory.
<i>directory/filename</i>	the path to the files to delete. You can use the wildcard character (*) for filename as long as it resolves to one file.
<b>abstime</b>	(Optional) The absolute time period, specified as hh:mm:MM/DD/YY hh:mm:MM/DD/YY.
<b>reltime</b>	(Optional) The relative time period, specified as months weeks days  hours  minutes value.
<b>match</b>	(Optional) Match a particular string in the filename, specified as string value.
<b>recurs</b>	(Optional) Get all files, including subdirectories.

**Usage Guidelines**

After the command identifies the specified files, you are prompted to enter an SFTP host, username, and password.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

**Examples**

This command gets all files in the activelog operating system directory that match the string plat:

```
file get activelog platform match plat
```

This command gets all operating system log files for a particular time period:

```
file get activelog platform/log abstime 18:00:9/27/2005 18:00:9/28/2005
```

**file list**

This command lists the log files in an available log directory.

**Command Syntax**

**file list** {**activelog**|**inactivelog**|**install**|**partBsalog**|**salog**} *directory/filename*[**page**|**detail**|**reverse**] [**date** | **size**]

**Syntax Description**

Parameters	Description
<b>activelog</b>	A log on the active side.

Parameters	Description
<b>inactivelog</b>	A log on the inactive side.
<b>install</b>	An installation log.
<b>partBsalog</b>	The partBsalog log directory.
<b>salog</b>	The salog log directory.
<i>directory</i>	The path to the directory to list. You can use a wildcard character (*) for directory as long as it resolves to one directory.
<b>page</b>	(Optional) Shows the output one screen at a time.
<b>detail</b>	(Optional) Shows a detailed listing with date and time.
<b>reverse</b>	(Optional) Reverse the sort direction.
<b>date</b>	(Optional) Sorts by date.
<b>size</b>	(Optional) Sorts by file size.

### Requirements

Command privilege level: 1 for logs

Allowed during upgrade: Yes

### Examples

This example lists operating system log files with details:

```
file list activelog platform/log page detail
```

This example lists directories created for Emergency Responder logs:

```
file list activelog er/logs
```

This example lists Emergency Responder logs in a specified directory by size:

```
file list activelog er/logs size
```

## file search

This command searches the content of a log and displays the matching lines a page at a time.

### Command Syntax

```
file search { activelog | inactivelog | install } directory/filename reg-exp [abstime hh:mm:ss mm/dd/yyyy  
hh:mm:ss mm/dd/yyyy] [ignorecase] [retime { days | hours | minutes } timevalue]
```



### Syntax Description

Parameters	Description
<b>activelog</b>	A log on the active side.
<b>inactivelog</b>	A log on the inactive side.
<b>install</b>	An installation log.
<i>directory/filename</i>	The path to the files to search. You can use the wildcard character (*) to represent all or part of the filename.
<i>reg-exp</i>	A regular expression.
<b>abstime</b>	(Optional) The files to search based on file creation time. Enter a start time and an end time.
<b>days hours minutes</b>	(Optional) The file age is in days, hours, or minutes.
<b>ignorecase</b>	(Optional) Ignores case when searching
<b>retime</b>	(Optional) The files to search based on file creation time. Enter the age of files to search.
<i>hh:mm:ss mm/dd/yyyy</i>	(Optional) An absolute time, in the format hours:minutes:seconds month/day/year.
<i>timevalue</i>	(Optional) The age of files to search. The unit of this value is specified with the { <b>days</b>   <b>hours</b>   <b>minutes</b> } option.

#### Usage Guidelines

Write the search term in the form of a regular expression, which is a special text string for describing a search pattern.

If the search term is found in only one file, the filename appears at the top of the output. If the search term is found in multiple files, each line of the output begins with the filename in which the matching line was found.

#### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

#### Example

```
file search activelog platform/log/platform.log Err[a-z] ignorecase
```

## file tail

This command prints the last few lines of a log file.

#### Command Syntax

```
file tail {activelog |inactivelog |install } directory/filename[detail] [hex] [lines]
```

**Syntax Description**

Parameters	Description
<b>activelog</b>	A log on the active side.
<b>inactivelog</b>	A log on the inactive side.
<b>install</b>	An installation log.
<i>directory/filename</i>	The path to the file to tail. You can use the wildcard character (*) for filename as long as it resolves to one file.
<b>detail</b>	(Optional) Long listing with date and time
<b>hex</b>	(Optional) Hexadecimal listing
<b>lines</b>	(Optional) Number of lines to display

**Requirements**

Command privilege level: 1 for logs

Allowed during upgrade: Yes

**Example**

This example tails the operating system CLI log file:

```
file tail activelog platform/log/cli00001.log
```

## file view

This command displays the contents of a file.

**Command Syntax**

**file view** {**activelog**|**inactivelog**|**install**|**system-management-log**} *directory/filename*

**Syntax Description**

Parameters	Description
<b>activelog</b>	A log on the active side.
<b>inactivelog</b>	A log on the inactive side.
<b>install</b>	An installation log.
<b>system-management-log</b>	The contents of the Integrated Management Logs (IML).
<i>directory/filename</i>	The path to the file to view. You can use the wildcard character (*) for filename as long as it resolves to one file.

---

## Usage Guidelines



---

**Caution** Do not use this command to view binary files because this can corrupt the terminal session.

---

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

### Examples

This example displays the install log:

```
file view install install.log
```

This example displays a particular CDR file:

```
file view activelog er/logs/CERAdmin01.log
```

# License Manager Commands

## license smart deregister

Use this command to unregister smart licensing on Cisco Emergency Responder and remove the product from Cisco Smart Software Manager.

**license smart deregister**

---

**Command Modes** Administrator (admin)

### Requirements

Command privilege level: 4

Allowed during upgrade: Yes

## license smart register idtoken

Use this command to register Cisco Emergency Responder with Cisco Smart Software Manager using an ID token.

**license smart register idtoken <token>**

---

**Command Modes** Administrator (admin)

### Requirements

Command privilege level: 4

Allowed during upgrade: Yes

## license smart register idtoken (force)

Use this command to reregister Cisco Emergency Responder with Cisco Smart Software Manager using an ID token.

**license smart register idtoken <token> [force]**

---

**Command Modes** Administrator (admin)

### Requirements

Command privilege level: 4

Allowed during upgrade: Yes

## license smart renew auth

Use this command to manually renew the license usage information.

**license smart renew auth**

---

**Command Modes** Administrator (admin)

### Requirements

Command privilege level: 4

Allowed during upgrade: Yes

## license smart renew ID

Use this command to manually renew the license registration.

**license smart renew ID**

---

**Command Modes** Administrator (admin)

### Requirements

Command privilege level: 4

Allowed during upgrade: Yes

## license smart call-home destination address default

This command enables to update transport setting as Direct.

### Command Syntax

**license smart call-home destination address default**

---

**Command Modes** Administrator (admin:)

---

**Usage Guidelines****Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

## license smart call-home destination address TransportGateway GatewayURL

This command enables to update transport setting as Transport Gateway/Satellite.

**Command Syntax**

**license smart call-home destination address TransportGateway <url>**

---

**Command Modes**

Administrator (admin:)

---

**Usage Guidelines****Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

## license smart call-home proxy ProxyIP ProxyPort

This command enables to update transport setting as as HTTP/HTTPS Proxy.

**Command Syntax**

**license smart call-home proxy <ip> <port>**

---

**Command Modes**

Administrator (admin:)

---

**Usage Guidelines****Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

## license smart reservation enable

This command enables the License Reservation.

**Command Syntax**

**license smart reservation enable**

---

**Command Modes**

Administrator (admin:)

---

**Usage Guidelines****Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

## license smart reservation disable

Use this command to disable the license reservation feature.

**license smart reservation disable**

---

**Command Modes**

Administrator (admin)

**Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

## license smart reservation cancel

Use this command to cancel the ongoing reservation request.

**Command Syntax**

**license smart reservation cancel**

---

**Command Modes**

Administrator (admin)

---

**Usage Guidelines****Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

## license smart reservation request

Use this command to request for reservation code that is entered while performing License Reservation in Cisco Smart Software Manager.

**Command Syntax**

**license smart reservation request**

---

**Command Modes**

Administrator (admin)

---

**Usage Guidelines****Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

## license smart reservation install "<authorization-code>"

Use this command to install the license reservation authorization-code generated on the Cisco Smart Software Manager.

**Command Syntax**

**license smart reservation install "<authorization-code>"**

**Command Modes**

Administrator (admin)

**Usage Guidelines****Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

## license smart reservation return

Use this command to generate a return code that must be entered into the Cisco Smart Software Manager to return the previously reserved licenses to the virtual account pool.

**Command Syntax**

**license smart reservation return**

**Command Modes**

Administrator (admin)

**Usage Guidelines****Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

## license smart reservation return-authorization "<authorization-code>"

Use this command to generate a return code using the authorization code specified on the command line. The return code must be entered into the Cisco Smart Software Manager to return the licenses to the virtual account pool.

**license smart reservation return-authorization "<authorization-code>"**

**Command Modes**

Administrator (admin)

**Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

## license smart reservation set license\_count

Use this command to configure or update the license count for the system to operate within, when Permanent License Reservation is enabled. License count configured using this CLI does not affect compliance status and is for administrator reference only. The license count set by admin using the CLI will be displayed on the Emergency Responder License Management UI screen.

**license smart reservation set license\_count****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

Applies to: Unified Communications Manager, Cisco Emergency Responder, and Cisco Unity Connection

## Run and Set commands

### run sql

This command allows you to run an SQL command.

**Command Syntax****run sql** *sql\_statement***Syntax Description**

Parameters	Description
<i>sql_statement</i>	The SQL command to run.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**Examples**

This example runs an SQL command:

```
run sql select * from cerserver
```

### set account

This command sets up a new account on the operating system.

**Command Syntax****set account** *name*



**Syntax Description**

Parameters	Description
<i>name</i>	<p>The username for the new account.</p> <p>Enter a name comprised of only alphabets or characters comprised of alphanumeric characters (a-z, A-D, 0-9).</p> <p><b>Note</b> Umlaut characters are not supported.</p>

**Usage Guidelines**

After you enter the username, the system prompts you to enter the privilege level and password for the new account.

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

**set account enable**

This command is used to enable the user account if the account is disabled due to the password inactivity feature.

Password inactivity period is the number of days of inactivity after a password has expired before the account is disabled.

After entering this command, the user account is enabled with current system settings. The system settings are Password min days, Password Max days, Password inactivity period.

**Command Syntax**

**set account enable** *userid*

**Syntax Description**

Parameters	Description
<i>userid</i>	The name of the user account.

**Example**

This example runs a set account enable command:

```
set account enable test
Enabling the account 'test' with current settings....
.....
Successfully enabled account 'test'
```

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

## show accountlocking

This command shows the current account locking settings.

### Command Syntax

**show accountlocking**

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

## set accountlocking disable

This command disables accountlocking for the current administrator accounts.

### Command Syntax

**set accountlocking disable**

### Syntax Description

Parameters	Description
disable	Disable account locking.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

## set accountlocking enable

This command enables accountlocking for the current administrator accounts.

### Command Syntax

**set accountlocking enable**

### Syntax Description

Parameters	Description
enable	Enable account locking.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

**set accountlocking unlocktime**

This command configures the unlock time for Emergency Responder OS administrator accounts in seconds.

Acceptable values should be equal to or greater than 300 seconds, but less than 3600 seconds (60 mins).

**Command Syntax**

**set accountlocking unlocktime** *seconds*

**Syntax Description**

Parameters	Description
<i>seconds</i>	The unlocktime in seconds.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

**set cert delete**

This command deletes the certificate test.pem for the unit IPsec.

**Command Syntax**

**set cert delete** [*unit*] [*name*]

**Syntax Description**

Parameters	Description
<i>unit</i>	The name of the trust category.
<i>name</i>	The certificate file name.

**Example**

```
set cert
  delete ipsec test.pem
```

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

## set cert import

This command imports the certificate for a specific unit | trust.

### Command Syntax

```
set cert import [unit name]
```

### Syntax Description

Parameters	Description
<i>unit name</i>	The name of the unit or trust.

### Example

The following example runs a set cert import command:

```
set cert
  import trust tomcat
```

Successfully regenerated certificate for tomcat.

Please restart services related to tomcat for the new certificate to become active.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

## set cert regen

This command regenerates the certificate for the unit.

### Command Syntax

```
set cert regen [name]
```

### Parameter

*Name* is unit name

### Syntax Description

Parameters	Description
<i>Name</i>	The name of the unit.

**Example**

This example runs a set cert regen command:

```
set cert regen tomcat
```

```
Successfully regenerated certificate for tomcat.
```

```
Please restart services related to tomcat for the new certificate to become active.
```

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

## set cli pagination

For the current CLI session, this command turns automatic pagination on or off.

**Command Syntax**

```
set cli pagination {on | off}
```

**Syntax Description**

Parameters	Description
on	Turns pagination on.
off	Turns pagination off.

**Requirements**

Level privilege: 1

Command privilege: 1

Allowed during upgrade: No

**Example**

```
admin:set cli pagination off
```

```
Automatic pagination is turned off
```

## set cli session timeout

This command sets the time, in minutes, after which an active CLI session times out and disconnects.

**Command Syntax**

```
set cli session timeout minutes
```

**Syntax Description**

Parameters	Description
<i>minutes</i>	Specifies the time, in minutes, that can elapse before an active CLI session times out and disconnects: <ul style="list-style-type: none"> <li>• Value range: 5-99999 minutes</li> <li>• Default value: 30 minutes</li> </ul>

**Usage Guidelines**

Be aware that the new session timeout value becomes effective immediately for a new CLI session; however, active sessions retain their original timeout value. Also the `show cli session timeout` command reflects the new value, even if the current session does not use that value.




---

**Note** This setting gets preserved through a software upgrade and does not get reset to the default value.

---

**Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**set commandcount**

This command changes the CLI command prompt so that it displays how many CLI commands have executed.

**Command Syntax**

`set commandcount {enable | disable}`

**Syntax Description**

Parameters	Description
<b>enable</b>	Turns on command count.
<b>disable</b>	Turns off command count.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

## set csr gen

It regenerates the certificate for the unit name.

### Command Syntax

**set csr gen** *name*

### Syntax Description

Parameters	Description
<i>name</i>	Specifies the unit on which the certificate is generated.

### Example

```
set csr gen tomcat
```

Successfully regenerated certificate for tomcat.

Please restart services related to tomcat for the new certificate to become active.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

## set date

This command sets the date on the system.

### Command Syntax

**set date** *HH:mm:ss:MM/DD/YY*

### Syntax Description

Parameters	Description
<i>HH:mm:ss</i>	Represents the time format (24 hours format).
<i>MM/DD/YY</i>	Represents the date format. This date format is also accepted: <b>MM/DD/YYYY</b> .

### Requirements

Command privilege level: 1

Allowed during upgrade: No

**Example**

To set date and time to 2:10:33 p.m. February 13, 2008:

```
set date 14:10:33:02/13/08
```

**set dscp**

This command enables or disables DSCP marking on outgoing TCP or UDP packets. You can enable or disable DSCP on a single port tag, or on all port tags at once.

**Command Syntax**

```
set dscp {enable | disable} {all|port_tag}
```

**Syntax Description**

Parameters	Description
<b>all</b>	Disables all DSCP port tags.
<i>port_tag</i>	Represents a DSCP port tag, which is a string that is mapped to a TCP or UDP port to identify the application that uses the port. This value is for the portTag field displayed when you use the command show dscp defaults.  The set of port tags is predefined.

**Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**set dscp defaults**

This command sets the factory default DSCP settings for all of the port tags.

**Command Syntax**

```
set dscp defaults
```

**Command Mode**

Administrator (admin:)



**Useage Guidelines**

This command removes all non-default DSCP settings. The command **show dscp defaults** displays the factory default DSCP settings.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

## set dscp marking

This command sets DSCP markings on port tags by using well-known DSCP classes and numeric values.

**Command Syntax**

**set dscp marking** *port\_tag value*

**Syntax Description**

Parameters	Description
<i>port_tag</i>	Represents a DSCP port tag, which is a string that is mapped to a TCP or UDP port to identify the application that uses the port. This value is for the portTag field displayed when you use the command show dscp defaults.
<i>value</i>	A DSCP value. You can enter the name of a well-known DSCP class or a numeric value in decimal or hexadecimal format. Precede hexadecimal values with 0x or 0X.

**Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**Useage Guidelines**

The valid class names as defined by DSCP are:

- Class Selector: values CS0, CS1, CS2, CS3, CS5, CS6, CS7 The class selector (CS) values correspond to IP Precedence values and are fully compatible with IP Precedence.
- Expedited Forwarding: value EF EF PHB is ideally suited for applications such as VoIP that require low bandwidth, guaranteed bandwidth, low delay, and low jitter.
- Best Effort: value BE Also called default PHB, this value essentially specifies that a packet be marked with 0x00, which gets the traditional best-effort service from the network router.

- Assured Forwarding: values AF11, AF12, AF13, AF21, AF22, AF23, AF41, AF42, AF43 There are four types of Assured Forwarding classes, each of which has three drop precedence values. These precedence values define the order in which a packet is dropped (if needed) due to network congestion. For example, packets in AF13 class are dropped before packets in the AF12 class.

## set ipsec

This command allows you to set IPSec policies and associations.

### Command Syntax

**set ipsec**

**policy** {**ALL** | *policy-name*}

**association** *policy-name* {**ALL** | *association-name*}

### Syntax Description

Parameters	Description
<i>policy-name</i>	An IPSec policy.
<i>association-name</i>	An IPSec association.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

## set logging

This command allows you to enable or disable logging.

### Command Syntax

**set logging** {**enable** | **disable**}

### Syntax Description

Parameters	Description
<b>enable</b>	Turns on logging.
<b>disable</b>	Turns off logging.

### Requirements

Command privilege level: 0

Allowed during upgrade: No

## set network cluster publisher hostname

This command configures the cluster publisher hostname. Changing the hostname is possible only from the subscriber in a server group. This is supported when migrating from MCS to VMware platforms, but not in any other scenarios.

A temporary loss of network connectivity occurs while the network is being restarted with the new configuration.

### Command Syntax

```
set network cluster publisher hostname name
```

### Syntax Description

Parameters	Description
<i>name</i>	The hostname to be assigned.

## set network cluster publisher ip

This command configures the cluster publisher IP address.

A temporary loss of network connectivity occurs while the network is being restarted with the new configuration.

### Command Syntax

```
set network cluster publisher ip addr
```

### Syntax Description

Parameters	Description
<i>ip addr</i>	Specifies the ip address of the network cluster.

## set network dhcp

This command enables or disables DHCP for Ethernet interface 0. You cannot configure Ethernet interface 1.

### Command Syntax

```
set network dhcp eth0 {enable| disable} {node_ip| net_mask| gateway_ip}
```

**Syntax Description**

Parameters	Description
<b>eth0</b>	Specifies Ethernet interface 0.
<b>enable</b>	This enables DHCP.
<b>disable</b>	This disables DHCP.
<i>node_ip</i>	The new static IP address for the server.
<i>net_mask</i>	The subnet mask for the server.
<i>gateway_ip</i>	The IP address of the default gateway.

**Usage Guidelines** The system asks whether you want to continue to execute this command.



**Caution** If you continue, this command causes the system to restart. We recommend that you restart all nodes whenever any IP address gets changed.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**set network dns**

This command sets the IP address for the primary or secondary DNS server.

**Command Syntax**

**set network dns** {**primary** | **secondary**} *ip-address*

**Syntax Description**

Parameters	Description
<i>ip-address</i>	The IP address of the primary or secondary DNS server.

**Usage Guidelines** The system asks whether you want to continue to execute this command.



**Caution** If you continue, this command causes a temporary loss of network connectivity. If you change the IP address of the DNS server, you must restart Cisco Tomcat. For more information, see [utils service, on page 121](#).

**Requirements**

Command privilege level: 1  
 Allowed during upgrade: No

**set network dns options**

This command sets DNS options.

**Command Syntax**

**set network dns options** [*timeout seconds*] [*attempts number*] [**rotate**]

**Syntax Description**

Parameters	Description
<b>timeout</b>	Sets the DNS request timeout.
<i>seconds</i>	The DNS timeout period, in seconds.
<b>attempts</b>	Sets the number of times to attempt a DNS request before quitting.
<i>number</i>	Specifies the number of attempts.
<b>rotate</b>	Causes the system to rotate among the configured DNS servers, distributing the load.

**Requirements**

Command privilege level: 0  
 Allowed during upgrade: Yes

**set network domain**

This command sets the domain name for the system.

**Command Syntax**

**set network domain** *domain-name*

**Syntax Description**

Parameters	Description
<i>domain-name</i>	The system domain that you want to assign.

**Usage Guidelines**

The system asks whether you want to continue to execute this command.



**Caution** If you continue, this command causes a temporary loss of network connectivity.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

## set network failover

This command enables and disables network fault tolerance.

### Command Syntax

**failover** {enable | disable}

### Syntax Description

Parameters	Description
<b>enable</b>	Enables network fault tolerance.
<b>disable</b>	Disables network fault tolerance.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

## set network gateway

This command enables you to configure the IP address of the network gateway.

### Command Syntax

**set network gateway** *ip-address*

### Syntax Description

Parameters	Description
<i>ip-address</i>	The IP address of the network gateway that you want to assign.

**Usage Guidelines** The system asks whether you want to continue to execute this command.



**Caution** If you continue, this command causes the system to restart.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

## set network hostname

This command allows an administrator to set the network host name, change the IP address of the node, and restart the system.

Before attempting this command, the administrator should have a valid DRF backup.



**Note** From Release 14SU2 onwards, tomcat and tomcat-ecdsa certificate must be exchanged between the publisher and subscriber nodes before and after changing the ipaddress/hostname.

### Command Syntax

**set network hostname** *hostname*

### Syntax Description

Parameters	Description
<i>hostname</i>	<p>Represents the new network hostname of the system.</p> <p><b>Note</b> The host name must follow the rules for ARPANET host names. It must start with an alphabetic character, end with an alphanumeric character, and consist of alphanumeric characters and hyphens. The host name can have a maximum length of 63 characters.</p>

### Command Mode

Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

### Usage Guidelines

The system asks whether you want to continue to execute this command.




---

**Caution** If you continue, this command causes the system to restart.

---

### Example

```
admin:set network hostname
WARNING: Changing this setting will invalidate software license on this server. The license
  will have to be re-hosted.
Continue (y/n):
Continue (y/n)?y

ctrl-c: To quit the input.

*** W A R N I N G ***
Do not close this window without first canceling the command.

This command will automatically restart system services.
The command should not be issued during normal operating
hours.

=====
Note: Please verify that the new hostname is a unique
name across the cluster and, if DNS services are
utilized, any DNS configuration is completed
before proceeding.
=====

Security Warning : This operation will regenerate
all CUCM Certificates including any third party
signed Certificates that have been uploaded.

Enter the hostname:: app-lfwelty5
Would you like to change the network ip address at this time [yes]::

Warning: Do not close this window until command finishes.

ctrl-c: To quit the input.

*** W A R N I N G ***
=====
Note: Please verify that the new ip address is unique
across the cluster.
=====

Enter the ip address:: 106.1.34.154
Enter the ip subnet mask:: 255.0.0.0
Enter the ip address of the gateway:: 106.1.1.1
Hostname: app-lfwelty5
IP Address: 106.1.34.154
IP Subnet Mask: 255.0.0.0
Gateway: 106.1.1.1

Do you want to continue [yes/no]? yes
...
```





**Note** The administrator can change both the hostname and IP address by responding **yes**. To change just the hostname, respond **no**.

## set network ip

This command sets the IP address for Ethernet interface 0. You cannot configure Ethernet interface 1.



**Note** From Release 14SU2 onwards, tomcat and tomcat-ecdsa certificate must be exchanged between the publisher and subscriber nodes before and after changing the ipaddress/hostname.

### Command Syntax

```
set network ip eth0 ip-address ip-mask
```

### Syntax Description

Parameters	Description
eth0	Specifies Ethernet interface 0.
<i>ip-address</i>	The IP address that you want assign.
<i>ip-mask</i>	The IP mask that you want to assign.

**Usage Guidelines** The system asks whether you want to continue to execute this command.



**Caution** If you continue, this command restarts the following services:

- NIC driver
- NTP
- CLM
- Service Manager

### Requirements

Command privilege level: 1

Allowed during upgrade: No

## set network max\_ip\_contrack

This command sets the `ip_contrack_max` value.

### Command Syntax

```
set network max_ip_contrack ip_contrack_max
```

### Syntax Description

Parameters	Description
<code>ip_contrack_max</code>	Specifies the value for <code>ip_contrack_max</code> .

## set network mtu

This command sets the maximum MTU value.

### Command Syntax

```
set network mtu mtu_max
```

### Syntax Description

Parameters	Description
<code>mtu_max</code>	Specifies the maximum MTU value.  <b>Note</b> The system default MTU value equals 1500.

**Usage Guidelines** The system asks whether you want to continue to execute this command.



**Caution** If you continue, the system temporarily loses network connectivity.

### Requirements

Level privilege: 1

Command privilege: 1

Allowed during upgrade: No

### Example

```
admin:set network mtu 576          ***  WARNING  ***
This will cause the system to temporarily lose network connectivity

Do you want to continue?

Enter "yes" to continue or any other key to abort
```

```
yes
executing...
```

## set network nic

This command sets the properties of the Ethernet interface 0. You cannot configure Ethernet interface 1.

### Command Syntax

```
set network nic eth0 {auto { en | dis }} {speed | {10 | 100} } {duplex| {half | full}}
```

### Syntax Description

Parameters	Description
<b>eth0</b>	Specifies Ethernet interface 0.
<b>auto</b>	Specifies whether auto negotiation gets enabled or disabled.
<b>speed</b>	Specifies the speed of the Ethernet connection: 10 or 100 Mbps.
<b>duplex</b>	Specifies half-duplex or full-duplex.

### Usage Guidelines

The system asks whether you want to continue to execute this command.



#### Caution

If you continue, this command causes a temporary loss of network connections while the NIC gets reset.



#### Note

You can enable only one active NIC at a time.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

## set network ntp option

This command adds a noquery option to /etc/config file.

### Command Syntax

```
set network ntp option noquery
```

## set network pmtud

This command enables and disables path MTU discovery.

**Command Syntax**

```
set network pmtud {enable | disable}
```

**Syntax Description**

Parameters	Description
<b>enable</b>	Enables Path MTU Discovery.
<b>disable</b>	Disables Path MTU Discovery.

**Usage Guidelines** The system asks whether you want to continue to execute this command.



**Caution** If you continue, the system temporarily loses network connectivity.

**Requirements**

Level privilege: 1

Command privilege: 1

Allowed during upgrade: No

**Example**

This example runs the set network pmtud command.

```
admin:set network pmtud enable
***  W A R N I N G  ***
This will cause the system to temporarily lose network connectivity

          Do you want to continue?

Enter "yes" to continue or any other key to abort
yes
executing...
admin:
```

**set network restore**

This command configures the specified Ethernet port to use a specified static IP address.



**Caution** Only use this command option if you cannot restore network connectivity using any other **set network** commands. This command deletes all previous network settings for the specified network interface, including network fault tolerance. After running this command, you must restore your previous network configuration manually.



**Caution** The server temporarily loses network connectivity when you use this command.

### Command Syntax

```
set network restore eth0 ip-address network-mask gateway
```

### Syntax Description

Parameters	Description
<b>eth0</b>	Specifies Ethernet interface 0.
<i>ip-address</i>	Specifies the IP address.
<i>network-mask</i>	Specifies the subnet mask.
<i>gateway</i>	Specifies the IP address of the default gateway.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

## set network status

This command sets the status of Ethernet 0 to up or down. You cannot configure Ethernet interface 1.

### Command Syntax

```
set network status eth0 {up | down}
```

### Syntax Description

Parameters	Description
<b>eth0</b>	Specifies Ethernet interface 0.
<b>up</b>	Sets the status of Ethernet interface 0 to up.
<b>down</b>	Sets the status of Ethernet interface 0 to down.

**Usage Guidelines** The system asks whether you want to continue to execute this command.



**Caution** If you continue, the system temporarily loses network connectivity.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**set password**

This command allows you to change the administrator password.

**Command Syntax**

```
set password {admin | security}
```

**Syntax Description**

Parameters	Description
admin	Administrator.
security	Security.

**Usage Guidelines**

The system prompts you for the old and new passwords.

The password must contain at least six characters, and the system checks it for strength.

Servers in a cluster use the security password to authenticate communication between servers. You must reset the cluster after you change the security password.

To change a password:

1. Change the security password on the publisher server and then reboot the server.
2. Change the security password on all the subscriber servers to the same password that you created on the publisher server and restart the subscriber server to propagate the password change.




---

**Note** We recommend that you restart each server after the password is changed on that server.

---




---

**Caution** Failure to reboot the servers causes system service problems and problems with the Emergency Responder Administration on the subscriber servers.

---

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

## set password age minimum

This command modifies the value of minimum password age for OS admin accounts in days.

### Usage Guidelines

Acceptable values should be equal to or greater than 0 days but less or equal to 10 days.

### Command Syntax

**set password age minimum** *days*

### Syntax Description

Parameters	Description
<i>days</i>	The minimum password age in days.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

## set password age maximum

This command modifies the value of maximum password age for Emergency Responder OS administration accounts in days.

### Command Syntax

**set password age maximum** *days*

### Usage Guidelines

Acceptable values should be equal to or greater than 10 days but less than 3650 days (10 years).

### Syntax Description

Parameters	Description
<i>days</i>	The maximum password age in days.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

## set password complexity character disable

This command disables password complexity. Changes take effect only at the next password change.

When disabled, the password created or changed after executing the command is no longer strong. The password does not need uppercase, lowercase, digit and special characters.

**Command Syntax**

**set password complexity character disable**

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

## set password complexity character enable

This command enables password complexity rules for the type of characters in a password.

When enabled, the passwords need to follow these guidelines:

- It must have at least one lowercase character.
- It must have at least one uppercase, one digit, and one special character.
- All of the adjacent characters on the keyboard are not accepted.
- Any of the previous ten passwords cannot be reused.
- The admin user password can only be changed once in 24 hours.
- A violation of any of the preceding rules results in a failure.

**Command Syntax**

**set password complexity character enable**

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

## set password complexity minimum-length

This command modifies the value of minimum password length for Unified CM OS accounts.

**Command Syntax**

**set password complexity minimum-length** *length*

**Syntax Description**

Parameters	Description
<i>length</i>	The minimum password length.

**Usage Guidelines**

Acceptable values should be equal to or greater than 6. Use this command only after enabling the character complexity of passwords.



**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**set password expiry maximum-age**

This command enables or disables the password expiry maximum age settings for Cisco Unified Operating System Administrator accounts.

**Command Syntax**

```
set password expiry maximum-age {enable|disable}
```

**Syntax Description**

Parameters	Description
<b>enable</b>	Turns on password expiry maximum age settings for Cisco Unified Operating System administrator accounts. The set password expiry enable command sets the value of <b>maximum password age</b> to 3650 days (10 yrs) for Cisco Unified Operating System Administrator accounts.
<b>disable</b>	Turns off password expiry maximum age settings for Cisco Unified Operating System administrator accounts. The set password expiry disable command results in Cisco Unified Operating System Administrator accounts never expiring.

**set password expiry minimum-age enable**

This command enables minimum password expiry for OS accounts.

**Usage Guidelines**

This command sets the value of minimum password age to 1 day (24 hrs) for OS administration accounts.

**Command Syntax**

```
set password expiry minimum-age enable.
```

**set password expiry minimum-age disable**

This command is used to disable minimum password aging for OS accounts.

This means passwords for OS admin accounts can be changed at any interval.

**Command Syntax**

```
set password expiry minimum-age disable
```

## set password expiry user maximum-age disable

This command disables password expiry for a particular OS account.

### Command Syntax

**set password expiry user maximum-age disable** *userid*

### Syntax Description

Parameters	Description
<i>userid</i>	The name of account for which to disable maximum password age settings.

## set password expiry user maximum-age enable

This command enables maximum password expiry for a particular OS account.

### Command Syntax

**set password expiry user maximum-age enable** *userid*

### Syntax Description

Parameters	Description
<i>userid</i>	The name of account for which to enable maximum password age settings.

## set password expiry user minimum-age disable

This command disables minimum password age settings for a particular OS account.

### Command Syntax

**set password expiry user minimum-age disable** *userid*

### Syntax Description

Parameters	Description
<i>userid</i>	The account for which to disable minimum password age settings.

## set password expiry minimum-age enable

This command enables minimum password age for a particular OS account.

**Command Syntax**

**set password expiry user minimum-age enable** *userid*

**Syntax Description**

Parameters	Description
<i>userid</i>	The account for which to enable minimum password age settings.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

## set password history

This command sets the number of passwords to maintain in history.

**Command Syntax**

**set password history** *number*

**Syntax Description**

Parameters	Description
<i>number</i>	The number of passwords to maintain in history.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

## set password inactivity disable

This command disables the password inactivity for the OS accounts.

**Command Syntax**

**set password inactivity disable**

## set password inactivity enable

This command enables the password inactivity for the OS accounts with the default value set as 10 days.

**Command Syntax**

```
set password inactivity enable
```

## set password inactivity period

This command sets the password inactivity for the OS accounts with the configured value.

**Command Syntax**

```
set password inactivity period days
```

**Syntax Description**

Parameters	Description
<i>days</i>	The number of days for which to set inactivity. Acceptable values are 1 to 99 days.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

## set password user admin

This commands sets a new administration password.

**Command Syntax**

```
set password user admin
```

**Example**

This example runs the set password user admin command:

```
set password user admin
Please enter the old password :*****
Please enter the new password:*****
re-enter new password to confirm:*****
```

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

## set password user security

This command sets a new platform security password.

**Command Syntax**

```
set password user security
```

**Example**

This example runs the set password user security command:

```
set password user security
Please enter the password:*****
re-enter the password to confirm: *****
```

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**set session maxlimit**

This command sets the upper limit for concurrent sessions.

**Command Syntax**

```
set session maxlimit [value]
```

**Syntax Description**

Parameters	Description
<b>maxlimit</b>	This command sets the upper limit for concurrent sessions. Acceptable values are 1 - 100.  If no upper limit is entered, the default value of 10 is assigned to sshd_config param.
<i>[value]</i>	Acceptable values are 1 - 100.

**Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

**set smtp**

This command sets the SMTP server hostname.

**Command Syntax**

```
set smtp hostname
```

**Syntax Description**

Parameters	Description
<i>hostname</i>	The SMTP server name.

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

**set timezone**

This command changes the system time zone.

**Command Syntax**

```
set timezone timezone
```

**Usage Guidelines**

Enter enough characters to uniquely identify the new time zone. Be aware that the time zone name is case-sensitive.



**Note** You must restart the system after you change the time zone.

**Syntax Description**

Parameters	Description
<i>timezone</i>	The new timezone.

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

**Example**

This example sets the time zone to Pacific time:

```
set timezone Pac
```

## set tls min-version

This command sets the minimum version of Transport Layer Security (TLS) protocol.



- Note**
- The system automatically restarts after you set the minimum TLS version.
  - You need to configure the minimum TLS version for each node.

### Command Syntax

```
set tls min-version tls minVersion
```

### Syntax Description

Parameters	Description
<i>tls minVersion</i>	Type any one of the following options to set the minimum TLS version. <ul style="list-style-type: none"> <li>• 1.0</li> <li>• 1.1</li> <li>• 1.2</li> </ul>

**Command Modes** Administrator (admin:)

### Usage Guidelines

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Emergency Responder

#### Example

```
admin: set tls min-version 1.1
```

This command results in setting the minimum TLS version to 1.1 to all secured interfaces. If you have custom applications that make secure connection to the system, then make sure the applications support the TLS version that you have selected to configure. See *Cisco Unified Reporting Administration Guide* to make sure the endpoints in your deployment support this feature.



**Warning** This will set the minimum TLS to 1.1 and the server will reboot.

Do you want to continue (Yes or No)? Yes

The minimum TLS version is set to 1.1 successfully.

The system restarts in few minutes.

## set tls resumption-timeout

This command sets the number of seconds after which the TLS resumption will not work and the sessions will be invalid.

### Command Syntax

```
set tls resumption-timeout set tls resumption-timeout
```

### Syntax Description

Parameters	Description
<i>seconds</i>	Enter a value up to 3600 seconds to configure. After the configured value, the TLS sessions are invalid.

**Command Modes** Administrator (admin:)

### Usage Guidelines

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Emergency Responder

## set tls trace

Currently the **set tls trace** command is supported only for the HAProxy service. Cisco Emergency Responder does not support the HAProxy service and hence the following commands are not applicable.

## set tls trace disable

This CLI command disables the TLS tracing for a service.



**Note** After you disable the TLS trace for a service, the service automatically gets restarted. During the restart process, any functionality related to the service will be not reachable.

### Command Syntax

```
set tls trace disable service
```

### Syntax Description

Parameters	Description
<i>service</i>	Specifies the service that you use to disable TLS tracing.



**Command Modes** Administrator (admin:)

**Usage Guidelines**

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**Example**

```
admin:set tls trace disable
CER doesnt support HAProxy service.Blocking user input
```

## set tls trace enable

This CLI command enables the TLS tracing for a service.



**Note** After you enable the TLS trace for a service, the service automatically gets restarted. During the restart process, any functionality related to the service will be not reachable.

**Command Syntax**

**set tls trace enable** *service*

**Syntax Description**

Parameters	Description
<i>service</i>	Specifies the service that you use to enable TLS tracing.

**Command Modes** Administrator (admin:)

**Usage Guidelines**

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**Example**

```
admin:set tls trace enable
CER doesnt support HAProxy service.Blocking user input
```

## set trace

This command sets trace activity for the specified task.

**Command Syntax**

**set trace**{enable Error| enable Special| enable State\_Transition| enable Significant| enable Entry\_exit| enable Arbitrary| enable Detailed| disable} *tname*

**Syntax Description**

Parameters	Description
<i>tname</i>	The task for which you want to enable or disable traces.
<b>enable Error</b>	Sets task trace settings to the error level.
<b>enable Special</b>	Sets task trace settings to the special level.
<b>enable State_Transition</b>	Sets task trace settings to the state transition level.
<b>enable Significant</b>	Sets task trace settings to the significant level.
<b>enable Entry_exit</b>	Sets task trace settings to the entry_exit level.
<b>enable Arbitrary</b>	Sets task trace settings to the arbitrary level.
<b>enable Detailed</b>	Sets task trace settings to the detailed level.
<b>disable</b>	Disables the task trace settings.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**set web-security**

This command sets the web security certificate information for the operating system.

**Command Syntax**

**set web-security** *orgunit orgname locality state* [*country*] [*alternate-host-name*]

**Usage Guidelines**

When you set an *alternate-host-name* parameter with the **set web-security** command, self-signed certificates for Tomcat contains the Subject Alternate Name extension with the alternate host name specified. CSR for Emergency Responder contains Subject Alternate Name Extension with the alternate host name included in the CSR.

**Syntax Description**

Parameters	Description
<i>orgunit</i>	The organizational unit.
<i>orgname</i>	The organizational name.
<i>locality</i>	The organization location.
<i>state</i>	The organization state.
<i>country</i> represents	The organization country.

Parameters	Description
<i>alternate-host-name</i>	(Optional) Specifies an alternate name for the host when you generate a web-server (Tomcat) certificate.

### Requirements

Command privilege level: 0

Allowed during upgrade: No

## set webapp session maxlimit

This command sets the maximum limit for concurrent web application sessions per user. This applies to the following interfaces:

- Cisco Unified Operating System Administration
- Disaster Recovery System

For the session maximum limit setting to become effective, the administrator must restart the Cisco Tomcat service.




---

**Note** Restarting the Cisco Tomcat service ends all active sessions and can affect the system performance. We recommend that you only execute this command during off-peak traffic hours.

---




---

**Note** This setting gets preserved through a software upgrade and does not get reset to the default value.

---

### Command Syntax

**set webapp session maxlimit** *number*

## Syntax Description

Parameters	Description
<i>number</i>	<p>Specifies the number to limit the concurrent web application sessions.</p> <p>The value ranges from 1 to 10.</p> <p>Default value is 10.</p> <p>If the <b>utils EnhancedSecurityMode</b> command is enabled, then the session limit is restricted to 3. For more details on how to Configure Enhanced Security Mode, see the "FIPS 140-2 Mode Setup" chapter in the <a href="#">Security Guide for Cisco Unified Communications Manager, Release 11.5(1)SU1</a>.</p> <p><b>Note</b> When you exceed the defined sign-in sessions maximum limit, then the interface sign-in page displays the Logon Status message as: The Session limit has already been reached for &lt;username&gt;. Please logout from those sessions or wait 30 minutes for inactive sessions to be automatically closed.</p> <p>When Enhanced Security Mode is enabled, then the session limit is restricted to 3. However, Administrator can change the session limit using the <b>set webapp session maxlimit command</b> to any value ranging from 1 to 10.</p>

## Command Mode

Administrator (admin:)

## Requirements

Command privilege level: 4

Allowed during upgrade: No

## set webapp session timeout

This command sets a timeout period for the web application session of Cisco Emergency Responder and logs off the user on expiry.

For the new webapp session timeout setting to become effective, you must restart the Cisco Tomcat service. Until you restart the Cisco Tomcat service, the show webapp session timeout command reflects the new values, but system continues to use and reflect the old values. This command prompts you to restart the service.




---

**Caution** Restarting the Cisco Tomcat service ends all active sessions and can affect system performance. Cisco recommends that you only execute this command during off-peak traffic hours.

---



**Note** This setting gets preserved through a software upgrade and does not get reset to the default value.

### Command Syntax

set webapp session timeout *minutes*

### Syntax Description

Parameters	Description
<i>minutes</i>	<p>Specifies the time, in minutes, that can elapse before a web application times out and logs off the user.</p> <p><b>Note</b> Cisco Emergency Responder User page does not expire in case of inactivity. Hence, this time out value is not applicable for this User page.</p> <ul style="list-style-type: none"> <li>• Value range: 5-35000 minutes</li> <li>• Default value: 30 minutes</li> </ul>

### Command Mode

Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No

## set workingdir

This command sets the working directory for active, inactive, and installation logs.

### Command Syntax

set workingdir {**activelog**|**inactivelog**|**install**} *directory*

### Syntax Description

Parameters	Description
<b>activelog</b>	Sets the working directory for active logs.
<b>inactivelog</b>	Sets the working directory for inactive logs.
<b>install</b>	Sets the working directory for installation logs.
<i>directory</i>	The current working directory.

**Requirements**

Command privilege level: 0 for logs

Allowed during upgrade: Yes

# Show Commands

## show account

This command lists current administrator accounts, except the master administrator account.

**Command Syntax**

**show account**

**Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

## show cert

This command displays certificate contents and certificate trust lists.

**Command Syntax**

*Table 1: Available Commands*

Command	Result
<b>show cert list</b> {own   trust}	This command displays certificate trust lists.
<b>show cert own</b> <i>filename</i>	This command displays certificate contents.
<b>show cert trust</b> <i>filename</i>	This command displays certificate contents.

**Syntax Description**

Parameters	Description
<i>filename</i>	The name of the certificate file.
<b>own</b>	Specifies owned certificates.
<b>trust</b>	Specifies trusted certificates.
<b>list</b>	Specifies a certificate trust list.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

**Example**

This command displays own certificate trust lists:

```
show cert list own
```

## show cli pagination

This command displays the status of the automatic CLI pagination.

**Command Syntax**

```
show cli pagination
```

**Requirements**

Level privilege: 0

Command privilege: 0

Allowed during upgrade: Yes

**Example**

The following example runs the show cli pagination command:

```
admin: show cli paginationAutomatic Pagination: Off.
```

## show cli session timeout

This command displays the CLI session timeout value, which is the amount of time, in minutes, that can elapse before a CLI session times out and disconnects.

**Command Syntax**

```
show cli session timeout
```

**Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

## show csr list

This command displays the selected CSR file.

### Command Syntax

**show csr list *type***

### Example

This example runs a show csr list command:

```
show csr list own

tomcat/tomcat.csr

Vipr-QuetzalCoatl/Vipr-QuetzalCoatl.csr
```

## show ctl

This command displays the contents of the Certificate Trust List (CTL) file on the server, and it notifies you if the CTL is not valid.

### Command Syntax

**show ctl**

## show date

This command shows the system date.

### Command Syntax

**show date**

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

## show diskusage

This command displays information about disk usage on the server.

### Command Syntax

**show diskusage activelog {activelog| common| inactivelog| install| tmp} filename *filename* {directory | sort}**



## Syntax Description

Parameters	Description
<b>activelog</b>	Displays disk usage information about the activelog directory.
<b>common</b>	Displays disk usage information about the common directory.
<b>inactivelog</b>	Displays disk usage information about the inactivelog directory.
<b>install</b>	Displays disk usage information about the install directory.
<b>tmp</b>	Displays disk usage information about the tmp directory.
<b>filename</b> <i>filename</i>	(Optional) Saves the output to a file specified by a filename. These files are stored in the platform/cli directory. To view saved files, use the <b>file view activelog</b> command.
<b>directory</b>	(Optional) Displays only the directory sizes.
<b>sort</b>	(Optional) Sorts the output based on file size. File sizes are displayed in 1024-byte blocks.

## Requirements

Command privilege level: 0

Allowed during upgrade: Yes

## show dscp all

This command displays the current DSCP traffic markings on all the ports. It displays the DSCP markings in decimal and hexadecimal. If the value corresponds to a class then it displays the correct class. If the value does not correspond to a class, then it displays N/A.

### Command Syntax

```
show dscp all
```

### Command Mode

Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: No

## show dscp defaults

This command displays the default factory DSCP settings. These values take effect if the **set dscp defaults** command is executed.

**Command Syntax****show dscp defaults****Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

## show dscp marking

This command displays the current DSCP traffic markings for a particular DSCP value.

**Command Syntax****show dscp marking** *value***Syntax Description**

Parameters	Description
<i>value</i>	DSCP value. You can enter the name of a well-known DSCP class, or a numeric value in decimal or hexadecimal format. Precede hexadecimal values with 0x or 0X.

**Usage Guidelines**

The valid class names as defined by DSCP are:

- Class Selector: values CS0, CS1, CS2, CS3, CS5, CS6 CS7 The class selector (CS) values correspond to IP Precedence values and are fully compatible with IP Precedence.
- Expedited Forwarding: value EF EF PHB is ideally suited for applications such as VoIP that require low bandwidth, guaranteed bandwidth, low delay, and low jitter.
- Best Effort: value BE Also called default PHB, this value essentially specifies that a packet be marked with 0x00, which gets the traditional best-effort service from the network router.
- Assured Forwarding: values AF11, AF12, AF13, AF21, AF22, AF23, AF41, AF42, AF43 There are four types of Assured Forwarding classes, each of which has three drop precedence values. These precedence values define the order in which a packet is dropped (if needed) due to network congestion. For example, packets in AF13 class are dropped before packets in the AF12 class.

**Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

**show dscp status**

This command displays the current DSCP traffic markings.

**Command Syntax**

**show dscp status** {**enabled**|**disabled**}

**Syntax Description**

Parameters	Description
<b>enabled</b>	Filters the output to show only DSCP traffic markings that are enabled. If you do not specify a status, this filter is the default option.
<b>disabled</b>	Filters the output to show only DSCP traffic markings that are disabled.

**Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

**show environment**

This command displays information about the server hardware.

**Command Syntax**

**show environment** {**fans** |**power-supply** |**temperatures**}

**Syntax Description**

Parameters	Description
<b>fans</b>	Displays information gathered by fan probes.
<b>power-supply</b>	Displays information gathered by power supply probes.
<b>temperatures</b>	Displays information gathered by temperature probes.

## show hardware

This command displays the following information about the platform hardware.

### Command Syntax

**show hardware**

### Usage Guidelines

This command displays the following information about the platform hardware:

- Platform
- Serial number
- BIOS build level
- BIOS manufacturer
- Active processors
- RAID controller status

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

## show ipsec

This command displays information about IPsec policies and associations.

### Command Syntax

*Table 2: Available Commands*

Command	Result
<b>show ipsec information</b> <i>policy_group policy_name</i>	This command displays detailed information about the specified ipsec policy.
<b>show ipsec policy_group</b>	This command displays all the ipsec policy group on the node.
<b>show ipsec policy_name</b> <i>policy_group</i>	This command displays the list of ipsec policy names that exist in the specified policy group.
<b>show ipsec status</b>	

### Syntax Description

Parameters	Description
<b>information</b>	Displays the association details and status for the policy.

Parameters	Description
<b>status</b>	Displays the status of all IPsec tunnels that are defined in the system.
<i>policy_group</i>	The name of a specific IPsec policy.

**Requirements**

Command privilege level: 1  
 Allowed during upgrade: yes

**Example**

This example displays IPsec policies:

```
show ipsec policy
```

## show license all

This command displays the details about smart licensing status, entitlements in use, product information, and smart agent version.

**show license all**


---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0  
 Allowed during upgrade: Yes

## show license status

This command displays the overall smart licensing status along with the failure reasons, if any.

**show license status**


---

**Command Modes** Administrator (admin:)

**Requirements**

Command privilege level: 0  
 Allowed during upgrade: Yes

## show license summary

This command displays the overall smart licensing status and license usage.

**show license summary****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

**show license tech support**

This command displays all information that aids in debugging smart agent.

**show license tech support****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

**show license trace**

This command dumps the content of smart agent-related logs to the console.

**show license trace****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

**show license udi**

This command displays the product information or all members in the Unique Device Identifier (UDI) structure that are not NULL.

**show license UDI****Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

## show license usage

This command displays the details of entitlements or licenses that are in use.

**show license usage**

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

## show logins

This command displays recent logins to the server.

### Command Syntax

**show logins** *number*

### Syntax Description

Parameters	Description
<i>number</i>	The number of most recent logins to display. The default is 20.

## show memory

This command displays information about the server memory.

### Command Syntax

**show memory** {*count* | **module**[**ALL** | *module\_number*] | **size**}

### Syntax Description

Parameters	Description
<b>ALL</b>	Displays information about all installed memory modules.
<i>module_number</i>	Specifies the memory module to display.
<b>count</b>	(Optional)Displays the number of memory modules on the system.
<b>module</b>	(Optional)Displays detailed information about each memory module.
<b>size</b>	(Optional)Displays the total amount of memory.

## show myself

This command displays information about the current account.

### Command Syntax

**show myself**

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

## show network

This command displays network information.

### Command Syntax

*Table 3: Available Commands*

Command	Result
<b>show networkall</b> [detail]	This command shows network information for listening and non-listening sockets.
<b>show networketh0</b> [detail]	This command shows network information for ethernet 0.
<b>show networkfailover</b> [detail] [page]	This command shows Network Fault Tolerance information.
<b>show networkroute</b> [detail]	This command shows network routing information.
<b>show network status</b> [detail] [listen] [process] [all] [nodns] [search stext]	This command shows active internet connections.
<b>show network ip_contrack</b>	This command shows ip_contrack usage information.
<b>show network max_ip_contrack</b>	This command shows max_ip_contrack information.
<b>show network dhcp eth0 status</b>	This command shows DHCP status information.
<b>show network cluster</b>	This command lists nodes in the network cluster.
<b>show network ipprefs</b> {all  enabled  public}	This command shows the list of ports that have been requested to be opened or translated in the firewall.
<b>show network ntp</b>	
<b>show network failover</b> [detail][page]	This command shows Network Fault Tolerance information.



Command	Result
<code>show network ipv6 {route  settings}</code>	This command shows IPv6 network routes and network settings.

### Syntax Description

Parameters	Description
<code>eth0</code>	Specifies Ethernet 0.
<code>failover</code>	Specifies Network Fault Tolerance information.
<code>route</code>	Specifies network routing information.
<code>status</code>	Specifies active Internet connections.
<code>ip_contrack</code>	Specifies ip_contrack usage information.
<code>max_ip_contrack</code>	Specifies max_ip_contrack information.
<code>dhcp eth0 status</code>	Displays DHCP status information.
<code>all</code>	Specifies all basic network information.
<code>options</code>	(Optional)Displays additional information.
<code>detail</code>	(Optional)Displays more detailed additional information.
<code>page</code>	(Optional)Displays information one page at a time.
<code>listen</code>	(Optional)Displays only listening sockets.
<code>process</code>	(Optional)Displays the process ID and name of the program to which each socket belongs.
<code>all</code>	(Optional)Displays both listening and nonlistening sockets.
<code>nodns</code>	(Optional)Displays numerical addresses without any DNS information.
<code>search stext</code>	(Optional)Searches for the stext in the output.

**Usage Guidelines** The `eth0` parameter displays Ethernet port 0 settings, including DHCP and DNS configurations and options.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

### Example

This example displays active Internet connections:

```
show network status
```

## show network cluster

This command lists nodes in the network cluster.

### Command Syntax

```
show network cluster
```

### Command Mode

Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

## show network ipprefs

This command displays the list of ports that have been requested to be opened or translated in the firewall.

### Command Syntax

```
ipprefs {all| enabled| public}
```

### Syntax Description

Parameters	Description
<b>all</b>	Displays all incoming ports that may be used on the product.
<b>enabled</b>	Displays all incoming ports that are currently opened.
<b>public</b>	Displays all incoming ports that are currently opened for any remote client.

### Requirements

Level privilege: 0

Command privilege: 0

Allowed during upgrade: Yes

### Example

The following example shows show the network ipprefs command:

```
admin:show network ipprefs public
Application IPProtocol PortValue Type XlatedPort Status Description
-----
```

```

sshd          tcp          22          public      -          enabled    sftp and ssh access
tomcat        tcp          8443        translated 443    enabled    secure web access
tomcat        tcp          8080        translated 80     enabled    web access
clm           udp          8500        public      -          enabled    cluster manager
clm           tcp          8500        public      -          enabled    cluster manager
ntpd          udp          123         public      -          enabled    network time sync
snmpdm        udp          161         public      -          enabled    SNMP
ccm           tcp          2000        public      -          enabled    SCCP-SIG
ctftp         udp          6969        translated 69     enabled    TFTP access to CUCM TFTP
Server
ctftp         tcp          6970        public      -          enabled    HTTP access to CUCM TFTP
Server
admin:

```

## set network ntp option

This command adds a noquery option to /etc/config file.

### Command Syntax

```
set network ntp option noquery
```

## show open

This command displays open files and ports on the system.

### Syntax Description

Table 4: Available Commands

Command	Result
<b>show open files</b> [ <b>all</b> ] [ <b>regex</b> <i>reg_exp</i> ]	This command shows open files on the system.
<b>show open ports</b> [ <b>all</b> ] [ <b>regex</b> <i>reg_exp</i> ]	This command shows all open ports on the system.

### Syntax Description

Parameters	Description
<b>files</b>	displays open files on the system.
<b>ports</b>	displays open ports on the system.
<b>all</b>	(Optional)Displays all open files or ports.
<b>process</b>	(Optional)Displays open files that belong to the specified process.
<i>processID</i>	(Optional)Specifies a process.
<b>regex</b>	(Optional)Displays open files or ports that match the specified regular expression.
<i>reg_exp</i>	(Optional)A regular expression.

## show packages

This command displays the name and version for installed packages.

### Command Syntax

```
show packages {active|inactive} name [page]
```

### Syntax Description

Parameters	Description
<b>active</b>	Specifies active packages.
<b>inactive</b>	Specifies inactive packages.
<i>name</i>	The package name. To display all active or inactive packages, use the wildcard character (*).
<b>page</b>	(Optional)Displays the output one page at a time.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

## show password expiry maximum-age

This command displays the configured password expiration parameters.

### Command Syntax

```
show password expiry maximum-age
```

## show password expiry minimum-age

This command displays the configured password expiration parameters.

### Command Syntax

```
show password expiry minimum-age
```

## show password expiry user maximum-age

This command displays the configured password expiration parameters for a particular OS user.

### Command Syntax

```
show password expiry user maximum-age userid
```

## show password expiry user minimum-age

This command displays the configured password expiration parameters for a particular OS user.

### Command Syntax

```
show password expiry user minimum-age userid
```

## show password history

This command displays the number of passwords that are maintained in the history for OS admin accounts.

### Command Syntax

```
show password history
```

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

## show password inactivity

This command displays the status of the password inactivity for OS accounts.

Password inactivity is the number of days of inactivity after a password has expired before the account is disabled.

### Command Syntax

```
show password inactivity
```

### Example

```
show password inactivity
Password Inactivity: Enabled and is currently set to 10
                    days
```

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

## show process

This command displays information about processes running on the system.

## Syntax

Command	Result
<b>show processlist</b> [ <b>file</b> filename] [ <b>detail</b> ]	This command displays a list of all the processes and critical information about each process and visually indicates the child-parent relationships between the processes.
<b>show processload</b> [ <b>cont</b> ] [ <b>clear</b> ] [ <b>noidle</b> ] [ <b>num number</b> ] [ <b>thread</b> ] [ <b>cpu</b>   <b>memory</b> ] [ <b>time</b> ] [ <b>page</b> ]	This command displays the current load on the system.
<b>show process name</b> process [ <b>file</b> filename]	This command displays the details of processes that share the same name and indicates their parent-child relationship.
<b>show process open-fd</b> process-id [, process-id2]	This command lists the open file descriptors for a comma-separated list of process IDs.
<b>show process search</b> regexp [ <b>file</b> filename]	This command searches for the pattern that the regular expression regexp specifies in the output of the operating system-specific process listing.
<b>show process using-most cpu</b> [number] [ <b>file</b> filename]	This command displays a list of the most CPU-intensive processes.
<b>show process using-most memory</b> [number] [ <b>file</b> filename]	This command displays a list of the most memory-intensive processes.
<b>show process pid</b> pid[ <b>file</b> filename]	This command displays a list of PIDs.
<b>show process user</b> username [ <b>file</b> filename]	This command retrieves details of processes that share the user name and displays parent-child relationship.
<b>show process using most</b>	This command lists the most intensive processes.

## Syntax Description

Parameters	Description
<b>list</b>	displays a list of all the processes and critical information about each process, and visually indicates the child-parent relationships between the processes.
<b>load</b>	displays the current load on the system.
<b>name</b>	displays the details of processes that share the same name and indicates their parent-child relationship.
<b>open-fd</b>	lists the open file descriptors for a comma-separated list of process IDs.
<b>search</b>	searches for the pattern specified by the regular expression regexp in the output of the operating system-specific process listing.

Parameters	Description
<b>using-most cpu</b>	displays a list of the most CPU-intensive processes.
<b>using-most memory</b>	displays a list of the most memory-intensive processes.
<b>file</b> <i>filename</i>	(Optional)Outputs the results to the file specified by the filename.
<b>detail</b>	(Optional)Displays the detailed output.
<b>cont</b>	(Optional)Repeats the command continuously.
<b>clear</b>	(Optional)Clears the screen before displaying output.
<b>noidle</b>	(Optional)Ignores the idle/zombie processes.
<b>num</b> number	(Optional)Displays the number of processes specified by number. The default number of processes is 10. Set number to <b>all</b> to display all processes.
<b>thread</b>	(Optional)Displays threads.
<b>[cpu   memory   time]</b>	(Optional)Sorts output by CPU usage, memory usage, or time usage. The default is to sort by CPU usage.
<b>page</b>	(Optional)Displays the output in pages.
<i>process</i>	(Optional)Specifies the name of a process.
<i>process-id</i>	(Optional)Specifies the process ID number of a process.
<i>regexp</i>	(Optional)A regular expression.
<i>number</i>	(Optional)The number of processes to display. The default is 5.
<i>pid</i>	Specifies the process ID number of a process.
<i>username</i>	Specifies the username.

## show session maxlimit

This command shows the upper limit for concurrent SSH sessions.

### Command Syntax

```
show session maxlimit
```

### Command Mode

Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

## show smtp

This command displays the name of the SMTP host.

### Command Syntax

**show snmp**

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

## show stats io

This command displays system I/O statistics.

### Command Syntax

**show stats io** [**kilo**] [**detail**] [**page**] [**file filename**]

### Syntax Description

Parameters	Description
<b>kilo</b>	Displays statistics in kilobytes.
<b>detail</b>	Displays detailed statistics on every available device on the system and overrides the kilo option.
<b>page</b>	Displays one page at a time.
<b>file filename</b>	Outputs the information to a file.

### Usage Guidelines

The file option saves the information to

`platform/cli/filename.txt`.

The filename cannot contain the "." character.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes



## show status

This command displays basic platform status.

### Command Syntax

**show status**

### Usage Guidelines

This command displays the following basic platform status:

- Host name
- Date
- Time zone
- Locale
- Product version
- Platform version
- CPU usage
- Memory and disk usage

### Requirements

Command privilege level: 0

## show tech all

This command displays the combined output of all **show tech** commands.

### Command Syntax

**show tech all** [**page**] [**file filename**]

### Syntax Description

Parameters	Description
<b>page</b>	Displays one page at a time.
<b>file filename</b>	Outputs the information to a file.

### Usage Guidelines

The file option saves the information to

`platform/cli/filename.txt`.

The file name cannot contain the "." character.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

**show tech database**

This command creates a CSV file of the entire database.

**Command Syntax**

**show tech database {dump|sessions}**

**Syntax Description**

Parameters	Description
<b>dump</b>	Creates a CSV file of the entire database.
<b>sessions</b>	Redirects the session and SQL information of the present session IDs to a file.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

**show tech database dump**

This command creates a CSV file of the entire database.

**Command Syntax**

**show tech database dump**

**show tech dbintegrity**

This command displays the database integrity.

**Command Syntax**

**show tech dbintegrity**

**show tech dbinuse**

This command displays the database in use.

**Command Syntax****show tech dbinuse****Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

## show tech dbschema

This command displays the database schema in a CSV file.

**Command Syntax****show tech dbschema****Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

## show tech dbstateinfo

This command displays the state of the database.

**Command Syntax****show tech dbstateinfo**

## show tech network

This command displays network aspects of the server.

**Command Syntax**

Command	Result
<b>show tech network</b>	
<b>show tech network</b> [page] [file filename]	This command displays network tech information for a page.
<b>show tech network all</b> [page] [search text] [file filename]	This command displays all network tech information.
<b>show tech network hosts</b> [page] [search text] [file filename]	This command displays information about hosts configuration.
<b>show tech network interfaces</b> [page] [search text] [file filename]	This command displays information about the network interfaces.

Command	Result
<b>show tech network resolv</b> [ <i>page</i> ] [ <i>search text</i> ] [ <b>file</b> <i>filename</i> ]	This command displays information about hostname resolution.
<b>show tech network routes</b> [ <i>page</i> ] [ <i>search text</i> ] [ <b>file</b> <i>filename</i> ]	This command displays information about network routes.
<b>show tech network sockets</b> { <i>numeric</i> }	This command displays the list of open sockets.

### Syntax Description

Parameters	Description
<b>all</b>	displays all network technical information.
<b>hosts</b>	displays information about hosts configuration.
<b>interfaces</b>	displays information about the network interfaces.
<b>resolv</b>	displays information about hostname resolution.
<b>routes</b>	displays information about network routes.
<b>sockets</b>	displays the list of open sockets.
<b>page</b>	(Optional)Displays one page at a time.
<b>search <i>text</i></b>	(Optional)Searches the output for the string specified by <i>text</i> . The search is not case sensitive.
<b>file <i>filename</i></b>	(Optional)Outputs the information to a file.
<b>numeric</b>	(Optional)Displays the numerical addresses of the ports instead of determining symbolic hosts. It is equivalent to running the Linux <b>netstat [-n]</b> shell command.

**Usage Guidelines** The **file** option saves the information to platform/cli/filename.txt. The file name cannot contain the "." character.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

## show tech prefs

This command displays all preferences files for Emergency Responder and its database.

**Usage Guidelines** This information is written to a file, which can be viewed subsequently using the **file view** CLI.

**Command Syntax**

```
show tech prefs
```

**show tech runtime**

This command displays server runtime.

**Command Syntax**

```
show tech runtime {all | cpu| disk| env| memory} [page] [file filename]
```

**Syntax Description**

Parameters	Description
<b>all</b>	Displays all runtime information.
<b>cpu</b>	Displays CPU usage information at the time the command is run.
<b>disk</b>	Displays system disk usage information.
<b>env</b>	Displays environment variables.
<b>memory</b>	Displays memory usage information.
<b>page</b>	Displays one page at a time.
<b>file filename</b>	Outputs the information to a file.

**Usage Guidelines**

The **file** option saves the information to `platform/cli/filename.txt`.

The file name cannot contain the "." character.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

**show tech systables**

This command displays the name of all tables in the sysmaster database.

**Command Syntax**

```
show tech systables
```

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

## show tech system

This command displays the system aspects of the server.

### Command Syntax

```
show tech system {all| bus| hardware| host| kernel| software| tools} [page] [file filename]
```

### Syntax Description

Parameters	Description
<b>all</b>	Displays all of the system information.
<b>bus</b>	Displays information about the data buses on the server.
<b>hardware</b>	Displays information about the server hardware.
<b>host</b>	Displays information about the server.
<b>kernel</b>	Lists the installed kernel modules.
<b>software</b>	Displays information about the installed software versions.
<b>tools</b>	Displays information about the software tools on the server.
<b>page</b>	Displays one page at a time.
<b>file filename</b>	Outputs the information to a file.

### Usage Guidelines

The **file** option saves the information to

```
platform/cli/filename.txt
```

. The file name cannot contain the "." character.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

## show tech table

This command displays the contents of the specified database table.

### Command Syntax

```
show tech table table_name [page] [csv]
```

**Syntax Description**

Parameters	Description
<i>table_name</i>	The name of the table to display.
<b>page</b>	Displays the output one page at a time.
<b>csv</b>	Sends the output to a comma separated values file.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

**show tech version**

This command displays the version of the installed components.

**Command Syntax**

**show tech version** [**page**]

**Syntax Description**

Parameters	Description
<b>page</b>	Displays the output one page at a time.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

**show timezone**

This command displays time zone information.

**Command Syntax**

**show timezone** {**config**|**list** [**page**] }

**Syntax Description**

Parameters	Description
<b>config</b>	Displays the current time zone settings.
<b>list</b>	Displays the available time zones.

Parameters	Description
page	Displays the output one page at a time.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

## show tls trace

This command shows the status of TLS trace for a service.

**Command Syntax**

**show tls trace** *service*

**Syntax Description**

Parameters	Description
<i>service</i>	Represents the TLS tracing status of a service. It is a mandatory parameter.

**Command Modes**

Administrator (admin:)

**Usage Guidelines****Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Emergency Responder

**Example**

```
admin:show tls trace
CER doesnt support HAProxy service.Blocking user input
```

## show tls min-version

This command shows the minimum configured version of Transport Layer Security (TLS) protocol.

**Command Syntax**

**show tls min-version**

**Command Modes**

Administrator (admin:)

**Usage Guidelines****Requirements**



Command privilege level: 1  
 Allowed during upgrade: Yes  
 Applies to: Cisco Emergency Responder

**Example**

```
admin:show tls min-version
```

The configured TLS minimum version is 1.0.

## show tls resumption-timeout

This command shows the TLS session resumption timeout.

**Command Syntax**

```
show tls resumption-timeout
```

**Command Modes**

Administrator (admin:)

**Usage Guidelines****Requirements**

Command privilege level: 1  
 Allowed during upgrade: Yes  
 Applies to: Cisco Emergency Responder

## show trace

This command displays trace information for a particular task.

**Command Syntax**

```
show trace [task_name]
```

**Syntax Description**

Parameters	Description
<i>task_name</i>	The name of the task for which you want to display the trace information.

**Usage Guidelines**

If you do not enter any parameters, the command returns a list of available tasks.

**Requirements**

Command privilege level: 0  
 Allowed during upgrade: Yes

**Example**

This example displays trace information for CDP.

```
show trace cdps
```

**show ups status**

This command shows the current status of the USB-connected APC smart-UPS device and starts the monitoring service if not already started.

**Command Syntax**

```
show ups status
```

**Usage Guidelines**

This command only can provide a complete status on 7835-H2 and 7825-H2 servers.

**show version**

This command displays the software version on the active or inactive partition.

**Command Syntax**

```
show version {active|inactive}
```

**Syntax Description**

Parameters	Description
active	Displays the version running on the active partition.
inactive	Displays the version on the inactive partition.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

**show webapp session timeout**

This command displays the webapp session timeout value, which is the amount of time, in minutes, that can elapse before a web application times out and logs off the user.

**Command Syntax**

```
show webapp session timeout
```

**Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

## show web-security

This command displays the contents of the current web-security certificate.

**Command Syntax**

**show web-security**

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

## show workingdir

This command retrieves the current working directory for activelog, inactivelog, install, and TFTP.

**Command Syntax**

**show workingdir**

**Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

# Unset Commands

## unset ipsec

This command allows you to disable IPsec policies and associations.

**Command Syntax**

Command	Result
<b>unset ipsec policy</b> {ALL   <i>policy-name</i> }	

Command	Result
<b>unset ipsec association</b> <i>policy-name</i> { <b>ALL</b>   <i>association-name</i> }	

### Syntax Description

Parameters	Description
<i>policy-name</i>	The name of an IPsec policy.
<i>association-name</i>	The name of an IPsec association.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

## unset network

This command unsets DNS options.

### Command Syntax

**unset network dns options** [**timeout**] [**attempts**] [**rotate**]

### Syntax Description

Parameters	Description
<b>timeout</b>	Sets the wait time before the system considers a DNS query failed to the default.
<b>attempts</b>	Sets the number of DNS attempts to make before failing to the default.
<b>rotate</b>	Sets the method for selecting a name server to the default. This affects how loads are distributed across name servers.

**Usage Guidelines** The system asks whether you want to continue to execute this command.



**Caution** If you continue, the system temporarily loses network connectivity.

## unset network domain

This command unsets the domain name and restarts the server.

**Command Syntax****unset network domain****Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

# Utils Commands

## utils auditd

This command starts, stops, and provides the status of the system auditing service.

**Command Syntax****utils auditd {enable|disable|status}****Syntax Description**

Parameters	Description
<b>enable</b>	Enables the collection of audit logs. When enabled, the system monitors and records user actions as well as Linux events such as the creation and removal of users, as well as the editing and deleting of files.
<b>disable</b>	Disables the collection of audit logs.
<b>status</b>	Displays the status of audit log collection. Cisco recommends that you retrieve the audit log by using the Real-Time Monitoring Tool, but you can also retrieve it by using the CLI.

**Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

**Usage Guidelines**

After the service has been enabled, it monitors and logs activity on the system. Be aware that the system auditing service logs a lot of information. Care must be taken not to overfill the disk.

## utils core list

This command lists all existing core files.

### Command Syntax

```
utils core {active|inactive} list
```

## utils core analyze

This command generates a backtrace for the specified core file, a thread list, and the current value of all CPU registers.

### Command Syntax

```
utils core analyze core file name
```

### Syntax Description

Parameters	Description
<i>core file name</i>	Specifies the name of a core file.

### Usage Guidelines

The command creates a file of the same name as the core file, with a .txt extension, in the same directory as the core file. This command works only on the active partition.

## utils create report

This command creates reports about the server in the platform or log directory.

### Command Syntax

```
utils create report {hardware|platform|csa}
```

### Syntax Description

Parameters	Description
<b>hardware</b>	Creates a system report containing disk array, remote console, diagnostic, and environmental data.
<b>platform</b>	Collects all of the platform configuration files into a TAR file.
<b>csa</b>	Collects all the files required for CSA diagnostics and assembles them into a single CSA diagnostics file. You can retrieve this file by using the <b>file get</b> command.

### Usage Guidelines

You are prompted to continue after you enter the command.

After creating a report, to get the report use the command **file get activelog platform/log/filename**, where *filename* is the report filename that is displayed after the command completes.

### Requirements

Level privilege: 1

Command privilege level: 0

Allowed during upgrade: Yes

## utils create report database

Collects all log files needed for database troubleshooting.

### Command Syntax

**Utils create report database.**

### Example

```
admin:utils create report database
Created /var/log/active/cm/log/informix/[hostname]_db_report_Oct_27_11_13_10 for log
collection...
Collecting database logs, please be patient...
Collecting message logs (ccm.log) and assert failure files (af files)...
Collecting ris and ats files...
Collecting DB Replication logs...
Collecting DB install logs...
Collecting dblrpc and dbmon logs...
Collecting CDR information...
COMPLETED! Database report created successfully...
To retrieve the [hostname]_db_report_Oct_27_11_13_10.tar, use CLI command:
file get activelog cm/log/informix/[hostname]_db_report_Oct_27_11_13_10.tar
To delete the [hostname]_db_report_Oct_27_11_13_10.tar, use CLI command:
file delete activelog cm/log/informix/[hostname]_db_report_Oct_27_11_13_10.tar
```

## utils configapisecurehttp

This command enables secure http for UCAT service(ConfigAPI).

### Command Syntax

Command	Result
utils configapisecurehttp enable	This command when enabled, UCAT(ConfigAPI) connections are allowed only over secure http.
utils configapisecurehttp disable	This command when disabled, non-secure http UCAT(ConfigAPI) connections are allowed.
utils configapisecurehttp status	Displays the enabled or disabled status of the command.

**Usage Guidelines**

We recommend that you enable the `configapisecurehttp` when the FIPS mode or Enhanced Security Mode is enabled on the Cisco Emergency Responder server.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

## utils dbreplication dropadmindb

This command drops the Informix syscdr database on any server in the cluster.

**Command Syntax**

**utils dbreplication dropadmindb**

**Usage Guidelines**

You should run this command only if database replication reset or cluster reset fails and replication cannot be restarted.

**Command Modes**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

Applies to: Unified Communications Manager, IM and Presence service on Unified Communications Manager, Cisco Unity Connection.

## utils dbreplication status

This command displays the status of database replication. Use this command only on the first publisher server of a cluster.

**Command Syntax**

**utils dbreplication status**

## utils dbreplication stop

This command stops the automatic setup of database replication. Run this command on subscriber and publisher servers before executing the CLI command **utils dbreplication reset** or **utils dbreplication clusterreset**. You can run this command on the subscriber servers simultaneously, before you run it on the publisher server.

**Command Syntax**

**utils dbreplication stop** {*nodename*|all}



**Syntax Description**

Parameters	Description
<i>nodename</i>	Specifies the name of the node on which to stop the automatic setup of database replication.
<b>all</b>	Stops database replication on all nodes.

**Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: No

## utils dbreplication repair

This command repairs database replication.

**Command Syntax**

**utils dbreplication repair**

## utils dbreplication reset

This command resets and restarts database replication.

**Command Syntax**

**utils dbreplication reset**

**Usage Guidelines**

You must restart the Emergency Responder Subscriber node from CUOS Administration or using the CLI command **utils system restart** after executing **utils dbreplication reset** command. See **help utils dbreplication reset** CLI command for more details.

## utils diagnose

This command enables you to diagnose and attempt to automatically fix system problems.

**Command Syntax**

**utils diagnose** {**fix**|**list**|**module**|**test**|**version**} [*module\_name*]

**Syntax Description**

Parameters	Description
<b>fix</b>	Runs all diagnostic commands and attempts to fix problems.
<b>list</b>	Lists all available diagnostic commands.
<b>module</b>	Runs a single diagnostic command or group of commands and attempts to fix problems.
<b>test</b>	Runs all diagnostic commands but does not attempt to fix problems.
<b>version</b>	Displays the diagnostic framework version.
<i>module_name</i>	The name of a diagnostics module.

**utils diagnose test**

This command enables you to run all diagnostic commands but does not attempt to fix any problems.

**Command Syntax**

utils diagnose test

**utils disaster\_recovery backup network**

This command starts a backup job and stores the resulting tar file on a remote server.

**Command Syntax**

utils disaster\_recovery backup network [*featurelist*] [*path*] [*servername*] [*username*]

**Syntax Description**

Parameters	Description
<i>featurelist</i>	Specifies the list of features to back up, separated by commas.
<i>path</i>	Represents the location of the backup files on the remote server.
<i>servername</i>	Represents the IP address or host name of the server where you stored the backup files.
<i>username</i>	Represents the username that is needed to log in to the remote server.

## Usage Guidelines



**Note** The system prompts you to enter the password for the account on the remote server.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

## utils disaster\_recovery cancel\_backup

This command cancels the ongoing backup job.

### Command Syntax

**utils disaster\_recovery cancel\_backup**

## Usage Guidelines

The system prompts you to confirm that you want to cancel the backup job.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

## utils disaster\_recovery device add network

This command adds the backup network device.

### Command Syntax

**utils disaster\_recovery device add network** *device\_name path server\_name/ip\_address username*  
[*Number\_of\_backups*]

### Syntax Description

Parameters	Description
<i>device_name</i>	The name of the backup device to be added.
<i>path</i>	The path to retrieve backup device from this location.
<i>server_name/ip_address</i>	The hostname or IP address of the server where the backup file needs to be stored.
<i>username</i>	the user ID to connect to remote machine
<i>Number_of_backups</i>	(Optional)The number of backups to store on Network Directory(default 2).

**Example**

Use the following example when running the `utils disaster_recovery device add network` command:

```
utils disaster_recovery device add network
networkDevice /root 10.77.31.116 root 3
```

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

## utils disaster\_recovery device delete

This command deletes the device.

**Command Syntax**

```
utils disaster_recovery device delete device_name*
```

**Syntax Description**

Parameters	Description
<i>device_name</i>	The name of the device to be deleted.
*	Deletes all the existing devices except for the ones associated to a schedule.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

## utils disaster\_recovery device list

This command shows the device name, device type, and device path for all the backup devices.

**Command Syntax**

```
utils disaster_recovery device list
```

**Example**

The following example shows how to run this command:

```
utils disaster_recovery device list
sftpdevice          NETWORK          10.77.31.116 : /root
tapedevice          TAPE             /dev/nst0
localdevice         LOCAL            /common/drbackup
```

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

**utils disaster\_recovery estimate\_tar\_size**

estimate\_tar\_size help:

This command provides the estimated size of last successful backup from SFTP/Local device.

**Syntax Description**

Parameters	Description
Name of the tar	This will give the tar file name through which the size can be estimated.

**Example**

```
admin:utils disaster_recovery estimate_tar_size CER
Estimated tar size successfully: Estimated size of backup for selected feature(s) is 42.52
MB.
```

**utils disaster\_recovery history**

This command shows the history of a previous backup or restore

**Command Syntax**

**utils disaster\_recovery history operation**

**Syntax Description**

Parameters	Description
<i>operation</i>	The name of an operation such as backup or restore.

**Example**

The following example shows how to run this command:

```
utils disaster_recovery history backup
Tar Filename: Backup Device: Completed On: Result: Backup Type: Features Backed Up:
2009-10-30-14-53-32.tar TAPE Fri Oct 30 14:55:31 CDT 2009 ERROR MANUAL
2009-12-10-10-30-17.tar TAPE Thu Dec 10 10:35:22 CST 2009 SUCCESS MANUAL
CDR_CAR,CCM
```

**utils disaster\_recovery jschLogs**

This command enables and disables detailed JSch logging.

**Example**

```
drfCliCommand: JSch detailed logging enabled.
Restart DRS Master and Local Agent in this machine for the changes to take effect.

drfCliCommand: JSch detailed logging disabled.
Restart DRS Master and Local Agent in this machine for the changes to take effect.
JSch logs deleted successfully.
```

**utils disaster\_recovery schedule add**

This command adds the configured schedules.

**Command Syntax**

```
utils disaster_recovery schedule add schedulename devicename featurelist datetime frequency
```

**Syntax Description**

Parameters	Description
<i>schedulename</i>	The name of the scheduler.
<i>devicename</i>	The name of the device for which scheduling is done.
<i>featurelist</i>	The comma-separated feature list to back up.
<i>datetime</i>	The date when the scheduler is set. The format is (yyyy/mm/dd-hh:mm) 24-hr clock.
<i>frequency</i>	The frequency at which the scheduler is set to receive a backup. For example: ONCE, DAILY, WEEKLY and MONTHLY .

**Example**

The following example show how to run this command:

```
utils disaster_recovery schedule add schedulename devicename featurelist
datetime frequency
Schedule has been saved successfully.
```

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

**utils disaster\_recovery schedule delete**

This command deletes the specified schedule.

**Command Syntax**

```
utils disaster_recovery schedule delete schedulename*
```

**Syntax Description**

Parameters	Description
<i>schedulename</i>	The name of the schedule that needs to be deleted.
*	Deletes all of the existing schedules.

**Example**

The following example shows how this command is run:

```
utils disaster_recovery schedule delete schedule1|
Schedules deleted successfully.
```

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**utils disaster\_recovery schedule disable**

This command disables the specified schedule.

**Command Syntax**

```
utils disaster_recovery schedule disable schedulename
```

**Syntax Description**

Parameters	Description
<i>schedulename</i>	The name of the schedule that needs to be disabled.

**Example**

The following example shows how to run this command:

```
utils disaster_recovery schedule disable schedule1
Schedule disabled successfully.
```

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**utils disaster\_recovery schedule enable**

This command enables the specified schedule.

**Command Syntax**

**utils disaster\_recovery schedule enable** *schedulename*

**Syntax Description**

Parameters	Description
<i>schedulename</i>	The name of the schedule that needs to be enabled.

**Example**

The following example shows how to run this command:

```
utils disaster_recovery schedule enable schedule1
Schedule enabled successfully.
```

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**utils disaster\_recovery schedule list**

This command displays all the of configured schedules.

**Command Syntax**

**utils disaster\_recovery schedule list**

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**utils disaster\_recovery restore network**

This command starts a restore job and takes the backup tar file from a remote server.

**Command Syntax**

**utils disaster\_recovery restore network** *restore\_server tarfilename path servername username*

**Syntax Description**

Parameters	Description
<i>restore_server</i>	Specifies the hostname of the server that you want to restore.
<i>tarfilename</i>	Specifies the name of the file to restore.



Parameters	Description
<i>path</i>	Represents the location of the backup files on the remote server.
<i>servername</i>	Represents the IP address or host name of the server where you stored the backup files.
<i>username</i>	Represents the username that is needed to log in to the remote server.

### Usage Guidelines



**Note** The system prompts you to enter the password for the account on the remote server.

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

## utils disaster\_recovery show\_backupfiles tape

This command displays information about the backup files that are stored on a tape.

#### Command Syntax

**utils disaster\_recovery show\_backupfiles tape** *tapeid*

#### Syntax Description

Parameters	Description
<i>tapeid</i>	Represents the ID of an available tape device.

#### Requirements

Command privilege level: 1

Allowed during upgrade: No

## utils disaster\_recovery show\_backupfiles network

This command displays information about the backup files that are stored on a remote server.

#### Command Syntax

**utils disaster\_recovery show\_backupfiles network** *path servername username*

**Syntax Description**

Parameters	Description
<i>path</i>	Represents the location of the backup files on the remote server.
<i>servername</i>	The IP address or host name of the server where you stored the backup files.
<i>username</i>	The username that is needed to log in to the remote server.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**utils disaster\_recovery show\_registration**

This command displays the registered features and components on the specified server.

**Command Syntax**

**utils disaster\_recovery show\_registration** *hostname*

**Syntax Description**

Parameters	Description
<i>hostname</i>	The server that you want to display registration information.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**utils disaster\_recovery status**

This command displays the status of the current backup or restore job.

**Command Syntax**

**utils disaster\_recovery status** *operation*

**Syntax Description**

Parameters	Description
<i>operation</i>	The name of the ongoing operation: backup or restore.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**utils EnhancedSecurityMode**

This command allows you to check and change Enhanced Security Mode status on a particular node.

**Command Syntax**

Command	Result
utils EnhancedSecurityMode	This command allows you to change and check Enhanced Security Mode status on a particular node. When Enhanced Security Mode is enabled, the system implements a set of strict security and risk management controls that allow your system to comply with the Enhanced Security Mode guidelines.
utils EnhancedSecurityMode disable	Run this command to disable a cluster node for Enhanced Security Mode.
utils EnhancedSecurityMode enable	Run this command to enable a cluster node for Enhanced Security Mode.
utils EnhancedSecurityMode status	Run this command to verify if Enhanced Security Mode is enabled.

**Syntax Description**

Parameters	Description
<b>disable</b>	Deactivates Enhanced Security Mode and prompts disabling of FIPS mode.
<b>enable</b>	Activates Enhanced Security Mode and prompts for enabling FIPS mode. If FIPS mode is enabled, then Enhanced Security Mode will be activated.
<b>status</b>	Displays the status of Enhanced Security Mode.

**Usage Guidelines**

FIPS mode must be enabled before you enable Enhanced Security Mode. If you haven't already enabled FIPS, you will be prompted to enable it when you attempt to enable Enhanced Security Mode.



**Note** FIPS Mode and Enhanced Security Mode do not support MD5 or DES encryption methods. If SNMPv3 setting is enabled using both MD5 and DES, then enabling FIPS Mode or Enhanced Security Mode changes these encryption methods to SHA-1 and AES-128 respectively.

Confirm that your phones support SHA-512. Enhanced Security Mode compliance requires this level of encryption for digital signatures. Legacy phones that do not support SHA-512 encryption will not work after you configure the system to use SHA-512.

Do not run this command on all nodes simultaneously.

### Requirements

Command privilege level: 0

Allowed during upgrade: No

## utils fior

This command allows you to monitor the I/O on the server.

### Usage Guidelines

The file I/O reporting service provides a kernel-based daemon for collecting file I/O per process.

### Command Syntax

Command	Result
<b>utils fior</b>	This command allows you to monitor the I/O on the server. The File I/O Reporting service provides a kernel-base daemon for collecting file I/O per process.
<b>utils fior disable</b>	
<b>utils fior enable</b>	
<b>utils fior list</b> [ <i>start=date-time</i> ] [ <i>stop=date-time</i> ]	This command displays a list of the I/O events for all processes.
<b>utils fiorstart</b>	
<b>utils fior status</b>	
<b>utils fior stop</b>	
<b>utils fior top</b> <i>number</i> [ <i>read</i>   <i>write</i>   <i>read-rate</i>   <i>write-rate</i> ] [ <i>start=date-time</i> ] [ <i>stop=date-time</i> ]	This command displays a list of I/O statistics for I/O bound processes at the time that you run this command.

### Syntax Description

Parameters	Description
<b>disable</b>	Prevents the file I/O reporting service from starting automatically when the machine boots. This command does not stop the service without a reboot. Use the <b>stop</b> option to stop the service immediately.

Parameters	Description
<b>enable</b>	Enables the file I/O reporting service to start automatically when the machine boots. This command does not start the service without a reboot. Use the <b>start</b> option to start the service immediately.
<b>list</b>	This command displays a list of file I/O events, in chronological order, from oldest to newest.
<b>start</b>	Starts a previously stopped file I/O reporting service. The service remains in a started state until it is manually stopped or the machine is rebooted.
<b>status</b>	Displays the status of the file I/O reporting service.
<b>stop</b>	Stops the file I/O reporting service. The service remains in a stopped state until it is manually started or the machine is rebooted.
<b>top</b>	Displays a list of top processes that create file I/O. This list can be sorted by the total number of bytes read, the total number of bytes written, the rate of bytes read, or the rate of bytes written.
<b>start</b>	Specifies a starting date and time.
<b>stop</b>	Specifies a stopping date and time.
<i>date-time</i>	Specifies a date and time, in any of the following formats: H:M, H:M:S a, H:M, a, H:M:S Y-m-d, H:M, Y-m-d, H:M:S.
<i>number</i>	Specifies how many of the top processes to list.
<b>[read   write   read-rate   write-rate]</b>	Specifies the metric used to sort the list of the top processes.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

## utils fips



### Caution

FIPS mode is only supported on releases that have been through FIPS compliance. Be warned that FIPS mode should be disabled before you upgrade to a non-FIPS compliance version of Cisco Emergency Responder.

For information about which releases are FIPS compliant and to view their certifications, see the *FIPS 140* document at [http://www.cisco.com/web/strategy/government/security\\_certification/net\\_business\\_benefit\\_seccert\\_fips140.html](http://www.cisco.com/web/strategy/government/security_certification/net_business_benefit_seccert_fips140.html).

This command enables, disables, or displays the status of FIPS 140-2 mode. FIPS 140-2 mode is disabled by default; only an administrator can enable FIPS.



**Note** FIPS Mode and Enhanced Security Mode do not support MD5 or DES encryption methods. If SNMPv3 setting is enabled using both MD5 and DES, then enabling FIPS Mode or Enhanced Security Mode changes these encryption methods to SHA-1 and AES-128 respectively.

### Command Syntax

```
utils fips {enable | disable | status}
```

### Syntax Description

Parameters	Description
<b>enable</b>	Activates FIPS 140-2 mode.
<b>disable</b>	Deactivates FIPS 140-2 mode.
<b>status</b>	Displays the status of FIPS 140-2 mode.

### Command Modes

Administrator (admin:)

### Usage Guidelines

Before enabling FIPS mode, we recommend that you perform a system backup. If FIPS checks fail at start-up, the system halts and requires a recovery CD to be restored.

Consider the following information before you enable FIPS 140-2 mode:

- After FIPS mode is enabled on a server, please wait until the server reboots before enabling FIPS on the next server.
- In FIPS mode, the Cisco Emergency Responder service uses Red Hat Openswan (FIPS validated) in place of Racoon (non-FIPS validated). If the security policies in Racoon contain functions that are not FIPS approved, the CLI command asks you to redefine the security policies with FIPS approved functions and abort.



**Note** Certificates and SSH key are regenerated automatically, in accordance with FIPS requirements.

Consider the following information before you disable FIPS 140-2 mode: In multiple server groups, each server must be disabled separately; FIPS mode is not disabled group-wise but on a per server basis.

### Requirements

Command privilege level: 0

Allowed during upgrade: No

## utils firewall

This command manages the firewall on the node.

### Command Syntax

Command	Result
<b>utils firewall</b> {enable  disable[time]}	This commands enables and disables firewall.
<b>utils firewall list</b>	This commands displays the current configuration of the firewall.
<b>utils firewall status</b>	This command displays the current status of the IPv4 firewall.

### Syntax Description

Parameters	Description
<b>disable</b>	Disables the firewall.
<i>time</i>	The duration for which the firewall is disabled, in one of these formats: <ul style="list-style-type: none"> <li>• [0–1440]<b>m</b> to specify a duration in minutes.</li> <li>• [0–24]<b>h</b> to specify a duration in hours.</li> <li>• [0–23]<b>h</b>[0–60]<b>m</b> to specify a duration in hours and minutes.</li> <li>• If you do not specify a time, the default is 5 minutes.</li> </ul>
<b>list</b>	The current firewall configuration.
<b>status</b>	The status of the firewall.

### Usage Guidelines

When the firewall is disabled, you must enter the URL of the Cisco Unified Communications Manager server in the following format to log into the web interface:

```
https://server:8443/
```

where *server* is the server name or IP address of the server.

Disabling the firewall is not recommended.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

## utils firewall ipv4

This command enables and disables IPv4 firewall.

### Command Syntax

```
utils firewall ipv4 {enable|disable}[time]}
```

### Syntax Description

Parameters	Description
<b>enable</b>	Turns on the IPv4 firewall.
<b>disable</b>	Turns off the IPv4 firewall. If you do not enter the time parameter, this command disables the firewall for 5 minutes.
<i>[time]</i>	(Optional) Sets the duration for which the firewall is to be disabled in the following formats: <ul style="list-style-type: none"> <li>• Minutes: 0–1440m</li> <li>• Hours: 0–23h</li> <li>• Hours and minutes: 0–23h 0–60m</li> </ul>

### Command Mode

Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

## utils firewall ipv4 debug

This command turns IPv4 firewall debugging on or off. If you do not enter a time parameter, this command turns on debugging for 5 minutes.

### Command Syntax

```
utils firewall ipv4 debug {off} [time]}
```



**Syntax Description**

Parameters	Description
<b>off</b>	Enables the collection of audit logs. When enabled, the system monitors and records user actions as well as Linux events such as the creation and removal of users, as well as the editing and deleting of files.
<i>[time]</i>	(Optional) Disables the collection of audit logs.

**Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

## utils firewall ipv4 list

This command displays the current configuration of the IPv4 firewall.

**Command Syntax**

**utils firewall ipv4 list**

**Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

## utils firewall ipv4 status

This command displays the current status of the IPv4 firewall.

**Command Syntax**

**utils firewall ipv4 status**

**Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

**utils filebeat**

This command uses the filebeat client to upload logs from the Cisco Emergency Responder server to the external logstash server.

**Command Syntax**

**utils filebeat** {**config** |**enable**|**disable**|**status**}

**Syntax Description**

Parameters	Description
<b>config</b>	Allows you to enter the logstash server details. You can enable the filebeat service if the logstash server is reachable by choosing one of the following log types: <ul style="list-style-type: none"> <li>Platform audit logs(/var/log/active/audit/vos/vos-audit.log)</li> <li>Remote Support logs(/var/log/active/audit/vos/remote_activity.log_*)</li> </ul>
<b>enable</b>	Enables the filebeat service, and the selected logs are uploaded to an external logstash server if service is active else, you can also restart the service.
<b>disable</b>	Disables the filebeat service.
<b>status</b>	Displays the active status of the filebeat service.

**Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 4

Allowed during upgrade: Yes

**Usage Guidelines**

After the service has been enabled, the selected logs will be uploaded to the external logstash server.

**Warning**

Warning: There may loss of data when the service is restarted.

## utils filebeat tls

This command configures Transport Layer Security (TLS) 1.2 as the protocol for communication between the FileBeat client and the logstash server.

### Command Syntax

```
utils filebeat tls {enable|disable|status}
```

### Syntax Description

Parameters	Description
enable	Enables a secure connection between the FileBeat client and the logstash server.
disable	Disables the TLS for FileBeat client.
status	Displays the status for TLS.

### Command Mode

Administrator (admin:)

### Requirements

Command privilege level: 4

A security certificate has to be uploaded from the logstash server to the cluster.

## utils import config

This command imports all configuration settings found on the platformConfig.xml file and then reboots the system.

### Command Syntax

```
utils import config
```

## utils iostat

This command displays the iostat output for the given number of iterations and interval.

### Command Syntax

```
utils iostat [interval] [iterations] [filename]
```

**Syntax Description**

Parameters	Description
<i>interval</i>	The value in seconds between two iostat readings (mandatory if you specify the number of iterations).
<i>iterations</i>	The number of iostat iterations to be performed (mandatory if you specify an interval).
<i>filename</i>	Redirects the output to a file.

**Requirements**

Level privilege: 0

Command privilege: 1

Allowed during upgrade: No

**utils iothrottle enable**

This command enables I/O throttling enhancements. When enabled, I/O throttling enhancements lower the impact of upgrades on an active system.

**Command Syntax**

**utils iothrottle enable**

**utils iothrottle disable**

This command disables I/O throttling enhancements.

**Usage Guidelines**

This could adversely affect the system during upgrades.

**Command Syntax**

**utils iothrottle disable**

**utils iothrottle status**

This command displays the status of I/O throttling enhancements.

**Command Syntax**

**utils iothrottle status**

**utils network arp**

This command lists, sets, or deletes Address Resolution Protocol (ARP) table entries.

**Command Syntax**

Command	Result
<b>utils network arplist</b> [ <i>host host</i> ] [ <i>page</i> ] [ <i>numeric</i> ]	This command lists the contents of the Address Resolution Protocol table.
<b>utils network arpset</b> { <i>host</i> } { <i>address</i> }	This command sets an entry in the Address Resolution Protocol table.
<b>utils network arpdelete</b> <i>host</i>	This command deletes an entry in the Address Resolution Protocol table.

**Syntax Description**

Parameters	Description
<b>list</b>	Lists the contents of the address resolution protocol table.
<b>set</b>	sets an entry in the address resolution protocol table.
<b>delete</b>	deletes an entry in the address resolution table.
<i>host</i>	represents the host name or IP address of the host to add or delete to the table.
<i>address</i>	represents the MAC address of the host to be added. Enter the MAC address in the following format: XX:XX:XX:XX:XX:XX.
<b>page</b>	Displays the output one page at a time.
<b>numeric</b>	Displays hosts as dotted IP addresses.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

**utils network capture eth0**

This command captures IP packets on the specified Ethernet interface.

**Command Syntax**

**utils network capture eth0** [*page*] [*numeric*] [*file fname*] [*count num*] [*size bytes*] [*src addr*] [*dest addr*] [*port num*]

**Syntax Description**

Parameters	Description
<b>eth0</b>	Specifies Ethernet interface 0.

Parameters	Description
<b>page</b>	(Optional)Displays the output one page at a time. When you use the page or file options, the complete capture of all requested packets must occur before the command completes.
<b>numeric</b>	(Optional)Displays hosts as dotted IP addresses.
<b>file</b> fname	(Optional)Outputs the information to a file. The file option saves the information to platform/cli/fname.cap. The filename cannot contain the "." character.
<b>count</b> num	(Optional)Sets a count of the number of packets to capture. For screen output, the maximum count equals 1000 and, for file output, the maximum count equals 10,000.
<b>size</b> bytes	(Optional)Sets the number of bytes of the packet to capture. For screen output, the maximum number of bytes equals 128, for file output, the maximum of bytes can be any number or <b>ALL</b> .
<b>src</b> addr	(Optional)Specifies the source address of the packet as a host name or IPV4 address.
<b>dest</b> addr	(Optional)Specifies the destination address of the packet as a host name or IPV4 address.
<b>port</b> num	(Optional)Specifies the port number of the packet, either source or destination.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

## utils network connectivity

This command verifies the server's network connection to the publisher server. It is only valid on a subscriber server.

### Command Syntax

**utils network connectivity**

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

## utils network connectivity output

This command verifies the node network connection to the first node in the cluster. It is for Cisco Emergency Responder Subscriber only.

### Command Syntax

**utils network connectivity output**

## utils network host

This command resolves a host name to an address or an address to a host name.

### Command Syntax

**utils network host** *hostname* [**server** *server-name*] [**page**] [**detail**] [**srv**]

### Syntax Description

Parameters	Description
<i>hostname</i>	The host name or IP address that you want to resolve.
<i>server-name</i>	(Optional)Specifies an alternate domain name server.
<b>page</b>	(Optional)Displays the output one screen at a time.
<b>detail</b>	(Optional)Displays a detailed listing.
<b>srv</b>	(Optional)Displays DNS SRV records.

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

## utils network ping

This command allows you to ping another server.

### Command Syntax

**utils network ping** *destination* [*count*]

### Syntax Description

Parameters	Description
<i>destination</i>	The hostname or IP address of the server that you want to ping.

Parameters	Description
<i>count</i>	(Option) Specifies the number of times to ping the external server. The default count equals 4.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

## utils network traceroute

This command traces IP packets that are sent to a remote destination.

**Command Syntax**

**utils network traceroute** *destination*

**Syntax Description**

Parameters	Description
<i>destination</i>	The hostname or IP address of the server to which you want to send a trace.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

## utils ntp

This command displays the NTP status or configuration.

**Command Syntax**

**utils ntp** {*status* | *config*}

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

## utils ntp restart

This command restarts the NTP service.



**Command Syntax****utils ntp restart****Parameters**

None

**Requirements**

Level privilege: 0

Command privilege: 0

Allowed during upgrade: Yes

## utils ntp server add

The command adds up to 5 specified NTP servers.

**Usage Guidelines***norestart* results in the NTP service not being restarted after adding the servers.**Note** If the *norestart* option is used, an explicit restart of the NTP service is required for the changes to take effect.**Command Syntax****utils ntp server add s1 [s2 s3 s4 s5] [norestart]****Usage Guidelines**

Note the following:

- Mandatory parameter: at least one NTP server to add.
- Optional parameters: up to four more ntp servers and the norestart option.

**Example****Adding servers with incorrect command line parameters**

```
-----
admin:utils ntp server add s1 s2 s3 s4 s5 s6 s7 s8
Incorrect number of parameters entered for add
usage: utils ntp server add s1 [s2 s3 s4 s5] [norestart]
admin:
```

**Example 2****Adding using norestart without specifying a server**

```
-----
admin:utils ntp server add norestart
At least one NTP server must be specified for add operation.
usage: utils ntp server add s1 [s2 s3 s4 s5] [norestart]
```

**Example 3****Adding servers without norestart**

```
-----
admin:utils ntp server add clock1.cisco.com clock2.cisco.com
clock1.cisco.com : added successfully.
clock2.cisco.com : added successfully.
Restarting NTP on the server.
```

**Example 4****Adding servers that are already added, without norestart**

```
-----
admin:utils ntp server add clock1.cisco.com clock2.cisco.com
clock1.cisco.com : [The host has already been added as an NTP server.]
clock2.cisco.com : [The host has already been added as an NTP server.]
admin:
```

**Example 5****Adding server to self without norestart**

```
-----
admin:utils ntp server add bglr-ccm26
bglr-ccm26 : [This server cannot be added as an NTP server.]
admin:
```

**Example 6****Adding inaccessible server without norestart**

```
-----
admin:utils ntp server add clock3.cisco.com
clock3.cisco.com : [ Inaccessible NTP server. Not added. ]
admin:
```

**Example 7****Adding servers with norestart**

```
-----
admin:utils ntp server add ntp01-syd.cisco.com ntp02-syd.cisco.com clock.cisco.com
norestart
ntp01-syd.cisco.com: added successfully.
ntp02-syd.cisco.com: added successfully.
clock.cisco.com: added successfully.
The NTP service must be restarted for the changes to take effect.
```

**Example 8****Adding servers when 5 are already configured**

```
-----
admin:utils ntp server add clock3.cisco.com
The maximum permissible limit of 5 NTP servers is already configured
```

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

## utils ntp server delete

The command deletes any configured NTP server or all of them.

### Usage Guidelines

After the user enters their choice, they are prompted if they would like to restart the NTP service.

Answering No results in the NTP service not being restarted after deleting the servers.



**Note** If the user chooses not to restart the NTP service, an explicit restart of the NTP service is required for the changes to take effect.

### Command Syntax

```
utils ntp server delete
```

### Example 1

#### Deleting servers with incorrect command line parameters

```
-----
admin:utils ntp server delete clock1.cisco.com clock2.cisco.com
Incorrect number of optional parameters entered for delete
usage: utils ntp server delete
admin:
```

### Example 2

#### Deleting single server with ntp restart

```
-----
admin:utils ntp server delete
1: clock1.cisco.com
2: clock2.cisco.com
3: ntp01-syd.cisco.com
4: ntp02-syd.cisco.com
5: clock.cisco.com
a: all
q: quit
Choice: 1
Restart NTP (y/n): y
clock1.cisco.com is deleted from the list of configured NTP servers.
Continue (y/n)?y
clock1.cisco.com: deleted successfully.
Restarting NTP on the server.
admin:
```

### Example 3

#### Deleting all servers without ntp restart

```
-----
admin:utils ntp server delete
1: clock1.cisco.com
2: clock2.cisco.com
3: ntp01-syd.cisco.com
```

```

4: ntp02-syd.cisco.com
5: clock.cisco.com
a: all
q: quit
Choice: a
Restart NTP (y/n): n
This results in all the configured NTP servers being deleted.
Continue (y/n)?y
clock1.cisco.com:  deleted successfully.
clock2.cisco.com:  deleted successfully.
ntp01-syd.cisco.com:  deleted successfully.
ntp02-syd.cisco.com:  deleted successfully.
clock.cisco.com:  deleted successfully.
The NTP service must be restarted for the changes to take effect.
admin:

```

**Example 4****Deleting all servers when no servers are configured**

```

-----
admin:utils ntp server delete
There are no NTP servers configured to delete.

```

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

## utils ntp server list

The command lists the configured NTP servers.

**Command Syntax**

**utils ntp server list**

**Example 1****Listing servers with incorrect command line parameters**

```

-----
admin:utils ntp server list all
Incorrect optional parameter entered for list
usage: utils ntp server list
admin:

```

**Example 2****Listing servers**

```

-----
admin:utils ntp server list
clock1.cisco.com
clock2.cisco.com
ntp01-syd.cisco.com
ntp02-syd.cisco.com
clock.cisco.com
admin:

```

### Example 3

#### Listing servers when no servers are configured

```
-----  
admin:utils ntp server list  
There are no NTP servers configured.
```

#### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

## utils ntp start

This command starts the NTP service, if it is not already running.



---

**Note** You cannot stop the NTP service from the CLI. Use this command when the **utils ntp status** command returns **stopped**.

---

#### Command Syntax

**utils ntp start**

#### Requirements

Level privilege: 0

Command privilege: 0

Allowed during upgrade: Yes

## utils os kerneldump

This command configures kerneldump to provide a kernel crash dumping mechanism. The kernel captures the dump to the local disk, in case of a kernel crash.



---

**Note** The netdump commands have been removed from release 8.6(1) and have been replaced with the kerneldump commands.

---

#### Command Syntax

**utils os kerneldump {enable|disable}**

#### Usage Guidelines

If a kernel crash occurs, the capture kernel dumps the core on the local disk of the server. The primary kernel reserves 128MB of physical memory that the capture kernel uses to boot. The kerneldump uses the **kexec** command to boot into a capture kernel whenever the kernel crashes.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

**Example**

```
admin: utils os kerneldump enable
*****WARNING*****
Enabling kerneldump requires system reboot
Would you like to boot the machine (y/n):y
kerneldump enable operation succeeded
System going for a reboot
```

## utils os kerneldump ssh

This command enables, disables, or displays the status of an external SSH server.

**Command Syntax**

```
utils os kerneldump ssh {enable|disable|status}
```

**Syntax Description**

Parameters	Description
<b>enable</b>	Configures an external SSH server as a kerneldump server to collect kernel dumps.
<b>disable</b>	Removes support of the external SSH server that is configured to collect kernel dumps.
<b>status</b>	Indicates whether an external SSH server is configured or not, to collect kernel dumps.

**Usage Guidelines**

If external SSH server has the kerneldump service enabled and a kernel crash occurs, the capture kernel dumps the core on the external server that is configured to collect the dump. Enabling and disabling kerneldump require a system reboot for the changes to come into effect.

**Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

**Example**

```
admin: utils os kerneldump ssh disable 10.77.31.60
Disabling kerneldump requires system reboot
Would you like to continue (y/n): y
kerneldump disable operation succeeded
System going for a reboot
```

## utils os secure

This command is used to specify the level of security provided by selinux.

**Command Syntax**

**utils os secure** {enforce |permissive|status}

**Usage Guidelines**

The selinux does not handle rate limiting. Rate limiting is handled by ippref and ip tables.

**Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

## utils remote\_account

This command allows you to enable, disable, create, and check the status of a remote account.

**Command Syntax**

Command	Result
<b>utils remote_account status</b>	This command allows you to check the status of a remote account.
<b>utils remote_account enable</b>	This command allows you to enable a remote account.
<b>utils remote_account disable</b>	This command allows you to disable a remote account.
<b>utils remote_account create</b> <i>username life</i>	This command creates a remote account.

**Syntax Description**

Parameters	Description
<i>username</i>	The name of the remote account. The username can contain only lowercase characters and must be more than six-characters long.

Parameters	Description
<i>life</i>	The life of the account in days. After the specified number of day, the account expires.

**Usage Guidelines**

A remote account generates a pass phrase that allows Cisco Systems support personnel to get access to the system for the specified life of the account. You can have only one remote account that is enabled at a time.

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

**Example**

```
utils remote_account status
```

**utils reset\_application\_ui\_administrator\_name**

This command resets the application user interface administrator name.

**Command Syntax**

```
utils reset_application_ui_administrator_name
```

**Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

**utils reset\_application\_ui\_administrator\_password**

This command resets the application user interface administrator password.

**Command Syntax**

```
utils reset_application_ui_administrator_password
```

**Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes



## utils service

This command stops, starts, or restarts a service.

### Command Syntax

**utils service** {start|stop|restart|auto-restart {enable|disable|show}} *service-name*

### Syntax Description

Parameters	Description
<i>service-name</i>	The name of the service that you want to stop or start: <ul style="list-style-type: none"> <li>• System NTP</li> <li>• System SSH</li> <li>• Cisco IDS</li> <li>• Cisco Tomcat</li> <li>• Cisco Database Layer Monitor</li> <li>• CiscoEmergencyResponder</li> <li>• Cisco Phone Tracking Engine</li> <li>• Cisco DB Replicator</li> <li>• CER Provider</li> <li>• Cisco CDP</li> <li>• Cisco CDP Agent</li> <li>• Cisco Certificate Expiry Monitor</li> <li>• Cisco DRF Local</li> <li>• Cisco DRF Master</li> <li>• Cisco Tomcat</li> <li>• Host Resources Agent</li> <li>• MIB2 Agent</li> <li>• SNMP Master Agent</li> <li>• System Application Agent</li> </ul>
<b>auto-restart</b>	Causes a service to automatically restart.
<b>enable</b>	Enables auto-restart
<b>disable</b>	Disables auto-restart.
<b>show</b>	Shows the auto-restart status.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

## utils service list

This command retrieves a list of all services and their status.

**Command Syntax****utils service list** [page]**Syntax Description**

Parameters	Description
page	(Option)Displays the output one page at a time.

**Requirements**

Command privilege level: 0

Allowed during upgrade: Yes

## utils snmp

This command manages SNMP on the server.

**Command Syntax**

<b>utils snmp get</b> <i>version community ip-address object [file]</i>	This interactive command gets the SNMP data using the specified version for the specified MIB OID.
<b>utils snmp hardware-agents</b> [status   restart]	This command affects the SNMP agents on the server.
<b>utils snmp test</b>	
<b>utils snmp walk</b> <i>version community ip-address object [file]</i>	This interactive commands walks through the SNMP MIB.

**Syntax Description**

Parameters	Description
get	Displays the value of the specified SNMP object.
hardware-agents status	Displays the status of the hardware agents on the server.
hardware-agents	Stops all SNMP agents provided by the hardware vendor.

Parameters	Description
<b>hardware-agents restart</b>	Restarts the hardware agents on the server.
<b>test</b>	Tests the SNMP host by sending sample alarms to local syslog and remote syslog.
<b>walk</b>	Walks the SNMP MIB, starting with the specified SNMP object.
<i>version</i>	Specifies the SNMP version. Possible values are 1 or 2c.
<i>community</i>	Specifies the SNMP community string.
<i>ip-address</i>	Specifies the IP address of the server. Enter 127.0.0.1 to specify the local host. You can enter the IP address of another node in the cluster to run the command on that node.
<i>object</i>	Specifies the SNMP Object ID (OID) to get.
<i>file</i>	Specifies a file in which to save the command output.

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

## utils snmp config 1/2c community-string

This interactive command adds, deletes, lists or updates a community string.

### Command Syntax

**utils snmp config 1/2c community-string {add|delete |list|update}**

### Syntax Description

Parameters	Description
<b>add</b>	Adds a new community string.
<b>delete</b>	Deletes a community string.
<b>list</b>	Lists all community strings.
<b>update</b>	Updates a community string.

### Usage Guidelines

The system prompts you for the parameters.

The SNMP Master Agent service is restarted for configuration changes to take effect. Do not abort command after execution until restart is complete. If the command is aborted during service restart, verify service status

of SNMP Master Agent by using **utils service list**. If service is down, start it by using **utils service start SNMP Master Agent** .

### Command Mode

Administrator (admin:)

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

## utils snmp config 3 user

This interactive command affects v3 user configuration.

### Command Syntax

**utils snmp config 3 user {add|delete|list|update}**

### Syntax Description

Parameters	Description
<b>add</b>	Adds a new v3 user with the v3 authentication and privacy passwords.
<b>delete</b>	Deletes the configuration information for an existing v3 user.
<b>list</b>	Lists the v3 users currently configured.
<b>update</b>	Updates configuration information for an existing v3 user.

### Usage Guidelines

The system prompts you for the parameters.

### Command Mode

Administrator (admin:)

### Requirements

Command privilege level:1

Allowed during upgrade: Yes

## utils snmp config mib2

This command affects the Mib2 configuration information.

**Command Syntax**

**utils snmp config mib2 {add|delete|list|update}**

**Syntax Description**

Parameters	Description
<b>add</b>	Adds the Mib2 configuration information.
<b>delete</b>	Deletes the Mib2 configuration information.
<b>list</b>	Lists the Mib2 configuration information.
<b>update</b>	Updates the Mib2 configuration information.

**Useage Guidelines**

The system prompts you for the parameters.

**Command Mode**

Administrator (admin:)

**Requirements**

Command privilege level: 1

Allowed during upgrade: Yes

## utils snmp walk 3

This command is used to walk the SNMP MIB starting with the specified OID.

**Command Syntax**

**utils snmp walk 3**

[system prompts you for the parameters]

**Example**

```
If you run snmp walk on a leaf in the MIB you basically get what you would
get with 'utils snmp get ...' command. Here is the sample walk
output we are getting for the OID 1.3.6
iso.3.6.1.2.1.1.1.0 = STRING: "Hardware:7825H, 1 Intel(R) Pentium(R) 4 CPU
3.40GHz, 2048 MB Memory: Software:UCOS 2.0.1.0-62"
iso.3.6.1.2.1.1.2.0 = OID: iso.3.6.1.4.1.9.1.583
iso.3.6.1.2.1.1.3.0 = Timeticks: (15878339) 1 day, 20:06:23.39
iso.3.6.1.2.1.1.4.0 = ""
iso.3.6.1.2.1.1.5.0 = STRING: "bldr-ccm34.cisco.com"
iso.3.6.1.2.1.1.6.0 = ""
iso.3.6.1.2.1.1.7.0 = INTEGER: 72
iso.3.6.1.2.1.2.1.0 = INTEGER: 3
iso.3.6.1.2.1.2.2.1.1 = INTEGER: 1
iso.3.6.1.2.1.2.2.1.2 = INTEGER: 2
```

```

iso.3.6.1.2.1.2.2.1.1.3 = INTEGER: 3
iso.3.6.1.2.1.2.2.1.2.1 = STRING: "lo"
iso.3.6.1.2.1.2.2.1.2.2 = STRING: "eth0"
iso.3.6.1.2.1.2.2.1.2.3 = STRING: "eth1"
iso.3.6.1.2.1.2.2.1.3.1 = INTEGER: 24
iso.3.6.1.2.1.2.2.1.3.2 = INTEGER: 6
iso.3.6.1.2.1.2.2.1.3.3 = INTEGER: 6
iso.3.6.1.2.1.2.2.1.4.1 = INTEGER: 16436
iso.3.6.1.2.1.2.2.1.4.2 = INTEGER: 1500
iso.3.6.1.2.1.2.2.1.4.3 = INTEGER: 1500
iso.3.6.1.2.1.2.2.1.5.1 = Gauge32: 0
iso.3.6.1.2.1.2.2.1.5.2 = Gauge32: 100000000
iso.3.6.1.2.1.2.2.1.5.3 = Gauge32: 100000000
iso.3.6.1.2.1.2.2.1.6.1 = Hex-STRING: 00 00 00 00 00 00
iso.3.6.1.2.1.2.2.1.6.2 = Hex-STRING: 00 16 35 5C 61 D0
iso.3.6.1.2.1.2.2.1.6.3 = Hex-STRING: 00 16 35 5C 61 CF
iso.3.6.1.2.1.2.2.1.7.1 = INTEGER: 1
.....

```

If you provide an IP address of a remote host the command is executed on that remote host. You have to provide the IP address, not the domain name.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

## utils snmp get 3

This command gets the SNMP data for the specified MIB OID.

### Command Syntax

#### utils snmp get 3

[system prompts you for the parameters]

### Usage Guidelines

If you use this command on a specific OID (leaf) in the MIB, you will get the value of the MIB. The SNMP get output of system uptime iso.3.6.1.2.1.25.1.1.0 = Timeticks: (19836825) 2 days, 7:06:08.25

If you provide an IP address of a remote host, the command is executed on that remote host. You have to provide the IP address not the domain name.

### Requirements

Command privilege level: 1

Allowed during upgrade: No

## utils system

This command restarts the system on the same partition, restarts the system on the inactive partition, or shuts down the system.

**Command Syntax**

```
utils system {restart | shutdown | switch-version}
```

**Syntax Description**

Parameters	Description
<b>restart</b>	Restarts the system.
<b>shutdown</b>	Shuts down the system.
<b>switch-version</b>	Switches to the product release installed on the inactive partition.

**Usage Guidelines**

The **utils system shutdown** command has a 5-minute timeout. If the system does not shut down within 5 minutes, the command gives you the option of doing a forced shutdown.

**Requirements**

Command privilege level: 1

Allowed during upgrade: No

**utils system boot**

This command redirects where the system boot output gets sent.

**Command Syntax**

```
utils system boot {console | serial | status}
```

**Syntax Description**

Parameters	Description
<b>console</b>	Redirects the system boot output to the console.
<b>serial</b>	Redirects the system boot output to the COM1 (serial port 1).
<b>status</b>	Displays the where the serial boot output currently gets sent.

**Requirements**

Level privilege: 1

Command privilege: 1

Allowed during upgrade: Yes

## utils system upgrade

This command allows you to install upgrades and Cisco Option Package (COP) files from both local and remote directories.

### Command Syntax

**utils system upgrade** {**initiate** | **cancel** | **status**}

### Syntax Description

Parameters	Description
<b>cancel</b>	Cancels the active upgrade.
<b>initiate</b>	Starts a new upgrade wizard or assumes control of an existing upgrade wizard. The wizard prompts you for the location of the upgrade file.
<b>status</b>	Displays the status of an upgrade.

### Usage Guidelines

To upgrade the system, follow these steps:

1. Use the **utils system upgrade list** command to display a list of the .iso upgrade files that are available on the local disk or remote server from which you plan to upgrade.
2. Use the **utils system upgrade get** command to get the upgrade file that you want to use.
3. Use the **utils system upgrade start** command to start upgrading from the upgrade file that you received.

## utils sso

This command provides information about SAML SSO authentication.

**utils sso** {**enable** | **disable** | **status**}

### Syntax Description

Parameters	Description
<b>enable</b>	Enables SAML SSO based authentication
<b>disable</b>	Disables SAML SSO based authentication.
<b>status</b>	Provides the status of SAML SSO.

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: No



Applies to: Cisco Emergency Responder

### Example

```
Admin: utils sso enable
*** W A R N I N G ***
SSO cannot be enabled using CLI command
=====
To enable SAML SSO in the Cisco Emergency Responder server group, please
access ER Administration Page->System->SAML Single Sign On
=====
```

## utils sso recovery-url

This command enables or disables recovery URL for SAML SSO based authentication.

**utils sso recovery-url** {enable | disable}

### Syntax Description

Parameters	Description
<b>enable</b>	Enables recovery URL for SAML SSO based authentication.
<b>disable</b>	Disables recovery URL for SAML SSO based authentication.

### Command Modes

Administrator (admin:)

### Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Applies to: Cisco Emergency Responder

## utils vmtools status

This command shows the version of the currently running VMware Tools.

### Command Syntax

**utils vmtools status**

### Requirements

Command privilege level: 0

Allowed during upgrade: Yes

## utils vmtools upgrade

This command updates the currently installed VMware Tools to the latest version required by the ESXi host for that VM.

**Command Syntax****utils vmtools upgrade**