

# **Network-based Recording Configuration**

- CUCM Configuration, on page 1
- Create a Recording Profile, on page 1
- Configure the SIP Trunk from CUCM to Recording Server, on page 2
- Creating a Recorder Route Group, on page 2
- Add a Route Group to a Route List, on page 3
- Create a Route Pattern Based on the DN for the Recorder, on page 3
- Configure the Device Phone for Recording, on page 3
- Enable the Device Phone for Recording, on page 4
- Configure the Ingress Gateway for Recording, on page 4
- Configure the Outgoing Trunk from CVP to CUCM, on page 5
- Gateway Setup for Network-based Recording, on page 6

### **CUCM** Configuration

Network- based recording is configured using Cisco Unified Communications Manager Administration. Network-based recording is controlled by using a recording profile assigned to the line. The recording can be selective or full-time audio-only recording. You can either configure CUBE or phone as the forking device and you can change the forking device during a call.

### **Create a Recording Profile**

#### Procedure

Step 1	From Cisco Unified Communications Manager Administration, choose Device > Device Settings >	
	Recording Profile.	
Step 2	To add a new recording profile, click Add New.	
Step 3	In the <b>Name</b> field, enter a name to identify the recording profile.	

**Step 4** In the **Recording Destination Address** field, enter the directory number (DN) or the URL of the recorder that associates with this recording profile. This field allows any characters except the following characters: double quotation marks ("), back quote ('), and space ().

Step 5 Click Save.

## **Configure the SIP Trunk from CUCM to Recording Server**

#### Procedure

Step 1	From Cisco Unified Communications Manager Administration, choose Device > Trunk.
Step 2	To add a new SIP trunk, click Add New.
Step 3	In the <b>Device Name</b> field, enter a unique identifier for the trunk (which is the IP address of the Recording serverMediaSense recorder).
Step 4	In the <b>Description</b> field, enter a name for the trunk.
Step 5	From the SIP Profile drop-down list, choose Standard SIP Profile for this SIP trunk.
Step 6	In the <b>Recording Information</b> section, click <b>None</b> .
Step 7	Click Save.

## **Creating a Recorder Route Group**

#### Procedure

Step 1		Cisco Unified Communications Manager Administration, choose Call Routing > Route/Hunt > Group.
Step 2		<b>Available Devices</b> drop-down list, choose a device to add and click <b>Add to Route Group</b> to move it <b>Selected Devices</b> list box. Repeat this step for each device that you want to add to this route group.
	Note	If an SIP trunk is already configured for CVP, Route Group does not list that trunk.
Step 3	in this	<b>belected Devices</b> drop-down list, choose the order in which the new device or devices must be accessed route group. To change the order of devices, click a device and use the <b>Up</b> and <b>Down</b> arrows to the <b>C</b> the list box.
Step 4	To add	the new device or devices, and to update the device order for this route group, click Save.

I

### Add a Route Group to a Route List

### Procedure

Step 1	From Cisco Unified Communications Manager Administration, select Call Routing > Route/Hunt > Route List.
Step 2	Select the route list to which you want to add the route group. The <b>Route List Configuration</b> page is displayed.
Step 3	Click <b>Add Route Group</b> . The <b>Route List Details Configuration</b> page is displayed.
Step 4	Select/enter values for the fields.
Step 5	Click <b>Save</b> . A confirmation message is displayed.
Step 6	Click <b>OK</b> . The route list configuration is saved and the route group is added.

### **Create a Route Pattern Based on the DN for the Recorder**

#### Procedure

Step 1	From Cisco Unified Communications Manager Administration, choose Call Routing > Route/Hunt >
	Route Pattern.
	The Find and List Route Patterns page is displayed.
Step 2	Select the route list for which you are adding a route pattern. The <b>Route Pattern Configuration</b> page is displayed.
Step 3	Select/enter values for the fields.
Step 4	Click <b>Save</b> . A confirmation message is displayed.
Step 5	Click <b>OK</b> .

### **Configure the Device Phone for Recording**

#### Procedure

**Step 1** From **Cisco Unified Communications Manager Administration**, choose **Device** > **Phone**. Click **Find** to list the phones.

Step 2	Click Find.
	Choose the trunk profile that you want to view.
Step 3	From the Association Information area, click the link associated with your phone.
Step 4	From the Recording Option drop-down list, choose one of the following options:
	<ul> <li>Call Recording Disabled—The calls that the agent makes on this line appearance are not recorded.</li> <li>Automatic Call Recording Enabled—The calls that the agent makes on this line appearance are automatically recorded.</li> <li>Application Invoked Call Recording Enabled—The calls that the agent makes on this line appearance are recorded if an application invokes calling recording.</li> <li>Device Invoked Call Recording Enabled—This option supports the external call control feature. If the policies on the policy server dictate that a chaperone must monitor and record calls, choose this option.</li> </ul>
Step 5	From the <b>Recording Profile</b> drop-down list, choose an existing recording profile.
Step 6	Set the <b>Recording Media Source</b> preference (either Phone Preferred or Gateway Preferred) when enabling recording on the line appearance of the device.
Step 7	Click Save.

## **Enable the Device Phone for Recording**

#### Procedure

Step 1	To enable phone-based recording, choose <b>Device</b> > <b>Phone</b> from <b>Cisco Unified Communications Manager</b> <b>Administration</b> .	
Step 2	From the <b>Built In Bridge</b> drop-down list, choose <b>On</b> .	
Step 3	If the recorder does not support codecs (for example, G.722, ILIBC), enable Cisco Unified CM to ignore the preference if audio codecs.	
	a) Choose <b>System</b> > <b>Service Parameters</b> .	
	b) From the <b>Server</b> drop-down list, choose the server.	
	c) From the <b>Server</b> drop-down list, choose the service that contains the <b>Accept Audio Codec Preferences</b> <b>in Received Offer</b> parameter.	
	d) From the Accent Audio Codec Preferences in Paceived Offer drop down list choose Off	

- d) From the Accept Audio Codec Preferences in Received Offer drop-down list, choose Off.
- e) Click Save.

### **Configure the Ingress Gateway for Recording**

### Procedure

 Step 1
 From Cisco Unified Communications Manager Administration, choose Device > Trunk.

Step 2	In the Device Name field, enter the IP address of the Ingress Gateway.
Step 3	From the Device Pool drop-down list, choose Default.
Step 4	From the Call Classification drop-down list, choose Use System Default.
Step 5	From the Location drop-down list, choose Hub_None.
	The locations feature does not track the bandwidth that this device consumes.
Step 6	From the AAR Group drop-down list, choose None.
Step 7	From the Tunneled Protocol drop-down list, choose None.
Step 8	From the QSIG Variant drop-down list, choose No Changes.
Step 9	From the ASN.1 ROSE OID Encoding drop-down list, choose No Changes.
Step 10	From the Packet Capture Mode drop-down list, choose None.
Step 11	In the Recording Information area, click the <b>This trunk connects to a recording-enabled gateways</b> radio button.
Step 12	Click Save.

# **Configure the Outgoing Trunk from CVP to CUCM**

#### Procedure

Step 1	To create a new SIP profile for recording, choose <b>Device &gt; Device Settings &gt; SIP Profile</b> from <b>Cisco Unified</b> <b>Communications Manager Administration</b> .
Step 2	To add a new SIP profile, click Add New.
Step 3	In the <b>Name</b> field, enter a name to identify the SIP profile.
Step 4	In the <b>Default MTP Telephony Event Payload Type</b> field, enter the default value, 101.
Step 5	From the <b>Early Offer for G.Clear Calls</b> drop-down list, choose <b>Disabled</b> to disable Early Offer for G.Clear Calls.
Step 6	From the User-Agent and Server header information drop-down list, choose Send Unified CM Version Information as User-Agent Header.
Step 7	From the Version in User-Agent and Server Headers drop-down list, choose Major and Minor.
Step 8	From the <b>Dial String Interpretation</b> drop-down list, choose <b>Phone number</b> .
Step 9	From the Confidential Access Level Headers drop-down list, choose Disabled.
Step 10	From the <b>SDP Session-level Bandwidth Modifier for Early Offer and Re-invites</b> drop-down list, choose <b>TIAS and AS</b> .
Step 11	From the Accept Audio Codec Preferences in Received Offer drop-down list, choose Default.
Step 12	Click Save.

### **Gateway Setup for Network-based Recording**

To set up the gateway for network-based recording, use the following Telnet command in CLI Enable mode:

```
uc wsapi
message-exchange max-failures 100
response-timeout 300
source-address <IP address of gateway>
probing interval negative 20
probing interval keepalive 255
provider xmf
remote-url 1 http://<IP address of CUCM>:8090/ucm_xml
```

Note

- When using ISR G2 for network-based recording, ensure that the VXML Voice Gateway functionality is not enabled on the same gateway.
- For more information, please refer the section Network-Based Recording in Cisco Unified Border Element Configuration Guide at https://www.cisco.com/c/en/us/support/unified-communications/ unified-border-element/products-installation-and-configuration-guides-list.html.