



# W

---

**Last Updated: June 20, 2007**

**web skipinitwizard**

webapp delete–IVR Only

webapp deploy–IVR Only

webapp reload–IVR Only

webapp start–IVR Only

webapp stop–IVR Only

**write**

# web skipinitwizard

To disable the initialization wizard during the Cisco Unity Express installation process, use the **web skipinitwizard** command in Cisco Unity Express EXEC mode.

## **web skipinitwizard**

**Syntax Description** This command has no arguments or keywords.

**Command Modes** Cisco Unity Express EXEC

<b>Command History</b>	<b>Cisco Unity Express Release</b>	<b>Modification</b>
	2.1	This command was introduced.

**Usage Guidelines** This command turns off the initialization wizard. You cannot turn on or return to the initialization wizard unless you reimage the Cisco Unity Express module.

Use this command after installing the Cisco Unity Express software files and before starting the configuration process.

Turning off the initialization wizard allows you to configure Cisco Unity Express using only CLI commands, for example, if you want to run configuration scripts.

See the [Cisco Unity Express 2.3 GUI Administrator Guide](#) for the configuration tasks covered by the initialization wizard.

**Examples** The following example turns off the initialization wizard:

```
se-10-0-0-0# web skipinitwizard
se-10-0-0-0#
```

# webapp delete–IVR Only

Use the **webapp delete** command in Cisco Unity Express IVR privileged EXEC mode to remove the specified web application from the Cisco Unity Express module.

**webapp delete** *webappname name*

<b>Syntax Description</b>	<p><b>webappname</b> <i>name</i></p> <p>Name of the web application used to generate the:</p> <ul style="list-style-type: none"> <li>Name of the web application subdirectory that hosts the application files.</li> <li>URL path matched against incoming URLs to access this web application.</li> </ul> <p>Name must be 8 characters or less in length.</p>				
<b>Command Default</b>	No web application is configured.				
<b>Command Modes</b>	Cisco Unity Express IVR privileged EXEC				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Cisco Unity Express Version</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>3.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Cisco Unity Express Version	Modification	3.0	This command was introduced.
Cisco Unity Express Version	Modification				
3.0	This command was introduced.				
<b>Usage Guidelines</b>	This command deletes all the resources of the web application from the Cisco Unity Express module.				
<b>Examples</b>	<p>The following example deletes all the resources of the web application <i>myapp</i> from the Cisco Unity Express module:</p> <pre>se-10-0-0-0# webapp delete webappname myapp</pre>				
<b>Related Commands</b>	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td><a href="#">show webapp–IVR Only</a></td> <td>Displays the Cisco Unity Express IVR web application status.</td> </tr> </tbody> </table>	Command	Description	<a href="#">show webapp–IVR Only</a>	Displays the Cisco Unity Express IVR web application status.
Command	Description				
<a href="#">show webapp–IVR Only</a>	Displays the Cisco Unity Express IVR web application status.				

# webapp deploy-IVR Only

Use the **webapp deploy** command associated with your web applications to upload and start the web application in Cisco Unity Express IVR privileged EXEC mode.

The **webapp deploy** command uploads and starts the web application archive (WAR) file to the Cisco Unity Express system.

```
webapp deploy url war-url webappname name [allow-network-connect | username userid
[password password [allow-network-connect]]]
```

Syntax Description		
<b>url</b> <i>war-url</i>		Installs and starts a web application using the name of the application and the URL of the WAR file to be uploaded.
<b>webappname</b> <i>name</i>		Name of the web application used to generate the: <ul style="list-style-type: none"> <li>Name of the web application subdirectory that hosts the application files.</li> <li>URL path matched against incoming URLs to access this web application.</li> </ul> Name must be 8 characters or less in length.
<b>allow-network-connect</b>		(Optional) Allows the specified web application to use the network connections.
<b>username</b> <i>userid</i>		(Optional) Username for authenticating connection to the network, if required.
<b>password</b> <i>password</i>		(Optional) Password for authenticating connection to the network, if required.

**Command Default** No web application is configured.

**Command Modes** Cisco Unity Express IVR privileged EXEC

Command History	Cisco Unity Express Version	Modification
	3.0	This command was introduced.

**Usage Guidelines** The Cisco Unity Express IVR feature allows you to deploy your VoiceXML scripts, which represent the static content of the Cisco Unity Express IVR application, and JSP and Java files, which generate the dynamic content of the Cisco Unity Express IVR application. Cisco Unity Express IVR applications are packaged using the WAR file format, which contain VoiceXML and compiled versions of the JSP and Java files, including their property and configuration files.

Before a web application is deployed, prompts must be loaded onto the Cisco Unity Express system by using the following command:

```
ccn copy url xxx://xxx/xxx.wav prompt xxx.wav language xx_YY
```

Databases to be used by the web application must be first configured. Also, fax or e-mail resources used by the application must be configured. The WAR file must be located in a directory that can be accessed by using FTP, TFTP, or SFTP.

After the web application is defined, one or more triggers can be defined to trigger operation of the application. For details on defining the web application, see the *Cisco Unity Express 3.0 Interactive Voice Response CLI Administrator Guide*.

---

**Examples**

The following example uploads the web application *myapp* file using the username and password options to authenticate a network connection:

```
se-10-0-0-0# webapp deploy url ftp://10.0.0.1/hr.war webappname myapp username tbdonald  
password ***** allow-network-connect
```

---

**Related Commands**

Command	Description
<a href="#">show webapp-IVR Only</a>	Displays the Cisco Unity Express IVR web application status.

---

# webapp reload–IVR Only

Use the **webapp reload** command to reload the specified web application in Cisco Unity Express IVR privileged EXEC mode.

**webapp reload** *webappname name*

<b>Syntax Description</b>	<p><b>webappname</b> <i>name</i></p> <p>Name of the web application used to generate the:</p> <ul style="list-style-type: none"> <li>Name of the web application subdirectory that hosts the application files.</li> <li>URL path matched against incoming URLs to access this web application.</li> </ul> <p>Name must be 8 characters or less in length.</p>				
<b>Command Default</b>	No web application is configured.				
<b>Command Modes</b>	Cisco Unity Express IVR privileged EXEC				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Cisco Unity Express Version</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>3.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Cisco Unity Express Version	Modification	3.0	This command was introduced.
Cisco Unity Express Version	Modification				
3.0	This command was introduced.				
<b>Usage Guidelines</b>	This command is equivalent to the <b>webapp stop</b> command immediately followed by the <b>webapp start</b> command, and is used to reload misbehaving web applications, and its status becomes <i>running</i> .				
<b>Examples</b>	<p>The following example reloads the web application <i>myapp</i>:</p> <pre>se-10-0-0-0# webapp reload webappname myapp</pre>				
<b>Related Commands</b>	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td><a href="#">show webapp–IVR Only</a></td> <td>Displays the Cisco Unity Express IVR web application status.</td> </tr> </tbody> </table>	Command	Description	<a href="#">show webapp–IVR Only</a>	Displays the Cisco Unity Express IVR web application status.
Command	Description				
<a href="#">show webapp–IVR Only</a>	Displays the Cisco Unity Express IVR web application status.				

# webapp start–IVR Only

Use the **webapp start** command to start the specified web application in Cisco Unity Express IVR privileged EXEC mode.

**webapp start** *webappname name*

<b>Syntax Description</b>	<p><b>webappname</b> <i>name</i></p> <p>Name of the web application used to generate the:</p> <ul style="list-style-type: none"> <li>Name of the web application subdirectory that hosts the application files.</li> <li>URL path matched against incoming URLs to access this web application.</li> </ul> <p>Name must be 8 characters or less in length.</p>				
<b>Command Default</b>	No web application is configured.				
<b>Command Modes</b>	Cisco Unity Express IVR privileged EXEC				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Cisco Unity Express Version</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>3.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Cisco Unity Express Version	Modification	3.0	This command was introduced.
Cisco Unity Express Version	Modification				
3.0	This command was introduced.				
<b>Usage Guidelines</b>	The <b>webapp deploy</b> command actually uploads and starts the web application, so the <b>webapp start</b> command is only used to restart the web application after it is stopped.				
<b>Examples</b>	<p>The following example starts the web application <i>myapp</i>:</p> <pre>se-10-0-0-0# webapp start webappname myapp</pre>				
<b>Related Commands</b>	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td><a href="#">show webapp–IVR Only</a></td> <td>Displays the Cisco Unity Express IVR web application status.</td> </tr> </tbody> </table>	Command	Description	<a href="#">show webapp–IVR Only</a>	Displays the Cisco Unity Express IVR web application status.
Command	Description				
<a href="#">show webapp–IVR Only</a>	Displays the Cisco Unity Express IVR web application status.				

# webapp stop—IVR Only

Use the **webapp stop** command to stop the specified web application in Cisco Unity Express IVR privileged EXEC mode.

**webapp stop** *webappname name*

## Syntax Description

<b>webappname</b> <i>name</i>	Name of the web application used to generate the: <ul style="list-style-type: none"> <li>• Name of the web application subdirectory that hosts the application files.</li> <li>• URL path matched against incoming URLs to access this web application.</li> </ul> Name must be 8 characters or less in length.
-------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

## Command Default

No web application is configured.

## Command Modes

Cisco Unity Express IVR privileged EXEC

## Command History

Cisco Unity Express Version	Modification
3.0	This command was introduced.

## Examples

The following example stops the web application *myapp*:

```
se-10-0-0-0# webapp stop webappname myapp
```

## Related Commands

Command	Description
<a href="#">show webapp—IVR Only</a>	Displays the Cisco Unity Express IVR web application status.



# write

To erase, copy, or display the running configuration, use the **write** command in Cisco Unity Express EXEC mode.

**write** [**erase** | **memory** | **terminal**]

## Syntax Description

<b>erase</b>	(Optional) Erases the running configuration.
<b>memory</b>	(Optional) Writes the running configuration to the startup configuration. This is the default.
<b>terminal</b>	(Optional) Displays the running configuration.

## Command Modes

Cisco Unity Express EXEC

## Command History

Cisco Unity Express Release	Modification
1.0	This command was introduced on the Cisco Unity Express network module and in Cisco Unified Communications Manager Express 3.0.
1.1	This command was implemented on the advanced integration module (AIM) and in Cisco Unified Communications Manager 3.3(3).
1.1.2	This command was implemented on the Cisco 2800 series and Cisco 3800 series routers.

## Usage Guidelines

Use the **write** or **write memory** command as a shortcut for the **copy running-config startup-config** command.

## Related Commands

Command	Description
<a href="#">erase startup-config</a>	Deletes the current startup configuration.

