



Out-Address Configuration Mode Commands

Command Modes

The Out-Address configuration mode provides the commands to configure the outbound parameters for the SCCP entities as part of the gtt-address-map configuration.

Exec > Global Configuration > GTT Address-Map Configuration > Out-Address Configuration

configure > gtt address-map *map_id* > **out-address** *address_name*

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-gtt-addrmap-outaddr-out_address) #
```



Important

The commands or keywords/variables that are available are dependent on platform type, product version, and installed license(s).



Important

For information on common commands available in this configuration mode, refer to the [Common Commands](#) chapter.

- [gt-address](#), on page 1
- [gt-format](#), on page 2
- [ni-indicator](#), on page 3
- [point-code](#), on page 3
- [routing-indicator](#), on page 4
- [ssf](#), on page 5
- [ssn](#), on page 5

gt-address

Configures the SCCP short address.

Product

SGSN

Privilege

Security Administrator, Administrator

Command Modes

Exec > Global Configuration > GTT Address-Map Configuration > Out-Address Configuration

```
configure > gtt address-map map_id > out-address address_name
```

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-gtt-addrmap-outaddr-out_address) #
```

Syntax Description

gt-address *gt_address*

gt_address

A string of 1 to 15 digits to define the GT-address

Usage Guidelines

Define the GT-address

Example

```
gt-address 010405525397
```

gt-format

The GT-format provides four formats that can be used during GTT.

Product

SGSN

Privilege

Security Administrator, Administrator

Command Modes

Exec > Global Configuration > GTT Address-Map Configuration > Out-Address Configuration

```
configure > gtt address-map map_id > out-address address_name
```

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-gtt-addrmap-outaddr-out_address) #
```

Syntax Description

gt-format *format_num*

format_num

1: Selects GT-format 1 options which include **nature-of-address** and **odd/even**. Once selected, the system enters GT-Format1 configuration mode.

2: Selects GT-format2 options which include **translation-type**. Once selected, the system enters GT-Format2 configuration mode.

3: Selects GT-format3 options which include **encoding-scheme**, **numbering-plan3** and **translation-type**. Once selected, the system enters GT-Format1 configuration mode.

4: Selects GT-format4 options which include **encoding-scheme**, **nature-of-address**, **numbering-plan**, and **translation-type**. Once selected, the system enters GT-Format4 configuration mode.

Usage Guidelines

Select the a GT-format that include encoding-scheme as part of the GTT process.

Example

```
gt-format 3
```

ni-indicator

Configures the National and International indicator to use during the GTT process.

Product

SGSN

Privilege

Security Administrator, Administrator

Command Modes

Exec > Global Configuration > GTT Address-Map Configuration > Out-Address Configuration

```
configure > gtt address-map map_id > out-address address_name
```

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-gtt-addrmap-outaddr-out_address)#
```

Syntax Description

```
ni-indicator ni_ind
```

ni_ind

Select one of the following as the appropriate type of national indicator for the address structure:

- **national**
- **international**

Usage Guidelines

Select the international indicator to be used for out-going addresses.

Example

```
ni-indicator international
```

point-code

Selects and configures the SS7-type point code for use with the out-going address.

Product

SGSN

Privilege

Security Administrator, Administrator

Command Modes

Exec > Global Configuration > GTT Address-Map Configuration > Out-Address Configuration

```
configure > gtt address-map map_id > out-address address_name
```

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-gtt-addrmap-outaddr-out_address)#
```

Syntax Description `point-code` *pt_code*

pt_code

Enter 1 to 11 digits in the point code format predefined during variant selection of GTT association.

Usage Guidelines Define an ITU point code to be used for out-going address processing.

Example

```
point-code 6.255.6
```

routing-indicator

Selects the type of routing and the indicator to be included in the out-going message.

Product SGSN

Privilege Security Administrator, Administrator

Command Modes Exec > Global Configuration > GTT Address-Map Configuration > Out-Address Configuration

configure > **gtt address-map** *map_id* > **out-address** *address_name*

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-gtt-addrmap-outaddr-out_address)#
```

Syntax Description `routing-indicator` *routing_ind*

routing_ind

Select one of the following options:

- **gt**: Inserts an indicator that identifies routing based on global title.
- **ssn**: Inserts an indicator that identifies routing based on the subsystem number.

Usage Guidelines Select global title as the appropriate routing indicator.

Example

```
routing-indicator gt
```

ssf

Selects the subservice field as factor in the out-going address processing. **ssf** sets the network indicator in the subservice field for SS7 Message Signal Units (MSUs). The indicator carried in the message's routing information typically identifies the structure of the point code as a message from within a nation or as a message coming from outside the national - international.

Product

SGSN

Privilege

Security Administrator, Administrator

Command Modes

Exec > Global Configuration > GTT Address-Map Configuration > Out-Address Configuration

configure > **gtt address-map** *map_id* > **out-address** *address_name*

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-gtt-addrmap-outaddr-out_address)#
```

Syntax Description

ssf *sub_svc fld*

sub_svc fld

Select one of the following options:

- **international:** The network indicator identifies the message as international with a point code structure that does not match the national point code structure,
- **national:** The network indicator identifies the messages as having a national point code structure.
- **reserved:** Provides an alternate network indicator for national messages.
- **spare:** Provides an alternate network indicator for international messages.

Usage Guidelines

Select the international NI for inclusion in out-going address subservice fields.

Example

```
ssf international
```

SSN

Selects the subsystem number to be included in the out-going message.

Product

SGSN

Privilege

Security Administrator, Administrator

Command Modes

Exec > Global Configuration > GTT Address-Map Configuration > Out-Address Configuration

configure > **gtt address-map** *map_id* > **out-address** *address_name*

Entering the above command sequence results in the following prompt:

```
[local]host_name(config-gtt-addrmap-outaddr-out_address)#
```

Syntax Description

ssn *sub_sys_num*

sub_sys_num

Enter an integer from 1 to 255.

Usage Guidelines

Use subsystem number 44 in the out-going address.

Example

ssn *44*