



## About the Documentation

---

This documentation describes the Cisco 4700 Series Application Control Engine (ACE) appliance (ACE Appliance Device Manager) and explains how to use it to manage your network.

This section provides the following topics about the documentation:

- [Audience, page i](#)
- [Organization, page i](#)
- [Related Documentation, page ii](#)
- [Conventions, page iv](#)
- [Obtaining Documentation, Obtaining Support, and Security Guidelines, page v](#)
- [Open-Source Software Included in Cisco 4700 Series Application Control Engine \(ACE\) appliance, page v](#)
- [Open Source License Acknowledgements, page vi](#)

## Audience

This documentation is intended for experienced system and network administrators. Depending on the configuration required, readers should have specific knowledge in the following areas:

- Networking and data communications
- Network security
- Router configuration

## Organization

This documentation contains the following sections:

- [Chapter 1, “Overview”](#) contains an summary of ACE features and the ACE Appliance Device Manager interface, terms, and getting started configuration information.
- [Chapter 2, “Configuring Virtual Contexts”](#) describes how to configure virtual contexts on the ACE appliance so that you can effectively and efficiently manage and allocate resources, users, and services.
- [Chapter 3, “Configuring Virtual Servers”](#) contains procedures for configuring virtual servers for load balancing on the ACE.

- [Chapter 4, “Configuring Real Servers and Server Farms”](#) provides an overview of server load balancing and procedures for configuring real servers and server farms for load balancing on the ACE.
- [Chapter 5, “Configuring Stickiness”](#) provides information about sticky behavior and procedures for configuring stickiness with the ANM.
- [Chapter 6, “Configuring Parameter Maps”](#) describes how to configure parameter maps so that the ACE can perform actions on incoming traffic based on certain criteria, such as protocol or connection attributes.
- [Chapter 7, “Configuring SSL”](#) describes the SSL configuration process and details the procedures for configuring SSL on the ACE appliance.
- [Chapter 8, “Configuring Network Access”](#) includes information about configuring virtual context VLAN interfaces, port channel interfaces, and gigabit Ethernet interfaces.
- [Chapter 9, “Configuring High Availability”](#) contains an overview of the redundancy feature and explains how to configure high available.
- [Chapter 10, “Configuring Traffic Policies”](#) describes how to configure class maps and policy maps to provide a global level of classification for filtering traffic received by or passing through the ACE appliance.
- [Chapter 11, “Configuring Application Acceleration and Optimization”](#) describes how to configure application acceleration and optimization options on the ACE appliance.
- [Chapter 12, “Monitoring Your Network”](#) allows you to monitor key areas of system usage.
- [Chapter 13, “Managing the ACE Appliance”](#) describes the administrative tools that manage the ACE appliance.
- [Chapter 14, “Using ACE Appliance Device Manager Troubleshooting Tools”](#) describes the administrator-only diagnostic tools to help troubleshoot ACE appliance management problems.
- [“Glossary”](#) defines some of the terms used in this document.

## Related Documentation

In addition to this documentation, the ACE documentation set includes the following:

**Table 1**      **ACE Appliance Documentation**

Document Title	Description
<i>Release Note for the Cisco 4700 Series Application Control Engine Appliance</i>	Provides information about operating considerations, caveats, and command-line interface (CLI) commands for the ACE.
<i>Cisco Application Control Engine Appliance Hardware Installation Guide</i>	Provides information for installing the ACE appliance.
<i>Regulatory Compliance and Safety Information for the Cisco Application Control Engine Appliance</i>	Regulatory compliance and safety information for the ACE appliance.

**Table 1**      **ACE Appliance Documentation (continued)**

<b>Document Title</b>	<b>Description</b>
<i>Cisco 4700 Series Application Control Engine Appliance Quick Start Guide</i>	Describes how to use the ACE appliance Device Manager and CLI to perform the initial setup and VIP load-balancing configuration tasks.
<i>Cisco 4700 Series Application Control Engine Appliance Administration Guide</i>	Describes how to perform the following administration tasks on the ACE: <ul style="list-style-type: none"> <li>• Setting up the ACE appliance</li> <li>• Establishing remote access</li> <li>• Managing software licenses</li> <li>• Configuring class maps and policy maps</li> <li>• Managing the ACE software</li> <li>• Configuring SNMP</li> <li>• Configuring redundancy</li> <li>• Configuring the XML interface</li> <li>• Upgrading the ACE software</li> </ul>
<i>Cisco 4700 Series Application Control Engine Appliance Virtualization Configuration Guide</i>	Describes how to operate your ACE in a single context or in multiple contexts.
<i>Cisco 4700 Series Application Control Engine Appliance Routing and Bridging Configuration Guide</i>	Describes how to configure the following routing and bridging tasks on the ACE: <ul style="list-style-type: none"> <li>• Ethernet ports</li> <li>• VLAN interfaces</li> <li>• Routing</li> <li>• Bridging</li> <li>• Dynamic Host Configuration Protocol (DHCP).</li> </ul>
<i>Cisco 4700 Series Application Control Engine Appliance Server Load-Balancing Configuration Guide</i>	Describes how to configure the following server load-balancing tasks on the ACE: <ul style="list-style-type: none"> <li>• Real servers and server farms</li> <li>• Class maps and policy maps to load-balance traffic to real servers in server farms</li> <li>• Server health monitoring (probes)</li> <li>• Stickiness</li> <li>• Firewall load balancing</li> <li>• TCL scripts</li> </ul>

**Table 1**      **ACE Appliance Documentation (continued)**

<b>Document Title</b>	<b>Description</b>
<i>Cisco 4700 Series Application Control Engine Appliance Security Configuration Guide</i>	Describes how to perform following ACE security configuration tasks: <ul style="list-style-type: none"> <li>• Security access control lists (ACLs)</li> <li>• User authentication and accounting using a Terminal Access Controller Access Control System + (TACACS+), Remote Authentication Dial-In User Service (RADIUS), or Lightweight Directory Access Protocol (LDAP) server</li> <li>• Application protocol and HTTP deep packet inspection</li> <li>• TCP/IP normalization and termination parameters</li> <li>• Network address translation (NAT)</li> </ul>
<i>Cisco 4700 Series Application Control Engine Appliance Application Acceleration and Optimization Configuration Guide</i>	Describes the configuration of the application acceleration and optimization features of the ACE appliance. It also provides an overview and description of these features.
<i>Cisco 4700 Series Application Control Engine Appliance SSL Configuration Guide</i>	Describes how to configure the following Secure Sockets Layer (SSL) tasks on the ACE: <ul style="list-style-type: none"> <li>• SSL certificates and keys</li> <li>• SSL initiation</li> <li>• SSL termination</li> <li>• End-to-end SSL</li> </ul>
<i>Cisco 4700 Series Application Control Engine Appliance System Message Guide</i>	Describes how to configure system message logging on the ACE. This guide also lists and describes the system log (syslog) messages generated by the ACE.
<i>Cisco 4700 Series Application Control Engine Appliance Command Reference</i>	Provides an alphabetical list and descriptions of all CLI commands by mode, including syntax, options, and related commands.
<i>Cisco CSS-to-ACE Conversion Tool User Guide</i>	Describes how to use the CSS-to-ACE conversion tool to migrate Cisco Content Services Switches (CSS) running- or startup-configuration files to the ACE.

## Conventions

This documentation uses the following conventions:

<b>Item</b>	<b>Convention</b>
Commands and keywords	<b>boldface font</b>
Variables for which you supply values	<i>italic font</i>

Item	Convention
Displayed session and system information	screen font
Information you enter	<b>boldface screen font</b>
Variables you enter	<i>italic screen font</i>
Menu items and button names	<b>boldface font</b>
Selecting a menu item in paragraphs	<b>Option &gt; Network Preferences</b>
Selecting a menu item in tables	Option > Network Preferences

**Note**

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the publication.

**Caution**

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

## Obtaining Documentation, Obtaining Support, and Security Guidelines

For information on obtaining documentation, obtaining support, providing documentation feedback, security guidelines, and also recommended aliases and general Cisco documents, see the monthly *What's New* in Cisco Product Documentation, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

## Open-Source Software Included in Cisco 4700 Series Application Control Engine (ACE) appliance

- Cisco 4700 Series Application Control Engine (ACE) appliance includes the following open-source software, which is covered by the Apache 2.0 license (<http://www.apache.org/>): Ant, Apache Axis, Avalon Logkit, Commons, Ehcache, Globus Toolkit, Jetty, Log4J, Oro, Tomcat.
- Cisco 4700 Series Application Control Engine (ACE) appliance includes the following open-source software, which is covered by The Legion of the Bouncy Castle (<http://www.bouncycastle.org/licence.html>) license: BouncyCastle.
- Cisco 4700 Series Application Control Engine (ACE) appliance includes the following open-source software, which is covered by The Castor license (<http://www.castor.org/license.html>): Castor-0.9.5.

- Cisco 4700 Series Application Control Engine (ACE) appliance includes the following open-source software, which is covered by the GNU Lesser General Public License Version 2.1 (<http://www.gnu.org/licenses/lgpl.html>): c3p0-0.9.0.2.jar, Enterprise DT, Jasperreports 1.2, Jcommon 1.2, Jfreechart 1.0.1
- Cisco 4700 Series Application Control Engine (ACE) appliance includes the following open-source software, which is covered by the Mozilla Public License Version 1.1 (<http://www.mozilla.org/MPL/MPL-1.1.html>): Itext 1.4.

## Open Source License Acknowledgements

The following acknowledgements pertain to this software license.

### OpenSSL/Open SSL Project

This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org/>).

This product includes cryptographic software written by Eric Young (eay@cryptsoft.com).

This product includes software written by Tim Hudson (tjh@cryptsoft.com).

### License Issues

The OpenSSL toolkit stays under a dual license, i.e. both the conditions of the OpenSSL License and the original SSLeay license apply to the toolkit. See below for the actual license texts. Actually both licenses are BSD-style Open Source licenses. In case of any license issues related to OpenSSL please contact [openssl-core@openssl.org](mailto:openssl-core@openssl.org).

#### OpenSSL License:

© 1998-1999 The OpenSSL Project. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions, and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgment: “This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (<http://www.openssl.org/>)”
4. The names “OpenSSL Toolkit” and “OpenSSL Project” must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact [openssl-core@openssl.org](mailto:openssl-core@openssl.org).
5. Products derived from this software may not be called “OpenSSL” nor may “OpenSSL” appear in their names without prior written permission of the OpenSSL Project.
6. Redistributions of any form whatsoever must retain the following acknowledgment:

“This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org/>)”

THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT “AS IS” AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OpenSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes cryptographic software written by Eric Young (eay@cryptsoft.com). This product includes software written by Tim Hudson (tjh@cryptsoft.com).

**Original SSLeay License:**

© 1995-1998 Eric Young (eay@cryptsoft.com). All rights reserved.

This package is an SSL implementation written by Eric Young (eay@cryptsoft.com).

The implementation was written so as to conform with Netscapes SSL.

This library is free for commercial and non-commercial use as long as the following conditions are adhered to. The following conditions apply to all code found in this distribution, be it the RC4, RSA, lhash, DES, etc., code; not just the SSL code. The SSL documentation included with this distribution is covered by the same copyright terms except that the holder is Tim Hudson (tjh@cryptsoft.com).

Copyright remains Eric Young’s, and as such any Copyright notices in the code are not to be removed. If this package is used in a product, Eric Young should be given attribution as the author of the parts of the library used. This can be in the form of a textual message at program startup or in documentation (online or textual) provided with the package.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement:

“This product includes cryptographic software written by Eric Young (eay@cryptsoft.com)”.

The word ‘cryptographic’ can be left out if the routines from the library being used are not cryptography-related.

4. If you include any Windows specific code (or a derivative thereof) from the apps directory (application code) you must include an acknowledgement: “This product includes software written by Tim Hudson (tjh@cryptsoft.com)”.

THIS SOFTWARE IS PROVIDED BY ERIC YOUNG “AS IS” AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT

NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The license and distribution terms for any publicly available version or derivative of this code cannot be changed. i.e. this code cannot simply be copied and put under another distribution license [including the GNU Public License].