



CHAPTER 4

Monitoring Notifications

This chapter describes the Cisco CMTS Universal Broadband Series Router notifications supported by the MIB enhancements feature introduced in Cisco IOS Release 12.3(21)SCC. SNMP uses notifications to report events on a managed device. The notifications are traps or informs for different events. The router also supports other notifications that are not listed.

This chapter contains the following sections:

- [SNMP Notification Overview, page 4-1](#)
- [Enabling Notifications, page 4-2](#)
- [Cisco SNMP Notifications, page 4-3](#)

SNMP Notification Overview

An SNMP agent can notify the SNMP manager when important system events occur, such as the following:

- An interface or card starts or stops running
- Temperature thresholds are crossed
- Authentication failures occur

When an agent detects an alarm condition, the agent:

- Logs information about the time, type, and severity of the condition
- Generates a notification message, which it then sends to a designated IP host

SNMP notifications are sent as one of the following:

- Traps—Unreliable messages, which do not require receipt acknowledgement from the SNMP manager.
- Informs—Reliable messages, which are stored in memory until the SNMP manager issues a response. Informs use more system resources than traps.

To use SNMP notifications on your system, you must specify trap recipients. These recipients indicate where network registrar notifications are directed. Traps are enabled using the **snmp-server enable traps** command .

Many commands use the key word **traps** in the command syntax. Unless there is an option in the command to select either **traps** or **informs**, the keyword **traps** refers to traps, informs, or both. Use the **snmp-server host** command to specify whether to send SNMP notifications as traps or informs. The types of traps can be specified in command.

**Note**

Most notification types are disabled by default. However, some notification types cannot be controlled with the **snmp** command. For example, some notification types are always enabled and other types are enabled by a different command. The linkUpDown notifications are controlled by the **snmp trap link-status** command. If you enter this command with no **notification-type** keywords, the default is set to enable all notification types controlled by the command.

Specify the trap types if you do not want all traps to be sent. Then use multiple **snmp-server enable traps** commands, one for each of the trap types that you used in the **snmp host** command. The event table must have an entry that specifies the action that is to be performed.

For detailed information about notifications and a list of notification types, refer the following Cisco documents at:

- *The Traps Sent with SNMP-Server Enabled Traps Configured* guide at:
http://www.cisco.com/en/US/tech/tk648/tk362/technologies_tech_note09186a008021de3e.shtml
- “Configuring SNMP Support” section in *Cisco IOS Configuration Fundamentals Configuration Guide, Release 12.2* guide at:
http://www.cisco.com/en/US/docs/ios/12_2/configfun/configuration/guide/fc014.html

Enabling Notifications

You can enable MIB notifications using either of the following procedures:

Using the command-line interface (CLI)—Specify the recipient of the trap message and specify the types of traps sent. For detailed procedures, go to the following URLs:

- *The Traps Sent with SNMP-Server Enabled Traps Configured* guide at:
http://www.cisco.com/en/US/tech/tk648/tk362/technologies_tech_note09186a008021de3e.shtml
- *Cisco IOS Software Releases 11.3, SNMP Inform Requests* guide at:
http://www.cisco.com/en/US/docs/ios/11_3/feature/guide/snmpinfm.html
- Performing an SNMP SET operation with the **setany** command—To enable or disable MIB notifications, perform an SNMP SET operation on a specific object.
 - To enable the notifications set the object to true(1).
 - To disable the notifications, set the object to false(2).

For detailed procedures, go to:

<http://www.cisco.com/en/US/docs/switches/lan/catalyst6500/catos/6.x/configuration/guide/snmp.html>

**Note**

If you issue the **snmp-server enable traps** command without a notification-type argument, the router generates traps for all types of events, which might not be desirable. Some MIBs require the user to set additional objects to enable some notifications.

Cisco SNMP Notifications

This section contains tables that describe a MIB event, why the event occurred, and a recommendation as to how to handle the event. Each table lists the following information:

- Event—The event display.
- Description—What the event indicates.
- Probable cause—What might have caused the notification.
- Recommended action—Recommendation as to what should be done when the particular notification occurs.



Note

In the following tables, where *no action required* appears in the Recommended Action column, there might be instances where an application, such as trouble ticketing, occurs.

Functional Notifications

Table 4-1 lists notifications generated for events that might indicate the failure of the Cisco CMTS uBR router or conditions that might affect the router functionality.

Table 4-1 Environmental or Functional Notifications

Event	Description	Probable Cause	Recommended Action
cefcModuleStatusChange	Indicates that the status of a module has changed. A management application can use this trap to update the status of a module it manages.	Module has unknown state.	Enter the show module command to view error message details. For syslog messages associated with this event, consult Messages and Recovery Procedures.
		A line card is provisioned for a slot but it is not present in the slot.	Insert a configured line card in the specific slot.
		Module is operational.	No action is required.
cefcPowerStatusChange	Indicates that the power status of a field-replaceable unit has changed.	Module has failed due to some condition.	Enter the show module command to view error message details. For Syslog messages associated with this event, consult Messages and Recovery Procedures.
		FRU is powered off because of an unknown problem.	Enter the show power command to check the actual power usage. For syslog messages associated with this event, consult Messages and Recovery Procedures.
		FRU is powered on.	No action is required.
		FRU is administratively off.	No action is required.

Table 4-1 Environmental or Functional Notifications (continued)

Event	Description	Probable Cause	Recommended Action
		FRU is powered off because available system power is insufficient.	Enter the show power command to check the actual power usage.
cefcFRUInserted	Indicates that a FRU was inserted. The trap indicates the entPhysicalIndex of the slot that the line card was inserted in.	A new field-replaceable unit such as the line card, SIP and SPA modules, fan, port, power supply, or redundant power supply was added.	No action is required; but you can enable this trap through the CLI or by setting <code>cefcMIBEnableStatusNotification</code> to true(1).
cefcFRURemoved	Indicates that a FRU was removed and indicates the entPhysicalIndex of the slot from which the line card was removed.	A field-replaceable unit such as the line cards, SIP, SPA, fan, ports, power supply, or redundant power supply was removed.	Replace the field-replaceable unit.
chassisAlarmOn	Indicates that a FRU status has changed.	The chassis temperature is too high, a minor or major alarm has been detected.	Inspect the indicated component closely to determine why it is operating out of the normal operating temperature range and whether it eventually exceeds the allowed operating temperature range.
		A redundant power supply has been powered off.	Replace the field-replaceable unit.
	Cooling fan of the router could be close to failure.	One or more fans in the system fan tray have failed. Although this is a minor alarm, system components may overheat and shut down.	Replace the fan as soon as possible or the system might shut itself down or fail to operate properly.
chassisAlarmOff	Indicates that a FRU status has changed.	A redundant power supply has been powered on.	No action is required.

Cisco Router Line Card Notifications

These notifications indicate the failure of a line card or error conditions on the card that might affect the functionality of all interfaces and connected customers.

Table 4-2 lists ENTITY-MIB notifications that the Cisco CMTS uBR router cards and SPAs generate.

Table 4-2 Line Card Notifications

Event	Description	Probable Cause	Recommended Action
entConfigChange	An entry for the line card or a shared port adapter is removed from the entPhysicalTable causing the value of entLastchangeTime to change.	A line card was removed.	Replace the field-replaceable unit.
cefcModuleStatusChange	Indicates that the line card operational state changed. A management application uses this trap to update the status of a module that it is managing.	A line card is provisioned for a slot but it is not present in the slot.	Add a module.
entSensorThresholdNotification	Indicates that the sensor value crossed the threshold. This notification reports the most recent measurement detected by the sensor and indicates the value of the threshold.	The sensor value in a module crossed the threshold listed in entSensorThresholdTable. This notification is generated once each time the sensor value crosses the threshold. The local CPU was unable to access the temperature sensor on the module. The module attempts to recover by resetting itself.	Remove the configuration that bypasses the module shutdown due to sensor thresholds being exceeded. Shut down the module after removing the configuration as it has exceeded major sensor thresholds. Copy the error message exactly as it appears on the console or in the system log, contact your Cisco technical support representative, and provide the representative with the gathered information.
ceAlarmAsserted	The agent generates this trap when a physical entity asserts an alarm, such as the power entry module 0 failure.	You manually shut down the line card, then you get the line card error or the alarm Card Stopped Responding OIR occurs.	Check the entPhysicalDescr type and take the corresponding action; there are many types of asserted alarms.

Table 4-2 Line Card Notifications (continued)

Event	Description	Probable Cause	Recommended Action
ceAlarmCleared	The agent generates this trap when a physical entity clears a previously asserted alarm or when the core or inlet temperature exceed a threshold, such as inlet critical temperature limit.	The agent generates this trap when: <ul style="list-style-type: none"> a physical entity clears a previously asserted alarm a line card is installed in a slot and the alarm <i>Active Card Removed OIR</i> is cleared 	No action is required.

Notes:

Sensor entities are the physical entities where entity class must be defined to type entity sensor(8) in the entPhysicalTable.

Notifications are generated only if the particular entity has an entry in the entity table.

If ceAlarmNotifiesEnable is set to 0, it disables ceAlarmAsserted and ceAlarmCleared notifications. Similarly, when ceAlarmSyslogEnable is set to 0, it disables syslog messages corresponding to alarms.

If ceAlarmHistTableSize is set to 0, it prevents any history from being retained in the ceAlarmHistTable. In addition, whenever the ceAlarmHistTableSize is reset (either increased or decreased), the existing log is deleted.

When a new alarm condition is detected, the line card software sets the carrier alarm LEDs in the individual line cards. The Cisco IOS alarm subsystem does not control the LEDs.

Flash Card Notifications

Table 4-3 lists CISCO-FLASH-MIB notifications that the Cisco CMTS uBR router flash cards generate. These notifications indicate the failure of a flash card or error conditions on the card that might affect the functionality of all interfaces and connected custom.

Table 4-3 Flash Card Notifications

Event	Description	Probable Cause	Recommended Action
ciscoFlashDeviceChangeTrap	Indicates a removable flash device was inserted into the router.	Status change occurred when a removable flash card is inserted in the router.	To identify the flash card inserted, use the <code>ciscoFlashDeviceIndex</code> to check the <code>ciscoFlashDeviceTable</code> .
entConfigChange	<p>Generated every time a conceptual row is created, modified, or deleted in any of the following tables:</p> <ul style="list-style-type: none"> • <code>entPhysicalTable</code> • <code>entLogicalTable</code> • <code>entLPMappingTable</code> • <code>entAliasMappingTable</code> • <code>entPhysicalContainsTable</code> <p>Indicates that a new device (flash or any card) is added or removed from the router.</p> <p>And the <code>entLastChangeTime</code> is the <code>sysUpTime</code> at the time a flash card is added or deleted.</p>	Status change occurred when a flash card was added or removed.	To identify the flash card removed from the router, use the <code>ciscoFlashDeviceIndex</code> to check the <code>ciscoFlashDeviceTable</code> .
ciscoFlashCopyCompletionTrap ciscoFlashPartitioningCompletionTrap ciscoFlashMiscOpCompletionTrap	Indicates that a flash operation has occurred.	<p>Sent when the following flash operations occur:</p> <ul style="list-style-type: none"> • Copy operation finishes • Partitioning operation finishes • Miscellaneous flash card operation finishes 	Enable this trap through the CLI or setting the corresponding flash object to <code>true(1)</code> .

Link Notifications

Table 4-4 lists notifications that the router generates for link-related (interface) events.

Table 4-4 Interface Notifications

Event	Description	Probable Cause	Recommended Action
linkDown	<ul style="list-style-type: none"> Indicates that a link is about to enter the down state, which means it cannot transmit or receive traffic. The ifOperStatus object shows the current link state. Value is down(2). Indicates that the wideband downstream ports on the SPA are in a down state. 	An internal software error might have occurred.	<p>To see if link traps are enabled or disabled on an interface, check ifLinkUpDownTrapEnable (IF-MIB) for the interface. To enable link traps, set ifLinkUpDownTrapEnable to enabled(1).</p> <p>Enable the IETF (RFC 2233) format of link traps by issuing the snmp-server trap link ietf CLI command.</p>
linkUp	<ul style="list-style-type: none"> Indicates that a link is about to enter the Up state and the ifOperStatus object shows the current link status. Indicates that the wideband downstream ports on the SPA are in a up state. 	The port manager reactivated a port in the link-down state during a switchover.	<p>To see if link traps are enabled or disabled on an interface, check ifLinkUpDownTrapEnable (IF-MIB) for the interface. To enable link traps, set ifLinkUpDownTrapEnable to enabled(1).</p> <p>Enable the IETF (RFC 2233) format of link traps by issuing the snmp-server trap link ietf CLI command.</p>

Packet Forwarding Engine Notifications

Table 4-5 lists notifications that the router generates for Packet Forwarding Engine (PFE) events on the Cisco uBR10012 router. For Cisco uBR10012 router, the PFE is the parallel express forwarding network processor (PXF), which is part of the performance routing engine (PRE).

Table 4-5 Packet Forwarding Engine Notifications

Event	Description	Probable Cause	Recommended Action
cePfeHistThldEvent	Indicates that the configured threshold is exceeded. The threshold value and type are found from the cePfeHistType and cePfeHistThld. And the event type can be any of the enumerations of the HistEventType.	A threshold event has occurred and the cePfeHistNotifiesEnable is set to notify(3) or logAndNotify(4).	No action is required, the system waits for the value to fall below the threshold value.

HistEventType

Objects:

- cePfeHistEntPhysIndex,
- cePfeHistType,
- cePfeHistThld,
- cePfeHistValue

Table 4-5 Packet Forwarding Engine Notifications (continued)

Event	Description	Probable Cause	Recommended Action
<ul style="list-style-type: none"> thldUtilizationEvent 	Generated if the cePfePerfCurrentUtilization, at the time of sampling, becomes greater than or equal to the cePfePerfThldUtilization.		
<ul style="list-style-type: none"> thldEfficiencyEvent 	Generated if the cePfePerfCurrentEfficiency, at the time of sampling, becomes less than or equal to the cePfePerfThldEfficiency.		
<ul style="list-style-type: none"> thld1MinUtilizationEvent 	Generated if the cePfePerfCurrent1MinUtilization, at the time of sampling, becomes greater than or equal to the cePfePerfThld1MinUtilization.		
<ul style="list-style-type: none"> thld1MinEfficiencyEvent 	Generated if the cePfePerfCurrent1MinEfficiency, at the time of sampling, becomes less than or equal to the cePfePerfThld1MinEfficiency.		
<ul style="list-style-type: none"> thld5MinUtilizationEvent 	Generated if the cePfePerfCurrent5MinUtilization, at the time of sampling, becomes greater than or equal to the cePfePerfThld5MinUtilization.		

Table 4-5 Packet Forwarding Engine Notifications (continued)

Event	Description	Probable Cause	Recommended Action
<ul style="list-style-type: none"> thld5MinEfficiencyEvent 	Generated if the cePfePerfCurrent5MinEficiency, at the time of sampling, becomes less than or equal to the cePfePerfThld5MinEfficiency.		
cePfeHistRestartEvent	Indicates a PFE restart occurred.	The PFE processor restarted.	Enable this trap using the snmp-server CLI command or by setting cePfeHistNotifiesEnable to notify(3) or logAndNotify(4).

Configuration Notifications

Table 4-6 lists notifications generated by the CMTS router for events related to system configuration.

Table 4-6 CMTS Configuration Notifications

Event	Description	Probable Cause	Recommended Action
ccCopyCompletion <ul style="list-style-type: none"> ccCopyServerAddress ccCopyFileName ccCopyState ccCopyTimeStarted ccCopyTimeCompleted ccCopyFailCause 	A ccCopyCompletion trap is sent when a config-copy request is completed. The ccCopyFailCause is not instantiated, and hence not included in a trap, when the ccCopyState is successful.	Sent when the CMTS router finishes copying a configuration file to or from another location.	Enable this trap by setting ccCopyNotificationOnCompletion to true(1).
ciscoConfigManEvent	The current configuration changed.	Sent when the running configuration changes.	No action is required.

MPLS Service Notifications

Table 4-7 lists service notifications generated by the CMTS router to indicate conditions for services.

Table 4-7 MPLS-Service Notifications

Event	Description	Probable Cause	Recommended Action
mplsTunnelUp	Indicates that a <code>mplsTunnelOperStatus</code> object for a configured tunnel is about to transition from the Down state to any state except NotPresent.	A configured tunnel transitioned from the Down state to any state except NotPresent. May be caused by an administrative or operational status check of the tunnel.	No action is required. Enable this trap through the CLI or by setting <code>mplsTunnelTrapEnable</code> to <code>true(1)</code> .
mplsTunnelDown	Indicates that the <code>mplsTunnelOperStatus</code> object for a configured MPLS traffic engineering tunnel is about to transition to up(1) or down(2) state respectively.	A configured tunnel is transitioning to the down state. May be caused by an administrative or operational status check of the tunnel.	
mplsTunnelRerouted	Indicates that the signalling path for an MPLS traffic engineering tunnel changed.	A tunnel was rerouted or reoptimized.	If you use the actual path, write the new path to <code>mplsTunnelRerouted</code> after the notification is issued.

Routing Protocol Notifications

Table 4-8 lists notifications that the Cisco CMTS uBR router generates to indicate error conditions for routing protocols.

Table 4-8 Routing Protocol Notifications

Event	Description	Probable Cause	Recommended Action
bgpEstablished	The BGP FSM enters the Established state. It becomes active on the router.	BGP changed status.	No action is required.
bgpBackwardTransition	Indicates that BGP transitions from a higher-level state to a lower-level state. The prefix count for an address family on a BGP session exceeded the configured threshold value.	BGP changed status.	This threshold value is configured using the <code>neighbor nbr_addr max_prefixes [threshold] [warning-only]</code> CLI command.
oamLoopbackPingCompletionTrap	Indicates a loopback test.	Sent when an OAM loopback test completes.	Enable this trap through the CLI or by setting <code>oamLoopbackPingTrapOnCompletion</code> to <code>true(1)</code> .

Table 4-8 Routing Protocol Notifications (continued)

Event	Description	Probable Cause	Recommended Action
cPppoeSystemSessionThresholdTrap	Indicates that the PPPoE system session exceeded a threshold.	Sent when the number of active PPPoE sessions exceeds the value of cPppoeSystemThresholdSessions.	Enable this trap through the CLI.
cPppoeVcSessionThresholdTrap	Indicates that the PPPoE VC session exceeded a threshold.	Sent when the number of active PPPoE sessions on the VC exceeds the value of cPppoeVcThresholdSessions.	Enable this trap through the CLI.

Routing Service Notifications

[Table 4-9](#) lists notifications generated by the Cisco CMTS uBR router to indicate error conditions for routing services.

Table 4-9 Routing Protocol Notifications

Event	Description	Probable Cause	Recommended Action
casServerStateChange	<p>The casState object changes status.</p> <p>The object casState does not necessarily indicate the current state of the server. This is because casState is always up(1) unless an AAA request fails. In that case, casState is set to dead(2) and then reset to up(1) to allow the router to send requests to the server after a failure.</p> <p>The number of minutes casState remains dead(2) is specified by the radius-server deadtime minutes command. For example, if server deadtime is 5 minutes and an AAA request fails, a trap is generated with casState set to dead(2). Five minutes later, another trap is generated with casState set to up(1) even though the server may still be down.</p>	<p>Sent when the casState object changes state. The value of casState indicates if the router should send requests to the authentication, authorization, and accounting (AAA) server:</p> <ul style="list-style-type: none"> • up(1)—Send requests to the server. • dead(2)—Do not send requests to the server. Send requests to the next available server instead. 	<p>Enable this trap by setting casServerStateChangeEnable to true(1).</p>
ciscoSsgRadiusClientReboot	<p>Sent when the Service Selection Gateway (SSG) detects that a RADIUS client has rebooted. SSG uses RADIUS servers to authenticate subscribers.</p>	<p>A RADIUS client has rebooted.</p>	<p>Enable this trap by setting ssgCfgRadiusClientRebootNotification to true(1).</p>

SONET Notifications

Table 4-10 lists alarm notifications generated by the router for SONET events.

Table 4-10 SONET Notifications

Event	Description	Probable Cause	Recommended Action
ceAssertAlarm ceClearAlarm	These notifications indicate error conditions on a SONET circuit and the status of SONET layers. Not all SONET and Packet over SONET (POS) line cards generate all of the traps.	Sent when one of the following alarm status has changed. See footnote below.	Check out the AlarmType and ceAlarmHistSeverity values.
	Paths, for example a Path Alarm Indication Signal		
	Line, for example a Line Remove Failure Indication		
	Section, for example a Section Loss of Frame Failure		
	Clock problems, for example a Far End Clock Out of Range		
	Signal, for example a Out of Frame Failure		
	Near End/Far End, for example a Far End Alarm Indication Signal		
	Thresholds, for example a Threshold Cross Alarm-B1		

Chassis Notifications

Table 4-11 lists CISCO-STACK-MIB notifications generated by the router to indicate that a chassis module has become active or stopped responding. These notifications are supported by the Cisco CMTS router.

Table 4-11 Chassis Notifications

Event	Description	Probable Cause	Recommended Action
moduleDown	The status of a module changes from the OK state to another state.	The agent entity has detected that the moduleStatus object in this MIB has transitioned out of the ok (2) state for one of its modules. The generation of this trap can be controlled by the sysEnableModuleTraps object in this MIB.	Replace module.
moduleUp	The status of a module changes to the OK state.	The agent entity has detected that the moduleStatus object in this MIB has transitioned to the ok (2) state for one of its modules. The generation of this trap can be controlled by the sysEnableModuleTraps object in this MIB.	No action is required.

RTT Monitor Notifications

Table 4-12 lists CISCO-RTTMON-MIB notifications that can occur during round-trip time (RTT) monitoring.

Table 4-12 RTT Monitor Notifications

Event	Description	Probable Cause	Recommended Action
rttMonConnectionChangeNotification	Sent when the value of rttMonCtrlOperConnectionLostOccurred changes.	Occurs when the connection to a target has either failed to be established or was lost and then re-established. Note that this is a connection to a target not to a hop in the path to the target.	Check for the connectivity to the target. There could be link problems to the target through different hops.
rttMonTimeoutNotification	A timeout occurred or was cleared during an RTT probe.	An RTT probe occurred and the system sends the notice when the value of rttMonCtrlOperTimeoutOccurred changes.	Check for the end-to-end connectivity if rttMonCtrlOperTimeoutOccurred if the notification returns true. No action is required if rttMonCtrlOperTimeoutOccurred is false.
rttMonThresholdNotification	Threshold violation occurred during an RTT probe.	Indicates that the previous violation has subsided for a subsequent RTT operation that results in rttMonCtrlOperOverThresholdOccurred changing value.	Check for the end-to-end connectivity if rttMonCtrlOperOverThresholdOccurred in the notification is true otherwise no action is required.

Environmental Notifications

Table 4-13 lists CISCO-ENVMON-MIB notifications generated for events that might indicate the failure of the Cisco CMTS uBR router or conditions that might affect the router functionality.

Table 4-13 Environmental Notifications

Event	Description	Probable Cause	Recommended Action
ciscoEnvMonShutdownNotification	<p>A ciscoEnvMonShutdown Notification is sent if the environmental monitor detects a testpoint reaching a critical state and is about to initiate a shutdown.</p> <p>This notification contains no objects so that it may be encoded and sent in the shortest amount of time possible. Management applications should not rely on receiving such a notification as it may not be sent before the shutdown completes.</p>	<p>A test point nears a critical state and the router is about to shut down (for example, if auto-shutdown is enabled and the chassis core or inlet temperature reaches critical state and remains there for more than 2 minutes).</p> <p>The system has a configuration to shut down a module if its operating temperature exceeds a temperature threshold. This configuration has been bypassed, and a module will still operate in an over-temperature condition. Operating at an over-temperature condition can damage the hardware.</p>	<p>Do not override the system critical alarms like facility-alarm-intake-temperature.</p> <p>Enable this trap through the snmp-server-enable traps envmon shutdown CLI command or by setting the ciscoEnvMonEnableShutdownNotification to true(1).</p>
ciscoEnvMonFanNotification	<p>Fan status. A ciscoEnvMonFanNotification is sent if the system detects a fan failure or an empty tray.</p>	<p>One or more fans in the system fan tray failed, or the fan tray is missing. Although this is a minor alarm, system components could overheat and shut down.</p>	<p>Replace the system fan tray.</p> <p>Enable this trap using the snmp-server-enable traps envmon fan CLI command or by setting ciscoEnvMonEnableFanNotification to true (1).</p>
ciscoEnvMonRedundantSupplyNotification	<p>Power supply status. Sent if the redundant power supply (if available) fails.</p>	<p>An environmental condition, an over-temperature condition, or inconsistent voltage to the module occurred. Since such a notification is usually generated before the shutdown state is reached, it can convey more data and has a better chance of being sent than does the ciscoEnvMonShutdownNotification.</p>	<p>Ensure that the system power supplies are optimally redundant.</p> <p>Use power supplies with identical output ratings or reduce system power consumption.</p> <p>Enable this trap using the snmp-server enable traps envmon supply CLI command or by setting ciscoEnvMonEnableRedundantSupplyNotification to true (1).</p>

Table 4-13 Environmental Notifications (continued)

Event	Description	Probable Cause	Recommended Action
ciscoEnvMonTempStatusChangeNotif	<p>Temperature status. The core or inlet temperature is outside its normal range, when ciscoEnvMonState is at the Warning or Critical state.</p> <p>Since such a Notification is usually generated before the shutdown state is reached, it can convey more data and has a better chance of being sent than does the ciscoEnvMonShutdownNotification.</p>	<p>During previous reloads, this module experienced a timeout while accessing the temperature sensor. All further access to the temperature sensor is disabled. This condition indicates a possible problem with the temperature sensor.</p>	<p>Copy the error message as it appears on the console or in the system log, contact your Cisco technical support representative, and provide the representative with the error message.</p> <p>Enable this trap using the snmp-server enable traps envmon temperature CLI command or by setting ciscoEnvMonEnableTemperatureNotification to true (1).</p>
<p>The cefcFRUPowerAdminStatus is on(1) when a redundant power supply is disabled. When there is a redundant power supply, the cefcFRUPowerAdminStatus is always on(1) for both power supplies, regardless of whether the redundant power supply is disabled.</p>			

Redundancy Framework Notifications

Table 4-14 lists CISCO-RF-MIB notifications that can occur in a redundant system. There are two types of notifications:

- Switch of Activity (SWACT)—Either a forced or automatic switch of active status from the active unit to the standby unit. The former standby unit is now referred to as the active unit.
- Progression—The process of making redundancy state of the standby unit equivalent to that of the active unit. This includes transitioning the RF state machine through several states which drives the RF clients on the active unit to synchronize any relevant data with their peer on the standby unit.

Table 4-14 Redundancy Framework Notifications

Event	Description	Probable Cause	Recommended Action
ciscoRFSwactNotif	Indicates that the RF state changed. A switch of activity notification is sent by the newly active redundant unit.	A switch of activity occurs. If a SWACT event is indistinguishable from a reset event, then a network management station should use this notification to differentiate the activity.	If the switchover occurred due to active unit failed indicated by <code>cRFStatusLastSwactReasonCode</code> , see if there is any hardware failures, otherwise no action is required.
ciscoRFProgressionNotif	Indicates that the RF state changed.	The active redundant unit RF state changed or the RF state of the peer unit changed.	To avoid an increase of notifications for all state transitions, send notifications for transitions to the following RF states: <ul style="list-style-type: none"> standbyCold(5) standbyHot(9) active(14) activeExtraload(15)

Cable Device Notifications

Table 4-16 lists the notifications that occur in the following supported MIBs:

- DOCS-IETF-CABLE-DEVICE-NOTIFICATION-MIB

Table 4-15 CMTS Diagnostic MIB Notifications

MIB and Event	Description	Probable Cause	Recommended Action
DOCS-IETF-CABLE-DEVICE-NOTIFICATION-MIB			
<ul style="list-style-type: none"> <code>docsDevCmtsInitRegReqFailNotif</code> 	Reports failure of a registration request from a Cable Modem (CM) during CM initialization process. CMTS detects this failure.	A registration request failed during the CM initialization process.	Correct the registration request failure.
<ul style="list-style-type: none"> <code>docsDevCmtsInitRegRspFailNotif</code> 	Reports failure of a registration response during the CM initialization process. CMTS detects this failure.	A registration response failed during the CM initialization process.	Correct the registration response failures.
<ul style="list-style-type: none"> <code>docsDevCmtsInitRegAckFailNotif</code> 	Reports failure of a registration acknowledgement from the CM during the CM initialization process. CMTS detects this failure.	A registration acknowledgement failed during the CM initialization process.	Correct the registration acknowledgement failures.

Table 4-15 CMTS Diagnostic MIB Notifications (continued)

MIB and Event	Description	Probable Cause	Recommended Action
• docsDevCmtsDynServReqFailNotif	Reports failure of a dynamic service request during the dynamic services process. CMTS detects this failure.	A dynamic service request failed during the dynamic services process.	Correct the dynamic service request failures.
• docsDevCmtsDynServRspFailNotif	Reports failure of a dynamic service response during the dynamic services process. CMTS detects this failure.	A dynamic service response failed during the dynamic services process.	Correct the dynamic service response failures.
• docsDevCmtsDynServAckFailNotif	Reports failure of a dynamic service acknowledgement during the dynamic services. CMTS detects this failure.	A dynamic service acknowledgement failed during the dynamic services process.	Correct the dynamic service acknowledgement failures.
• docsDevCmtsBpiInitNotif	Reports failure of a BPI initialization attempt during the CM registration process. CMTS detects this failure.	A BPI initialization attempt failed during the CM registration process.	Correct the BPI initialization attempt failures.
• docsDevCmtsBPKMNotif	Reports failure of a BPKM operation. CMTS detects this failure.	A BPKM operation failed.	Correct the BPKM operation failures.
• docsDevCmtsDynamicSANotif	Reports failure of a dynamic security association operation. CMTS detects this failure.	A dynamic security association operation failed.	Correct the dynamic security association operation failures.
• docsDevCmtsDCCRspFailNotif	Reports the failure of a dynamic channel change request, during the dynamic channel change process. CMTS detects this failure.	A dynamic channel change request failed during the dynamic channel change process.	Correct the dynamic channel change request failures.
• docsDevCmtsDCCReqFailNotif	Reports failure of a dynamic channel change response during the dynamic channel process. CMTS detects this failure.	A dynamic channel change response failed during the dynamic channel change process.	Correct the dynamic channel change response failures.
• docsDevCmtsDCCAckFailNotif	Reports failure of a dynamic channel change acknowledgement during the dynamic channel change process. CMTS detects this failure.	A dynamic channel change acknowledgement failed during the dynamic channel change process.	Correct the dynamic channel change acknowledgement failures.

CMTS Diagnostic Notifications

Table 4-16 lists the notifications that occur in the DOCS-DIAG-MIB.

Table 4-16 CMTS Diagnostic MIB Notifications

MIB and Event	Description	Probable Cause	Recommended Action
DOCS-DIAG-MIB			
<ul style="list-style-type: none"> docsDiagLogSizeHighThreshldReached 	Indicates that the size of Diagnostic Log has exceeded docsDiagLogNotifyLogSizeHighThreshld.	Diagnostic log record exceeds the given maximum threshold. (docsDiagLogNotifyLogSizeHighThreshld.0)	Clear the out-of-date log. Use the set docsDiagLogClearAll.0 command via SNMP.
<ul style="list-style-type: none"> docsDiagLogSizeLowThreshldReached 	Indicates that the size of Diagnostic Log is below the docsDiagLogNotifyLogSizeLowThreshld size after exceeding docsDiagLogNotifyLogSizeHighThreshld size.	Diagnostic log record reaches the give minimum threshold. (docsDiagLogNotifyLogSizeLowThreshld.0)	No action is required.
<ul style="list-style-type: none"> docsDiagLogSizeFull 	Indicates that the Diagnostic Log is full.	Diagnostic log reaches the given maximum size. (docsDiagLogMaxSize.0)	Clear the out-of-date log. Use the set docsDiagLogClearAll.0 CLI command via SNMP.

Cable MIB Notifications

Table 4-17 lists the notifications that occur in the following supported MIBs:

- DOCS-CABLE-DEVICE-TRAP-MIB
- CISCO-DOCS-REMOTE-QUERY-MIB
- CISCO-CABLE-METERING-MIB
- CISCO-DOCS-EXT-MIB

Table 4-17 CABLE MIB Notifications

MIB and Event	Description	Probable Cause	Recommended Action
DOCS-CABLE-DEVICE-TRAP-MIB			
<ul style="list-style-type: none"> docsDevCmtsInitRegReqFailTrap 	Indicates that a registration request failed. The failure was detected on the CMTS side.	A registration request failed during the CM initialization process.	Correct the registration request failure.
<ul style="list-style-type: none"> docsDevCmtsInitRegRspFailTrap 	Indicates a registration response failed. The failure was detected on the CMTS side.	A registration response failed during the CM initialization process.	Correct the registration response failures.

Table 4-17 CABLE MIB Notifications (continued)

MIB and Event	Description	Probable Cause	Recommended Action
• docsDevCmtsInitRegAckFailTrap	Indicates a registration acknowledgement failed. The failure was detected on the CMTS side.	A registration acknowledgement failed during the CM initialization process.	Correct the registration acknowledgement failures.
• docsDevCmtsDynServReqFailTrap	Indicates a dynamic service request failed. The failure was detected on the CMTS side.	A dynamic service request failed during the dynamic services process.	Correct the dynamic service request failures.
• docsDevCmtsDynServRspFailTrap	Indicates a dynamic service response failed. The failure was detected on the CMTS side.	A dynamic service response failed during the dynamic services process.	Correct the dynamic service response failures.
• docsDevCmtsDynServAckFailTrap	Indicates a dynamic service acknowledgement failed. The failure was detected on the CMTS side.	A dynamic service acknowledgement failed during the dynamic services process.	Correct the dynamic service acknowledgement failures.
• docsDevCmtsBpiInitTrap	Indicates a BPI initialization attempt failed. The failure was detected on the CMTS side.	A BPI initialization attempt failed during the CM registration process.	Correct the BPI initialization attempt failures.
• docsDevCmtsBPKMTrap	Indicates a BPKM operation failed. The failure was detected on the CMTS side.	A BPKM operation failed.	Correct the BPKM operation failures.
• docsDevCmtsDynamicSATrapTrap	Indicates a dynamic security association operation failed. The failure was detected on the CMTS side.	A dynamic security association operation failed.	Correct the dynamic security association operation failures.
• docsDevCmtsDCCRReqFailTrap	A dynamic channel change request failed. The failure was detected on the CMTS side.	A dynamic channel change request failed during the dynamic channel change process	Correct the dynamic channel change request failures.
• docsDevCmtsDCCRspFailTrap	Indicates a dynamic channel change response failed. The failure was detected on the CMTS side.	A dynamic channel change response failed during the dynamic channel change process.	Correct the dynamic channel change response failures.

Table 4-17 CABLE MIB Notifications (continued)

MIB and Event	Description	Probable Cause	Recommended Action
<ul style="list-style-type: none"> docsDevCmtsDCCAckFailTrap 	A dynamic channel change acknowledgement failed. The failure was detected on the CMTS side.	A dynamic channel change acknowledgement failed during the dynamic channel change process.	Correct the dynamic channel change acknowledgement failures.

1 The following traps can be enabled using the CLI `snmp-server enable trap docsis-cmts` command.

bpi—Enable BPI init fail trap

bpkm—Enable BPKM fail trap

dccack—Enable dynamic channel change acknowledgement fail trap

dccreq—Enable dynamic channel change request fail trap

dccrsp—Enable dynamic channel change response fail trap

dsack—Enable dynamic service acknowledgement fail trap

dsreq—Enable dynamic service request fail trap

dsrsp—Enable dynamic service response fail trap

dynsa—Enable Dynamic SA fail trap

regack—Enable registration acknowledgement fail trap

regreq—Enable registration request fail trap

regrsp—Enable registration response fail trap

2 The following traps can be enabled by setting the bit value in docsDevCmtsTrapControl:

cmtsInitRegReqFailTrap(0)

cmtsInitRegRspFailTrap(1)

cmtsInitRegAckFailTrap(2)

cmtsDynServReqFailTrap(3)

cmtsDynServRspFailTrap(4)

cmtsDynServAckFailTrap(5)

cmtsBpiInitTrap(6)

cmtsBPKMTrap(7)

cmtsDynamicSATrap(8)

cmtsDCCReqFailTrap(9)

cmtsDCCRspFailTrap(10)

cmtsDCCAckFailTrap(11)

DOCS-REMOTE-QUERY-MIB			
<ul style="list-style-type: none"> cdrqCmtsCmRQDoneNotification 	Indicates the CMTS CM poller finished polling for the current cycle.		
<ul style="list-style-type: none"> cdrqCmtsCmPollerStartTime 	Indicates the time when the polling cycle started.	CMTS CM poller started polling.	No action is required.
<ul style="list-style-type: none"> cdrqCmtsCmPollerStopTime 	Indicates the time when the polling cycle finished.	CMTS CM poller finished polling.	No action is required.
CISCO-CABLE-METERING-MIB			

Table 4-17 CABLE MIB Notifications (continued)

MIB and Event	Description	Probable Cause	Recommended Action
ccmtrCollectionNotification	Indicates if the metering record file was created successfully or not and if streaming the file to the collection server was successful or not.	The receipt of this notification is an indication to the collection server that the file can be accessed through FTP or any file transfer protocol in the case of local storage.	Enable this trap by setting <code>ccmtrMeteringNotifEnable</code> to true(1).
<ul style="list-style-type: none"> • <code>ccmtrCollectionStatus</code>, • <code>ccmtrCollectionDestination</code>, • <code>ccmtrCollectionTimestamp</code> 	<p>Indicates the success or failure of the export.</p> <p>Indicates the destination of the export in both the success and failure scenarios.</p> <p>Indicates the timestamp of the export in both the success and failure scenarios.</p>		
cdxCmtsCmDMICLockNotification	Indicates a failure relating to DMIC.	Sent whenever a modem is locked because it failed the Dynamic Message Integrity Check (DMIC).	
ccsSpecMgmtNotification	Describes a change in status for cable hopping, modulation profile, or channel width.	Cable upstream runtime frequency (hopping), profile, or channel width status changed. See footnote below.	Use the cable upstream threshold command to change these values The CNR threshold for the secondary modulation profile defaults to 15 dB. The correctable FEC error threshold defaults to 1 percent of total packets received, and the invalid FEC error threshold defaults to 1 percent of total packets received.

1. In the case of frequency hopping, `ccsUpSpecMgmtHopCondition` would indicate whether SNR or `modemOffline` that caused the hopping.
2. Frequency hopping is based on the carrier-to-noise ratio (CNR) and the correctable FEC error and uncorrectable FEC error values. A channel performs frequency hop if the CNR falls below the configurable threshold AND either the correctable or uncorrectable FEC error values exceed the configurable threshold values.
3. Channel width may be too small.

