

SMDS Commands

Use the commands in this chapter to configure the Switched Multimegabit Data Service (SMDS), a wide-area networking service offered by some Regional Bell Operating Companies (RBOCs) and MCI.

For SMDS configuration information and examples, refer to the chapter “Configuring SMDS” in the *Access and Communication Servers Configuration Guide*.

arp

Use the following variation of the **arp** interface configuration command to enable ARP entries for static routing over the SMDS network. Use the **no** form of the command to disable this capability.

```
arp ip-address smds-address smds  
no arp ip-address smds-address smds
```

Syntax Description

<i>ip-address</i>	IP address.
<i>smds-address</i>	SMDS address.
smds	Enables ARP for SMDS.

Default

Disabled

Command Mode

Interface configuration

Example

The following example sets a static ARP entry for routing from IP network 172.30.173.28 to SMDS address C141.5797.1313 on serial interface 0:

```
interface serial 0  
arp 172.30.173.28 C141.5797.1313.FFFF smds
```

Related Command

smds enable-arp

encapsulation smds

Use the **encapsulation smds** interface configuration command to enable SMDS service on the desired interface.

encapsulation smds

Syntax Description

This command has no arguments or keywords.

Default

Disabled

Command Mode

Interface configuration

Usage Guidelines

The interface to which this command applies must be a serial interface. All subsequent SMDS configuration commands apply only to an interface with encapsulation SMDS.

Note The maximum packet size allowed in the SMDS specifications (TA-772) is 9188. This is larger than the packet size used by servers with most media. The Cisco default MTU size is 1500 bytes to be consistent with Ethernet. However, on HSSI interfaces, the default MTU size is 4470 bytes. If a larger MTU is used, the **mtu** command must be entered before the **encapsulation smds** command.

Keep in mind, however, that the Cisco MCI card has buffer limitations that prevent setting the MTU size higher than 2048, and the HSSI card has buffer limitations that prevent setting the MTU size higher than 4500. Configuring higher settings has caused access server inconsistencies and performance problems.

Example

The following example shows how to configure the SMDS service on serial interface 0:

```
interface serial 0
 encapsulation smds
```

Related Command

A dagger (†) indicates that the command is documented in another chapter.

mtu †

interface serial multipoint

To define a logical subinterface on a serial interface to support multiple logical IP subnetworks (Multi-LIS) over SMDS, use the **interface serial multipoint** interface configuration command.

interface serial *interface.subinterface* **multipoint**

Syntax Description

<i>interface</i>	Interface number.
<i>subinterface</i>	Number for this subinterface; values in the range 0 through 255.

Default

This command has no default values.

Usage Guidelines

Use this command only for access servers that need knowledge of multiple IP networks. Other access servers can be configured with information only about their own networks.

Example

The following example configures serial interface 2 with multipoint logical subinterface 1.

```
interface serial 2.1 multipoint
```

Related Command

A dagger (†) indicates that the command is documented in another chapter.

ip address †
smds address
smds enable-arp
smds multicast

show arp

Use the **show arp** privileged EXEC command to display the entries in the ARP table for the access server.

show arp

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Sample Display

The following is sample output from the **show arp** command:

```
Router# show arp

Protocol   Address           Age (min)  Hardware Addr   Type   Interface
-----
Internet   1172.30.42.112    120        0000.a710.4baf   ARPA   Ethernet3
AppleTalk  4028.5            29         0000.0c01.0e56   SNAP   Ethernet2
Internet   1172.30.42.114    105        0000.a710.859b   ARPA   Ethernet3
AppleTalk  4028.9            -          0000.0c02.a03c   SNAP   Ethernet2
Internet   1172.30.42.121    42         0000.a710.68cd   ARPA   Ethernet3
Internet   1172.30.36.9      -          0000.3080.6fd4   SNAP   TokenRing0
AppleTalk  4036.9            -          0000.3080.6fd4   SNAP   TokenRing0
Internet   1172.30.33.9      -          c222.2222.2222   SMDS   Serial0
```

Table 10-1 describes significant fields shown in the first line of output in the display.

Table 10-1 Show ARP Field Descriptions

Field	Description
Protocol	Type of network address this entry includes.
Address	Network address that is mapped to the MAC address in this entry.
Age (min)	Interval (in minutes) since this entry was entered in the table, rather than the interval since the entry was last used. (The timeout value is 4 hours.)
Hardware Addr	MAC address mapped to the network address in this entry.
Type	Encapsulation type the access server is using for the network address in this entry. Possible values include the following: <ul style="list-style-type: none"> • ARPA • SNAP • ETLK (EtherTalk) • SMDS
Interface	Interface associated with this network address.

show smds addresses

Use the **show smds addresses** privileged EXEC command to display the individual addresses and the interface with which they are associated.

show smds addresses

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Sample Display

The following is sample output from the **show smds addresses** command:

```
Router# show smds addresses  
  
SMDS address - Serial0 c141.5555.1212.FFFF
```

Table 10-2 describes the fields shown in the display.

Table 10-2 Show SMDS Addresses Field Descriptions

Field	Description
Serial0	Interface to which this SMDS address has been assigned.
c141.5555.1212	SMDS address that has been assigned to the interface.

show smds map

Use the **show smds map** privileged EXEC command to display all SMDS addresses that are mapped to higher-level protocol addresses.

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Sample Display

The following is sample output from the **show smds map** command:

```
Router# show smds map

Serial0: ARP maps to e180.0999.9999.FFFF multicast
Serial0: IP maps to e180.0999.9999.FFFF 72.16.42.112 255.255.255.0 multicast
Serial0: XNS 1006.AA00.0400.0C55 maps to c141.5688.1212.FFFF static [broadcast]
Serial0: IPX 1ABC.000.0c00.d8db maps to c111.1111.1111.1111 -- dynamic, TTL: 4 min
```

Table 1 describes the fields shown in the display.

Table 1 Show SMDS Map Field Descriptions

Field	Description
Serial0	Name of interface on which SMDS has been enabled.
ARP maps to	Higher-level protocol address that maps to this particular SMDS address.
e180.0999.9999.FFFF	SMDS address. Includes all SMDS addresses entered with either the smds static-map command (static) and smds multicast command (multicast).
172.30.21.112	IP address.
255.255.255.0	Subnet mask for the IP address.
static/dynamic	The address was obtained from a static map or dynamic map.
TTL	Time to live.

show smds traffic

Use the **show smds traffic** privileged EXEC command to display statistics on bad SMDS packets the access server has received.

show smds traffic

Syntax Description

This command has no arguments or keywords.

Command Mode

Privileged EXEC

Sample Display

The following is sample output from the **show smds traffic** command:

```
Router# show smds traffic
624363 Input packets
759695 Output packets
2 DXI heartbeat sent
0 DXI heartbeat received
0 DXI DSU polls received
0 DXI DSU polls sent
0 DXI invalid test frames
0 Bad BA size errors
0 Bad Header extension errors
65 Invalid address errors
1 Bad tag errors
```

Table 10-1 describes the fields shown in the display.

Table 10-1 Show SMDS Traffic Field Descriptions

Field	Description
0 Input packets	Number of input packets.
0 Output packets	Number of output packets.
0 DXI heartbeat sent	Number of DXI heartbeat polls transmitted.
0 DXI heartbeat received	Number of DXI heartbeat polls received.
0 DXI DSU polls sent	Number of DXI DSU polls sent.
0 DXI DSU polls received	Number of DXI DSU polls received.
0 DXI invalid test frames	Number of invalid test frames seen.
0 Bad BA size errors	Number of packets that have a size less than 32 bytes or greater than 9188 bytes.
0 DXI Header extension errors	Number of extended SIP L3 header errors.
0 DXI Invalid address errors	Number of address errors.

Field	Description
0 Bad tag errors	Status indicating the number of errors that occur when there is a mismatch between the BeTag values in the header and trailer of an SMDS frame. This usually indicates that there is a misconfiguration (that is, a DXI is connected to a non-DXI) or that the SDSU is scrambling the L2 PDUs.

smds address

Use the **smds address** interface configuration command to specify the SMDS individual address for a particular interface. Use the **no smds address** command to remove the address from the configuration file.

```
smds address smds-address  
no smds address smds-address
```

Syntax Description

<i>smds-address</i>	Individual address provided by the SMDS service provider. This address is protocol independent. For more information, see the “Usage Guidelines” section.
---------------------	---

Default

No address is specified.

Command Mode

Interface configuration

Usage Guidelines

All addresses for SMDS service are assigned by the service provider and can be assigned to individuals and groups.

Addresses are entered in the Cisco SMDS configuration software using an E prefix for Multicast addresses and a C prefix for Unicast addresses. Our software expects the addresses to be entered in E.164 format, which is 64 bits. The first 4 bits are the address type and the remaining 60 bits are the address. If the first 4 bits are 1100 (0xC), the address is a unicast SMDS address, which is the address of an individual SMDS host. If the first 4 bits are 1110 (0xE), the address is a multicast SMDS address, which is used when broadcasting a packet to multiple end points. The 60 bits of the address are in binary-coded decimal (BCD) format. Each 4 bits of the address field presents a single telephone number digit, allowing for up to 15 digits. At a minimum, you must specify at least 11 digits (44 bits). Unused bits at the end of this field are filled with ones.

Note If bridging is enabled on any interface, the SMDS address is erased and must be reentered.

Example

The following example specifies an individual address in Ethernet-style notation:

```
interface serial 0  
smds address c141.5797.1313.FFFF
```

smds dxi

Use the **smds dxi** interface configuration command to enable the DXI 3.2 support. Use the **no** form of the command to disable the DXI 3.2 support.

smds dxi
no smds dxi

Syntax Description

This command has no arguments or keywords.

Default

Enabled

Command Mode

Interface configuration

Usage Guidelines

Adding this command to the configuration enables the Data Exchange Interface (DXI) version 3.2 mechanism and encapsulates SMDS packets in a DXI frame before they are transmitted. DXI 3.2 adds an additional four bytes to the SMDS packet header to communicate with the SDSU. These bytes specify the frame type. The interface will expect all packets to arrive with DXI encapsulation.

The DXI 3.2 support also includes the heartbeat process as specified in the SIG-TS-001/1991 standard, revision 3.2. The heartbeat (active process) is enabled when both DXI and keepalives are enabled on the interface. The echo (passive process) is enabled when DXI is enabled on the interface. The heartbeat mechanism automatically generates a heartbeat poll frame every 10 seconds. This default value can be changed with the **keepalive** command. The Interim Local Management Interface (ILMI) is not supported.

Note If you are running serial lines back to back, disable keepalive on SMDS interfaces. Otherwise, DXI will declare the link down.

Note Switching in or out of DXI mode causes the IP cache to be cleared. This is necessary to remove all cached IP entries for the serial line being used. Stale entries must be removed to allow the new MAC header with or without DXI framing to be installed in the cache. This is not frequently done and is not considered to be a major performance penalty.

Fast switching of DXI frames is also supported as of this software release.

Example

The following example enables DXI 3.2 on HSSI interface 0:

```
interface hssi 0
encapsulation smds
smds dxi
smds address C120.1111.2222.FFFF
ip address 172.30.1.30 255.255.255.0
smds multicast ip E180.0999.9999
smds enable-arp
```

Related Command

A dagger (†) indicates that the command is documented in another chapter.

keepalive †

smds enable-arp

Use the **smds enable-arp** interface configuration command to enable the Address Resolution Protocol (ARP). The multicast address for ARP must be set before this command is issued. Once ARP has been enabled, use the **no** form of the command to disable the interface.

smds enable-arp
no smds enable-arp

Syntax Description

This command has no arguments or keywords.

Default

Disabled

Command Mode

Interface configuration

Example

The following example enables the dynamic ARP routing table:

```
interface serial 0
ip address 172.30.1.30 255.255.255.0
smds multicast IP E180.0999.9999.2222
smds enable-arp
```

Related Command

arp

smds glean

Use the **smds glean** interface configuration command to enable dynamic address mapping for IPX over SMDS. To disable dynamic address mapping for IPX over SMDS, use the **no** form of this command.

```
smds glean protocol [timeout value] [broadcast]  
no smds glean protocol
```

Syntax Description

<i>protocol</i>	Protocol type. Only IPX is supported.
<i>timeout value</i>	(Optional) Time to live value. Value can be 1 to 65535 minutes. The default is 5 minutes. This value indicates how long a gleaned dynamic map will be stored in the SMDS map table.
broadcast	(Optional) Marks the gleaned protocol address as a candidate for broadcast packets. All broadcast requests will be sent to the unicast SMDS address.

Default

Disabled

Command Mode

Interface configuration

Usage Guidelines

The **smds glean** command dynamically creates SMDS address to higher-level protocol address mappings from incoming packets. Therefore the need for static map configuration for the IPX protocol is optional rather than mandatory. However, any static map configuration will override the dynamic maps.

If a map is gleaned and it already exists as a dynamic map, the timer for the dynamic map is reset to the default value or the user specified value.

Example

The following example enables dynamic address mapping for IPX on interface serial 0 and set the time to live to 14 minutes:

```
interface serial 0  
encapsulation smds  
smds address c141.5797.1313.FFFF  
smds multicast ipx e1800.0999.9999.FFFF  
smds glean ipx 14
```

smds multicast

To assign a multicast SMDS E.164 address to a higher-level protocol, use the **smds multicast** interface configuration command. To remove an assigned multicast address, use the **no** form of the command with the appropriate address.

```
smds multicast protocol-type smds-address
no smds multicast protocol-type smds-address
```

Syntax Description

<i>protocol-type</i>	Protocol type. See Table 10-2 in the “Usage Guidelines” section for a list of supported protocols and their keywords.
<i>smds-address</i>	SMDS address. Because SMDS does not incorporate broadcast addressing, a group address for a particular protocol must be defined to serve the broadcast function.

Default

No mapping is defined.

Command Mode

Interface configuration

Usage Guidelines

Table 10-2 lists the high-level protocols supported by the **smds multicast** command.

Table 10-2 Supported Protocols

Keyword	Protocol
ip	IP
arp	ARP
novell	Novell IPX

Example

The following example maps the IP broadcast address to the SMDS group address E180.0999.9999:

```
interface serial 0
smds multicast IP E180.0999.9999.FFFF
```

smds multicast arp

Use the **smds multicast arp** interface configuration command to map the SMDS address to a multicast address. Use the **no** form of the command to disable this feature.

```
smds multicast arp smds-address [ip-address mask]  
no smds multicast arp smds-address [ip-address mask]
```

Syntax Description

<i>smds-address</i>	SMDS address in E.164 format
<i>ip-address</i>	(Optional) IP address
<i>mask</i>	(Optional) Subnet mask for the IP address

Default

Disabled

Command Mode

Interface configuration

Usage Guidelines

This command is only used when an ARP server is present on a network. When broadcast ARPs are sent, SMDS first attempts to send the packet to all multicast ARP SMDS addresses. If none exist in the configuration, they are sent to all multicast IP SMDS multicast addresses. If the optional ARP multicast address is missing, each entered IP multicast command will be used for broadcasting.

Example

The following example configures broadcast ARP messages:

```
interface serial 0  
smds multicast arp E180.0999.9999.2222
```

Related Command

smds multicast ip

smds multicast ip

Use the **smds multicast ip** interface configuration command to map an SMDS group address to a secondary IP address. Use the **no** form of the command to remove the address map.

```
smds multicast ip smds-address [ip-address mask]  
no smds multicast ip smds-address [ip-address mask]
```

Syntax Description

<i>smds-address</i>	SMDS address in E.164 format
<i>ip-address</i>	(Optional) IP address
<i>mask</i>	(Optional) Subnet mask for the IP address

Default

The IP address and mask will default to the primary address of the interface if they are left out of the configuration.

Command Mode

Interface configuration

Usage Guidelines

This command allows a single SMDS interface to be treated as multiple logical IP subnets (MultiLIS). If taking advantage of the MultiLIS support in SMDS, you can use more than one multicast address on the SMDS interface, that is, multiple commands can be entered. However, each **smds multicast ip** command entry must be associated with a different IP address on the SMDS interface.

Broadcasts can be sent on the SMDS interface using the multicast address. By sending broadcasts in this manner, the access server is not required to replicate broadcast messages to every remote host.

In addition, the higher-level protocols such as OSPF and IS-IS can use the multicast capability by sending one update packet or routing packet to the multicast address.

If the optional IP address and mask arguments are not present, the SMDS address and multicast address are associated with the primary IP address of the interface. This allows the command to be backward compatible with earlier versions of the software.

If an ARP multicast address is missing, each entered IP multicast command will be used for broadcasting. The ARP multicast command has the same format as the IP multicast command and is typically used only when an ARP server is present in the network.

Note All access servers at the other end of the SMDS cloud must have the MultiLIS capability enabled. A receiving access server must have the primary IP network address of the transmitter configured as a secondary IP network. This is required in order for replies to return. IP discards all packets with a destination address not equal to the primary network address on the SMDS interface.

Example

The following example configures an interface that supports two different subnets with different multicast addresses to each network. The first multicast configuration command associates the multicast address with the primary IP address and mask of the interface.

```
interface hssi 0
encapsulation smds
smds address C120.1111.2222.FFFF
ip address 172.30.1.30 255.255.255.0
ip address 172.30.5.30 255.255.255.0 secondary
smds multicast ip E180.0999.9999.FFFF
smds multicast ip E180.0333.3333.FFFF 172.30.5.0 255.255.255.0
smds enable-arp
```

Related Command

smds multicast arp

smds static-map

Use the **smds static-map** interface configuration command to configure a static map between an individual SMDS address and a higher-level protocol address. Use the **no** form of the command with the appropriate arguments to remove the map.

```
smds static-map protocol-type protocol-address smds-address [broadcast]
no smds static-map protocol-type protocol-address smds-address [broadcast]
```

Syntax Description

<i>protocol-type</i>	Protocol type. It can be one of the following values: ip or ipx .
<i>protocol-address</i>	Address of the higher-level protocol.
<i>smds-address</i>	SMDS address, to complete the mapping.
broadcast	(Optional) Marks the specified protocol address as a candidate for broadcast packets. All broadcast requests will be sent to the unicast SMDS address.

Default

No mapping is defined.

Command Mode

Interface configuration

Usage Guidelines

The **smds static-map** command provides pseudo-broadcasting by allowing the use of broadcasts on those hosts that cannot support SMDS multicast addresses.

Examples

The following example illustrates how to enable pseudo-broadcasting. In addition to broadcasting IP and ARP requests to E180.0999.9999, the device at address C120.4444.9999 will also receive a copy of the broadcast request. The host at address 131.108.1.15 is incapable of receiving multicast packets. Multicasting is simulated with this feature.

```
interface hssi 0
encapsulation smds
smds address C120.1111.2222.FFFF
ip address 172.30.1.30 255.255.255.0
smds static-map ip 172.30.1.15 C120.4444.9999.FFFF broadcast
smds enable-arp
```

The following example illustrates how to enable multicasting. In addition to IP and ARP requests to E180.0999.9999, the device at address C120.4444.9999 will also receive a copy of the multicast request. The host at address 131.108.1.15 is incapable of receiving broadcast packets.

```
interface hssi 0
encapsulation smds
smds address C120.1111.2222.FFFF
ip address 172.30.1.30 255.255.255.0
```

smds static-map

```
smds multicast ip E100.0999.999.FFFF  
smds static-map ip 172.30.1.15 C120.4444.9999.FFFF  
smds enable-arp
```