

# APPN Configuration Commands

---

This chapter describes the commands to configure and monitor the Advanced Peer-to-Peer Networking (APPN) feature. For APPN configuration tasks and examples, refer to the “Configuring APPN” chapter of the *Router Products Configuration Guide*.

Note: This chapter introduces seven new command modes:

- APPN class of service configuration
- APPN connection network configuration
- APPN control point configuration
- APPN link station configuration
- APPN mode configuration
- APPN partner LU location configuration
- APPN port configuration

## adjacent-cp-name

Use the **adjacent-cp-name** APPN link station configuration command to specify the name of the partner node for the link station. Use the **no** form of this command to delete the definition.

**adjacent-cp-name** *netid.cpname*  
**no adjacent-cp-name**

### Syntax Description

*netid.cpname* Fully qualified network name of the remote control point. A fully qualified name is a string of 1 to 8 characters, followed by a period, followed by a string of 1 to 8 characters. The following characters are acceptable:  
A - Z, a - z  
0 - 9  
\$ # @  
The first character of either string must not be a number.

### Default

The default state is **no adjacent-cp-name**.

### Command Mode

APPN link station configuration

### Usage Guidelines

If the name configured with this command does not match the remote node's CP name, the link will not come up. If the no form of the command is issued, or the command is not issued at all, no checking is done. This command must be specified if the adjacent node is LEN.

### Example

The following example defines a link station that specifies the name of the partner node:

```
appn link-station APPN1
port TR0
lan-dest-address 1000.C4C1.E5C5
adjacent-cp-name CISCO.APPN1
complete
```

### Related Commands

**appn link-station**  
**show appn link-station**

## appn class-of-service

Use the **appn class-of-service** global configuration command to define an APPN class of service that is not an IBM-supplied default. Use the **no** form of this command to delete the definition. This command begins the APPN class of service configuration command mode.

```
appn class-of-service cosname
no appn class-of-service cosname
```

### Syntax Description

<i>cosname</i>	Class of service name not among IBM default names. Class of service names must be a Type A character string. A Type A character string is a string of 1 to 8 of the following characters: A - Z, a - z 0 - 9 \$ # @
----------------	--

### Default

There is no default class of service name.

If this command is not issued, an IBM default class of service can be used. The IBM supplied default classes of service are #CONNECT, #BATCH, #INTER, #BATCHSC, #INTERSC, CPSVCMG, and SNASVCMG.

### Command Mode

Global configuration

### Usage Guidelines

Class of Service (COS) is a definition of the transport network characteristics that should be used to establish a particular session. The COS definition assigns relative values to factors such as acceptable levels of security, cost per byte, cost per connect-time, propagation delay, and effective capacity. APPN network nodes use COS to select the best session routes between LUs.

If one of the IBM default classes of service does not meet the needs of a particular network, the **appn class-of-service** global configuration command can be used to create a user defined definition.

### Example

The following example defines a COS with one node row and one tg row:

```
appn class-of-service #SECURE
node-row 1 weight 5 congestion no no route-additional-resistance 0 255
tg-row 1 weight 30 byte 0 255 time 0 255 capacity 0 255 delay 0 255 security 200 255 user1
0 255 user2 0 255 user3 0 255
complete
```

Related Commands

**node-row**

**show appn class-of-service**

**tg-row**

**transmission-priority**

## appn connection-network

Use the **appn connection-network** global configuration command to specify the fully qualified network name for the connection network. Use the **no** form of this command to delete the definition. This command begins the APPN connection network configuration command mode.

```
appn connection-network netid.cname  
no appn connection-network netid.cname
```

### Syntax Description

*netid.cname* Fully qualified network name for the connection network. *cname* is the name of the virtual network node in the connection network. A fully qualified name is a string of 1 to 8 characters, followed by a period, followed by a string of 1 to 8 characters. The following characters are acceptable:  
A - Z, a - z  
0 - 9  
\$ # @  
The first character of either string must not be a number.

### Default

No default connection network name is assigned.

### Command Mode

Global Configuration

### Usage Guidelines

The connection network name must be the same on all nodes that define the connection network, and must be different from any other connection network, LU, or control point in the total network.

### Example

The following example defines a connection network using APPN port TR0:

```
appn connection-network CISCO.CAPPN1  
port TR0  
complete
```

### Related Commands

**port (APPN connection network)**  
**show appn connection-network**

## appn control-point

Use the **appn control-point** global configuration command to specify the fully qualified control point name for the node. Use the **no** form of this command to delete the name and clear all APPN definitions. This command begins the APPN control point configuration command mode.

**appn control-point** *netid.cpname*  
**no appn control point** *netid.cpname*

### Syntax Description

*netid.cpname*

Fully qualified control point name for the local node. A fully qualified name is a string of 1 to 8 characters, followed by a period, followed by a string of 1 to 8 characters. The following characters are acceptable:  
A - Z, a - z  
0 - 9  
\$ # @  
The first character of either string must not be a number.

### Default

No default control point name is assigned.

### Command Mode

Global configuration

### Usage Guidelines

You must issue the appn control-point command to activate APPN routing. There can be only one control point definition in the system. The control point name must be unique in the network.

### Example

The following example defines a control point named CISCO.APPN1:

```
appn control-point CISCO.APPN1
complete
```

### Related Commands

**appn routing**  
**appn start**  
**appn stop**  
**backup-dlus (APPN control point)**  
**buffer-percent**  
**dlur**  
**dlus (APPN control point)**  
**interrupt-switched**  
**max-cached-entries**  
**max-cached-trees**  
**maximum-memory**

**route-additional-resistance**  
**safe-store-cycle**  
**safe-store-host**  
**safe-store-interval**  
**show appn node**  
**xid-block-number**  
**xid-id-number**

## appn link-station

Use the **appn link-station** global configuration command to assign the name of an adjacent link station. Use the **no** form of this command to delete the link station name. This command begins the APPN link station configuration command mode.

```
appn link-station linkname  
no appn link-station linkname
```

### Syntax Description

<i>linkname</i>	Name that identifies the link station. The name must be a Type A string. A Type A character string is a string of 1 to 8 of the following characters: A - Z, a - z 0 - 9 \$ # @
-----------------	---

### Default

No default link station name is assigned.

### Command Mode

Global configuration

### Usage Guidelines

A link represents a connection between a local link station and a link station in an adjacent node. The link can be considered a direct connection between two distinct Type 2.1 or Type 2.0 nodes. The link station provides a route over which local sessions or intermediate sessions can pass. Two link stations are required to build a link: one on each node.

A link station can be pre-defined with the **appn link-station** command, or dynamically defined. If you specify **service-any** in the associated **appn port** command, link-stations can be dynamically defined when a connect request is received. In this case, the **appn link-station** command would not be required. You must define an APPN link station if you intend this node to initiate the connection to the adjacent node.

### Example

The following example defines a link station using port TR0:

```
appn link-station CISCO1  
port TR0  
lan-destination-address 0200.0000.0001  
complete
```

### Related Commands

**adjacent-cp-name**  
**backup-dlus (APPN link station)**  
**connect-at-startup**

**cost-per-byte (APPN link station)**  
**cost-per-connect-time (APPN link station)**  
**cp-cp-sessions-supported**  
**dlur-dspu-name**  
**dplus (APPN link station)**  
**effective-capacity (APPN link station)**  
**fr-dest-address**  
**lan-dest-address**  
**limited-resource (APPN link station)**  
**link-queuing**  
**port (APPN link station)**  
**propagation-delay (APPN link station)**  
**pu-type-20**  
**retry-limit (APPN link station)**  
**role (APPN link station)**  
**sdlc-dest-address**  
**security (APPN link station)**  
**show appn link-station**  
**tg-number**  
**user-defined-1 (APPN link station)**  
**user-defined-2 (APPN link station)**  
**user-defined-3 (APPN link station)**  
**verify-adjacent-node-type**  
**x25-dest-address**

## appn mode

Use the **appn mode** global configuration command to specify a new mode or to change an IBM defined mode and identify the class of service associated with the mode name. Use the **no** form of this command to delete the previous definition. This command begins the APPN mode configuration command mode.

```
appn mode [modename]  
no appn mode [modename]
```

### Syntax Description

<i>modename</i>	Name of the mode. A Type A character string. A Type A character string is a string of 1 to 8 of the following characters: A - Z, a - z 0 - 9 \$ # @
-----------------	---

### Default

IBM defined [blank]

### Command Mode

Global configuration

### Usage Guidelines

The IBM defined modes are #BATCH, #BATCHSC, #INTER, #INTERSC, #CPSVCMG, #SNASVCMG, #CPSVRMG, and [blank]. These definitions can not be changed.

This command is required when LEN nodes are using this node for network services. The LEN node will issue a BIND containing this mode name; this command will be used to associate the mode name with a COS name.

### Example

The following example changes the IBM defined mode #BATCH to use the #CONNECT class of service:

```
appn mode #BATCH  
class-of-service #CONNECT  
complete
```

### Related Commands

**class-of-service**  
**show appn mode**

## appn partner-lu-location

Use the **appn partner-lu-location** global configuration command to specify an LU that would be the destination LU for an LU-LU session request from an LU using this node for network services. Use the **no** form of this command to delete the previous definition. This command begins the APPN partner LU configuration command mode.

```
appn partner-lu-location netid.luname
no appn partner-lu-location netid.luname
```

### Syntax Description

*NETID.LUNAME* Fully qualified name of the partner LU.  
 A fully qualified name is a string of 1 to 8 characters, followed by a period, followed by a string of 1 to 8 characters. The following characters are acceptable:  
 A - Z, a - z  
 0 - 9  
 \$ # @  
 The first character of either string must not be a number.

### Default

No default *NETID.LUNAME* is specified. You must supply a value; otherwise the configuration will fail.

### Command Mode

Global configuration

### Usage Guidelines

Use this command to define an entry in the directory database. This command improves network performance by allowing directed LOCATE (because the partner name is known), instead of a broadcast. The disadvantage is that definitions must be created. Alternatively, partner names can be discovered dynamically and added to the database as they are learned. This process, however, requires either prior sessions to the node or broadcast traffic (which causes additional network traffic) sent to locate the node.

### Example

The following example defines the location of an LU named CISCO.LU21:

```
appn partner-lu-location CISCO.LU21
owning-cp CISCO.CP2
complete
```

### Related Commands

```
owning-cp
serving-nn
show appn directory
wildcard
```

## appn port

Use the **appn port** global configuration command to define an APPN port and relate it to a previously defined interface.

```
appn port portname {type number | rsrb}  
no appn port portname
```

### Syntax Description

<i>portname</i>	Port name to be associated with the interface.
<i>type number</i>	Previously defined interface type and number with which the port name is to be associated.
<b>rsrb</b>	Specify <b>rsrb</b> instead of an interface if this port will utilize RSRB as a transport protocol.

### Default

No default port name is specified. No default interface is provide. Both must be provided or the configuration will fail.

### Command Mode

Global configuration

### Usage Guidelines

At least one APPN port must be defined for each interface that will participate in APPN routing. If more than one service access point (SAP) will be used over a particular port, then a port must be defined for each SAP.

### Example

The following example associates an APPN port named FDDI0 with FDDI interface 0:

```
appn port FDDI0 fddio  
complete
```

### Related Commands

A dagger (†) indicates that the command is documented in another chapter.

**appn start port**  
**appn stop port**  
**cost-per-byte (APPN port)**  
**cost-per-connect-time (APPN port)**  
**desired-max-send-btu-size**  
**effective-capacity (APPN port)**  
**interface** †  
**limited-resource (APPN port)**  
**local-sap**  
**max-link-stations**

**max-rcv-btu-size**  
**propagation-delay (APPN port)**  
**reserved-inbound**  
**reserved-outbound**  
**retry-limit (APPN port)**  
**role (APPN port)**  
**rsrb-virtual-station**  
**security (APPN port)**  
**service-any**  
**sdlc-sec-addr**  
**show appn port**  
**user-defined-1 (APPN port)**  
**user-defined-2 (APPN port)**  
**user-defined-3 (APPN port)**  
**x25-subaddress**

## appn routing

Use the **appn routing** global configuration command to indicate that APPN routing should be activated. Use the **no** form to deactivate APPN routing.

**appn routing**  
**no appn routing**

### Syntax Description

This command has no arguments or keywords.

### Default

The default state is **no appn routing**.

### Command Mode

Global configuration

### Usage Guidelines

For **appn routing** to complete successfully, an APPN control point must be configured using the **appn control-point** global configuration command.

### Example

The following example specifies that APPN routing should be started:

```
appn routing
```

### Related Commands

**appn control-point**  
**appn start**  
**appn stop**

## appn start

Use the **appn start** EXEC command to activate the APPN subsystem in this node.

**appn start**

### Syntax Description

This command has no arguments or keywords.

### Default

This command has no default state.

### Command Mode

EXEC

### Example

The following example activates APPN:

```
appn start
```

### Related Commands

**appn stop**

**appn routing**

## appn start link-station

Use **appn start link-station** to activate a logical APPN link.

**appn start link-station** *linkname*

### Syntax Description

<i>linkname</i>	The name of the link-station. Must be a Type A character string. A Type A character string is a string of 1 to 8 of the following characters: A - Z, a - z 0 - 9 \$ # @
-----------------	---

### Default

No default is provided for *linkname*.

### Command Mode

EXEC

### Example

The following example activates an APPN link station:

```
appn start link-station TR0
```

### Related Commands

**appn link-station**  
**appn stop link-station**  
**show appn link-station**

---

## appn start port

Use the **appn start port EXEC** command to activate APPN routing over a particular port.

**appn start port** *portname*

### Syntax Description

<i>portname</i>	The name of the port. Must be a Type A character string. A Type A character string is a string of 1 to 8 of the following characters: A - Z, a - z 0 - 9 \$ # @
-----------------	---

### Default

No default is provided for *portname*.

### Command Mode

EXEC

### Usage Guidelines

This command is also used when the APPN subsystem is already started and a port is added or a characteristic is changed by subcommand.

### Example

The following example activates APPN routing over port TR0:

```
appn start port TR0
```

### Related Commands

**appn port**  
**appn stop port**  
**show appn port**

## appn stop

This command will deactivate APPN routing without affecting the current configuration.

### **appn stop**

#### Syntax Description

This command has no arguments or keywords.

#### Default

This command has no default state.

#### Command Mode

EXEC

#### Example

The following command deactivates APPN routing:

```
appn stop
```

#### Related Commands

**appn control-point**

**appn routing**

**appn start**

## appn stop link-station

Use the **appn stop link-station** EXEC command to deactivate an APPN connection between the local node and an adjacent node.

**appn stop link-station** *linkname*

### Syntax Description

<i>linkname</i>	The name of the link station. The name must be a Type A character string. A Type A character string is a string of 1 to 8 of the following characters: A - Z, a - z 0 - 9 \$ # @
-----------------	--

### Default

There is no default provided for *linkname*.

### Command Mode

EXEC

### Example

The following command deactivates an APPN link between the local node and an adjacent node:

```
appn stop link-station APPN1
```

### Related Commands

**appn link-station**

**appn start link-station**

## appn stop port

Use **appn stop port** to deactivate APPN routing over a specified port.

**appn stop port** *portname*

### Syntax Description

<i>portname</i>	The name of the port. Must be a Type A character string A Type A character string is a string of 1 to 8 of the following characters: A - Z, a - z 0 - 9 \$ # @.
-----------------	---

### Default

No default is provided for *portname*.

### Command Mode

EXEC

### Usage Guidelines

For a port deactivation to be successful, no APPN link station can be active on that port.

### Example

The following example deactivates APPN routing over port TR0:

```
appn stop port TR0
```

### Related Commands

**appn port**

**appn start port**

## backup-dlus (APPN control point)

Use the **backup dlus** APPN control point configuration command to specify the name of the default backup DLUS, which performs SSCP services for downstream PUs if the default DLUS is unable to provide the services. Use the **no** form of this command to delete the definition.

```
backup-dlus NETID.CPNAME  
no backup-dlus
```

### Syntax Description

*NETID.CPNAME*

Fully qualified network name.

A fully qualified name is a string of 1 to 8 characters, followed by a period, followed by a string of 1 to 8 characters. The following characters are acceptable:

A - Z, a - z

0 - 9

\$ # @

The first character of either string must not be a number.

### Default

This default state is **no backup-dlus**.

### Command Mode

APPN control point configuration

### Usage Guidelines

You must specify **dlur** and **dlus (control-point)** before you can specify **backup-dlus**. You can use the **backup-dlus** link station configuration command to override this command for a particular link station.

### Example

The following example defines an APPN control point with a backup DLUS:

```
appn control-point CISCO.ROUTER  
dlur  
dlus CISCO.APPN1  
backup-dlus CISCO.APPN2  
complete
```

### Related Commands

**appn control-point**

**backup-dlus (APPN link station)**

**backup-dlus (APPN control point)**

## backup-dlus (APPN link station)

Use the **backup-dlus** APPN link station configuration command to specify the default backup DLUS node that provides SSCP services to the downstream PUs of the link in the event that the DLUS is unable to provide the DLUR function. Use the **no** form of this command to delete the definition.

**backup-dlus** *NETID.CPNAME*  
**no backup-dlus**

### Syntax Description

*NETID.CPNAME* Fully qualified network name.  
A fully qualified name is a string of 1 to 8 characters, followed by a period, followed by a string of 1 to 8 characters. The following characters are acceptable:  
A - Z, a - z  
0 - 9  
\$ # @  
The first character of either string must not be a number.

### Default

The default state is **no backup-dlus**.

### Command Mode

APPN link station configuration

### Usage Guidelines

You must specify the **dlur** and **dlus** APPN control point commands before you can specify **backup-dlus**. You can use the **backup-dlus** link station configuration command on the link station to override this command for that particular link station.

### Example

The following example specifies the backup DLUS node for a link station:

```
appn link-station CISCO.HOST
port FDDI0
lan-dest-address 0200.0000.1234
dlus CISCO.APPN1
backup-dlus CISCO.APPN3
complete
```

### Related Commands

**appn link-station**  
**backup-dlus (APPN control point)**  
**dlus (APPN control point)**  
**dlus (APPN link station)**

## buffer-percent

Use the **buffer-percent** APPN control point configuration command to specify the percent of buffers that are reserved for use by APPN. Use the **no** form of this command to cancel the buffer reservation.

**buffer-percent** *number*  
**no buffer-percent**

### Syntax Description

*number* The maximum percentage of I/O memory that APPN is allowed to allocate for buffers. The valid range is 1 to 100 percent.

### Default

The default is 100 percent.

### Command Mode

APPN control point configuration

### Usage Guidelines

Use the **buffer-percent** command to ensure that APPN will not monopolize the router's buffers. If other protocols are to be routed through the local node, this command can be utilized to reserve buffers for protocols other than APPN.

### Example

The following example limits APPN's buffer usage to 25% of the router's buffers:

```
appn control-point CISCO.ROUTER
buffer-percent 25
complete
```

### Related Commands

A dagger (†) indicates that the command is documented in another chapter.

**appn control-point**  
**show buffers** †  
**show memory** †

## class-of-service

Use the **class-of-service** APPN mode configuration command to specify the class of service that maps to a particular mode name. Use the **no** form of this command to delete the definition.

**class-of-service** *cosname*  
**no class-of-service**

### Syntax Description

*cosname*                      The name of the class of service. Must be a Type A character string.  
A Type A character string is a string of 1 to 8 of the following characters:  
A - Z, a - z  
0 - 9  
\$ # @

### Default

The default class-of-service name is #CONNECT.

### Command Mode

APPN mode configuration

### Usage Guidelines

LEN nodes use this node for network services. The mode name is passed in the BIND and this command is used to correlate the mode name to a class-of-service name.

### Example

The following example defines a mode with class of service #INTER:

```
appn mode MAPPN1
class-of-service #INTER
complete
```

### Related Command

**appn mode**

## connect-at-startup

Use the **connect-at-startup** APPN link station configuration command to specify that the link will call out to the partner and attempt to bring up the link when the link's definition is complete. Use the **no** form of this command to delete the definition.

**connect-at-startup**  
**no connect-at-startup**

### Syntax Description

This command has no arguments or keywords.

### Default

The default state is **connect-at-startup**.

### Command Mode

APPN link station configuration

### Usage Guidelines

### Example

The following example deactivates call out for APPN link station ETHER12:

```
appn link-station ETHER12
appn port ETHER1
lan-dest-address 0200.0000.4321
no connect-at-startup
complete
```

### Related Command

**appn link-station**









## cp-cp-sessions-supported

Use the **cp-cp-sessions-supported** APPN link station configuration command to specify that a CP - CP session can be established over this connection. Use the **no** form of this command to specify that a CP - CP session can not be established over this link.

**cp-cp-sessions-supported**  
**no cp-cp-sessions-supported**

### Syntax Description

This command has no arguments or keywords.

### Default

CP - CP sessions are supported.

### Command Mode

APPN link station configuration

### Usage Guidelines

The **no** form of this command must be specified for a link to a LEN node.

CP sessions to additional NNs are optional. Having fewer CP - CP sessions reduces the number of topology update messages and memory required, while increasing convergence time (the time required to update all network nodes).

### Example

The following example specifies that no CP - CP sessions are supported:

```
appn link-station FDDI41
port FDDI1
lan-dest-address 0400.0000.2323
no cp-cp-sessions-supported
complete
```

### Related Commands

**appn link-station**  
**show appn link-station**  
**verify-adjacent-node-type**



## dlur

Use the **dlur** APPN control point configuration command to specify that the Dependent LU Requestor (DLUR) function is supported on this CP. Use the **no** form of this command to delete the definition.

**dlur**  
**no dlur**

### Syntax Description

This command has no arguments or keywords.

### Default

DLUR is not specified.

### Command Mode

APPN control point configuration

### Example

The following example specifies the DLUR function on the CP:

```
appn control-point CISCO.ROUTER
dlur
dlus CISCO.HOST
complete
```

### Related Commands

**appn control-point**  
**dlus (APPN control point)**  
**show appn dlur-lu**  
**show appn dlur-pu**  
**show appn dlus**

## dlur-dspu-name

Use the **dlur-dspu-name** APPN link station configuration command to specify the name of the downstream PU connected by this link. Use the **no** form of this command to delete the definition.

**dlur-dspu-name** *puname*  
**no dlur-dspu-name**

### Syntax Description

*puname* Type A character string.  
A Type A character string is a string of 1 to 8 of the following characters:  
A - Z, a - z  
0 - 9  
\$ # @

### Default

No default name is specified.

### Command Mode

APPN link station configuration

### Usage Guidelines

The DLUR function requires the specification of the DSPU name for a PU2.0 node. Specification is also required when the DLUR function must activate the link to a PU2.1 or PU2.0 node, when driven by a host-initiated PU activation, and when the link to the PU is not active.

### Example

The following example specifies the DSPU name of a downstream node:

```
appn link-station LINK4
port TR1
lan-dest-address 1000.2020.0211
dlur-dspu-name PU003334
pu-type-20
complete
```

### Related Commands

**appn link-station**  
**dlur**  
**dlus (APPN link station)**

## dlus (APPN control point)

Use the **dlus** APPN control point configuration command to specify the name of the default Dependent LU Server (DLUS) that provides SSCP services to the downstream PUs. Use the **no** form of this command to delete the definition.

**dlus** *netid.cpname*  
**no dlus**

### Syntax Description

*netid.cpname*

Fully qualified CP name.

A fully qualified name is a string of 1 to 8 characters, followed by a period, followed by a string of 1 to 8 characters. The following characters are acceptable:

A - Z, a - z

0 - 9

\$ # @

The first character of either string must not be a number

### Default

No default DLUS is defined.

### Command Mode

APPN control point configuration

### Usage Guidelines

**dlur** must be specified in the CP command if **dlus** is specified. The name of the node-default DLUS should be specified when supporting downstream PUs that request or require ACTPUs, DLUR does not currently have an active session with the DLUS, and when no DLUS or back-up DLUS name has been provided on the APPN link station definition.

### Example

The following example defines the DLUS:

```
appn control-point CISCO.ROUTER1
dlur
dlus CISCO.APPN1
complete
```

### Related Commands

**appn control-point**

**dlur**

**dlus (APPN link station)**

**show appn dlur-lu**

## dlus (APPN link station)

Use the **dlus** APPN link station configuration command to specify the name of the default Dependent LU Server (DLUS) node that provides SSCP services to the downstream PUs of this link station. Use the **no** form of this command to delete the definition.

```
dlus netid.cpname  
no dlus
```

### Syntax Description

*netid.cpname*

Fully qualified CP name.

A fully qualified name is a string of 1 to 8 characters, followed by a period, followed by a string of 1 to 8 characters. The following characters are acceptable:

A - Z, a - z

0 - 9

\$ # @

The first character of either string must not be a number

### Default

The default state is **no dlus**.

### Command Mode

APPN link station configuration

### Usage Guidelines

The **dlus** command is used to override the value of **dlus** specified in the control point definition.

### Example

The following example specifies the DLUS for a specific APPN link station:

```
appn link-station LINK5  
port TR1  
lan-dest-address 0200.0000.5678  
dlus CISCO.APPN1  
complete
```

### Related Commands

**appn control-point**

**dlur**

**dlus (APPN control point)**

**show appn dlus**



## effective-capacity (APPN port)

Use the **effective-capacity** APPN port configuration command to specify the effective capacity of a link. Use the **no** form of this command to delete the definition.

**effective-capacity** *capacity*  
**no effective-capacity**

### Syntax Description

*capacity*                      Number in the range 0 to 100000000 specifying bits per second (bps).

### Default

The default is media dependent:

Ethernet	10,000,000 bps
FDDI	100,000,000 bps
Frame Relay	56,000 bps
QLLC	56,000 bps
RSRB	56,000 bps
SDLC	56,000 bps
Token Ring	16,000,000 bps

### Command Mode

APPN port configuration

### Usage Guidelines

Specifying this command at the port level identifies the capacity for all link stations accessed through this port. Specifying this command on the link station command overrides the port value. This command also specifies the value for dynamically created transmission groups. The cost is used in route selection for a particular class of service.

### Example

The following example defines the effective capacity:

```
appn port FR0 Serial1/1
effective-capacity 2000000
complete
```

### Related Commands

**appn port**  
**effective-capacity (APPN link station)**  
**show appn port**

## fr-dest-address

Use the **fr-dest-address** APPN link station configuration command to specify the address of the partner node for Frame Relay links. Use the **no** form of this command to delete the definition.

**fr-dest-address** *dci* [*sap*]  
**no fr-dest-address**

### Syntax Description

<i>dci</i>	Number in the range 16 to 1007 that represents the DLCI, or virtual circuit, for a Frame Relay connection.
<i>sap</i>	1-byte hexadecimal number in the range 04 to ec, and divisible by 4.

### Default

No default DLCI is provided.  
The default SAP is 04 (hexadecimal)

### Command Mode

APPN link station configuration

### Usage Guidelines

The command should be specified only if the APPN port used by the link station is a Frame Relay port.

### Example

The following example specifies DLCI 100:

```
appn link-station FRLNK100
port FR0
fr-dest-address 100
complete
```

### Related Commands

**appn link-station**  
**lan-dest-address**  
**sdhc-dest-address**  
**show appn link-station**

## interrupt-switched

Use the interrupt-switched APPN control point configuration command to specify that ISR should be processed at the interrupt level.

**interrupt-switched**  
**no interrupt-switched**

### Syntax Description

This command has no arguments or keywords.

### Default

The default state is **no interrupt-switched**.

### Command Mode

APPN control point

### Usage Guidelines

This command improves the performance of ISR routing. The command can be used only if segment size is the same on all nodes in the message path. Re-segmenting cannot be accomplished at the interrupt level. In addition, this command should only be used when routing between interfaces with similar speeds. This is because no pacing is done in the node when **interrupt-switched** is specified.

### Example

The following example specifies that ISR should be processed at the interrupt level:

```
appn control-point CISCO.APPN1
interrupt-switched
complete
```

### Related Commands

**appn control-point**  
**show appn intermediate-session**

## lan-dest-address

Use the **lan-dest-address** APPN link station configuration command to specify the MAC address of the partner node. Use the **no** form of this command to delete the definition.

```
lan-dest-address lan-addr [sap]  
no lan-dest-address
```

### Syntax Description

<i>lan-addr</i>	12-byte hexadecimal number in the form xxxx.xxxx.xxxx
<i>sap</i>	1-byte hexadecimal number in the range 04 to ec, and divisible by 4.

### Defaults

No default lan-addr is specified.

The default SAP is 04 (hexadecimal).

### Command Mode

APPN link station configuration

### Usage Guidelines

This command is required for interface types Token Ring, Ethernet, or FDDI. It is not allowed for other interface types.

### Example

The following example sets the MAC address and SAP for a link to a partner node:

```
appn link-station LINK0001  
port ETHER1  
lan-dest-address 1234.cfe0.9745 08  
complete
```

### Related Commands

```
appn link-station  
fr-dest-address  
sdhc-dest-address  
show appn link-station
```

## limited-resource (APPN link station)

Use the **limited-resource** APPN link station configuration command to specify that the connection is to be taken down when no sessions are using it. Use the **no** form of this command to specify that the connection will remain active when no sessions are using it.

**limited-resource**  
**no limited-resource**

### Syntax Description

This command has no arguments or keywords.

### Default

The value specified in the **appn port** command.

### Command Mode

APPN link station configuration

### Usage Guidelines

This command identifies a link that has a higher cost or is a switched connection and should not remain active if no resource is using the link. The **limited-resource** command issued at the APPN link station level overrides the same command issued at the APPN port level.

### Example

The following example specifies that the link be taken down when no sessions are active:

```
appn link-station FRLINK34
port FR1
fr-dest-address 34
limited-resource
complete
```

### Related Commands

**appn link-station**  
**limited-resource (APPN port)**  
**show appn link-station**

## limited-resource (APPN port)

Use the **limited-resource** APPN link station configuration command to specify that the link is to be taken down when no sessions are using the link. Use the **no** form of this command to specify that the link will remain active when no sessions are using the link.

**limited resource**  
**no limited resource**

### Syntax Description

This command has no arguments or keywords.

### Default

The default is no limited resource.

### Command Mode

APPN port configuration

### Usage Guidelines

This command identifies a link that has a higher cost or is a switched connection and should not remain active if no resource is using the link. This command applies to all link stations accessed through this port. Specifying limited resource at the link station level overrides this command.

### Example

The following example activate limited resource:

```
appn port FR0 Serial0/2
limited-resource
complete
```

### Related Commands

**appn port**  
**limited-resource (APPN link station)**  
**show appn port**

## link-queuing

Use the **link-queuing** command to specify queuing options and parameters for the link station. Use the **no** form of the command to cancel the option.

```
link-queuing {priority [high | medium | normal | low] | custom queue-number}  
no link-queuing
```

### Syntax Description

<b>priority</b> [ <b>high</b>   <b>medium</b>   <b>normal</b>   <b>low</b> ]	Priority level.
<i>queue-number</i>	Priority number used to specify custom queuing for the link station.

### Default

No default priority number is assigned.

### Command Mode

APPN link station configuration

### Example

The following example specifies medium priority level queuing for the link station:

```
link-queuing medium
```

### Related Command

**show appn link-station**

## local-sap

Use the **local-sap** APPN port configuration command to specify the local SAP to activate on the interface. Use the **no** form of this command to delete the definition.

**local-sap** *sap*  
**no local-sap**

### Syntax Description

*sap* Hexadecimal number in the range 04 to ec, and divisible by 4.

### Default

The default local SAP (service access point) is 0x04.

### Command Mode

APPN port configuration.

### Example

The following example specifies the local SAP:

```
appn port TR0 TokenRing0
local-sap 44
complete
```

### Related Commands

**appn port**  
**show appn port**

## max-cached-entries

Use the **max-cached-entries** APPN control point configuration command to specify the maximum number of cached directory entries. Use the **no** form of this command to delete the definition.

**max-cached-entries** *number*  
**no max-cached-entries**

### Syntax Description

*number* The maximum number of cached directory entries. The valid range is 0 to 32767.

### Default

255 cached directory entries

### Command Mode

APPN control point configuration

### Usage Guidelines

This command enables you to balance memory usage and performance. A large number requires more memory, but reduces the number of network broadcasts. Cached directory entries are created as nodes learn locations of other network resources. This command affects cached entries only. A value of zero still allows location of node, but broadcasts are required.

### Example

The following example specifies the maximum number of cached directory entries:

```
appn control-point CISCO.ROUTER
max-cached-entries 100
complete
```

### Related Commands

**appn control-point**  
**show appn node**

## max-cached-trees

Use the **max-cached-trees** APPN control point configuration command to specify the maximum number of cached class of service routing trees. Use the **no** form of this command to delete the definition.

**max-cached-trees** *number*  
**no max-cached-trees**

### Syntax Description

*number* Maximum number of cached class of service routing trees.  
The valid range is 0 to 32767.

### Default

20 trees

### Command Mode

APPN control point configuration

### Usage Guidelines

This command allows you to balance memory usage and performance. Each cached tree represents all paths through the network for a class of service. If you specify a lower number, fewer will be caches and longer processing time may be required to calculate the paths through the network and select a route.

### Example

The following example specifies the maximum number of cached topology trees:

```
appn control-point CISCO.ROUTER
max-cached-trees 5
complete
```

### Related Commands

**appn control-point**  
**show appn node**

## minimum-memory

Use the **minimum-memory** APPN control point configuration command to specify the minimum amount of memory available to APPN. Use the **no** form of the command to cancel the specification.

**minimum-memory** *memory*  
**no minimum-memory**

### Syntax Description

*memory* The maximum amount of memory (in bytes) available to APPN. The valid range is 1,000,000 to 64,000,000

### Default

The default is 1,000,000 bytes.

### Command Mode

APPN control point configuration

### Usage Guidelines

This command ensures that APPN will always have a specified amount of memory. Memory that is dedicated to APPN will not be available for other processing.

### Example

The following example reserves 10,000,000 bytes of memory for APPN

```
appn control-point CISCO.APPN1
minimum-memory 10000000
complete
```

### Related Commands

**appn control-point**  
**maximum-memory**





## max-rcv-btu-size

Use the **max-rcv-btu-size** APPN port configuration command to specify the desired maximum receive BTU. Use the **no** form of this command to delete the definition.

**max-rcv-btu-size** *size*  
**no max-rcv-btu-size**

### Syntax Description

*size* Maximum receive BTU (in bytes), in the range 99 to 5107.  
The default is 1024 bytes.

### Default

1024 bytes

### Command Mode

APPN port configuration

### Usage Guidelines

The Basic Transmission Unit (BTU) specifies a maximum message size at the physical layer, similar to the Maximum Transmission Unit (MTU) in TCP/IP. Don't confuse BTU with MAXRU, which is session related.

### Example

The following example sets the maximum BTU value:

```
appn port TR11 TokenRing1/1
max-rcv-btu-size 500
complete
```

### Related Commands

**appn port**  
**show appn port**

## node-row

Use the **node-row** APPN class-of service configuration command to specify a node description or node row, and associated weights defined for this class of service. Use the **no** form of this command to delete a previous node row description.

```
node-row index weight weight congestion [yes | no] [yes | no] route-additional-resistance min
max
no node-row index
```

### Syntax Description

<i>index</i>	Specifies which row is being entered. The valid range is 1 to 8.
<b>weight</b> <i>weight</i>	Weight assigned to a node, given the characteristics identified in the remainder of the row. The weight of row n must be less than the weight of row n+1. The valid range is 0 to 255.
<b>congestion</b> [ <b>yes</b>   <b>no</b> ] [ <b>yes</b>   <b>no</b> ]	Congestion tolerance.
<b>yes</b> <b>yes</b>	Only yes. Only congested transmission groups match this row.
<b>no</b> <b>yes</b>	Yes or no. Congestion does not affect class of service row.
<b>no</b> <b>no</b>	Only no. Only non-congested transmission groups match this row. The default is no no.
<b>route-additional-resistance</b> <i>min max</i>	The minimum and maximum router additional resistance value for the row. The value is compared to the same parameter defined in the CP for each network node and exchanged on the topology database updates. The valid range for minimum and maximum is 0 to 255. The default range for minimum and maximum is 0 and 0.

### Default

No default node row is specified.

No default weight is specified.

The default congestion tolerance is no no.

The default route additional resistance is 0 0.

### Command Mode

APPN class of service configuration

### Usage Guidelines

You can define up to 8 rows. Each row represents the characteristics of a node that meets the requirements for this class of service and defines a weight for the node that will be used in calculating the cost of a total route.

### Example

The following example defines the an APPN class of service with one node row:

```
appn class-of-service #SECURE
node-row 1 weight 5 congestion no no route-additional-resistance 0 255
tg-row 1 weight 30 byte 0 255 time 0 255 capacity 0 255 delay 0 255 security 200 255 user1
0 255 user2 0 255 user3 0 255
complete
```

### Related Commands

- appn class-of-service**
- show appn class-of-service**

## null-xid-poll

Use the **null-xid-poll** APPN port configuration command to specify that the null XID should be used to poll the remote node associated with this APPN port. Use the **no** form of the command to cancel the specification.

**null-xid-poll**  
**no null-xid-poll**

### Syntax Description

This command has no arguments or keywords.

### Default

XID3 negotiation is used to poll remote devices.

### Command Mode

APPN port configuration

### Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

The **null-xid-poll** command permits PU 2.0 devices that connect in with XID0 to build a dynamic link station. It is no longer necessary to configure a link definition. When this command is used, the router expects its partner to reveal its identity first by responding with either XID3 or XID0.

This feature works in a mixed environment of PU 2.0 and PU 2.1 devices where the same APPN port is shared by both types of devices. By default, XID3 is used to poll the devices. When a PU 2.0 device responds with XID0, the link is created and established dynamically. PU 2.1 devices are not affected by this change, and go through the XID3 negotiation as usual.

Some care must be exercised when configuring **null-xid-poll**: If two Cisco APPN network node routers connect across ports configured with **null-xid-poll**, the APPN connection will fail because both routers expect the other to respond first using either XID0 or XID3. Similar behavior may occur when a port configured with **null-xid-poll** attempts communication with a front-end processor configured for XID polling. You only need to configure **null-xid-poll** when dealing with a PU 2.0 device that does not respond gracefully to the XID3 poll.

### Example

The following example specifies that null XID should be used to poll the remote nodes associated with the APPN port FDDI0.

```
appn port FDDI0 fddi 0
null-xid-poll
complete
```

### Related Command

**appn port**

## owning-cp

Use the **owning-cp** APPN partner-lu-location configuration command to specify the name of the CP owning the partner LU. Use the **no** form of this command to delete the definition.

**owning-cp** *netid.cpname*  
**no owning-cp**

### Syntax Description

*netid.cpname*

Fully qualified network name.

A fully qualified name is a string of 1 to 8 characters, followed by a period, followed by a string of 1 to 8 characters. The following characters are acceptable:

A - Z, a - z

0 - 9

\$ # @

The first character of either string must not be a number

### Default

No default name is assigned.

### Command Mode

APPN partner LU location configuration

### Usage Guidelines

The NETID.CPNAME must be unique in the network and must match the name specified as control point on the specific node.

### Example

The following command sets the owning CP name:

```
appn partner-lu-location CISCO.LU000012
owning-cp CISCO.CP00001
complete
```

### Related Commands

**appn partner-lu-location**  
**show appn directory**

## port (APPN connection network)

Use the **port** APPN connection network configuration command to specify the ports that have visibility to the connection network. Use the **no port** form of this command to delete the definition.

**port** *portname*  
**no port** *portname*

### Syntax Description

*portname*                      Type A name.  
A Type A character string is a string of 1 to 8 of the following characters:  
A - Z, a - z  
0 - 9  
\$ # @

### Default

No default port name is assigned.

### Command Mode

APPN connection network configuration

### Usage Guidelines

Up to 5 ports can be specified by repeating the command. portnames must be previously defined by the **appn port** command.

### Example

The following example specifies an APPN connection network with one port.

```
appn connection-network CISCO.CN1
port TR0
complete
```

### Related Commands

**appn connection-network**  
**appn port**  
**show appn connection-network**

## port (APPN link station)

Use the **port** APPN link station configuration command to specify the port that can be used to access the link station. Use the **no** form of this command to delete the definition.

**port** *portname*  
**no port**

### Syntax Description

<i>portname</i>	Required when defining a new link station; optional on subsequent changes to the link station. Type A name. A Type A character string is a string of 1 to 8 of the following characters: A - Z, a - z 0 - 9 \$ # @
-----------------	---

### Default

No default port is specified.

### Command Mode

APPN link station configuration

### Usage Guidelines

PORTNAME must be a value defined in a previous **appn port** command. The **port** command is required to define an APPN link station.

### Example

The following example defines the port:

```
appn link-station FDDILINK
port FDDI0
lan-dest-address 0200.0000.cfbf
complete
```

### Related Commands

**appn link-station**  
**appn port**  
**show appn link-station**

## propagation-delay (APPN link station)

Use the **propagation-delay** APPN link station configuration command to specify the amount of inherent delay of the connection. Use the **no** form of this command to delete the definition.

```
propagation-delay { minimum | lan | telephone | packet-switched | satellite | maximum }  
no propagation-delay
```

### Syntax Description

<b>minimum</b>	No delay.
<b>lan</b>	Less than 480 microseconds delay.
<b>telephone</b>	Between 480 and 49152 microseconds delay.
<b>packet-switched</b>	Between 49152 and 245760 microseconds delay.
<b>satellite</b>	Over 245760 microseconds delay.
<b>maximum</b>	Maximum delay allowed.

### Default

The value specified in the **appn port** command.

### Command Mode

APPN link station configuration

### Usage Guidelines

The inherent delay is used in route selection by comparing this to the value requested for a particular class of service. This value supersedes any value specified on the **appn port** command. Propagation delay is used by the node to determine the least cost route for APPN intermediate sessions.

### Example

The following example specifies a delay of less than 480 microseconds:

```
appn link-station FRLINK12  
port FR1  
propagation-delay lan  
complete
```

### Related Commands

**appn link-station**  
**show appn link-station**

## propagation-delay (APPN port)

Use the **propagation-delay** APPN port configuration command to specify the propagation delay of the link. Use the **no** form of this command to delete the definition.

```
propagation-delay { minimum | lan | telephone | packet-switched | satellite | maximum }  
no propagation-delay
```

### Syntax Description

<b>minimum</b>	No delay.
<b>lan</b>	Less than 480 microseconds delay.
<b>telephone</b>	Between 480 and 49152 microseconds delay.
<b>packet-switched</b>	Between 49152 and 245760 microseconds delay.
<b>satellite</b>	Over 245760 microseconds delay.
<b>maximum</b>	Maximum delay allowed.

### Default

Media dependent:

Ethernet	lan
FDDI	lan
Frame Relay	packet-switched
QLLC	packet-switched
RSRB	packet-switched
SDLC	telephone
Token Ring	lan

### Command Mode

APPN port configuration

### Usage Guidelines

This command applies to all link stations accessed through this port. Specifying propagation-delay at the link station level overrides this command. The value of propagation delay is used by the node to determine the least cost route for APPN intermediate sessions.

### Example

The following example specifies a delay of less than 480 microseconds:

```
appn port FR1 Serial1/1  
propagation-delay lan  
complete
```

Related Commands

**appn port**

**show appn port**

## pu-type-20

Use the **pu-type-20** APPN link station configuration command to indicate that the downstream PU whose dependent LU request is propagated through the link is a PU Type 2.0. Use the **no** form of this command, or omit this command to indicate that the downstream PU is a Type 2.1.

**pu-type-20**  
**no pu-type-20**

### Syntax Description

This command has no arguments or keywords.

### Default

The downstream PU is defined as a PU Type 2.1.

### Command Mode

APPN link station configuration

### Usage Guidelines

This command is normally used in conjunction with the **dlur-dspu-name** link-station configuration command.

### Example

The following example indicates that the downstream is a PU Type 2.0:

```
appn link-station LINK0001
port TR0
lan-dest-address 1000.4521.9812
pu-type-20
dlur-dspu-name PU009812
complete
```

### Related Commands

**appn link-station**  
**show appn link-station**





## retry-limit (APPN link station)

Use the **retry-limit** APPN link station configuration command to specify the number of times a link station attempts reactivation after failure. Use the **no** form of this command to specify the default.

```
retry-limit {retries | infinite [time]}  
no retry-limit
```

### Syntax Description

<i>retries</i>	The number of reactivation attempts. The valid range is 0 to 255. (0 equals infinite retries.) The default number of retries is 5.
<b>infinite</b>	Infinite retries.
<i>time</i>	(Optional) The amount of time allowed between reactivation attempts (in seconds). The valid range is 0 - 32,767 seconds. The default amount of time is 30 seconds.

### Default

The default is to use the values defined for the specified port.

### Command Mode

APPN link station configuration

### Usage Guidelines

This value supersedes any value specified in the **appn port** command.

### Example

The following example specifies 25 retries for APPN link station LINK12:

```
appn link-station LINK12  
port FDDI1  
lan-dest-address 4000.0211.4567  
retry-limit 25  
complete
```

### Related Commands

**appn link-station**  
**show appn link-station**

## retry-limit (APPN port)

Use the **retry-limit** APPN port configuration command to specify how many times a line will attempt reactivation after failure. Use the **no** form of this command to delete the previous definition.

```
retry-limit {retries | infinite [time]}  
no retry-limit
```

### Syntax Description

<i>retries</i>	The number of reactivation attempts. The valid range is 0 to 255. (0 equals infinite retries.)
<b>infinite</b>	Infinite retries.
<i>time</i>	(Optional) The amount of time allowed between reactivation attempts (in seconds).

### Default

The default number of retries is 5.

The default amount of time is 30 seconds.

### Command Mode

APPN port configuration

### Usage Guidelines

This command applies to all link stations accessed through this port. Specifying retry limit at the link station level overrides this command.

### Example

The following example specifies 25 retries:

```
appn port ETHER0 Ethernet0  
retry-limit 25  
complete
```

### Related Commands

**appn port**  
**show appn port**

## role (APPN link station)

Use the **role** APPN link station configuration command to specify the link station role used in XID negotiations. Use the **no** form of this command to delete a previous definition.

```
role {negotiable | primary | secondary}  
no role
```

### Syntax Description

<b>negotiable</b>	The link station can be the primary or secondary end of the link station connection.
<b>primary</b>	The link station is the primary end of the link station connection.
<b>secondary</b>	The link station is the secondary end of the link station connection.

### Default

The value specified in the **appn port** command.

### Command Mode

APPN link station configuration

### Usage Guidelines

This command overrides the value specified on the port definition.

### Example

The following example sets the role to primary:

```
appn link-station LINK44  
port ETHER1  
lan-dest-address 0200.98ab.de23  
role primary  
complete
```

### Related Commands

**appn link-station**  
**show appn link-station**

## role (APPN port)

Use the **role** APPN port configuration command to specify the link station role used in XID negotiations for all link stations defined through this port. Use the **no** form of this command to delete a previous definition.

```
role { negotiable | primary | secondary }  
no role
```

### Syntax Description

<b>negotiable</b>	The link station can be the primary or secondary end of the link station connection.
<b>primary</b>	The link station is the primary end of the link station connection.
<b>secondary</b>	The link station is the secondary end of the link station connection.

### Default

The default role is **negotiable**

### Command Mode

APPN port configuration

### Usage Guidelines

This command applies to all link stations accessed through this port. Specifying role at the link station overrides this command.

### Example

The following example sets the role to primary:

```
appn port FDDI0 Fddio  
role primary  
complete
```

### Related Commands

**appn port**  
**show appn port**

## route-additional-resistance

Use the **route-additional-resistance** APPN control point configuration command to specify an arbitrary value for the local node. Use the **no** form of this command to delete the definition.

**route-additional-resistance** *number*  
**no route-additional-resistance**

### Syntax Description

*number* Arbitrary value in the range of 0 to 255.

### Default

The default resistance value is 128.

### Command Mode

APPN control point configuration

### Usage Guidelines

The route additional resistance value is included in topology updates and is used by network nodes to select a least-cost path associated with a particular class of service. You use this command to assign an arbitrary value and to indicate preference or non-preference for particular nodes in route paths.

### Example

The following example specifies a route additional resistance value of 200:

```
appn control-point CISCO.ROUTER
route-additional-resistance 200
complete
```

### Related Commands

**appn control-point**  
**show appn node**

## rsrb-virtual-station

Use the **rsrb-virtual-station** APPN port configuration command to configure APPN for remote source-route bridging. Use the no form of this command to delete the configuration.

**rsrb-virtual-station** *virtual-mac-addr local-ring-num bridge-number target-ring-num*  
**no rsrb-virtual-station**

### Syntax Description

<i>virtual-mac-addr</i>	The virtual MAC address on which APPN resides.
<i>local-ring-num</i>	The virtual ring number on which the APPN station resides. The valid range is 1 - 255.
<i>bridge-number</i>	Bridge number connecting the local virtual ring and the RSRB target virtual ring. The valid range is 1 to 15.
<i>target-ring-num</i>	The target ring through which the local ring bridges data. The valid range is 1 - 255.

### Default

No defaults are defined.

### Command Mode

APPN port configuration

### Example

The following example defines an APPN port that uses RSRB as a transport protocol:

```
appn port rsrb
rsrb-virtual-station 1234.1234.1234 50 1 60
complete
```

### Related Commands

**appn port**  
**show appn port**

## safe-store-cycle

Use the **safe-store-cycle** APPN control point configuration command to specify the number of cache instances to be saved. Use the **no** form of this command to delete the previous definition.

**safe-store-cycle** *number*  
**no safe-store-cycle**

### Syntax Description

*number*                                      Number of cache instances to be saved.

### Default

The default is 2.

### Command Mode

APPN control point configuration

### Example

The following example specifies that 5 cache instances will be saved:

```
appn control-point CISCO.APPN1
safe-store-host ip-address 171.69.44.1 directory appnsafe
safe-store-cycle 5
complete
```

### Related Command

**appn control-point**

## safe-store-host

Use the **safe-store-host** APPN control point configuration command to specify the IP host address and the file path for safe store. Use the **no** form of this command to delete the previous definition.

**safe-store-host ip-address** *address* **directory** *path*  
**no safe-store-host**

### Syntax Description

<b>ip-address</b> <i>address</i>	Host IP address.
<b>directory</b> <i>path</i>	File path for safe store.

### Default

No defaults are assigned.

### Command Mode

APPN control point configuration

### Example

The following example specifies that the IP host address and the file path where the database will be stored:

```
appn control-point CISCO.APPN1
safe-store-host ip-address 171.69.44.1 directory appnsafe
safe-store-cycle 5
complete
```

### Related Command

**appn control-point**

## safe-store-interval

Use the **safe-store-interval** APPN control point configuration command to specify how often the directory database is stored to permanent media. Use the **no** form of this command to delete the previous definition.

**safe-store-interval** *interval*  
**no safe-store-interval**

### Syntax Description

*interval* Interval in minutes between storage of the directory database to permanent media. The valid range is 0 to 32767 minutes.

### Default

20 minutes

### Command Mode

APPN control point configuration

### Usage Guidelines

This command allows you to balance processor usage with potential performance savings. A longer interval reduces the processor cycles used to save data, but potentially reduces the validity of the data due to less frequent updates.

### Example

The following example specifies that the database will be stored to permanent media every 30 minutes:

```
appn control-point CISCO.APPN1
safe-store-host ip-address 171.69.44.1 directory appnsafe
safe-store-interval 30
complete
```

### Related Command

**appn control-point**

## sdlc-dest-address

Use the **sdlc-dest-address** APPN link station configuration command to specify the local address of the partner node for non-switched SDLC. Use the **no** form of this command to delete the definition.

**sdlc-dest-address** *address*  
**no sdlc-dest-address** *address*

### Syntax Description

*address* A 2-digit hexadecimal number in the range of 00 to fe.

### Default

No default address is assigned.

### Command Mode

APPN link station configuration

### Usage Guidelines

This command is optional if the interface type is switched SDLC. It is not allowed for other interface types.

### Example

The following example assigns address f1:

```
appn link-station LINK12
port SDLC1
sdlc-dest-address f1
complete
```

### Related Commands

**appn link-station**  
**show appn link-station**

## sdlc-sec-addr

Use the `sdlc-sec-addr` command to configure APPN for SDLC. Use the `no` form of this command to delete the configuration.

```
sdlc-sec-addr sdlc-addr  
no sdlc-sec-addr
```

### Syntax Description

*sdlc-addr* SDLC secondary address. The valid range is 0 to fe (hexadecimal).

### Default

The default address is 0.

### Command Mode

APPN port configuration

### Example

The following example defines a port with a local SDLC address of 2.

```
appn port Serial1  
sdlc-sec-address 2  
complete
```

### Related Commands

```
appn port  
show appn port
```

## security (APPN link station)

Use the **security** APPN link station configuration command to specify the security level of the connection. Use the **no** form of this command to delete the previous definition.

```
security {security-level}  
no security
```

### Syntax Description

*security-level*

One of the following keywords: **nonsecure**,  
**public-switched**, **underground-cable**, **secure-conduit**,  
**guarded-conduit**, **encrypted**, **guarded-radiation**

### Default

The default value specified in the **appn port** command.

### Command Mode

APPN link station configuration

### Usage Guidelines

The security level is used in route selection.

### Example

The following example sets the security level to encrypted:

```
appn link-station LINK12  
security encrypted  
complete
```

### Related Commands

**appn link-station**  
**show appn link-station**

---

## security (APPN port)

Use the **security** APPN port configuration command to specify security level. Use the **no** form of this command to delete the previous definition.

```
security {security-level}  
no security
```

### Syntax Description

*security-level*

One of the following keywords: **nonsecure**,  
**public-switched**, **underground-cable**, **secure-conduit**,  
**guarded-conduit**, **encrypted**, **guarded-radiation**

### Default

The default security is nonsecure.

### Command Mode

APPN port configuration

### Usage Guidelines

This command applies to all link stations accessed through this port. Specifying security at the link station level overrides this command.

### Example

The following command sets the security level to encrypted:

```
appn port TR0 TokenRing0  
security encrypted  
complete
```

### Related Commands

**appn port**  
**show appn port**

## service-any

Use the **service-any** APPN port configuration command to specify that this port will create dynamic transmission groups for outbound or inbound links. Use the **no** form of this command to specify that the link station must be defined through configuration commands.

**service-any**  
**no service-any**

### Syntax Description

This command has no arguments or keywords.

### Default

The default state is **service-any**.

### Command Mode

APPN port configuration

### Usage Guidelines

Specifying no service-any serves as a security mechanism to control who may or may not connect to the local node.

### Example

The following example activate service any:

```
appn port FDDI0 Fddio
no service-any
complete
```

### Related Commands

**appn port**  
**show appn port**

## serving-nn

Use the **serving-nn** APPN partner-lu-location configuration command to specify the name of the network node server servicing the partner LU. Use the **no** form of this command to delete the definition.

```
serving-nn netid.cpname  
no serving-nn
```

### Syntax Description

*netid.cpname*

Fully qualified network name.

A fully qualified name is a string of 1 to 8 characters, followed by a period, followed by a string of 1 to 8 characters. The following characters are acceptable:

A - Z, a - z

0 - 9

\$ # @

The first character of either string must not be a number

### Default

The CP name of the local network node.

### Command Mode

APPN partner LU location configuration

### Usage Guidelines

The **serving-nn** may be specified as null if the LU name is specified as null. This specification indicates a wildcard definition for all LUs.

### Example

The following example sets **serving-nn**:

```
appn partner-lu-location CISCO.LU000012  
serving-nn CISCO.APPN1  
complete
```

### Related Commands

**appn partner-lu-location**

**show appn directory**

## show appn class-of-service

Use the **show appn class-of-service EXEC** command to display the APPN classes of service defined to the local node.

**show appn class-of-service [brief | detail]**

### Syntax Description

- brief** (Optional) A short display of APPN classes of service.
- detail** (Optional) A long display of APPN classes of service.

### Default

Brief display

### Command Mode

EXEC

### Sample Display

- Brief:

```

Number of class of service definitions          7
APPN Classes of Service
  Name      Trans. Pri.  Node Rows  TG Rows
  -----  -
1> #CONNECT Medium          8         8
2> CPSVCMG Network          8         8
3> SNASVCMG Network          8         8
4> #INTER  High           8         8
5> #INTERSC High            8         8
6> #BATCH  Low             8         8
7> #BATCHSC Low             8         8
    
```

- Detail:

This example shows just one part of one table. There could be up to 8 node rows and 8 TGs and multiple tables. This shows, however, the correspondence between the configuration commands and SHOW commands.

```

Number of class of service definitions          8
1> Class of service name                       #connect
  Transmission priority                       Medium
  Number of node rows                         8
  Number of TG rows                           8
1.1> Node row weight                          5
  Congestion min                             no
  Congestion max                             no
  Route additional resistance min              0
  Route additional resistance max              31
.
1.1>TG row weight                             .
  Cost per connect time min                   0
  Cost per connect time max                   0
    
```

Cost per byte min	0
Cost per byte max	0
Security min	Nonsecure
Security max	Maximum security
Propagation delay min	0 microseconds (minimum)
Propagation delay max	384 microseconds (local area network)
Effective capacity min	4 megabits per second
Effective capacity max	604 gigabits per second
User defined parameter 1 min	0
User defined parameter 1 max	255
User defined parameter 2 min	0
User defined parameter 2 max	255
User defined parameter 3 min	0
User defined parameter 3 max	255

**Table 32-1 Show APPN Class-of-Service Field Descriptions**

Field	Description
Class of Service Name	Administratively-assigned name for this COS
transmission priority	The relative priority this COS will receive when transmitting out of this node.
Number of node rows	The number of node rows associated with this COS
Node of TG Rows	The number of TG rows associated with this COS.
Node Row Weight	The weight assigned to this node given the characteristics identified in the remainder this row.
Congestion Min	
Congestion Max	
Route additional resistance min	The minimum route additional resistance for this node row.
Route additional resistance max	The maximum route additional resistance for this node row.
TG Row Weight	The weight associated with this TG given the characteristics identified in the remainder of this row.
Cost per connect time min	The minimum acceptable value for cost per connect time for this TG row.
Cost per connect time max	The maximum acceptable value for cost per connect time for this TG row.
Cost per byte min	The minimum acceptable value for cost per byte for this TG row.
Cost per byte max	The maximum acceptable value for cost per byte for this TG row.
Security min	The minimum acceptable value for security for this TG row.
Security max	The maximum acceptable value for security for this TG row.
Propagation delay min	The minimum acceptable value for propagation delay for this TG row.
Propagation delay max	The maximum acceptable value for propagation delay for this TG row.
Effective capacity min	The minimum acceptable value for effective capacity for this TG row.
Effective capacity max	The maximum acceptable value for effective capacity for this TG row.
User defined parameter 1 min	The minimum value for a network-unique TG characteristic - parameter 1.
User defined parameter 1 max	The maximum value for a network-unique TG characteristic - parameter 1.

## show appn class-of-service

---

User defined parameter 2 min	The minimum value for a network-unique TG characteristic - parameter 2.
User defined parameter 2 max	The maximum value for a network-unique TG characteristic - parameter 2.
User defined parameter 3 min	The minimum value for a network-unique TG characteristic - parameter 3.
User defined parameter 3 max	The maximum value for a network-unique TG characteristic - parameter 3.

### Related Commands

**appn class-of-service**  
**class-of-service**

## show appn connection-network

Use **show appn connection-network** to display the APPN connection networks defined to the local node.

**show appn connection-network [brief | detail]**

### Syntax Description

- brief** (Optional) A short display of APPN connection networks.
- detail** (Optional) A long display of APPN connection networks.

### Default

Brief display

### Command Mode

EXEC

### Sample Display

- Brief:

```

Connection network definitions                2
  APPN Connection Networks
  Resource Name      Attached Ports  First Port Name
  -----
1> NETA.CN          2             TR0
                   ABCDEFGH
2> NETADDDD.WWWEEEE 1             TR0

```

- Detail:

```

Connection network definitions                1

1>Connection network name                    NETA.CONNECT
Effective capacity                          15974400 bits per second
Cost per connect time                       0
Cost per byte                               0
Propagation delay                          384 microseconds (local area network)
User defined parameter 1                   128
User defined parameter 2                   128
User defined parameter 3                   128
Security                                    Nonsecure
Attached ports                              1

1.1>Port name                               TR0

```

**Table 32-2 Show APPN Connection-Network Field Descriptions**

Field	Description
Connection Network Name	The fully-qualified name of the connection network.
Effective capacity	The bit rate for the connection network.
Cost per connect time	The relative cost of this connection network's TG.

## show appn connection-network

---

Cost per byte	The cost-per-byte of transmitting a byte over this TG.
Propagation delay	The inherent delay of the connection network
User defined parameter 1	The value for a network-unique TG characteristic - parameter 1.
User defined parameter 2	The value for a network-unique TG characteristic - parameter 2.
User defined parameter 3	The value for a network-unique TG characteristic - parameter 3.
Security	The security level for this connection network.
Attached ports	The number of ports associated with the connection network.
Port Name	The port supporting this connection network.

### Related Command

**appn connection-network**

## show appn directory

Use **show appn directory** to display the contents of the APPN directory database.

**show appn directory [brief | detail]**

### Syntax Description

**brief** (Optional) A short display of the APPN directory database.

**detail** (Optional) A long display of the APPN directory database.

### Default

Brief display

### Syntax Description

This command has no arguments or keywords.

### Command Mode

EXEC

### Sample Display

- Brief:

```
Total directory entries          5
APPN Directory Entries
Resource Name      Owing CP Name      NN Server      Entry Type
-----
1> NETA.BART       NETA.BART           NETA.BART     Register
2> NETA.DUMB       NETA.MARGE          NETA.BART     Register
3> NETA.DUMBER     NETA.MARGE          NETA.BART     Register
4> NETA.DUMBEST    NETA.MARGE          NETA.BART     Register
5> NETA.MARGELU1   NETA.MARGE          NETA.BART     Register
```

- Detail:

This example shows a very small directory, but points out key characteristics of the displays.

The LU in this case was added to the directory through registration when resources were activated.

```
Total directory entries          2
Network node entries             1

1>Network node CP name           CISCO.BARNEY
   Number of associated LUs       1

1.1>LU name                      CISCO.MARGELU1
   Owing CP name                  CISCO.MARGE
   LU entry typ                   Register

Local and adjacent node entries   0

Local and adjacent node entries   0
```

**Table 32-3 Show APPN Directory Field Descriptions**

<b>Field</b>	<b>Description</b>
Network Node CP name	The fully-qualified name of the resource entry
Number of associated LUs	The number of LUs associated with the above CP.
LU Name	The LU name belonging to the Network node above.
Owning CP Name	The control point owning this partner LU.
LU entry type	The type of entry this LU is in the directory database.

**Related Command**

**appn partner-lu-location**

## show appn dlur-lu

Use **show appn dlur-lu** to display all active SSCP dependent LUs known to DLUR.

**show appn dlur-lu** *luname* [**brief** | **detail**]

### Syntax Description

<i>luname</i>	8-character Type-A string of a specific LU.
<b>brief</b>	(Optional) A short display of the APPN directory database.
<b>detail</b>	(Optional) A long display of the APPN directory database.

### Default

Brief display

### Command Mode

EXEC

### Sample Display

- Brief:

```
APPN DLUR-LU:
  LU Name   PU Name   DLUS Name   PLU Name
  -----
1> SJDRLU11 BEAGLE    NETA.CPAC   NETA.TSO0005
```

- Detail:

```
LU name           SJDRLU11
PU name           BEAGLE
Dependent LU Server Name NETA.CPAC
LU location       Remote
NAU address       2
PLU name          NETA.TSO0005
```

**Table 32-4 Show APPN DLUR-LU Field Descriptions**

Field	Description
LU Name	Logical Unit name of the active SSCP dependent LUs supported by DLUR.
PU Name	Physical Unit name of the active SSCP dependent LU.
DLUS Name	Fully-qualified name of the DLUS providing SSCP services for the SSCP dependent LU.
LU Location	Always identifies the LUs as remote LUs.
NAU Address	Network Addressable Unit of the LU.
PLU Name	When the SSCP dependent LU has an active session, the name of the Primary LU Name will be displayed.

Related Commands

**backup-dlus (APPN control point)**

**dlur**

**dlus (APPN control point)**

**show appn dlur-pu**

**show appn dlus**

## show appn dlur-pu

Use **show appn dlur-pu** to display all active SSCP dependent PUs known to DLUR.

**show appn dlur-pu** *puname* [**brief** | **detail**]

### Syntax Description

<i>puname</i>	8-character Type-A string of a specific PU.
<b>brief</b>	(Optional) A short display of the APPN directory database.
<b>detail</b>	(Optional) A long display of the APPN directory database.

### Default

Brief display

### Command Mode

EXEC

### Sample Display

- Brief:

```
APPN DLUR-PU:
  PU NameR   Active DLUS   Defined DLUS   Backup DLUS
  -----
1> BEAGLE    NETA.CPAC
```

- Detail:

```
PU name                BEAGLE
Defined DLUS name
Backup DLUS name
Physical unit (PU) Node ID      05D00010
PU location                Downstream
Active DLUS name            NETA.CPAC
ANS support                 Continue
PCID                       D6DB11281AF90044
Fully qualified CP name      NETA.WONDER
```

**Table 32-5** Show APPN DLUR-PU Field Descriptions

Field	Description
PU Name	Physical Unit name of active SSCP dependent PUs
Defined DLUS Name	DLUS name specified with the <b>dlus</b> (APPN link station) configuration command
Backup DLUS Name	DLUS name specified with the <b>backup-dlus</b> (APPN link station) configuration command
PU Node ID	IDBLK and IDNUM of the PU
PU Location	Always identifies the PU as downstream
Active DLUS name	Fully qualified name of the DLUS providing SSCP services for the PU

## show appn dlur-pu

---

ANS Support	Identifies whether DLUR will keep active LU-LU sessions (Continue) when the connection to the DLUS is lost or whether DLUR will tear down active LU-LU sessions (Stop).
PCID	Procedure Correlation Identifier used to distinguish encapsulated traffic associated with this PU
Fully Qualified CP Name	Fully qualified CP name of the CP which generated the PCID above.

### Related Commands

**backup-dlus (APPN control point)**

**dlur**

**dlus (APPN control point)**

**show appn dlur-lu**

**show appn dlus**

## show appn dlus

Use **show appn dlur** to display all LUs known to DLUR.

**show appn dlus [brief | detail]**

### Syntax Description

**brief** (Optional) A short display of the APPN directory database.

**detail** (Optional) A long display of the APPN directory database.

### Default

Brief display

### Command Mode

EXEC

### Sample Display

- Brief:

```
APPN DLUS:
  DLUS Name      State      # Active PUs
  -----      -
1> NETA.CPAC    ACTIVE          1
```

- Detail:

```
Dependent LU Server Name      NETA.CPAC
Is this default DLUS?         Yes
Is this default backup DLUS?  No
Pipe State                     Active
Number of active PUs          1
Pipe statistics
# of REQACTPU requests sent    1
# of REQACTPU responses received 1
# of ACTPU requests received   1
# of ACTPU responses sent      1
# of REQDACTPU requests sent   0
# of REQDACTPU responses received 0
# of DACTPU requests received  0
# of DACTPU responses sent     0
# of ACTLU requests received   1
# of ACTLU responses sent      1
# of DACTLU requests received  0
# of DACTLU responses sent     0
# of SSCP_PU MUs received      0
# of SSCP_PU MUs sent          0
# of SSCP_LU MUs received      4
# of SSCP_LU MUs sent          5
```

**Table 32-6 Show APPN DLUS Field Descriptions**

<b>Field</b>	<b>Description</b>
DLUS Name	Fully qualified DLUS name.
Default DLUS	Identifies the DLUS as the node default DLUS.
Default Backup DLUS	Identifies the DLUS as the node backup default DLUS.
Pipe State	Identifies the state of the DLUS-DLUR connection.
Number of Active PUs	Total number of active PUs.
REQACTPU sent/rcvd	The number of REQACTPU requests sent to the DLUS and the number of REQACTPU responses received from DLUS.
ACTPU sent/rcvd	The number of ACTPU responses sent to the DLUs and the number of ACTPU requests received from the DLUS.
REQDACTPU sent/rcvd	The number of REQDACTPU requests sent to the DLUS and the number of REQDACTPU responses received from the DLUS.
DACTPU sent/rcvd	The number of DACTPU responses sent to the DLUS and the number of DACTPU requests received from the DLUS.
ACTLU sent/rcvd	The number of ACTLU responses sent to the DLUS and the number of ACTLU requests received from the DLUS.
DACTLU sent/rcvd	The number of DACTLU responses sent to the DLUS and the number of DACTLU requests received from the DLUS.
SSCP PU MUs sent/rcvd	The number of SSCP PU MUs sent and received from the DLUS.
SSCP LU MUs sent/rcvd	The number of SSCP LU MUs sent and received from the DLUS.

**Related Commands**

**backup-dlus (APPN control point)**

**dlur**

**dlus (APPN control point)**

## show appn intermediate-session

Use the **show appn intermediate-session EXEC** command to display information about the SNA sessions that are currently being routed through the local node.

**show appn intermediate-session [brief | detail]**

### Syntax Description

<b>brief</b>	(Optional) A short display of APPN intermediate session information.
<b>detail</b>	(Optional) A long display of APPN intermediate session information.

### Default

Brief display

### Command Mode

EXEC

### Sample Display

- Brief:

```

Number of intermediate sessions          1
APPN Intermediate Sessions
  PCID (hex)      Primary LU Name      Secondary LU Name      Mode      COS
-----
1> C6D328B0922EE4FF  NETA.MARGE      NETA.APU      #INTER      #INTER

```

- Detail:

```

Number of intermediate sessions          2

1>Procedure correlator ID (PCID) X'SS3321E8934CF101'
Primary LU name NETA.LISA
Secondary LU name NETA.BART
Mode name #INTER
Class of service name #INTER
Primary side adjacent CP name           NETA.PATTY
Secondary side adjacent CP name         CISCO.MARGE
Primary side link name                   PATTY
Secondary side link name                 MARGE
PCID generator CP name                   NETA.PATTY

2>Procedure correlator ID (PCID) X'DD3321E8944CF101'
Primary LU Name NETA.LISA
Secondary LU Name NETA.BART
Mode name SNASVCMG
Class of service name SNASVCMG
Primary side adjacent CP name           NETA.PATTY
Secondary side adjacent CP name         CISCO.MARGE
Primary side link name                   PATTY
Secondary side link name                 MARGE
PCID generator CP name                   NETA.PATTY

```

**Table 32-7 Show APPN Intermediate-Session Field Descriptions**

<b>Field</b>	<b>Description</b>
Procedure Correlator ID (PCID)	The PCID for this session.
Primary LU Name	The primary LU name for this session.
Secondary LU Name	The secondary LU name for this session.
Mode Name	The mode used by this session.
Class of service name	The class of service used by this session.
Primary side adjacent CP name	The fully-qualified name of the adjacent CP on the primary side.
Secondary side adjacent CP name	The fully-qualified name of the adjacent CP on the secondary side.
Primary side link name	The link name used on the primary side.
Secondary side link name	The link name used on the secondary side.
PCID generator CP name	The fully-qualified CP name which generated the PCID.
Session interrupt switched	Specifies is this session is processed at interrupt-level.

**Related Command**

**show appn connection-network**

## show appn link-station

Use the **show appn link-station** EXEC command to display information about the APPN link-stations active on or defined to the local node.

**show appn link-station** [**brief** | **detail**]

### Syntax Description

- brief** (Optional) A short display of active APPN links. Brief is the default display.
- detail** (Optional) A long display of active APPN links with more information.

### Default

Brief display

### Command Mode

EXEC

### Sample Display

- Brief:

```
Number of active links 3
APPN Logical Links
  Link Name  State      Port Name  Adjacent CP Name  Node Type
  -----  -
1> HOST      Inactive   FDDIO     CISCO.HOMER      Learn
2> DOWNSTR   Inactive   RSRB     CISCO.HOMER      Learn
3> HOMER     Inactive   FDDIO     CISCO.HOMER      Learn
```

- Detail:

```
Number of active links 3

1>Link name          FHOMER
  Port name          FDDIO
  Link activated      Locally
  Link state          Active
  Deactivating link   No
  Max frame data (BTU) size 521
  Adjacent node CP name CISCO.HOMER
  Adjacent node type  Network node
  CP-CP session support Yes
  Link station role    Primary
  Line type            Shared access transport facility
  Transmission group number 21
  Effective capacity    100000000 bits per second
  Cost per connect time 0
  Cost per byte         0
  Propagation delay     384 microseconds (local area network)
  User defined parameter 1 0
  User defined parameter 2 0
  User defined parameter 3 0
  Security              Nonsecure
```

**Table 32-8 Show APPN Link-Station Field Descriptions**

<b>Field</b>	<b>Description</b>
Link name	The name of the link station.
Port name	The port this link station is using.
Interface name	The interface used by this link.
Destination DLC address (remote SAP)	The DLC address of the partner node and its SAP.
Link Activated	Specifies with node activated this link.
Link state	The state of the link.
Deactivating link	Is the link currently deactivating?
Max frame data (BTU) size	The maximum BTU size this link can support.
Adjacent node CP name	Name of the partner node for the link station.
Adjacent node type	The node type of the partner node of this link.
CP-CP session support	Specifies whether CP-CP sessions can be supported.
Link station role	Specifies the role the link uses in XID negotiation.
Line type	
Transmission group number	The TG assigned to this link.
Effective capacity	The bit rate of this link.
Cost per connect time	The relative cost of this link.
Cost per byte	The cost-per-byte of transmitting a byte over this link.
Propagation delay	Specifies the inherent delay of the link.
User defined parameter 1	The value for a network-unique TG characteristic - parameter 1.
User defined parameter 2	The value for a network-unique TG characteristic - parameter 2.
User defined parameter 3	The value for a network-unique TG characteristic - parameter 3.
Security	The security level of the link.

**Related Command**

**appn link-station**

## show appn mode

Use the **show appn mode EXEC** command to display information about the APPN modes defined to the local node.

**show appn mode [brief | detail]**

### Syntax Description

**brief** (Optional) A short display of APPN mode definitions.

**detail** (Optional) A long display of APPN mode definitions.

### Default

Brief display

### Command Mode

EXEC

### Sample Display

```

Number of modes                               8
APPN Modes
Name      Associated COS
-----
1>        #CONNECT
2> #BATCH  #BATCH
3> #BATCHSC #BATCHSC
4> #INTER  #INTER
5> #INTERSC #INTERSC
6> CPSVCMG CPSVCMG
7> SNASVCMG SNASVCMG
8> CPSVRMGR SNASVCMG

```

**Table 32-9 Show APPN Mode Field Descriptions**

Field	Description
Mode name	The mode name
Class of service name	The class of service this mode maps to

### Related Command

**appn mode**

## show appn node

Use the **show appn node** EXEC command to display information about the local APPN control point.

**show appn node**

### Syntax Description

This command has no arguments or keywords.

### Command Mode

EXEC

### Sample Display

```
Network name                CISCO
Control point (CP) name     BARNEY
Node ID (for XID)          X'07700000'
Route additional resistance  128
Maximum directory cache entries 255
Current directory cache entries 0
Directory save interval     20
```

**Table 32-10 Show APPN Node Field Descriptions**

Field	Description
Network name	The network name for this node.
Control point (CP) name	The control point name for this node.
Node ID (for XID)	The 8-digit hexadecimal node ID value for this node.
Route additional resistance	An arbitrary value associated with the cost of sessions passing through this node.
Maximum directory cache entries	The maximum number of cached directory entries.
Current directory cache entries	The current number of cached directory entries
Directory save interval	Time (in minutes) between directory save stores.

### Related Command

**appn control-point**

## show appn port

Use the **show appn port** EXEC command to display information about the APPN ports active on the local node.

**show appn port [brief | detail]**

### Syntax Description

**brief** (Optionam) A short display of APPN port definitions.

**detail** (Optionam) A long display of APPN port definitions.

### Default

Brief display

### Command Mode

EXEC

### Sample Display

- Brief:

```
Number of ports                               2
APPN Ports
  Name      State      SAP  Interface
  -----  -
1> TR0      Active      x04  TokenRing0
2> ABCDEFGH Active      x04  Ethernet0
```

- Detail:

```
Number of ports                               2

1>Port name                                FDDI0
Interface name Fddi0
Port State Active
SAP X'04'
  Link station role                          Negotiable
  Line type                                    Shared access transport facility
  Limited resource                            No
  Limited resource timeout                    0
  Max frame data (BTU) size                   521
  Maximum link stations                       0
  Asynchronous balanced mode                  No
  Effective capacity                           100000000 bits per second
  Cost per connect time                       0
  Cost per byte                               0
  Propagation delay                           384 microseconds (local area network)
  User defined parameter 1                    0
  User defined parameter 2                    0
  User defined parameter 3                    0
  Security                                     Nonsecure
```

**Table 32-11 Show APPN Port Field Descriptions**

<b>Field</b>	<b>Description</b>
Port name	The name of this port.
Interface name	The interface used by this port
Port State	The current state of this port.
SAP	The default service access point for links on this port.
Link station role	Specifies the role link stations use in XID negotiation.
Line type	
Limited resource	Specifies if links on this port should be taken down when no sessions are using the link.
Limited resource timeout	The time (in seconds) before the links on this port will be taken down if there are no sessions.
Max frame data (BTU) size	The maximum BTU size for links on this port.
Maximum link stations	The maximum number of link stations allowed on this port.
Asynchronous balanced mode	Is asynchronous balanced mode supported?
Effective capacity	The bit rate of this port.
Cost per connect time	The relative cost of the links on this port.
Cost per byte	The cost-per-byte of transmitting a byte over the links on this port.
Propagation delay	Specifies the inherent delay of the port.
User defined parameter 1	The value for a network-unique TG characteristic - parameter 1.
User defined parameter 2	The value for a network-unique TG characteristic - parameter 2.
User defined parameter 3	The value for a network-unique TG characteristic - parameter 3.
Security	The security level of this port.

**Related Command**

**appn port**

## show appn session

Use the **show appn session EXEC** command to display information about the SNA LU6.2 sessions, such as CP-CP sessions, that originate from the local node.

**show appn session [brief | detail]**

### Syntax Description

- brief** (Optionam) A short display of APPN session information.
- detail** (Optionam) A long display of APPN session information.

### Default

Brief display

### Command Mode

EXEC

### Sample Display

- Brief:

```

Number of sessions                               4
APPN Endpoint Sessions
  PCID (hex)      Local LU Name      Partner LU Name      Mode      COS
  -----
1> C6D328B0912EE4FF  NETA.BART      NETA.MARGE      CPSVCMG  CPSVCMG
2> F1DBABC818AB53AC  NETA.BART      NETA.APU        CPSVCMG  CPSVCMG
3> F37F3BE237DE7242  NETA.BART      NETA.MARGE      CPSVCMG  CPSVCMG
4> F37F3BE237DE7243  NETA.BART      NETA.APU        CPSVCMG  CPSVCMG

```

- Detail:

```

Number of sessions                               6

1>LU name                                         CISCO.BARNEY
  Partner LU name                                NETA.HOMER
  Mode name                                       CPSVCMG
Class of service name CPSVCMG
  Link name                                       FHOMER
  Send maximum RU size                            512
  Receive maximum RU size                         512
  Send pacing window                              2
  Receive pacing window                           9
  Pacing type                                     Adaptive
  Outbound destination address (DAF)             X'00'
  Outbound origin address (OAF)                  X'02'
  OAF-DAF assignor indicator (ODAI)              B'1'
  Procedure correlator ID (PCID)                 X'E48712C9077C03C3'
  PCID generator CP name                          NETA.HOMER
  Session ID                                      X'00000000007ED384'
  Conversation group ID                           X'00000022'

2>LU name                                         CISCO.BARNEY
  Partner LU name                                NETA.HOMER
  Mode name                                       CPSVCMG

```

**show appn session**

---

```

Class of service name CPSVCMG
  Link name                               FHOMER
Send maximum RU size 512
  Receive maximum RU size                 512
  Send pacing window                       2
  Receive pacing window                   8
  Pacing type                             Adaptive
Outbound destination address (DAF)        X'02'
Outbound origin address (OAF)             X'00'
OAF-DAF assignor indicator (ODAI)        B'0'
Procedure correlator ID (PCID)           X'CDEFA1343053A784'
PCID generator CP name                   CISCO.BARNEY
Session ID                               X'00000000007ED368'
Conversation group ID                     X'00000023'

```

**Table 32-12 Show APPN Session Field Descriptions**

Field	Description
LU Name	The fully-qualified name of the local LU.
Partner LU Name	The fully-qualified name of the partner LU.
Mode name	The mode used by this session.
Class of service name	The class of service used by this session.
Link name	The link this session traverses.
Send maximum RU size	The maximum RU size that can be sent on this sessions.
Receive maximum RU size	The maximum RU size that can be received on this session.
Send pacing window	The current send pacing window size.
Receive pacing window	The current receive pacing window size.
Pacing type	The type of pacing used by this session.
Outbound destination address (DAF)	
Outbound origin address (OAF)	
OAF-DAF assignor indicator (ODAI)	
Procedure correlator ID (PCID)	The PCID used by this session.
PCID generator CP name	The fully-qualified CP name which generated this PCID.
Session ID	The local session ID.
Conversation group ID	The conversation group ID for this session.

## show appn topology

Use the **show appn topology** EXEC command to display the contents of the APPN topology database.

**show appn topology [brief | detail]**

### Syntax Description

**brief** (Optional) A short display of APPN topology information

**detail** (Optional) A long display of APPN topology information.

### Default

Brief display

### Command Mode

EXEC

### Sample Display

This shows the information contained in the topology databases. Note that CISCO.BARNEY has 2 TGs connected--one to CISCO.HOMER, which is a network node and stored in the network topology, and one to CISCO.PATTY, which is stored in the local topology. There would be additional entries for other network nodes and TGs in the network to provide the complete network topology.

- Brief:

```

Number of network nodes                3
APPN Topology Entries
Resource Name      Type      TG#  Dest. Node      TG Type  TG Status
-----
1> NETA.BARNEY    Network Node
1>                 0  NETA.CN         Intermed Active
2>                 0  NETA.CN1        Intermed Active
3>                 21 NETA.R2CP0389   Intermed Active
4>                 21 NETA.BART        Intermed Active

```

- Detail:

```

Number of network nodes                2

1>Network node CP name                  CISCO.BARNEY
Node type Network Node
Route additional resistance              128
Congested?                              No
Quiescing?                              No
ISR depleted?                           No
Number of TGs                            2

1.1>TG partner CP name                  CISCO.HOMER
Transmission group number                21
TG partner node type                      real
Tg Type Intermediate Routing
TG Status Active
Quiescing?                               No
Topology                                  Network

```

```

Effective capacity          98 megabits per second
Cost per connect time      0
Cost per byte              0
Propagation delay          384 microseconds
User defined parameter 1   128
User defined parameter 2   128
User defined parameter 3   128
Security                   Nonsecure
    
```

**Table 32-13 Show APPN Topology Field Descriptions**

Field	Description
Network node CP name	The fully-qualified name of the resource.
Node type	Resource type of this node.
Route additional resistance	An arbitrary number associated with the cost of using this node.
Congested?	Is this node able to current/future requests?
Quiescing?	Is this node in the process of stopping?
ISR depleted?	If this node able to process additional ISR requests?
Number of TGs	The number of TGs associated with the network node
TG partner CP name	Partner node's fully-qualified name.
Transmission group number	The transmission group number
TG partner node type	Resources type for the partner of this TG.
TG Type	The type of TG: Intermediate or Endpoint
TG Status	The status of the transmission group.
Quiescing?	Is this TG in the process of stopping?
Topology	Topology type: local or network
Effective capacity	The bit rate of the TG.
Cost per connect time	The relative cost of the TG.
Cost per byte	The cost-per-byte of transmitting a byte over the TG.
Propagation delay	Specifies the inherent delay of the TG.
User defined parameter 1	The value for a network-unique TG characteristic - parameter 1.
User defined parameter 2	The value for a network-unique TG characteristic - parameter 2.
User defined parameter 3	The value for a network-unique TG characteristic - parameter 3.
Security	The security level of the TG.

**Related Command**

**show appn connection-network**



## tg-row

Use the **tg-row** APPN class of service configuration command to specify a transmission group description, or tg row, and associated weight for the row. Use the no form of this command to delete the previous definition.

```
tg-row index weight weight byte min max time min max capacity min max delay value value
security value value user1 number number user2 number number user3 number number
no tg-row index
```

### Syntax Description

<b>index</b> <i>index</i>	Specifies which row is being entered. The valid range is 1 to 8.
<b>weight</b> <i>weight</i>	The weight assigned to a transmission group, given the characteristics defined in the remainder of the row.
<b>byte</b> <i>min max</i>	The minimum and maximum cost-per-byte values, compared with the <b>cost-per-byte</b> command on the port or link station command.
<b>capacity</b> <i>min max</i>	The minimum and maximum capacity values, compared with the <b>effective-capacity</b> command on the port or link station command.
<b>time</b> <i>min max</i>	The minimum and maximum cost-per-connect-time values, compared with the <b>cost-per-connect-time</b> command on the port or link station command.
<b>delay</b> <i>value value</i>	The two values compared with the propagation-delay command.
<b>security</b> <i>value value</i>	The value compared with the security command. The minimum and maximum are specified with one the defined values, in ascending order:
<b>user1</b> <i>number number</i>	Number in the range 1 to 255.
<b>user2</b> <i>number number</i>	Number in the range 1 to 255.
<b>user3</b> <i>number number</i>	Number in the range 1 to 255.

### Default

There is no default provided. A minimum of one transmission group row must be provided or the configuration will fail.

### Command Mode

APPN class of service configuration

## Usage Guidelines

The characteristics of transmission groups in the topology database are compared to the characteristics in each row. A weight is assigned which determines a low-cost route for a session. You can define from one to eight tg rows.

## Example

The following example defines an APPN class of service with one tg-row:

```
appn class-of-service #SECURE
node-row 1 weight 5 congestion no no route-additional-resistance 0 255
tg-row 1 weight 30 byte 0 255 time 0 255 capacity 0 255 delay 0 255 security 200 255 user1
0 255 user2 0 255 user3 0 255
complete
```

## Related Commands

**appn class-of-service**

**show appn class-of-service**

## transmission-priority

Use the **transmission-priority** APPN class of service configuration command to specify the transmission priority for the class of service. Use the **no** form of this command to delete the previous definition.

**transmission priority** {*priority*}  
**no transmission priority**

### Syntax Description

**network** One of the following keywords: **network**, **high**, **medium**, **low**

### Default

The default priority is medium.

### Command Mode

APPN class of service configuration

### Usage Guidelines

The value **network** is reserved for control traffic and cannot be specified for LU-LU sessions. High, medium, and low reflect the priority that traffic for an individual application should receive when congestion begins to build and queues form.

### Example

The following example defines an APPN class of service with a transmission priority of high:

```
appn class-of-service #SECURE
transmission-priority high
node-row 1 weight 5 congestion no no route-additional-resistance 0 255
tg-row 1 weight 30 byte 0 255 time 0 255 capacity 0 255 delay 0 255 security 200 255 user1
0 255 user2 0 255 user3 0 255
complete
```

### Related Commands

**appn class-of-service**  
**show appn class-of-service**









## user-defined-2 (APPN port)

Use the **user-defined-1** APPN port configuration command to specify the relative value for a network-unique transmission group characteristic. Use the **no** form of this command to delete the definition.

**user-defined-2** *value*  
**no user-defined-2**

### Syntax Description

*value*                      Number in the range 0 to 255 used to specify the relative value.

### Default

128

### Command Mode

APPN port configuration

### Usage Guidelines

This command is specified for defined transmission groups (with the **appn link-station** command) if the command has not been specified at that level. This command also specifies the value for dynamically created transmission groups. The cost is used in route selection for a particular class of service.

### Example

The following example defines a port with a user-defined-2 value of 50.

```
appn port ETHER1
user-defined-2 50
complete
```

### Related Commands

**appn port**  
**show appn port**



## verify-adjacent-node-type

Use the **verify-adjacent-node-type** APPN link station configuration command to specify that the adjacent node type must be verified as a requirement of link activation. Use the **no** form of this command to delete the definition.

```
verify-adjacent-node-type { learn | len | nn }  
no verify-adjacent-node-type
```

### Syntax Description

<b>learn</b>	Any adjacent node type is accepted.
<b>len</b>	Only LEN adjacent node type is accepted.
<b>nn</b>	Only NN adjacent node type is accepted.

### Default

The default node type is **learn**.

### Command Mode

APPN link station configuration

### Usage Guidelines

If the adjacent node type is LEN, the cp-cp-sessions-supported command must specify no.

If the adjacent node type is LEN, the adjacent-cp-name must be specified.

There is no verification for type EN

### Example

The following example specifies that any adjacent node type is accepted:

```
appn link-station NN4  
port ETHER1  
lan-dest-address 0200.5672.3212  
verify-adjacent-node-type nn  
complete
```

### Related Command

```
appn link-station  
show appn link-station
```

## wildcard

Use the **wildcard** APPN partner-lu-location configuration command to specify this entry as a “wildcard.” Use the **no** form of this command to delete the previous definition.

**wildcard**  
**no wildcard**

### Syntax Description

This command has no arguments or keywords.

### Default

The default state is **no wildcard**.

### Command Mode

APPN partner LU location configuration

### Usage Guidelines

A wildcard entry serves any LU whose name matches the configured name up to the length of the configured name. Without an LU name and wildcard specified, the entry services all LUs.

### Example

The following example defines a wildcard that represents any LU that starts with LU2, such as LU21, LULU21, LU234, and so on:

```
appn partner-lu-location LU2
owning-cp CISCO.CP2
wildcard
complete
```

### Related Commands

**appn partner-lu-location**  
**show appn directory**

## x25-dest-address

Use the **x25-dest-address** to configure APPN over QLLC. Use the **no** form of this command to delete the configuration.

```
x25-dest-address [pvc | svc] x25-addr  
no x25-dest-address
```

### Syntax Description

<b>pvc</b>	(Optional) Use x25 permanent virtual circuit.
<b>svc</b>	(Optional) Use x.25 switch virtual circuit.
<i>x25-addr</i>	The x.25 destination link station address.

### Default

No default address is specified.

### Command Mode

APPN link station configuration

### Usage Guidelines

*x25-addr* must be a valid X.121 address. This address must match that assigned by the X.25 network service provider.

### Example

The following example configures the X.25 destination address:

```
appn link-station QLLC  
port QLLC1  
x25-dest-address 170090  
complete
```

### Related Commands

```
appn link-station  
show appn link-station
```

## x25-subaddress

Use the **x25-subaddress** command to configure APPN over QLLC. Use the **no** form of this command to delete the configuration.

```
x25-subaddress [pvc | svc] x25-addr  
no x25-subaddress
```

### Syntax Description

<b>pvc</b>	(Optional) Use x25 permanent virtual circuit.
<b>svc</b>	(Optional) Use x.25 switch virtual circuit.
<i>x25-addr</i>	The x.25 sub-address from which data is received.

### Default

No default address is assigned.

### Command Mode

APPN port configuration

### Usage Guidelines

*x25-addr* must be a valid X.121 address. This address must match that assigned by the X.25 network service provider.

### Example

The following example configures the X.25 subaddress from which data is received:

```
appn port QLLC1 Serial0/1  
x25-subaddress svc 0001121  
complete
```

### Related Commands

```
appn port  
show appn port
```



