



Frame Relay Commands

Use the commands described in this chapter to configure access to Frame Relay networks.

For Frame Relay configuration information and examples, refer to the “Configuring Frame Relay” chapter in the *Wide-Area Networking Configuration Guide*.

class (map-list configuration)

To associate a map class with a protocol-and-address combination, use the **class** map-list configuration command.

```
protocol protocol-address class map-class [broadcast] [trigger] [ietf]
```

Syntax Description

<i>protocol</i>	Supported protocol, bridging, or logical link control keywords: appletalk , bridging , clns , decnet , dls , ip , ipx , llc2 , rsrb , vines , and xns .
<i>protocol-address</i>	Protocol address. The bridge and clns keywords do not use protocol addresses.
class <i>map-class</i>	Name of the map class from which to derive quality of service (QoS) information.
broadcast	(Optional) Allows broadcasts on this SVC.
trigger	(Optional) Enables a broadcast packet to trigger an SVC. If an SVC already exists that uses this map class, the SVC will carry the broadcast. This keyword can be configured only if broadcast is also configured.
ietf	(Optional) Specifies RFC 1490 encapsulation. The default is Cisco encapsulation.

Default

No protocol, protocol address, and map class are defined. If the **ietf** keyword is not specified, the default is Cisco encapsulation. If the **broadcast** keyword is not specified, no broadcasts are sent.

Command Mode

Map-list configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

This command is used for Frame Relay switched virtual circuits (SVCs); the parameters within the map class are used to negotiate for network resources.

The class is associated with a static map that is configured under a map list.

Examples

In the following example, if IP triggers the call, the SVC is set up with the QoS parameters defined within the class *hawaii*. However, if AppleTalk triggers the call, the SVC is set up with the QoS parameters defined in the class *rainbow*. An SVC triggered by either protocol results in two SVC

maps, one for IP and one for AppleTalk. Two maps are set up because these protocol-and-address combinations are heading for the same destination, as defined by the **dest-addr** keyword and the values following it in the **map-list** command.

```
map-list bermuda source-addr E164 14085551212 dest-addr E164 15085551212
ip 131.108.177.100 class hawaii
appletalk 1000.2 class rainbow
```

In the following example, the **trigger** keyword allows AppleTalk broadcast packets to trigger an SVC:

```
ip 172.21.177.1 class jamaica broadcast ietf
appletalk 1000.2 class jamaica broadcast trigger ietf
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

map-class frame-relay

map-list

class (virtual circuit configuration)

To associate a map class with a specified data-link connection identifier (DLCI), use the **class** virtual circuit configuration command. To remove the association between the DLCI and the map class, use the **no** form of this command.

class *name*
no class *name*

Syntax Description

name Name of map class to associate with this DLCI.

Default

No map class is defined.

Command Mode

Virtual circuit configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

This command applies to DLCIs. The class parameter values are specified with the **map-class frame-relay** command.

Examples

The following example shows how to define map class *slow_vcs* and apply it to DLCI 100:

```
interface serial 0.1 point-to-point
frame-relay interface-dlci 100
  class slow_vcs

map-class frame-relay slow_vcs
frame-relay cir out 9600
```

The following example shows how to apply a map class to a DLCI for which a **frame-relay map** statement exists. The **frame-relay interface-dlci** command must also be used.

```
interface serial 0.2 point-to-multipoint
frame-relay map ip 131.26.13.2 100
frame-relay interface-dlci 100
  class slow_vcs

interface serial 0
frame-relay interface-dlci 100
  class fast_vc

map-class frame-relay fast_vc
frame-relay traffic-rate 56000 128000
frame-relay idle-timer 30
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

frame-relay interface-dlci

frame-relay map

map-class frame-relay

clear frame-relay-inarp

To clear dynamically created Frame Relay maps, which are created by the use of Inverse Address Resolution Protocol (ARP), use the **clear frame-relay-inarp** EXEC command.

clear frame-relay-inarp

Syntax Description

This command has no arguments or keywords.

Command Mode

EXEC

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

Example

The following example clears dynamically created Frame Relay maps:

```
clear frame-relay-inarp
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

frame-relay inverse-arp

show frame-relay map

encapsulation frame-relay

To enable Frame Relay encapsulation, use the **encapsulation frame-relay** interface configuration command. To disable Frame Relay encapsulation, use the **no** form of this command.

```
encapsulation frame-relay [cisco | ietf]  
no encapsulation frame-relay [ietf]
```

Syntax Description

cisco	(Optional) Uses Cisco's own encapsulation, which is a 4-byte header, with 2 bytes to identify the data-link connection identifier (DLCI) and 2 bytes to identify the packet type. This is the default.
ietf	(Optional) Sets the encapsulation method to comply with the Internet Engineering Task Force (IETF) standard (RFC 1490). Use this keyword when connecting to another vendor's equipment across a Frame Relay network.

Default

Enabled

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

Use this command with no keywords to restore the default Cisco encapsulation, which is a 4-byte header with 2 bytes for the DLCI and 2 bytes to identify the packet type.

We recommend that you shut down the interface prior to changing encapsulation types. Although this is not required, shutting down the interface ensures the interface is reset for the new encapsulation.

Examples

The following example configures Cisco Frame Relay encapsulation on interface serial 1:

```
interface serial 1  
encapsulation frame-relay
```

Use the **ietf** keyword if your router or access server is connected to another vendor's equipment across a Frame Relay network to conform with RFC 1490:

```
interface serial 1  
encapsulation frame-relay ietf
```

frame-relay adaptive-shaping

Use the **frame-relay adaptive-shaping** map-class subcommand to select the type of backward notification you want to use. Use the **no** form of the command to disable backward notification.

```
frame-relay adaptive-shaping {becn | foresight}  
no frame-relay adaptive-shaping
```

Syntax Description

becn	Enables rate adjustment in response to BECN.
foresight	Enables rate adjustment in response to ForeSight messages.

Default

Disabled

Command Mode

Map-class subcommand

Usage Guidelines

This command first appeared in Cisco IOS Release 11.3.

This command replaces the **frame-relay becn-response-enable** command, which will be removed in a future Cisco IOS release. If you use the **frame-relay becn-response-enable** command in scripts, you should replace it with the **frame-relay adaptive-shaping** command.

The **frame-relay adaptive-shaping** command configures a router to respond to either BECN or ForeSight backward congestion notification messages.

Include this command in a map-class definition and apply the map class to either the main interface or to a subinterface.

Example

This example shows the map-class definition for a router configured with traffic shaping and Router ForeSight enabled.

```
interface Serial0  
  no ip address  
  encapsulation frame-relay  
  frame-relay traffic-shaping  
  frame-relay class control-A  
  map-class frame-relay control-A  
    frame-relay adaptive-shaping foresight  
  frame-relay cir 56000  
  frame-relay bc 64000
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

frame-relay traffic-shaping

map-class frame-relay

frame-relay bc

To specify the incoming or outgoing committed burst size (Bc) for a Frame Relay virtual circuit, use the **frame-relay bc** map-class configuration command. To reset the committed burst size to the default, use the **no** form of this command.

```
frame-relay bc {in | out} bits  
no frame-relay bc {in | out} bits
```

Syntax Description

in | out Incoming or outgoing; if neither is specified, both in and out values are set.

bits Committed burst size, in bits. Default is 7000 bits.

Default

7000 bits

Command Mode

Map-class configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

The Frame Relay committed burst size is specified within a map class to request a certain burst rate for the circuit. Although it is specified in bits, an implicit time factor is the sampling interval T_c on the switch, which is defined as the burst size B_c divided by the committed information rate (CIR).

Example

In the following example, the serial interface already has a basic configuration, and a map group called *bermuda* has already been defined. The example shows a map-list configuration that defines the source and destination addresses for *bermuda*, provides IP and IPX addresses, and ties the map list definition to the map class called *jamaica*. Then traffic shaping parameters are defined for the map class.

```
map-list bermuda local-addr X121 31383040703500 dest-addr X121 31383040709000  
  ip 172.21.177.26 class jamaica ietf  
  ipx 123.0000.0c07.d530 class jamaica ietf  
  
map-class frame-relay jamaica  
  frame-relay cir in 2000000  
  frame-relay mincir in 1000000  
  frame-relay cir out 15000  
  frame-relay mincir out 10000  
  frame-relay bc in 15000  
  frame-relay bc out 9600  
  frame-relay be in 10000  
  frame-relay be out 10000  
  frame-relay idle-timer 30
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

frame-relay be

frame-relay cir

frame-relay be

To set the incoming or outgoing excess burst size (Be) for a Frame Relay virtual circuit, use the **frame-relay be** map-class configuration command. To reset the excess burst size to the default, use the **no** form of this command.

```
frame-relay be {in | out} bits  
no frame-relay be {in | out} bits
```

Syntax Description

in out	Incoming or outgoing.
<i>bits</i>	Excess burst size, in bits. Default is 7000 bits.

Default

7000 bits

Command Mode

Map-class configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

The Frame Relay excess burst size is specified within a map class to request a certain burst rate for the circuit. Although it is specified in bytes, an implicit time factor is the sampling interval T_c on the switch, which is defined as the burst size B_c divided by the committed information rate (CIR).

Example

In the following example, the serial interface already has a basic configuration, and a map group called *bermuda* has already been defined. The example shows a map-list configuration that defines the source and destination addresses for *bermuda*, provides IP and IPX addresses, and ties the map list definition to the map class called *jamaica*. Then traffic shaping parameters are defined for the map class.

```
map-list bermuda local-addr X121 31383040703500 dest-addr X121 31383040709000  
  ip 172.21.177.26 class jamaica ietf  
  ipx 123.0000.0c07.d530 class jamaica ietf  
  
map-class frame-relay jamaica  
  frame-relay cir in 2000000  
  frame-relay mincir in 1000000  
  frame-relay cir out 15000  
  frame-relay mincir out 10000  
  frame-relay bc in 15000  
  frame-relay bc out 9600  
  frame-relay be in 10000  
  frame-relay be out 10000  
  frame-relay idle-timer 30
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

frame-relay bc

frame-relay cir

frame-relay becn-response-enable

This command has been replaced by the **frame-relay adaptive-shaping** command. If you use the **frame-relay becn-response-enable** command in scripts, you should replace it with the **frame-relay adaptive-shaping** command. This command will be removed from the product in a future release.

frame-relay broadcast-queue

To create a special queue for a specified interface to hold broadcast traffic that has been replicated for transmission on multiple DLCIs, use the **frame-relay broadcast-queue** interface configuration command.

frame-relay broadcast-queue *size* *byte-rate* *packet-rate*

Syntax Description

<i>size</i>	Number of packets to hold in the broadcast queue. The default is 64 packets.
<i>byte-rate</i>	Maximum number of bytes to be transmitted per second. The default is 256000 bytes per second.
<i>packet-rate</i>	Maximum number of packets to be transmitted per second. The default is 36 packets per second.

Defaults

The default values are as follows:

size—64 packets
byte-rate—256000 bytes per second
packet-rate—36 packets per second

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.3.

For purposes of the Frame Relay broadcast queue, *broadcast traffic* is defined as packets that have been replicated for transmission on multiple DLCIs. However, the broadcast traffic does not include the original routing packet or service access point (SAP) packet, which passes through the normal queue. Due to timing sensitivity, bridged broadcasts and spanning-tree packets are also sent through the normal queue.

The Frame Relay broadcast queue is managed independently of the normal interface queue. It has its own buffers and a configurable service rate.

A broadcast queue is given a maximum transmission rate (throughput) limit measured in bytes per second and packets per second. The queue is serviced to ensure that only this maximum is provided. The broadcast queue has priority when transmitting at a rate below the configured maximum, and hence has a guaranteed minimum bandwidth allocation. The two transmission rate limits are intended to avoid flooding the interface with broadcasts. The actual limit in any second is the first rate limit that is reached.

Given the transmission rate restriction, additional buffering is required to store broadcast packets. The broadcast queue is configurable to store large numbers of broadcast packets.

The queue size should be set to avoid loss of broadcast routing update packets. The exact size will depend on the protocol being used and the number of packets required for each update. To be safe, set the queue size so that one complete routing update from each protocol and for each DLCI can be stored. As a general rule, start with 20 packets per DLCI.

As a general rule, the byte rate should be less than both of the following:

- $N/4$ times the minimum remote access rate (measured in *bytes* per second), where N is the number of DLCIs to which the broadcast must be replicated
- $1/4$ the local access rate (measured in *bytes* per second)

The packet rate is not critical if you set the byte rate conservatively. As a general rule, set the packet rate assuming 250-byte packets.

Example

The following example specifies a broadcast queue to hold 80 packets, to have a maximum byte transmission rate of 240,000 bytes per second, and to have a maximum packet transmission rate of 160 packets per second:

```
frame-relay broadcast-queue 80 240000 160
```

frame-relay cir

To specify the incoming or outgoing committed information rate (CIR) for a Frame Relay virtual circuit, use the **frame-relay cir** map-class configuration command. To reset the CIR to the default, use the **no** form of this command.

```
frame-relay cir {in | out} bps  
no frame-relay cir {in | out} bps
```

Syntax Description

in out	Incoming or outgoing.
<i>bps</i>	Committed information rate (CIR), in bits per second. Default is 56000 kps.

Default

56000 bits per second

Command Mode

Map-class configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

Use this command to specify a CIR for an SVC. The specified CIR value is sent through the SETUP message to the switch, which then attempts to provision network resources to support this value.

Example

The following example sets a higher committed information rate for incoming traffic than for outgoing traffic (which is going out on a slow WAN line):

```
frame-relay cir in 2000000  
frame-relay cir out 9600
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

frame-relay bc
frame-relay be

frame-relay class

To associate a map class with an interface or subinterface, use the **frame-relay class** interface configuration command. To remove the association between in the interface or subinterface and the named map class, use the **no** form of this command.

frame-relay class *name*
no frame-relay class *name*

Syntax Description

name Name of the map class to associate with this interface or subinterface.

Default

No map class is defined.

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

This command can apply to interfaces or subinterfaces.

All relevant parameters defined in the *name* map class are inherited by each virtual circuit created on the interface or subinterface. For each virtual circuit, the precedence rules are as follows:

- 1 Use the map class associated with the virtual circuit if it exists.
- 2 If not, use the map class associated with the subinterface if the map class exists.
- 3 If not, use map class associated with interface if the map class exists.
- 4 If not, use the interface default parameters.

Example

In the following example, the map class *slow_vcs* is associated with the serial 0.1 subinterface and the map class *slow_vcs* is defined to have an outbound CIR value of 9600:

```
interface serial 0.1
  frame-relay class slow_vcs

map-class frame-relay slow_vcs
  frame-relay cir out 9600
```

If a virtual circuit exists on the serial 0.1 interface and is associated with some other map class, the parameter values of the second map class override those defined in the *slow_vc* map class for that virtual circuit.

Related Commands

You can use the master indexes or search online to find documentation of related commands.

map-class frame-relay

frame-relay custom-queue-list

To specify a custom queue to be used for the virtual circuit queuing associated with a specified map class, use the **frame-relay custom-queue-list** map-class configuration command. To remove the specified queuing from the virtual circuit and cause it to revert to the default first-come-first-served queuing, use the **no** form of this command.

```
frame-relay custom-queue-list list-number  
no frame-relay custom-queue-list list-number
```

Syntax Description

list-number List number.

Default

If this command is not entered, the default queuing is first come first served.

Command Mode

Map-class configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

Definition of the custom queue takes place in the existing manner (through **queue-list** commands).

Only one form of queuing can be associated with a particular map class; subsequent definitions overwrite previous ones.

Example

The following example configures a custom queue list for the *fast_vcs* map class:

```
map-class frame-relay fast_vcs  
  frame-relay custom-queue-list 1  
  
queue-list 1 queue 4 byte-count 100
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

map-class frame-relay

frame-relay de-group

To specify the discard eligibility (DE) group number to be used for a specified DLCI, use the **frame-relay de-group** interface configuration command. To disable a previously defined group number assigned to a specified DLCI, use the **no** form of the command with the relevant keyword and arguments.

```
frame-relay de-group group-number dcli  
no frame-relay de-group [group-number] [dcli]
```

Syntax Description

<i>group-number</i>	DE group number to apply to the specified DLCI number, in the range from 1 through 10.
<i>dcli</i>	DLCI number.

Default

No DE group is defined.

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

To disable all previously defined group numbers, use the **no** form of this command with no arguments.

This command requires that Frame Relay software be enabled.

The DE bit is not set or recognized by the Frame Relay switching code, but must be recognized and interpreted by the Frame Relay network.

Example

The following example specifies that group number 3 will be used for DLCI 170:

```
frame-relay de-group 3 170
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

frame-relay de-list

frame-relay de-list

To define a discard eligibility (DE) list specifying the packets that have the DE bit set and thus are eligible for discarding when congestion is experienced on the Frame Relay switch, use the **frame-relay de-list** global configuration command. To delete a portion of a previously defined DE list, use the **no** form of this command.

```
frame-relay de-list list-number {protocol protocol | interface type number} characteristic
no frame-relay de-list list-number {protocol protocol | interface type number} characteristic
```

Syntax Description

<i>list-number</i>	Number of the DE list.
protocol <i>protocol</i>	One of the following keywords corresponding to a supported protocol or device: arp —Address Resolution Protocol. apollo —Apollo Domain. appletalk —AppleTalk. bridge —bridging device. clns —ISO Connectionless Network Service. clns_es —CLNS end systems. clns_is —CLNS intermediate systems. compressedtcp —Compressed Transmission Control Protocol (TCP). decnet —DECnet. decnet_node —DECnet end node. decnet_router-L1 —DECnet Level 1 (intra-area) router. decnet_router-L2 —DECnet Level 2 (interarea) router. ip —Internet Protocol. ipx —Novell Internet Packet Exchange Protocol. vines —Banyan VINES. xns —Xerox Network Systems.
interface <i>type</i>	One of the following interface types: serial , null , or ethernet .
<i>number</i>	Interface number.
<i>characteristic</i>	One of the following: fragments —Fragmented IP packets. tcp port —TCP packets to or from a specified port. udp port —User Datagram Protocol (UDP) packets to or from a specified port. list access-list-number —Previously defined access list number. gt bytes —Sets the DE bit for packets larger than the specified number of bytes. lt bytes —Sets the DE bit for packets smaller than the specified number of bytes.

Default

Discard eligibility is not defined.

Command Mode

Global configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

To remove an entire DE list, use the **no** form of this command with no options and arguments.

This prioritizing feature requires that the Frame Relay network be able to interpret the DE bit as indicating which packets can be dropped first in case of congestion, or which packets are less time sensitive, or both.

When you calculate packet size, include the data packet size, the ICMP header, the IP header, and the Frame Relay encapsulation bytes. For example, count 92 bytes of data, 8 bytes of data for the ICMP header, 20 bytes for the IP header, and 4 bytes for the Frame Relay encapsulation, which equals 124 bytes.

Example

The following example specifies that IP packets larger than 512 bytes will have the DE bit set:

```
frame-relay de-list 1 protocol ip gt 512
```

frame-relay idle-timer

To specify the idle timeout interval for a switched virtual circuit, use the **frame-relay idle-timer** map-class configuration command. To reset the idle timer to its default interval, use the **no** form of this command.

frame-relay idle-timer *seconds*
no frame-relay idle-timer *seconds*

Syntax Description

seconds Time interval, in seconds, with no frames exchanged on a switched virtual circuit, after which the SVC is released. Default is 120 seconds.

Default

120 seconds

Command Mode

Map-class configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

The **frame-relay idle-timer** command applies to switched virtual circuits that are associated with the map class where the idle-timer is defined.

The idle timer must be tuned for each application. Routing protocols such as Routing Information Protocol (RIP) might keep the SVC up indefinitely because updates go out every 10 seconds.

Example

The following example defines the traffic rate and idle timer for the *fast_vcs* map class and applies those values to DLCI 100, which is associated with that map class:

```
interface serial 0
  frame-relay interface-dlci 100
  class fast_vc

map-class frame-relay fast_vcs
  frame-relay traffic-rate 56000 128000
  frame-relay idle-timer 30
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

map-class frame-relay

frame-relay interface-dlci

To assign a data link connection identifier (DLCI) to a specified Frame Relay subinterface on the router or access server, use the **frame-relay interface-dlci** interface configuration command. To remove this assignment, use the **no** form of this command.

```
frame-relay interface-dlci dlci [ietf | cisco]  
no frame-relay interface-dlci dlci [ietf | cisco]
```

```
frame-relay interface-dlci dlci [protocol ip ip-address] (for a BOOTP server only)
```

Syntax Description

<i>dlci</i>	DLCI number to be used on the specified subinterface. The following DLCI ranges are based on LMI protocol: ANSI: 16 - 991 CISCO: 16 - 1007 Q933a: 16 - 991
ietf cisco	(Optional) Encapsulation type: Internet Engineering Task Force (IETF) Frame Relay encapsulation or Cisco Frame Relay encapsulation.
protocol ip <i>ip-address</i>	(Optional) Indicates the IP address of the main interface of a new router or access server onto which a router configuration file is to be automatically installed over a Frame Relay network. Use this option only when this device will act as the BOOTP server for automatic installation over Frame Relay.

Default

No DLCI is assigned.

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

This command is typically used for subinterfaces; however, it can also be used on main interfaces. Using the **frame-relay interface-dlci** command on main interfaces will enable the use of routing protocols on interfaces that use Inverse ARP. The **frame-relay interface-dlci** command on a main interface is also valuable for assigning a specific class to a single PVC where special characteristics are desired. Subinterfaces are logical interfaces associated with a physical interface. You must specify the interface and subinterface before you can use this command to assign any DLCIs and any encapsulation or broadcast options. See the “Example” section for the sequence of commands.

This command is required for all point-to-point subinterfaces; it is also required for multipoint subinterfaces for which dynamic address resolution is enabled. It is not required for multipoint subinterfaces configured with static address mappings.

Use the **protocol ip** *ip-address* option only when this router or access server will act as the BOOTP server for autoinstallation over Frame Relay.

For more information about automatically installing router configuration files over a Frame Relay network, see the “Loading System Images and Microcode” chapter in the *Configuration Fundamentals Configuration Guide*.

Example

The following example assigns DLCI 100 to serial subinterface 5.17:

```
! Enter interface configuration and begin assignments on interface serial 5
interface serial 5
! Enter subinterface configuration by assigning subinterface 17
interface serial 5.17
! Now assign a DLCI number to subinterface 5.17
frame-relay interface-dlci 100
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

frame-relay class

frame-relay intf-type

Use the **frame-relay intf-type** interface configuration command to configure a Frame Relay switch type. Use the **no** form of this command to disable the switch.

```
frame-relay intf-type [dce | dte | nni]
no frame-relay intf-type [dce | dte | nni]
```

Syntax Description

dce	(Optional) Router or access server functions as a switch connected to a router.
dte	(Optional) Router or access server is connected to a Frame Relay network. This is the default.
nni	(Optional) Router or access server functions as a switch connected to a switch—supports Network-to-Network Interface (NNI) connections.

Default

dte

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

This command can be used only if Frame Relay switching has previously been enabled globally by use of the **frame-relay switching** command.

Example

The following example configures a data terminal equipment (DTE) switch type:

```
frame-relay switching
!
interface serial 2
frame-relay intf-type dte
```

frame-relay inverse-arp

If the Inverse Address Resolution Protocol (Inverse ARP) was previously disabled on a router or access server configured for Frame Relay, use the **frame-relay inverse-arp** interface configuration command to reenable Inverse ARP on a specified interface or subinterface. Use the **no** form of this command to disable this feature.

```
frame-relay inverse-arp [protocol] [dldci]  
no frame-relay inverse-arp [protocol] [dldci]
```

Syntax Description

<i>protocol</i>	Supported protocols: appletalk , decnet , ip , ipx , vines , and xns .
<i>dldci</i>	One of the DLCI numbers used on the interface. Acceptable numbers are integers in the range 16 through 1007.

Default

Enabled

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

To enable Inverse ARP for all protocols that were enabled before the prior **no frame-relay inverse-arp** command was issued, use the **frame-relay inverse-arp** command without arguments. To disable Inverse ARP for all protocols of an interface, use the **no frame-relay inverse-arp** command without arguments.

To enable or disable Inverse ARP for a specific protocol and DLCI pair, use both the *protocol* and *dldci* arguments. To enable or disable Inverse ARP for all protocols on a DLCI, use only the *dldci* argument. To enable or disable Inverse ARP for a protocol for all DLCIs on the specified interface or subinterface, use only the *protocol* argument.

This implementation of Inverse ARP is based on RFC 1293. It allows a router or access server running Frame Relay to discover the protocol address of a device associated with the virtual circuit.

In Frame Relay, permanent virtual circuits (PVCs) are identified by a DLCI, which is the equivalent of a hardware address. By exchanging signaling messages, a network announces a new virtual circuit, and with Inverse ARP, the protocol address at the other side of the circuit can be discovered.

The **show frame-relay map** command displays the word “dynamic” to flag virtual circuits that are created dynamically by Inverse ARP.

Example

The following example sets Inverse ARP on an interface running AppleTalk:

```
interface serial 0  
frame-relay inverse-arp appletalk 100
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

clear frame-relay-inarp
show frame-relay map

frame-relay ip tcp header-compression

To configure an interface to ensure that the associated PVC will always carry outgoing Transmission Control Protocol/Internet Protocol (TCP/IP) headers in compressed form, use the **frame-relay ip tcp header-compression** interface configuration command. To disable compression of TCP/IP packet headers on the interface, use the **no** form of this command.

```
frame-relay ip tcp header-compression [passive]  
no frame-relay ip tcp header-compression
```

Syntax Description

passive (Optional) Compresses the outgoing TCP/IP packet header only if an incoming packet had a compressed header.

Default

Active TCP/IP header compression; all outgoing TCP/IP packets are subjected to header compression.

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

This command applies to interfaces that support Frame Relay encapsulation, specifically serial ports and High-Speed Serial Interface (HSSI).

Frame Relay must be configured on the interface before this command can be used.

TCP/IP header compression and IETF encapsulation are mutually exclusive. If an interface is changed to IETF encapsulation, all encapsulation and compression characteristics are lost.

When you use this command to enable TCP/IP header compression, every IP map inherits the compression characteristics of the interface, unless header compression is explicitly rejected or modified by use of the **frame-relay map ip tcp header compression** command.

We recommend that you shut down the interface prior to changing encapsulation types. Although this is not required, shutting down the interface ensures the interface is reset for the new

Example

The following example configures serial interface 1 to use the default encapsulation (**cisco**) and passive TCP header compression:

```
interface serial 1  
encapsulation frame-relay  
frame-relay ip tcp header-compression passive
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

frame-relay map ip tcp header-compression

frame-relay lapf frmr

To resume the default setting of sending the Frame Reject (FRMR) frame at the LAPF Frame Reject procedure after having set the option of not sending the frame, use the **frame-relay frmr** command. To set the option of *not* sending the Frame Reject (FRMR) frame at the LAPF Frame Reject procedure, use the **no frame-relay lapf frmr** interface configuration command.

frame-relay frmr
no frame-relay lapf frmr

Syntax Description

This command has no keywords and arguments.

Default

Send FRMR during the Frame Reject procedure.

Command Mode

Interface configuration command

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

If the Frame Relay switch does not support FRMR, use the **no** form of this command to suppress the transmission of FRMR frames.

Example

The following example suppresses the transmission of FRMR frames:

```
no frame-relay lapf frmr
```

frame-relay lapf k

To set the Link Access Procedure for Frame Relay (LAPF) window size *k*, use the **frame-relay lapf k** interface configuration command. To reset the maximum window size *k* to the default value, use the **no** form of this command

```
frame-relay lapf k number  
no frame-relay lapf k [number]
```

Syntax Description

number Maximum number of Information frames that are either outstanding for transmission or are transmitted but unacknowledged, in the range 1 through 127. Default is 7 frames.

Default

7 frames

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

This command is used to tune Layer 2 system parameters to work well with the Frame Relay switch. Normally, you do not need to change the default setting.

Manipulation of Layer 2 parameters is not recommended if you do not know well the resulting functional change. For more information, refer to the ITU-T Q.922 specification for LAPF.

Example

The following example resets the LAPF window size *k* to the default value:

```
no frame-relay lapf k
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

frame-relay lapf t203

frame-relay lapf n200

To set the LAPF maximum retransmission count *N200*, use the **frame-relay lapf n200** interface configuration command. To reset the maximum retransmission count to the default of 3, use the **no** form of this command.

```
frame-relay lapf n200 retries  
no frame-relay lapf n200 [retries]
```

Syntax Description

<i>retries</i>	Maximum number of retransmissions of a frame. Default is 3 retransmissions.
----------------	---

Default

3 retransmissions

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

This command is used to tune Layer 2 system parameters to work well with the Frame Relay switch. Normally, you do not need to change the default setting.

Manipulation of Layer 2 parameters is not recommended if you do not know well the resulting functional change. For more information, refer to the ITU-T Q.922 specification for LAPF.

Example

The following example resets the N200 maximum retransmission count to the default value:

```
no frame-relay lapf n200
```

frame-relay lapf n201

To set the LAPF N201 value (the maximum length of the Information field of the LAPF I frame), use the **frame-relay lapf n201** interface configuration command. To reset the maximum length of the Information field to the default of 260 bytes (octets), use the **no** form of this command.

```
frame-relay lapf n201 bytes  
no frame-relay lapf n201 [bytes]
```

Syntax Description

bytes Maximum number of bytes in the Information field of the LAPF I frame, in the range 1 through 16384. Default is 260 bytes.

Default

260 bytes

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

This command is used to tune Layer 2 system parameters to work well with the Frame Relay switch. Normally, you do not need to change the default setting.

Manipulation of Layer 2 parameters is not recommended if you do not know well the resulting functional change. For more information, refer to the ITU-T Q.922 specification for LAPF.

Example

The following example resets the N201 maximum information field length to the default value:

```
no frame-relay lapf n201
```

frame-relay lapf t200

To set the LAPF retransmission timer value T200, use the **frame-relay lapf t200** interface configuration command. To reset the T200 timer to the default value of 15, use the **no** form of this command.

```
frame-relay lapf t200 tenths-of-a-second  
no frame-relay lapf t200
```

Syntax Description

<i>tenths-of-a-second</i>	Time, in tenths of a second, in the range 1 through 100. Default is 15 tenths of a second (1.5 seconds).
---------------------------	--

Default

15 tenths of a second (1.5 seconds)

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

The retransmission timer value T200 should be less than the link idle timer value T203 (using the same time unit).

This command is used to tune Layer 2 system parameters to work well with the Frame Relay switch. Normally, you do not need to change the default setting.

Manipulation of Layer 2 parameters is not recommended if you do not know well the resulting functional change. For more information, refer to the ITU-T Q.922 specification for LAPF.

Example

The following example resets the T200 timer to the default value:

```
no frame-relay lapf t200
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

frame-relay lapf t203

frame-relay lapf t203

To set the LAPF link idle timer value T203 of DLCI 0, use the **frame-relay lapf t203** interface configuration command. To reset the link idle timer to the default value, use the **no** form of this command.

```
frame-relay lapf t203 seconds  
no frame-relay lapf t203
```

Syntax Description

seconds Maximum time allowed with no frames exchanged, in the range 1 through 65535 seconds. Default is 30 seconds.

Default

30 seconds

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

The **frame-relay lapf t203** command applies to the link; that is, it applies to DLCI 0. Circuits other than DLCI 0 are not affected.

The link idle timer value T203 should be greater than the retransmission timer value T200 (using the same time unit).

This command is used to tune Layer 2 system parameters to work well with the Frame Relay switch. Normally, you do not need to change the default setting.

Manipulation of Layer 2 parameters is not recommended if you do not know well the resulting functional change. For more information, refer to the ITU-T Q.922 specification for LAPF.

Example

The following example resets the T203 idle link timer to the default value:

```
no frame-relay lapf t203
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

```
frame-relay lapf k  
frame-relay lapf t200
```

frame-relay lmi-n391dte

To set a full status polling interval, use the **frame-relay lmi-n391dte** interface configuration command. To restore the default interval value, assuming an LMI has been configured, use the **no** form of this command.

```
frame-relay lmi-n391dte keep-exchanges  
no frame-relay lmi-n391dte keep-exchanges
```

Syntax Description

<i>keep-exchanges</i>	Number of keep exchanges to be done before requesting a full status message. Acceptable value is a positive integer in the range 1 through 255.
-----------------------	---

Default

6 keep exchanges

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

Use this command when the interface is configured as data terminal equipment (DTE) or a Network-to-Network Interface (NNI) as a means of setting the full status message polling interval.

Example

In the following example, one out of every four status inquiries generated will request a full status response from the switch. The other three status inquiries will request keepalive exchanges only.

```
interface serial 0  
frame-relay intf-type DTE  
frame-relay lmi-n391dte 4
```

frame-relay lmi-n392dce

To set the DCE and the Network-to-Network Interface (NNI) error threshold, use the **frame-relay lmi-n392dce** interface configuration command. To remove the current setting, use the **no** form of this command.

```
frame-relay lmi-n392dce threshold  
no frame-relay lmi-n392dce threshold
```

Syntax Description

threshold Error threshold value. Acceptable value is a positive integer in the range 1 through 10. Default is 2 errors.

Default

2 errors

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

In Cisco's implementation, N392 errors must occur within the number defined by the N393 event count in order for the link to be declared down. Therefore, the threshold value for this command must be less than the count value defined in the **frame-relay lmi-n393dce** command.

Example

In the following example, the LMI failure threshold is set to 3. The router acts as a Frame Relay DCE or NNI switch.

```
interface serial 0  
frame-relay intf-type DCE  
frame-relay lmi-n392dce 3
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

frame-relay lmi-n393dce

frame-relay lmi-n392dte

To set the error threshold on a DTE or NNI interface, use the **frame-relay lmi-n392dte** interface configuration command. To remove the current setting, use the **no** form of this command.

```
frame-relay lmi-n392dte threshold  
no frame-relay lmi-n392dte threshold
```

Syntax Description

threshold Error threshold value. Acceptable value is a positive integer in the range 1 through 10. Default is 3 errors.

Default

3 errors

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

Example

In the following example, the LMI failure threshold is set to 3. The router acts as a Frame Relay DTE or NNI switch.

```
interface serial 0  
frame-relay intf-type DTE  
frame-relay lmi-n392dte 3
```

frame-relay lmi-n393dce

To set the DCE and NNI monitored events count, use the **frame-relay lmi-n393dce** interface configuration command. To remove the current setting, use the **no** form of this command.

```
frame-relay lmi-n393dce events  
no frame-relay lmi-n393dce events
```

Syntax Description

events Monitored events count value. Acceptable value is a positive integer in the range 1 through 10. Default is 2 events.

Default

2 events

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

This command and the **frame-relay lmi-n392dce** command define the condition that causes the link to be declared down. In Cisco's implementation, N392 errors must occur within the *events* count in order for the link to be declared down. Therefore, the *events* value defined in this command must be greater than the threshold value defined in the **frame-relay lmi-n392dce** command.

Example

In the following example, the LMI monitored events count is set to 3. The router acts as a Frame Relay DCE or NNI switch.

```
interface serial 0  
frame-relay intf-type DCE  
frame-relay lmi-n393dce 3
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

frame-relay lmi-n392dce

frame-relay lmi-n393dte

To set the monitored event count on a DTE or NNI interface, use the **frame-relay lmi-n393dte** interface configuration command. To remove the current setting, use the **no** form of this command.

frame-relay lmi-n393dte *events*
no frame-relay lmi-n393dte *events*

Syntax Description

events Monitored events count value. Acceptable value is a positive integer in the range 1 through 10. Default is 4 events.

Default

4 events

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

Example

In the following example, the LMI monitored events count is set to 3. The router acts as a Frame Relay DTE or NNI switch.

```
interface serial 0
frame-relay intf-type DTE
frame-relay lmi-n393dte 3
```

frame-relay lmi-t392dce

To set the polling verification timer on a DCE or NNI interface, use the **frame-relay lmi-t392dce** interface configuration command. To remove the current setting, use the **no** form of this command.

```
frame-relay lmi-t392dce seconds  
no frame-relay lmi-t392dce seconds
```

Syntax Description

seconds Polling verification timer value, in seconds. Acceptable value is a positive integer in the range 5 through 30. Default is 15 seconds.

Default

15 seconds

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

The value for the timer must be greater than the DTE or NNI keepalive timer.

Example

The following example indicates a polling verification timer on a DCE or NNI interface set to 20 seconds:

```
interface serial 3  
frame-relay intf-type DCE  
frame-relay lmi-t392dce 20
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

keepalive

frame-relay lmi-type

To select the Local Management Interface (LMI) type, use the **frame-relay lmi-type** interface configuration command. To return to the default LMI type, use the **no** form of this command.

```
frame-relay lmi-type {ansi | cisco | q933a}  
no frame-relay lmi-type {ansi | q933a}
```

Syntax Description

ansi	Annex D defined by American National Standards Institute (ANSI) standard T1.617.
cisco	LMI type defined jointly by Cisco and three other companies.
q933a	ITU-T Q.933 Annex A.

Note The International Telecommunication Union Telecommunication Standardization Sector (ITU-T) carries out the functions of the former Consultative Committee for International Telegraph and Telephone (CCITT).

Default

LMI autosense is active and determines the LMI type by communicating with the switch.

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

Cisco's implementation of Frame Relay supports three LMI types: Cisco, ANSI Annex D, and ITU-T Q.933 Annex A.

The LMI type is set on a per-interface basis and is shown in the output of the **show interfaces EXEC** command.

If you want to deactivate LMI autosense, use this command and the **keepalive** command to configure the LMI. For more information about LMI autosense and configuring the LMI, see the "Configuring Frame Relay" chapter in the *Wide-Area Networking Configuration Guide*.

Example

The following is an example of the commands you might enter to configure an interface for the ANSI Annex D LMI type:

```
interface Serial1  
encapsulation frame-relay  
frame-relay lmi-type ansi  
keepalive 15
```

frame-relay local-dlci

To set the source DLCI for use when the LMI is not supported, use the **frame-relay local-dlci** interface configuration command. To remove the DLCI number, use the **no** form of this command.

frame-relay local-dlci *number*
no frame-relay local-dlci

Syntax Description

number Local (source) DLCI number to be used.

Default

No source DLCI is set.

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

If LMI is supported and the multicast information element is present, the network server sets its local DLCI based on information provided via the LMI.

Note The **frame-relay local-dlci** command is provided mainly to allow testing of the Frame Relay encapsulation in a setting where two servers are connected back-to-back. This command is not required in a live Frame Relay network.

Example

The following example specifies 100 as the local DLCI:

```
interface serial 4
frame-relay local-dlci 100
```

frame-relay map

To define the mapping between a destination protocol address and the DLCI used to connect to the destination address, use the **frame-relay map** interface configuration command. Use the **no** form of this command to delete the map entry.

```
frame-relay map protocol protocol-address dlcI [broadcast] [ietf | cisco]
    [payload-compress {packet-by-packet | frf9 stac [hardware-options] } ]
no frame-relay map protocol protocol-address
```

Syntax Description

<i>protocol</i>	Supported protocol, bridging, or logical link control keywords: appletalk , decnet , dlsW , ip , ipx , llc2 , rsrb , vines and xns .
<i>protocol-address</i>	Destination protocol address.
<i>dlci</i>	DLCI number used to connect to the specified protocol address on the interface.
broadcast	(Optional) Forwards broadcasts to this address when multicast is not enabled (see the frame-relay multicast-dlci command for more information about multicasts). This keyword also simplifies the configuration of Open Shortest Path First (OSPF) (see the “Usage Guidelines” section for more detail).
ietf	(Optional) Internet Engineering Task Force (IETF) form of Frame Relay encapsulation. Used when the router or access server is connected to another vendor’s equipment across a Frame Relay network.
cisco	(Optional) Cisco encapsulation method.
payload-compress packet-by-packet	(Optional) Packet-by-packet payload compression using the Stacker method.
payload-compress frf9 stac	(Optional) Enables FRF.9 compression using the Stacker method. <ul style="list-style-type: none"> • If the router contains a compression service adapter (CSA), compression is performed in the CSA hardware (hardware compression). • If the CSA is not available, compression is performed in the software installed on the VIP2 (distributed compression). • If the VIP2 is not available, compression is performed in the router’s main processor (software compression).

*hardware-options***distributed**

(Optional) Specifies that compression is implemented in the software that is installed in a VIP2. If the VIP2 is not available, compression is performed in the router's main processor (software compression). This option applies only to the Cisco 7500 series.

software

(Optional) Specifies that compression is implemented in the Cisco IOS software installed in the router's main processor.

csa csa_number

(Optional) Specifies the CSA to use for a particular interface. This option applies only to Cisco 7200 series routers.

Default

No mapping is defined.

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

The **payload-compress frf9 stac** keyword first appeared in Cisco IOS Release 11.3.

There can be many DLCIs known by a router or access server that can send data to many different places, but they are all multiplexed over one physical link. The Frame Relay map defines the logical connection between a specific protocol and address pair and the correct DLCI.

The optional **ietf** and **cisco** keywords allow flexibility in the configuration. If no keywords are specified, the map inherits the attributes set with the **encapsulation frame-relay** command. You can use the **frame-relay map** command to specify bridging that uses a Cisco encapsulation. You can also use the encapsulation options to specify that, for example, all interfaces use IETF encapsulation except one, which needs the original Cisco encapsulation method and can be configured through use of the **cisco** keyword with the **frame-relay map** command.

Packet-by-packet compression is Cisco-proprietary and will not interoperate with routers of other manufacturers.

You can disable payload compression by entering the **no frame-relay map payload** command and then entering the **frame-relay map** command again with one of the other encapsulation keywords (**cisco** or **ietf**).

Use the **frame-relay map** command to enable or disable payload compression on multipoint interfaces. Use the **frame-relay payload-compress** command to enable or disable payload compression on point-to-point interfaces.

We recommend that you shut down the interface prior to changing encapsulation types. Although this is not required, shutting down the interface ensures the interface is reset for the new encapsulation.

The **broadcast** keyword provides two functions: it forwards broadcasts when multicasting is not enabled, and it simplifies the configuration of OSPF for nonbroadcast networks that will use Frame Relay.

The **broadcast** keyword might also be required for some routing protocols—for example, AppleTalk—that depend on regular routing table updates, especially when the router at the remote end is waiting for a routing update packet to arrive before adding the route.

By requiring selection of a designated router, OSPF treats a nonbroadcast, multiaccess network such as Frame Relay in much the same way as it treats a broadcast network. In previous releases, this required manual assignment in the OSPF configuration using the **neighbor interface** router command. When the **frame-relay map** command is included in the configuration with the **broadcast** keyword, and the **ip ospf network** command (with the **broadcast** keyword) is configured, there is no need to configure any neighbors manually. OSPF will now automatically run over the Frame Relay network as a broadcast network. (Refer to the **ip ospf network** interface command for more detail.)

Note The OSPF broadcast mechanism assumes that IP class D addresses are never used for regular traffic over Frame Relay.

Examples

The following example maps the destination IP address 172.16.123.1 to DLCI 100:

```
interface serial 0
  frame-relay map IP 172.16.123.1 100 broadcast
```

OSPF will use DLCI 100 to broadcast updates.

The example shows FRF.9 compression configuration using the **frame-relay map** command.

```
!
interface Serial2/0/1
  ip address 172.16.1.4 255.255.255.0
  no ip route-cache
  encapsulation frame-relay IETF
  no keepalive
  shutdown
  frame-relay map ip 172.16.1.1 105 IETF payload-compression FRF9 stac
!
```

The following example shows IETF encapsulation on the interface, and stun traffic configured to use Cisco encapsulation:

```
!
interface Serial0
  no ip address
  no ip mroute-cache
  encapsulation frame-relay IETF
  no ip route-cache
  no keepalive
  no fair-queue
  clockrate 64000
  no frame-relay inverse-arp IP 100
  no frame-relay inverse-arp NOVELL 100
  no frame-relay inverse-arp APPLETALK 100
  no frame-relay inverse-arp XNS 100
  no frame-relay inverse-arp DECNET 100
  no frame-relay inverse-arp VINES 100
  frame-relay local-dlci 100
  frame-relay map stun 100 CISCO
!
```

```
interface Serial1
  no ip address
  no ip mroute-cache
  encapsulation stun
  no ip route-cache
  stun group 123
  stun sdlc-role primary
  sdlc address 62
  stun route address 62 interface Serial0 dlci 100 4 local-ack
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

frame-relay payload-compress

frame-relay map bridge

To specify that broadcasts are to be forwarded during bridging, use the **frame-relay map bridge** interface configuration command. Use the **no** form of this command to delete the map entry.

```
frame-relay map bridge dcli [broadcast] [ietf]  
no frame-relay map bridge dcli
```

Syntax Description

<i>dcli</i>	DLCI number to be used for bridging on the specified interface or subinterface.
broadcast	(Optional) Broadcasts are forwarded when multicast is not enabled.
ietf	(Optional) IETF form of Frame Relay encapsulation. Use when the router or access server is connected to another vendor's equipment across a Frame Relay network.

Default

No broadcasts are forwarded.

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

Examples

The following example uses DLCI 144 for bridging:

```
interface serial 0  
frame-relay map bridge 144 broadcast
```

The following example sets up separate point-to-point links over a subinterface and runs transparent bridging over it:

```
interface serial 0  
bridge-group 1  
encapsulation frame-relay  
interface serial 0.1  
bridge-group 1  
frame-relay map bridge 42 broadcast  
interface serial 0.2  
bridge-group 1  
frame-relay map bridge 64 broadcast  
interface serial 0.3  
bridge-group 1  
frame-relay map bridge 73 broadcast
```

DLCI 42 is used as the link; see the section “Frame Relay Configuration Examples” in the *Wide-Area Networking Configuration Guide* for more examples of subinterfaces.

frame-relay map clns

To forward broadcasts when ISO CLNS is used for routing, use the **frame-relay map clns** interface configuration command. Use the **no** form of this interface configuration command to delete the map entry.

```
frame-relay map clns dci [broadcast]  
no frame-relay map clns dci
```

Syntax Description

dci DLCI number to which CLNS broadcasts are forwarded on the specified interface.

broadcast (Optional) Broadcasts are forwarded when multicast is not enabled.

Default

No broadcasts are forwarded.

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

Example

The following example uses DLCI 125 for ISO CLNS routing:

```
interface serial 0  
frame-relay map clns 125 broadcast
```

frame-relay map ip tcp header-compression

To assign header compression characteristics to an IP map that differ from the compression characteristics of the interface with which the IP map is associated, use the **frame-relay map ip tcp header-compression** interface configuration command. To remove the IP map, use the **no** form of this command.

```

frame-relay map ip ip-address dlc [broadcast] [cisco | ietf] [nocompress]
    tcp header-compression {active | passive}
no frame-relay map ip ip-address dlc
    
```

Syntax Description

<i>ip-address</i>	IP address.
<i>dlci</i>	DLCI number.
broadcast	(Optional) Forwards broadcasts to the specified IP address.
cisco	(Optional) Uses Cisco's proprietary encapsulation. This is the default.
ietf	(Optional) Uses RFC 1490 encapsulation. No TCP/IP header compression is done if IETF encapsulation is chosen for the IP map or the associated interface.
nocompress	(Optional) Disables TCP/IP header compression for this map.
active	Compresses the header of every outgoing TCP/IP packet.
passive	Compresses the header of an outgoing TCP/IP packet only if an incoming TCP/IP packet had a compressed header.

Default

The default encapsulation is **cisco**.

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

To disable TCP/IP header compression on the IP map, use the **nocompress** form of the command.

IP maps inherit the compression characteristics of the associated interface unless this command is used to provide different characteristics. This command can also reconfigure an IP map that existed before TCP header compression was configured on the associated interface.

When IP maps at both ends of a connection inherit passive compression, the connection will never transfer compressed traffic because neither side will generate a packet with a compressed header.

If you change the encapsulation characteristics of the interface to IETF, you lose the TCP header compression configuration of the associated IP map.

The command **frame-relay map ip *ip-address* *dcli* tcp header-compression active** can also be entered as **frame-relay map ip *ip-address* *dcli* active tcp header-compression**.

We recommend that you shut down the interface prior to changing encapsulation types. Although this is not required, shutting down the interface ensures the interface is reset for the new encapsulation.

Example

The following example illustrates a command sequence configuring an IP map associated with serial interface 1 to enable active TCP/IP header compression:

```
interface serial 1
 encapsulation frame-relay
 ip address 131.108.177.170 255.255.255.0
 frame-relay map ip 131.108.177.180 190 cisco tcp header-compression active
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

frame-relay ip tcp header-compression

frame-relay mincir

To specify the minimum acceptable incoming or outgoing committed information rate (CIR) for a Frame Relay virtual circuit, use the **frame-relay mincir** map-class configuration command. To reset the minimum acceptable CIR to the default, use the **no** form of this command.

```
frame-relay mincir {in | out} bps
```

Syntax Description

in out	Incoming or outgoing.
<i>bps</i>	Committed information rate, in bits per second. Default is 56000 bps.

Default

56000 bps

Command Mode

Map-class configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

Rate values greater than 2048 must be entered with trailing zeros. For example, 2048000 and 5120000.

The network uses the **mincir** value when allocating resources for the SVC. If the **mincir** value cannot be supported, the call is cleared.

Example

The following example defines the peak and average traffic rate, the minimum CIR, and the idle timer for the *fast_vcs* map class and applies those values to DLCI 100, which is associated with that map class:

```
interface serial 0
frame-relay interface-dlci 100
class fast_vc

map-class frame-relay fast_vc
frame-relay traffic-rate 56000 128000
frame-relay idle-timer 30
frame-relay mincir out 48000
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

map-class frame-relay

frame-relay multicast-dlci

Use the **frame-relay multicast-dlci** interface configuration command to define the DLCI to be used for multicasts. Use the **no** form of this command to remove the multicast group.

frame-relay multicast-dlci *number*
no frame-relay multicast-dlci

Syntax Description

number Multicast DLCI.

Default

No DLCI is defined.

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

Use this command when the multicast facility is not supported. Network transmissions (packets) sent to a multicast DLCI are delivered to all network servers defined as members of the multicast group.

Note The **frame-relay multicast-dlci** command is provided mainly to allow testing of the Frame Relay encapsulation in a setting where two servers are connected back-to-back. This command is not required in a live Frame Relay network.

Example

The following example specifies 1022 as the multicast DLCI:

```
interface serial 0
frame-relay multicast-dlci 1022
```

frame-relay payload-compress

Use the **frame-relay payload-compress** interface configuration command to enable Stacker payload compression on a specified point-to-point interface or subinterface, To disable payload compression on a specified point-to-point interface or subinterface, use the **no** form of this command.

```
frame-relay payload-compress { packet-by-packet | frf9 stac [hardware-options ] }
no frame-relay payload-compress { packet-by-packet | frf9 stac }
```

Syntax Description

packet-by-packet Packet-by-packet payload compression, using the Stacker method.

frf9 stac (Optional) Enables FRF.9 compression using the Stacker method.

- If the router contains a compression service adapter (CSA), compression is performed in the CSA hardware (hardware compression).
- If the CSA is not available, compression is performed in the software installed on the VIP2 (distributed compression).
- If the VIP2 is not available, compression is performed in the router’s main processor (software compression).

hardware-options

distributed
 (Optional) Specifies that compression is implemented in the software that is installed in a VIP2. If the VIP2 is not available, compression is performed in the router’s main processor (software compression). This option applies only to the Cisco 7500 series.

software
 (Optional) Specifies that compression is implemented in the Cisco IOS software installed in the router’s main processor.

csa csa_number
 (Optional) Specifies the CSA to use for a particular interface. This option applies only to Cisco 7200 series routers.

Default
 Disabled

Command Mode
 Subinterface configuration

Usage Guidelines

The **frame-relay payload-compress** command first appeared in Cisco IOS Release 11.0.
 The **packet-by-packet** keyword first appeared in Cisco IOS Release 11.2.
 The **frf9 stac** keyword first appeared in Cisco IOS Release 11.3.

Use the **frame-relay payload-compress** command to enable or disable payload compression on a point-to-point interface or subinterface. Use the **frame-relay map** command to enable or disable payload compression on a multipoint interface or subinterface.

We recommend that you shut down the interface prior to changing encapsulation types. Although this is not required, shutting down the interface ensures the interface is reset for the new encapsulation.

Example

This example shows FRF.9 compression configuration for subinterfaces.

```
!  
interface Serial2/0/0  
  no ip address  
  no ip route-cache  
  encapsulation frame-relay  
  ip route-cache distributed  
  no keepalive  
  shutdown  
!  
interface Serial2/0/0.500 point-to-point  
  ip address 172.16.1.4 255.255.255.0  
  no cdp enable  
  frame-relay interface-dlci 500 IETF  
  frame-relay payload-compression FRF9 stac  
!
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

frame-relay map

frame-relay priority-dlci-group

To prioritize multiple DLCIs based on the type of Frame Relay traffic, use the **frame-relay priority-dlci-group** interface configuration command. Associate the DLCIs to their perspective groups and define their priority levels. This command is used for multiple DLCIs, where the source and destination endpoints are the same (parallel paths). This command should not be used on a main interface, or point-to-point subinterface, where only a single DLCI is configured.

frame-relay priority-dlci-group *group-number high-dlci medium-dlci normal-dlci low-dlci*

Syntax Description

<i>group-number</i>	Specific group number.
<i>high-dlci</i>	DLCI that is to have highest priority level.
<i>medium-dlci</i>	DLCI that is to have medium priority level.
<i>normal-dlci</i>	DLCI that is to have normal priority level.
<i>low-dlci</i>	DLCI that is to have lowest priority level.

Default

Disabled

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.0.

This command is applied at the interface or subinterface level.

Levels in descending order are high, medium, normal, and low.

This command allows you to define different DLCIs for different categories of traffic based on traffic priorities. This command does not itself define priority queuing, but it can be used in conjunction with priority queuing.

A global priority list must be defined, and the associated DLCIs must already be applied to the configuration before you enable this command.

A DLCI can only be affiliated with a single priority-group; however, there can be multiple groups per interface or subinterface.

You must configure the *high-priority* and *medium-priority* DLCI values. If you do not explicitly associate a DLCI for the *normal-dlci* and *low-dlci* priority levels, the last DLCI specified in the command line is used as the value of the remaining arguments. For example, the following two commands are equivalent:

```
frame-relay priority-dlci-group 1 40 50
frame-relay priority-dlci-group 1 40 50 50 50
```

When you configure static map entries using **frame-relay map** commands or use Inverse ARP, the high-level DLCI is the only DLCI that is mapped. In the example, DLCI 40 is defined as having the highest priority. Therefore, DLCI 40 is the only DLCI that should be included in the **frame-relay map** command. DLCI 50 should not be included in a **frame-relay map** command.

Examples

The following example shows the **frame-relay priority-dlci-group** command configured on a main interface with a static Frame Relay map entry. Note that DLCI 40 is the high-priority DLCI as defined in the **frame-relay priority-dlci-group** command and the only DLCI included in the **frame-relay map** command.

```
interface serial 1
 ip address 172.21.177.1 255.255.255.0
 encapsulation frame-relay
 frame-relay priority-dlci-group 1 40
 frame-relay map ip 172.21.177.2 40 broadcast
```

The following example shows the **frame-relay priority-dlci-group** command configured on subinterfaces where multiple priority groups are defined. DLCI 40 is the high-priority DLCI in group 1, and DLCI 80 is the high-priority DLCI in group 2.

```
interface Serial3
 no ip address
 encapsulation frame-relay
 !
 interface Serial3.2 multipoint
 ip address 172.21.177.1 255.255.255.0
 frame-relay interface-dlci 40
 frame-relay priority-dlci-group 1 40
 !
 interface Serial3.3 multipoint
 ip address 131.108.177.180 255.255.255.0
 frame-relay priority-dlci-group 2 80 90 100 100
 frame-relay interface-dlci 80
 !
 interface Serial 4
 no ip address
 encapsulation frame-relay
 !
 interface serial4.1 multipoint
 ip address 172.16.1.1 255.255.255.0
 frame-relay priority-dlci-group 3 200 210 300 300
 frame-relay priority-dlci-group 4 400 410 410 410
 frame-relay interface-dlci 200
 frame-relay interface-dlci 400
 !
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

frame-relay map
priority-list

frame-relay priority-group

To assign a priority queue to virtual circuits associated with a map class, use the **frame-relay priority-group** map-class configuration command. To remove the specified queuing from the virtual circuit and cause it to revert to the default first-come-first-served queuing, use the **no** form of this command.

```
frame-relay priority-group list-number  
no frame-relay priority-group list-number
```

Syntax Description

list-number Priority-list number to be associated with the specified map class.

Default

If this command is not entered, the default is first-come-first-served queuing.

Command Mode

Map-class configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

Definition of the priority queue takes place in the existing manner (through **priority-list** commands).

Because only one form of queuing can be associated with a particular map class, subsequent definitions overwrite previous ones.

Example

The following example configures a map class for a specified DLCI, specifies a priority list for the map class, and then defines the priority list:

```
interface serial 0  
  encapsulation frame-relay  
  frame-relay interface-dlci 100  
  class pri_vc  
  
  map-class frame-relay pri_vc  
  frame-relay priority-group 1  
  
priority-list 1 protocol ip high
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

class (virtual circuit configuration)
frame-relay interface-dlci
map-class frame-relay
priority-list

frame-relay qos-autosense

Use the **frame-relay qos-autosense** interface configuration command to enable Enhanced Local Management Interface on the Cisco router. Use the **no** form of this command to disable Enhanced Local Management Interface on the Cisco router.

frame-relay qos-autosense
no frame-relay qos-autosense

Syntax

This command has no arguments or keywords.

Default

Disabled

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

Enhanced Local Management Interface must be configured on both the Cisco router and the Cisco StrataCom switch.

Traffic shaping is optional with Enhanced Local Management Interface. Configure traffic shaping on the interface if you want QOS information to be used by the router for traffic rate enforcement.

Example

This configuration example shows a Frame Relay interface enabled to receive Enhanced Local Management Interface messages from the Cisco StrataCom switch that is also configured with Enhanced Local Management Interface enabled. Traffic shaping is also configured on the interface for traffic rate enforcement and dynamic rate throttling. This allows the router to adjust its output rate based on congestion information it receives from the switch.

```
interface serial0
  no ip address
  encapsulation frame-relay
  frame-relay lmi-type ansi
  frame-relay traffic-shaping
  frame-relay qos-autosense

interface serial0.1 point-to-point
  no ip address
  frame-relay interface-dlci 101
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

encapsulation frame-relay
frame-relay adaptive-shaping
frame-relay traffic-shaping
show frame-relay qos-autosense

frame-relay route

Use the **frame-relay route** interface configuration command to specify the static route for PVC switching. Use the **no** form of this command to remove a static route.

```
frame-relay route in-dlci out-interface out-dlci  
no frame-relay route in-dlci out-interface out-dlci
```

Syntax Description

<i>in-dlci</i>	DLCI on which the packet is received on the interface.
<i>out-interface</i>	Interface that the router or access server uses to transmit the packet.
<i>out-dlci</i>	DLCI that the router or access server uses to transmit the packet over the specified <i>out-interface</i> .

Default

No static route is specified.

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

Examples

The following example configures a static route that allows packets in DLCI 100 and transmits packets out over DLCI 200 on interface serial 2:

```
frame-relay route 100 interface Serial2 200
```

The following example illustrates the commands you enter for a complete configuration that includes two static routes for PVC switching between interface serial 1 and interface serial 2:

```
interface Serial1  
no ip address  
encapsulation frame-relay  
keepalive 15  
frame-relay lmi-type ansi  
frame-relay intf-type dce  
frame-relay route 100 interface Serial2 200  
frame-relay route 101 interface Serial2 201  
clockrate 2000000
```

frame-relay svc

To enable Frame Relay SVC operation on the specified interface, use the **frame-relay svc** interface configuration command. To disable SVC operation on the specified interface, use the **no** form of this command

frame-relay svc
no frame-relay svc

Syntax Description

This command has no keywords and arguments.

Default

Disabled

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

SVC operation can be enabled at the interface level only. Once it is enabled at the interface level, it is enabled on all subinterfaces on the interface. One signaling channel, DLCI 0, is set up for the interface, and all SVCs are controlled from the physical interface.

The first use of this command on the router starts all SVC-related processes on the router. If they are already up and running because SVCs are enabled on another interface, no additional action is taken. These processes are not removed once they are created.

Example

The following example enables Frame Relay SVC operation on serial interface 0 and starts SVC-related processes on the router:

```
interface serial 0
ip address 172.68.3.5 255.255.255.0
encapsulation frame-relay
frame-relay lmi-type q933a
frame-relay svc
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

interface serial
ip address
encapsulation frame-relay
frame-relay lmi-type

frame-relay switching

Use the **frame-relay switching** global configuration command to enable PVC switching on a Frame Relay DCE or an NNI. Use the **no** form of this command to disable switching.

frame-relay switching
no frame-relay switching

Syntax Description

This command has no arguments or keywords.

Default

Disabled

Command Mode

Global configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

You must add this command to the configuration file before configuring the routes.

Example

The following example shows the simple command that is entered in the configuration file before the Frame Relay configuration commands to enable switching:

```
frame-relay switching
```

frame-relay traffic-rate

To configure all the traffic shaping characteristics of a virtual circuit in a single command, use the **frame-relay traffic-rate** map-class configuration command. To remove the specified traffic shaping from the map class, use the **no** form of this command.

```
frame-relay traffic-rate average [peak]  
no frame-relay traffic-rate average [peak]
```

Syntax Description

<i>average</i>	Average rate, in bits per second; equivalent to specifying the contracted CIR.
<i>peak</i>	(Optional) Peak rate, in bits per second; equivalent to $CIR + Be/Tc = CIR (1 + Be/Bc) = CIR + EIR$.

Default

If the peak rate is omitted, the default value used is the average rate configured (CIR).

Command Mode

Map-class configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

For SVCs, the configured *peak* and *average* rates are converted to the equivalent CIR, excess burst size (*Be*), and committed burst size (*Bc*) values for use by SVC signaling.

This command lets you configure all the traffic shaping characteristics of a virtual circuit in a single command. Using it is simpler than the alternative of entering the three subcommands **frame-relay cir out**, **frame-relay be out** and **frame-relay bc out**, but offers slightly less flexibility.

Example

The following example associates a map class with specified DLCI and then sets a traffic rate for the map-class (and thus for the DLCI):

```
interface serial 0  
  frame-relay interface-dlci 100  
    class fast_vc  
  
map-class frame-relay fast_vc  
  frame-relay traffic-rate 56000 128000
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

```
frame-relay bc out  
frame-relay be out  
frame-relay cir out
```

frame-relay traffic-shaping

To enable both traffic shaping and per-virtual circuit queuing for all PVCs and SVCs on a Frame Relay interface, use the **frame-relay traffic-shaping** interface configuration command. To disable traffic shaping and per-virtual circuit queuing, use the **no** form of this command.

frame-relay traffic-shaping
no frame-relay traffic-shaping

Syntax Description

This command has no keywords and arguments.

Default

Disabled

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

For virtual circuits for which no specific traffic shaping or queuing parameters are specified, a set of default values are used. The default queuing is performed on a first-come-first-served basis.

Frame Relay traffic shaping is not effective for Layer 2 PVC switching using the **frame-relay route** command.

Example

The following example enables both traffic shaping and per-virtual circuit queuing:

```
frame-relay traffic-shaping
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

frame-relay class
frame-relay custom-queue-list
frame-relay priority-group
frame-relay traffic-rate
map-class frame-relay

keepalive

To enable the Local Management Interface (LMI) mechanism for serial lines using Frame Relay encapsulation, use the **keepalive** interface configuration command. Use the **no** form of this command to disable this capability.

keepalive *number*
no keepalive

Syntax Description

number Number of seconds that defines the keepalive interval. The interval must be set as a positive integer that is less than the interval set on the switch; see the **frame-relay lmi-t392dce** command description. Default is 10 seconds.

Default

10 seconds

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

The **keepalive** command enables the keepalive sequence, which is part of the Local Management Interface (LMI) protocol.

Note When booting from a network server over Frame Relay, you might need to disable keepalives.

Example

The following example sets the keepalive timer on the server for a period that is two or three seconds faster (shorter interval) than the interval set on the keepalive timer of the Frame Relay switch. The difference in keepalive intervals ensures proper synchronization between the Cisco server and the Frame Relay switch.

```
interface serial 3
keepalive 8
```

Related Commands

You can use the master indexes or search online to find documentation of related commands

frame-relay lmi-t392dce

map-class frame-relay

To specify a map class to define quality of service (QOS) values for an SVC, use the **map-class frame-relay** global configuration command.

```
map-class frame-relay map-class-name
```

Syntax Description

frame-relay	Keyword specifying the type of map class.
<i>map-class-name</i>	Name of this map class.

Default

Disabled. No default name is defined.

Command Mode

Global configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

After you specify the named map class, you can specify the QOS parameters—such as incoming and outgoing CIR, committed burst rate, excess burst rate, and the idle timer—for the map class.

To specify the protocol-and-address combination to which the QOS parameters are to be applied, associate this map class with the static maps under a map list.

Example

The following example specifies a map class called *hawaii* and defines three QOS parameters for it. The *hawaii* map class is associated with a protocol-and-address static map defined under the **map-list** command.

```
map-list bermuda source-addr E164 123456 dest-addr E164 654321
  ip 131.108.177.100 class hawaii
  appletalk 1000.2 class hawaii

map-class frame-relay hawaii
  frame-relay cir in 2000000
  frame-relay cir out 56000
  frame-relay be out 9000
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

frame-relay bc
frame-relay be
frame-relay cir
frame-relay idle-timer

map-group

To associate a map list with a specific interface, use the **map-group** interface configuration command.

```
map-group group-name
```

Syntax Description

group-name Name used in a **map-list** command.

Default

Disabled. No map group name is defined.

Command Mode

Interface configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

A map-group association with an interface is required for SVC operation. In addition, a map list must be configured.

The **map-group** command applies to the interface or subinterface on which it is configured. The associated E.164 or X.121 address is defined by the **map-list** command, and the associated protocol addresses are defined by using the **class** command under the **map-list** command.

Example

The following example configures a physical interface, applies a map group to the physical interface, and then defines the map group:

```
interface serial 0
ip address 172.10.8.6
encapsulation frame-relay
map-group bermuda
frame-relay lmi-type q933a
frame-relay svc

map-list bermuda source-addr E164 123456 dest-addr E164 654321
ip 131.108.177.100 class hawaii
appletalk 1000.2 class rainbow
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

class (map-list configuration)

map-list

map-list

To specify a map group and link it to a local E.164 or X.121 source address and a remote E.164 or X.121 destination address for Frame Relay SVCs, use the **map-list** global configuration command. To delete a previous map-group link, use the **no** form of this command.

```
map-list map-group-name source-addr {e164 | x121} source-address dest-addr {e164 | x121}
destination-address
no map-list map-group-name source-addr {e164 | x121} source-address dest-addr
{e164 | x121} destination-address
```

Syntax Description

<i>map-group-name</i>	Name of the map group. This map group must be associated with a physical interface.
source-addr { e164 x121 }	Type of source address.
<i>source-address</i>	Address of the type specified (E.164 or X.121).
dest-addr { e164 x121 }	Type of destination address.
<i>destination-address</i>	Address of the type specified (E.164 or X.121).

Default

Disabled. No default list name and no default address type are defined.

Command Mode

Global configuration

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

Use the **map-class** command and its subcommands to define quality of service (QoS) parameters—such as incoming and outgoing CIR, committed burst rate, excess burst rate, and the idle timer—for the static maps defined under a map list.

Each SVC needs to use a source and destination number, in much the same way that a public telephone network needs to use source and destination numbers. These numbers allow the network to route calls from a specific source to a specific destination. This specification is done through map lists.

Based on switch configuration, addressing can take either of two forms: E.164 or X.121.

An X.121 number is 14 digits long and has the following form:

```
Z CC P NNNNNNNNNNN
```

Table 9 describes the codes in an X.121 number form.

Table 9 X.121 Numbers

Code	Meaning	Value
Z	Zone code	3 for North America
C	Country code	10–16 for the United States
P	Public data network (PDN) code	Provided by the PDN
N	10-digit number	Set by the network for the specific destination

An E.164 number has a variable length; the maximum length is 15 digits. An E.164 number has the fields shown in Figure 2 and described in Table 10.

Figure 2 E.164 Address Format




Table 10 E.164 Address Field Descriptions

Field	Description
Country Code	Can be 1, 2, or 3 digits long. Some current values are the following: <ul style="list-style-type: none"> • Code 1—United States of America • Code 44—United Kingdom • Code 61—Australia
National Destination Code + Subscriber Number	Referred to as the National ISDN number; the maximum length is 12, 13, or 14 based on the country code.
ISDN Subaddress	Identifies one of many devices at the termination point. An ISDN subaddress is similar to an extension on a PBX.

Example

In the following SVC example, if IP or AppleTalk triggers the call, the SVC is set up with the QOS parameters defined within the class *hawaii*. An SVC triggered by either protocol results in two SVC maps, one for IP and one for AppleTalk. Two maps are set up because these protocol-and-address combinations are heading for the same destination, as defined by the **dest-addr** keyword and the values following it in the **map-list** command.

```
map-list bermuda source-addr E164 123456 dest-addr E164 654321
ip 131.108.177.100 class hawaii
appletalk 1000.2 class hawaii
```

Related Commands

You can use the master indexes or search online to find documentation of related commands.

class (map-list configuration)

map-class frame-relay

show frame-relay ip tcp header-compression

To display statistics and TCP/IP header compression information for the interface, use the **show frame-relay ip tcp header-compression EXEC** command.

show frame-relay ip tcp header-compression

Syntax Description

This command has no arguments or keywords.

Command Mode

EXEC

Usage Guidelines

This command first appeared in Cisco IOS Release 10.3.

Sample Display

The following is sample output from the **show frame-relay ip tcp header-compression** command:

```
Router# show frame-relay ip tcp header-compression

DLCI 200          Link/Destination info: ip 131.108.177.200
Interface Serial0:
Rcvd:      40 total, 36 compressed, 0 errors
           0 dropped, 0 buffer copies, 0 buffer failures
Sent:      0 total, 0 compressed
           0 bytes saved, 0 bytes sent
Connect:   16 rx slots, 16 tx slots, 0 long searches, 0 misses, 0% hit ratio
           Five minute miss rate 0 misses/sec, 0 max misses/sec
```

Table 11 describes the fields shown in the display.

Table 11 Show Frame-Relay IP TCP Header-Compression Field Descriptions

Field	Description
Rcvd	
total	Sum of compressed and uncompressed packets received.
compressed	Number of compressed packets received.
errors	Number of errors caused by errors in the header fields (version, total length, or IP checksum).
dropped	Number of packets discarded. Seen only after line errors.
buffer copies	Number of times that a new buffer was needed to put the uncompressed packet in.
buffer failures	Number of times that a new buffer was needed but was not obtained.

Table 11 Show Frame-Relay IP TCP Header-Compression Field Descriptions (Continued)

Field	Description
Sent	
total	Sum of compressed and uncompressed packets sent.
compressed	Number of compressed packets sent.
bytes saved	Number of bytes reduced because of the compression.
bytes sent	Actual number of bytes transmitted.
Connect	
rx slots, tx slots	Number of states allowed over one TCP connection. A state is recognized by a source address, a destination address, and an IP header length.
long searches	Number of times that the connection ID in the incoming packet was not the same as the previous one that was processed.
misses	Number of times that a matching entry was not found within the connection table and a new entry had to be entered.
hit ratio	Percentage of times that a matching entry was found in the compression tables and the header was compressed.
Five minute miss rate	Miss rate computed over the most recent 5 minutes and the maximum per-second miss rate during that period.

show frame-relay lapf

To display information about the status of the internals of Frame Relay Layer 2 (LAPF) if SVCs are configured, use the **show frame-relay lapf** EXEC command.

show frame-relay lapf

Syntax Description

This command has no keywords and arguments.

Command Mode

EXEC

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

Sample Display

The following is sample output from the **show frame-relay lapf** command.

```
raven# show frame-relay lapf

Interface = Serial1 (up), LAPF state = TEI_ASSIGNED (down)
SVC disabled, link down cause = LMI down, #link-reset = 0
T200 = 1.5 sec., T203 = 30 sec., N200 = 3, k = 7, N201 = 260
I xmt = 0, I rcv = 0, I reXmt = 0, I queued = 0
I xmt dropped = 0, I rcv dropped = 0, Rcv pak dropped = 0
RR xmt = 0, RR rcv = 0, RNR xmt = 0, RNR rcv = 0
REJ xmt = 0, REJ rcv = 0, FRMR xmt = 0, FRMR rcv = 0
DM xmt = 0, DM rcv = 0, DISC xmt = 0, DISC rcv = 0
SABME xmt = 0, SABME rcv = 0, UA xmt = 0, UA rcv = 0
V(S) = 0, V(A) = 0, V(R) = 0, N(S) = 0, N(R) = 0
Xmt FRMR at Frame Reject
```

Table 12 describes significant fields in this output.

Table 12 Show Frame-Relay LAPF Field Descriptions

Field	Description
Interface	Identifies the interface and indicates the line status (up, down, administratively down)
LAPF state	A LAPF state of MULTIPLE FRAME ESTABLISHED or RIMER_RECOVERY indicates that Layer 2 is functional. Others, including TEI_ASSIGNED, AWAITING_ESTABLISHMENT, and AWAITING_RELEASE indicate that Layer 2 is not functional.
SVC disabled	Indicates whether SVCs are enabled or disabled.
link down cause	Indicates the reason that the link is down. For example, N200 error, memory out, peer disconnect, LMI down, line down, and SVC disabled. Many other causes are described in the Q.922 specification.
#link-reset	Number of times the Layer 2 link has been reset.
T200 , T203, N200 , k, N201	Values of Layer 2 parameters.

Table 12 Show Frame-Relay LAPF Field Descriptions (Continued)

Field	Description
I xmt, I rcv, I reXmt, I queued	Number of I frames transmitted, received, retransmitted, and queued for transmission, respectively.
I xmt dropped	Number of transmitted I frames that were dropped.
I rcv dropped	Number of I frames received over DLCI 0 that were dropped.
Rcv pak dropped	Number of received packets that were dropped.
RR xmt, RR rcv	Number of RR frames transmitted; number of RR frames received.
RNR xmt, RNR rcv	Number of RNR frames transmitted; number of RNR frames received.
REJ xmt, REJ rcv	Number of REJ frames transmitted; number of REJ frames received.
FRMR xmt, FRMR rcv	Number of FRMR frames transmitted; number of FRMR frames received.
DM xmt, DM rcv	Number of DM frames transmitted; number of DM frames received.
DISC xmt, DISC rcv	Number of DISC frames transmitted; number of DISC frames received.
SABME xmt, SABME rcv	Number of SABME frames transmitted; number of SABME frames received.
UA xmt, UA rcv	Number of UA frames transmitted; number of UA frames received.
V(S) 0, V(A) 0, V(R) 0, N(S) 0, N(R) 0	Layer 2 sequence numbers.
Xmt FRMR at Frame Reject	Indicates whether the FRMR frame is transmitted at Frame Reject.

show frame-relay lmi

To display statistics about the Local Management Interface (LMI), use the **show frame-relay lmi EXEC** command.

show frame-relay lmi [*type number*]

Syntax Description

type (Optional) Interface type; it must be serial.
number (Optional) Interface number.

Command Mode

EXEC

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

Enter the command without arguments to obtain statistics about all Frame Relay interfaces.

Sample Displays

The following is sample output from the **show frame-relay lmi** command when the interface is a DTE:

```
Router# show frame-relay lmi

LMI Statistics for interface Serial1 (Frame Relay DTE) LMI TYPE = ANSI
  Invalid Unnumbered info 0          Invalid Prot Disc 0
  Invalid dummy Call Ref 0          Invalid Msg Type 0
  Invalid Status Message 0          Invalid Lock Shift 0
  Invalid Information ID 0          Invalid Report IE Len 0
  Invalid Report Request 0          Invalid Keep IE Len 0
  Num Status Enq. Sent 9            Num Status msgs Rcvd 0
  Num Update Status Rcvd 0          Num Status Timeouts 9
```

The following is sample output from the **show frame-relay lmi** command when the interface is an NNI:

```
Router# show frame-relay lmi

LMI Statistics for interface Serial3 (Frame Relay NNI) LMI TYPE = CISCO
  Invalid Unnumbered info 0          Invalid Prot Disc 0
  Invalid dummy Call Ref 0          Invalid Msg Type 0
  Invalid Status Message 0          Invalid Lock Shift 0
  Invalid Information ID 0          Invalid Report IE Len 0
  Invalid Report Request 0          Invalid Keep IE Len 0
  Num Status Enq. Rcvd 11           Num Status msgs Sent 11
  Num Update Status Rcvd 0          Num St Enq. Timeouts 0
  Num Status Enq. Sent 10           Num Status msgs Rcvd 10
  Num Update Status Sent 0          Num Status Timeouts 0
```

Table 13 describes significant fields shown in the output.

Table 13 Show Frame-Relay LMI Field Descriptions

Field	Description
LMI Statistics	Signaling or LMI specification: CISCO, ANSI, or ITU-T.
Invalid Unnumbered info	Number of received LMI messages with invalid unnumbered information field.
Invalid Prot Disc	Number of received LMI messages with invalid protocol discriminator.
Invalid dummy Call Ref	Number of received LMI messages with invalid dummy call references.
Invalid Msg Type	Number of received LMI messages with invalid message type.
Invalid Status Message	Number of received LMI messages with invalid status message.
Invalid Lock Shift	Number of received LMI messages with invalid lock shift type.
Invalid Information ID	Number of received LMI messages with invalid information identifier.
Invalid Report IE Len	Number of received LMI messages with invalid Report IE Length.
Invalid Report Request	Number of received LMI messages with invalid Report Request.
Invalid Keep IE Len	Number of received LMI messages with invalid Keep IE Length.
Num Status Enq. Sent	Number of LMI status inquiry messages sent.
Num Status Msgs Rcvd	Number of LMI status messages received.
Num Update Status Rcvd	Number of LMI asynchronous update status messages received.
Num Status Timeouts	Number of times the status message was not received within the keepalive time value.
Num Status Enq. Rcvd	Number of LMI status enquiry messages received.
Num Status Msgs Sent	Number of LMI status messages sent.
Num Status Enq. Timeouts	Number of times the status enquiry message was not received within the T392 DCE timer value.
Num Update Status Sent	Number of LMI asynchronous update status messages sent.

show frame-relay map

To display the current map entries and information about the connections, use the **show frame-relay map EXEC** command.

show frame-relay map

Syntax Description

This command has no arguments or keywords.

Command Mode

EXEC

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

Sample Display

The following is sample output from the **show frame-relay map** command:

```
Router# show frame-relay map

Serial 1 (administratively down): ip 131.108.177.177
dlci 177 (0xB1,0x2C10), static,
broadcast,
CISCO
TCP/IP Header Compression (inherited), passive (inherited)
```

Table 14 describes significant fields shown in the display.

Table 14 Show Frame-Relay Map Field Descriptions

Field	Description
Serial 1 (administratively down)	Identifies a Frame Relay interface and its status (up or down).
ip 131.108.177.177	Destination IP address.
dlci 177 (0xB1,0x2C10)	DLCI that identifies the logical connection being used to reach this interface. This value is displayed in three ways: its decimal value (177), its hexadecimal value (0xB1), and its value as it would appear on the wire (0x2C10).
static	Indicates whether this is a static or dynamic entry.
CISCO	Indicates the encapsulation type for this map; either CISCO or IETF.
TCP/IP Header Compression (inherited), passive (inherited)	Indicates whether the TCP/IP header compression characteristics were inherited from the interface or were explicitly configured for the IP map.

Related Commands

You can use the master indexes or search online to find documentation of related commands.

show frame-relay pvc

show frame-relay pvc

To display statistics about PVCs for Frame Relay interfaces, use the **show frame-relay pvc EXEC** command.

```
show frame-relay pvc [type number [dlci]]
```

Syntax Description

<i>type</i>	(Optional) Interface type.
<i>number</i>	(Optional) Interface number.
<i>dlci</i>	(Optional) One of the specific DLCI numbers used on the interface. Statistics for the specified PVC display when a DLCI is also specified.

Command Mode

EXEC

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

Statistics Reporting

To obtain statistics about PVCs on all Frame Relay interfaces, use this command with no arguments.

Per VC counters are not incremented at all when either autonomous or SSE switching is configured; therefore, PVC values will be inaccurate if either switching method is used.

DCE, DTE, and Logical Interfaces

When the interface is configured as a DCE and the DLCI usage is SWITCHED, the value displayed in the PVC STATUS field is determined by the status of outgoing interfaces (up or down) and the status of the outgoing PVC. The status of the outgoing PVC is updated in the Local Management Interface (LMI) message exchange. PVCs terminated on a DCE interface use the status of the interface to set the PVC STATUS.

In the case of a hybrid DTE switch, the PVC status on the DTE side is determined by the PVC status reported by the external Frame Relay network through the LMI.

If the outgoing interface is a tunnel, the PVC status is determined by what is learned from the tunnel.

Traffic Shaping

Congestion control mechanisms are currently not supported, but the switch passes forward explicit congestion notification (FECN) bits, backward explicit congestion notification (BECN) bits, and discard eligibility (DE) bits unchanged from entry to exit points in the network.

If an LMI status report indicates that a PVC is not active, then it is marked as inactive. A PVC is marked as deleted if it is not listed in a periodic LMI status message.

Sample Displays

The following is sample output from the **show frame-relay pvc** command:

```
Router# show frame-relay pvc
      PVC Statistics for interface Serial (Frame Relay DCE)

DLCI = 22, DLCI USAGE = LOCAL, PVC STATUS = ACTIVE, INTERFACE = Serial3/1:1.1

input pkts 9output pkts 300008in bytes 2754
out bytes 161802283dropped pkts 0in FECN pkts 0
in BECN pkts 1out FECN pkts 0out BECN pkts 0
in DE pkts 0out DE pkts 0
outbcast pkts 0outbcast bytes 0
  Shaping adapts to ForeSight   in ForeSight signals 1304
  pvc create time 1d05h, last time pvc status changed 00:11:00
```

If the circuit is configured for shaping to adapt to BECN, it is indicated in the display:

```
Shaping adapts to BECN
```

If traffic shaping on the circuit does not adapt to either BECN or ForeSight, nothing extra shows:

```
DLCI = 100, DLCI USAGE = SWITCHED, PVC STATUS = ACTIVE

input pkts 0output pkts 0in bytes 0
out bytes 0dropped pkts 0in FECN pkts 0
in BECN pkts 0out FECN pkts 0out BECN pkts 0
in DE pkts 0out DE pkts 0
outbcast pkts 0outbcast bytes 0
pvc create time 0:03:03 last time pvc status changed 0:03:03
  Num Pkts Switched 0
```

The following is sample output from the **show frame-relay pvc** command for multipoint subinterfaces. The output displays both the subinterface number and the DLCI. This display is the same whether the PVC is configured for static or dynamic addressing.

```
DLCI = 300, DLCI USAGE = LOCAL, PVC STATUS = ACTIVE, INTERFACE = Serial0.103

input pkts 10output pkts 7in bytes 6222
out bytes 6034dropped pkts 0in FECN pkts 0
in BECN pkts 0out FECN pkts 0out BECN pkts 0
in DE pkts 0out DE pkts 0
outbcast pkts 0outbcast bytes 0
pvc create time 0:13:11 last time pvc status changed 0:11:46

DLCI = 400, DLCI USAGE = LOCAL, PVC STATUS = ACTIVE, INTERFACE = Serial0.104

input pkts 20output pkts 8in bytes 5624
out bytes 5222dropped pkts 0in FECN pkts 0
in BECN pkts 0out FECN pkts 0out BECN pkts 0
in DE pkts 0out DE pkts 0
outbcast pkts 0outbcast bytes 0
pvc create time 0:03:57 last time pvc status changed 0:03:48
```

Table 15 describes the fields shown in the displays.

Table 15 Show Frame-Relay PVC Field Descriptions

Field	Description
DLCI	One of the data link connection identifier (DLCI) numbers for the PVC.
DLCI USAGE	Lists SWITCHED when the router or access server is used as a switch, or LOCAL when the router or access server is used as a DTE.
PVC STATUS	Status of the PVC: ACTIVE, INACTIVE, or DELETED.
INTERFACE = Serial0.103	Specific subinterface associated with this DLCI.
input pkts	Number of packets received on this PVC.
output pkts	Number of packets sent on this PVC.
in bytes	Number of bytes received.
out bytes	Number of bytes sent.
dropped pkts	Number of packets dropped by the router at Frame Relay level because an active outbound DLCI was not found
in FECN pkts	Number of packets received with the FECN bit set.
in BECN pkts	Number of packets received with the BECN bit set.
out FECN pkts	Number of packets sent with the FECN bit set.
out BECN pkts	Number of packets sent with the BECN bit set.
in DE pkts	Number of DE packets received.
out DE pkts	Number of DE packets sent.
outcast pkts	Number of output broadcast packets.
outcast bytes	Number of output broadcast bytes.
pvc create time	Time the PVC was created.
last time pvc status changed	Time the PVC changed status (active to inactive).
Num Pkts Switched	Number of packets switched within the router or access server; this PVC is the source PVC.

This sample output shows output from the **show frame-relay pvc** command with no traffic shaping configured on the interface.

```

Router# show frame-relay pvc

PVC Statistics for interface Serial11 (Frame Relay DTE)

DLCI = 100, DLCI USAGE = LOCAL, PVC STATUS = ACTIVE, INTERFACE = Serial11

input pkts 0          output pkts 0          in bytes 0
out bytes 0          dropped pkts 0          in FECN pkts 0
in BECN pkts 0        out FECN pkts 0        out BECN pkts 0
in DE pkts 0          out DE pkts 0
out bcast pkts 0      out bcast bytes 0
    
```

This sample output shows output from the **show frame-relay pvc** command when traffic shaping is in effect:

```
Router# show frame-relay pvc

PVC Statistics for interface Serial1 (Frame Relay DTE)

DLCI = 101, DLCI USAGE = LOCAL, PVC STATUS = ACTIVE, INTERFACE = Serial1
input pkts 14046    output pkts 4339    in bytes 960362
  out bytes 675566    dropped pkts 0      in FECN pkts 0
  in BECN pkts 148    out FECN pkts 0     out BECN pkts 0
  in DE pkts 44      out DE pkts 0
  out bcast pkts 4034      out bcast bytes 427346
pvc create time 11:59:29, last time pvc status changed 11:59:29
CIR 64000          BC 8000           BE 1600          limit 2000       interval 125
mincir 32000       byte incremen 500           BECN response yes
pkts 9776          bytes 838676      pkts delayed 0   bytes delayed 0
shaping inactive

List  Queue  Args
1     4      byte-count 100
  Output queues: (queue #: size/max/drops)
    0: 0/20/0 1: 0/20/0 2: 0/20/0 3: 0/20/0 4: 0/20/0
    5: 0/20/0 6: 0/20/0 7: 0/20/0 8: 0/20/0 9: 0/20/0
   10: 0/20/0 11: 0/20/0 12: 0/20/0 13: 0/20/0 14: 0/20/0
   15: 0/20/0 16: 0/20/0
```

Table 16 describes the additional fields shown in the display when traffic shaping is in effect.

Table 16 Show Frame-Relay PVC Field Descriptions with Traffic Shaping in Effect

Field	Description
CIR	Current committed information rate (CIR), in bits per second.
BC	Current committed burst size, in bits.
BE	Current excess burst size, in bits.
limit	Maximum number of bytes transmitted per internal interval. (excess plus sustained)
interval	Interval being used internally interval being used internally (may be smaller than the interval derived from Bc/CIR; this happens when the router determines that traffic flow will be more stable with a smaller configured interval)
mincir	Minimum committed information rate (CIR) for the PVC.
incremen	Number of bytes that will be sustained per internal interval
BECN response	Frame Relay has BECN Adaptation configured
List Queue Args	Identifier and parameter values for a custom queue list defined for the PVC. These identifiers and values correspond to the command queue-list 1 queue 4 byte-count 100 .
Output queues	Output queues used for the PVC, with the current size, the maximum size, and the number of dropped frames shown for each queue.

The packet and byte values are counts for the number for the number of packets and bytes that have gone through the traffic shaping system.

show frame-relay qos-autosense

Use the **show frame-relay qos-autosense EXEC** command to show the QOS values sensed from the switch.

show frame-relay qos-autosense [interface number]

Syntax Description

interface number (Optional) Indicates the number of the physical interface for which you want to display QOS information.

Command Mode

EXEC

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

Sample Displays

This sample display shows the output of the **show frame-relay qos-autosense** command when Enhanced Local Management Interface is enabled.

```
router# show frame-relay qos-autosense

ELMI information for interface Serial1
  Connected to switch:FRSM-4T1  Platform:AXIS  Vendor:cisco
  (Time elapsed since last update 00:00:30)

DLCI = 100
OUT:  CIR 64000      BC 50000      BE 25000      FMIF 4497
IN:   CIR 32000      BC 25000      BE 12500      FMIF 4497
Priority 0      (Time elapsed since last update 00:00:12)

DLCI = 200
OUT:  CIR 128000     BC 50000      BE 5100       FMIF 4497
IN:   CIR Unknown   BC Unknown    BE Unknown    FMIF 4497
Priority 0      (Time elapsed since last update 00:00:13)
```

Table 17 describes the significant fields in the output display.

Table 17 Show Frame-Relay QOS-Autosense Field Descriptions

Field	Description
ELMI information for interface Serial1	Label indicating the port for which the status is being displayed. it also displays the name, platform, and vendor information about the switch.
DLCI	Value that indicates which PVC statistics are being reported
Out:	Values reporting settings configured for the outgoing Committed Information Rate, Burst Size, Excess Burst Size, and FMIF.

Table 17 Show Frame-Relay QOS-Autosense Field Descriptions (Continued)

Field	Description
In:	Values reporting settings configured for the incoming Committed Information Rate, Burst Size, Excess Burst Size, and FMIF
Priority	Value indicating priority level (currently not used).

Related Commands

You can use the master indexes or search online to find documentation of related commands.

frame-relay qos-autosense

show frame-relay pvc

show frame-relay route

Use the **show frame-relay route** EXEC command to display all configured Frame Relay routes, along with their status.

show frame-relay route

Syntax Description

This command has no arguments or keywords.

Command Mode

EXEC

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

Sample Display

The following is sample output from the **show frame-relay route** command:

```
Router# show frame-relay route

      Input Intf      Input DlcI      Output Intf      Output DlcI      Status
      Serial1        100             Serial2          200              active
      Serial1        101             Serial2          201              active
      Serial1        102             Serial2          202              active
      Serial1        103             Serial3          203              inactive
      Serial2        200             Serial1          100              active
      Serial2        201             Serial1          101              active
      Serial2        202             Serial1          102              active
      Serial3        203             Serial1          103              inactive
```

Table 18 describes significant fields shown in the output.

Table 18 Show Frame-Relay Route Field Descriptions

Field	Description
Input Intf	Input interface and unit.
Input DlcI	Input DLCI number.
Output Intf	Output interface and unit.
Output DlcI	Output DLCI number.
Status	Status of the connection: active or inactive.

show frame-relay svc maplist

To display all the SVCs under a specified map list, use the **show frame-relay svc maplist EXEC** command.

show frame-relay svc maplist *name*

Syntax Description

name Name of the map list.

Command Mode

EXEC

Usage Guidelines

This command first appeared in Cisco IOS Release 11.2.

Sample Output

The following example shows, first, the configuration of the map-list *shank* and, second, the corresponding output of the **show frame-relay svc maplist** command. The following lines show the configuration:

```
map-list shank local-addr X121 87654321 dest-addr X121 12345678
 ip 172.21.177.26 class shank ietf
 ipx 123.0000.0c07.d530 class shank ietf
!
map-class frame-relay shank
 frame-relay incir 192000
 frame-relay min-incir 19200
 frame-relay outcir 192000
 frame-relay min-outcir 19200
 frame-relay inubr(bytes) 15000
 frame-relay outubr(bytes) 15000
```

The following lines show the output of the **show frame-relay svc maplist** command for the preceding configuration.

```
Router# show frame-relay svc maplist shank
Map List : shank
Local Address : 87654321          Type: X121
Destination Address: 12345678    Type: X121

Protocol : ip 172.21.177.26
Protocol : ipx 123.0000.0c07.d530
Encapsulation : IETF
Call Reference : 1                DLCI : 501

Configured Frame Mode Information Field Size :
Incoming : 1500                   Outgoing : 1500
Frame Mode Information Field Size :
Incoming : 1500                   Outgoing : 1500
Configured Committed Information Rate (CIR) :
Incoming : 192 * (10**3)          Outgoing : 192 * (10**3)
Committed Information Rate (CIR) :
Incoming : 192 * (10**3)          Outgoing : 192 * (10**3)
Configured Minimum Acceptable CIR :
```

show frame-relay svc maplist

```

Incoming : 192 * (10**2)                Outgoing : 192 * (10**2)
Minimum Acceptable CIR :
Incoming : 0 * (10**0)                  Outgoing : 0 * (10**0)
Configured Committed Burst Rate (bytes) :
Incoming : 15000                        Outgoing : 15000
Committed Burst Rate (bytes) :
Incoming : 15000                        Outgoing : 15000
Configured Excess Burst Rate (bytes) :
Incoming : 16000                        Outgoing : 1200
Excess Burst Rate (bytes) :
Incoming : 16000                        Outgoing : 1200

```

Table 19 describes significant fields in the output.

Table 19 Show Frame-Relay SVC Maplist Field Descriptions

Field	Description
Map List	Name of the configured map-list.
Local Address...Type	Configured source address type (E.164 or X.121) for the call.
Destination Address...Type	Configured destination address type (E.164 or X.121) for the call.
Protocol : ip ... Protocol : ipx ...	Destination protocol addresses configured for the map-list.
Encapsulation	Configured encapsulation type (CISCO or IETF) for the specified destination protocol address.
Call Reference	Call identifier.
DLCI : 501	Number assigned by the switch as the DLCI for the call.
Configured Frame Mode Information Field Size: Incoming : Outgoing :	Lines that contrast the configured and actual frame mode information field size settings used for the calls.
Frame Mode Information Field Size : Incoming : 1500 Outgoing : 1500	
Configured Committed Information Rate (CIR) : Incoming : 192 * (10**3) Outgoing : 192 * (10**3)	Lines that contrast the configured and actual committed information rate (CIR) settings used for the calls.
Committed Information Rate (CIR) : Incoming : 192 * (10**3) Outgoing : 192 * (10**3)	
Configured Minimum Acceptable CIR : Incoming : 192 * (10**2) Outgoing : 192 * (10**2)	Lines that contrast the configured and actual minimum acceptable CIR settings used for the calls.
Minimum Acceptable CIR : Incoming : 0 * (10**0) Outgoing : 0 * (10**0)	

Table 19 Show Frame-Relay SVC Maplist Field Descriptions (Continued)

Field	Description
Configured Committed Burst Rate (bytes) : Incoming : 15000 Outgoing : 15000	Lines that contrast the configured and actual committed burst rate (bytes) settings used for the calls.
Committed Burst Rate (bytes) : Incoming : 15000 Outgoing : 15000	
Configured Excess Burst Rate (bytes) : Incoming : 16000 Outgoing : 1200	Lines that contrast the configured and actual excess burst rate (bytes) settings used for the calls.
Excess Burst Rate (bytes) : Incoming : 16000 Outgoing : 1200	

Related Commands

You can use the master indexes or search online to find documentation of related commands.

class (map-list configuration)**frame-relay bc****frame-relay cir****frame-relay mincir****map-class frame-relay****map-list**

show frame-relay traffic

To display the global Frame Relay statistics since the last reload, use the **show frame-relay traffic** EXEC command.

show frame-relay traffic

Syntax Description

This command has no arguments or keywords.

Command Mode

EXEC

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

Sample Display

The following is sample output from the **show frame-relay traffic** command:

```
Router# show frame-relay traffic

Frame Relay statistics:
ARP requests sent 14, ARP replies sent 0
ARP request recvd 0, ARP replies recvd 10
```

Information shown in the display is self-explanatory.

show interfaces serial

Use the **show interfaces serial** EXEC command to display information about a serial interface. When using the Frame Relay encapsulation, use the **show interfaces serial** command to display information about the multicast DLCI, the DLCIs used on the interface, and the DLCI used for the Local Management Interface (LMI).

show interfaces serial *number*

Syntax Description

number Interface number.

Command Mode

EXEC

Usage Guidelines

This command first appeared in Cisco IOS Release 10.0.

Use this command to determine the status of the Frame Relay link. This display also indicates Layer 2 status if SVCs are configured.

Sample Displays

The following is sample output from the **show interfaces serial** command for a serial interface with the CISCO LMI enabled:

```
Router# show interface serial 1

Serial1 is up, line protocol is down
Hardware is MCI Serial
Internet address is 131.108.174.48, subnet mask is 255.255.255.0
MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 246/255, load 1/255
Encapsulation FRAME-RELAY, loopback not set, keepalive set (10 sec)
LMI enq sent 2, LMI stat recvd 0, LMI upd recvd 0, DTE LMI down
LMI enq recvd 266, LMI stat sent 264, LMI upd sent 0
LMI DLCI 1023 LMI type is CISCO frame relay DTE
Last input 0:00:04, output 0:00:02, output hang never
Last clearing of "show interface" counters 0:44:32
Output queue 0/40, 0 drops; input queue 0/75, 0 drops
Five minute input rate 0 bits/sec, 0 packets/sec
Five minute output rate 0 bits/sec, 0 packets/sec
 307 packets input, 6615 bytes, 0 no buffer
  Received 0 broadcasts, 0 runts, 0 giants
  0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
  0 input packets with dribble condition detected
 266 packets output, 3810 bytes, 0 underruns
  0 output errors, 0 collisions, 2 interface resets, 0 restarts
 178 carrier transitions
```

The display shows the statistics for the LMI as the number of status inquiry messages sent (*LMI enq* and *LMI stat sent*), the number of status messages received (*LMI enq* and *LMI stat recvd*), and the number of status updates received (*LMI upd recvd*). See the *Frame Relay Interface* specification for additional explanations of this output.

The following is sample output from the **show interfaces serial** command for a serial interface with the ANSI LMI enabled:

```
Router# show interface serial 1
Serial1 is up, line protocol is down
Hardware is MCI Serial
Internet address is 131.108.174.48, subnet mask is 255.255.255.0
MTU 1500 bytes, BW 1544 Kbit, DLY 20000 usec, rely 249/255, load 1/255
Encapsulation FRAME-RELAY, loopback not set, keepalive set (10 sec)
LMI enq sent 4, LMI stat recvd 0, LMI upd recvd 0, DTE LMI down
LMI enq recvd 268, LMI stat sent 264, LMI upd sent 0
LMI DLCI 0 LMI type is ANSI Annex D frame relay DTE
Last input 0:00:09, output 0:00:07, output hang never
Last clearing of "show interface" counters 0:44:57
Output queue 0/40, 0 drops; input queue 0/75, 0 drops
Five minute input rate 0 bits/sec, 0 packets/sec
Five minute output rate 0 bits/sec, 0 packets/sec
309 packets input, 6641 bytes, 0 no buffer
Received 0 broadcasts, 0 runts, 0 giants
0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
0 input packets with dribble condition detected
268 packets output, 3836 bytes, 0 underruns
0 output errors, 0 collisions, 2 interface resets, 0 restarts
180 carrier transitions
```

Each display provides statistics and information about the type of LMI configured, either *CISCO* for the Cisco LMI type, *ANSI* for the ANSI T1.617 Annex D LMI type, or *ITU-T* for the ITU-T Q.933 Annex A LMI type. See the **show interfaces** command for a description of the other fields displayed by this command.

Related Commands

You can use the master indexes or search online to find documentation of related commands.

show interfaces