



## GPRS GGSN Command Set

---

GPRS is a new service designed for Global System for Mobile Communications (GSM) networks. This chapter provides a reference list for all of the GPRS GGSN commands that are documented in this book.

Use the commands in this chapter to configure and monitor the GPRS feature in the Cisco IOS software, which allows you to configure a Cisco Systems router to function as a Gateway GPRS Support Node (GGSN). For GPRS configuration tasks and examples, refer to the *Cisco IOS Mobile Wireless Configuration Guide*.

The following GPRS GGSN commands are documented in this book:

- [access-mode](#), page 2
- [access-point](#), page 4
- [access-point-name](#), page 5
- [access-violation](#), page 6
- [clear gprs charging cdr](#), page 7
- [clear gprs gtp pdp-context](#), page 9
- [clear gprs gtp statistics](#), page 11
- [dhcp-gateway-address](#), page 12
- [dhcp-server](#), page 14
- [encapsulation gtp](#), page 16
- [gprs access-point-list](#), page 17
- [gprs canonical-qos best-effort bandwidth-factor](#), page 19
- [gprs canonical-qos gsn-resource-factor](#), page 20
- [gprs canonical-qos map tos](#), page 21
- [gprs canonical-qos premium mean-throughput-deviation](#), page 23
- [gprs charging cdr-aggregation-limit](#), page 47
- [gprs charging cdr-option local-record-sequence-number](#), page 48
- [gprs charging cdr-option node-id](#), page 49
- [gprs charging cdr-option no-partial-cdr-generation](#), page 50
- [gprs charging cdr-option packet-count](#), page 52
- [gprs charging cdr-option served-msisdn](#), page 53
- [gprs charging cg-path-requests](#), page 54

- [gprs charging container volume-threshold, page 55](#)
- [gprs charging disable, page 57](#)
- [gprs charging flow-control private-echo, page 58](#)
- [gprs charging map data tos, page 60](#)
- [gprs charging packet-queue-size, page 62](#)
- [gprs charging path-protocol, page 64](#)
- [gprs charging server-switch-timer, page 66](#)
- [gprs charging tariff-time, page 67](#)
- [gprs charging transfer interval, page 68](#)
- [gprs default charging-gateway, page 70](#)
- [gprs default dhcp-server, page 72](#)
- [gprs default ip-address-pool, page 74](#)
- [gprs default radius-server, page 76](#)
- [gprs fastswitch, page 25](#)
- [gprs gtp error-indication throttle, page 26](#)
- [gprs gtp map signalling tos, page 27](#)
- [gprs gtp n3-buffer-size, page 28](#)
- [gprs gtp n3-requests, page 29](#)
- [gprs gtp path-echo-interval, page 30](#)
- [gprs gtp t3-response, page 31](#)
- [gprs gtp t3-tunnel, page 32](#)
- [gprs idle-pdp-context purge-timer, page 33](#)
- [gprs maximum-pdp-context-allowed, page 34](#)
- [gprs qos default-response requested, page 35](#)
- [gprs qos map canonical-qos, page 36](#)
- [gprs radius msisdn first-byte, page 37](#)
- [ip-access-group, page 38](#)
- [ip-address-pool, page 39](#)
- [msisdn suppression, page 41](#)
- [protocol-type, page 43](#)
- [radius-server, page 44](#)
- [service gprs, page 46](#)
- [show gprs access-point, page 78](#)
- [show gprs charging parameters, page 81](#)
- [show gprs charging statistics, page 84](#)
- [show gprs gtp parameters, page 86](#)
- [show gprs gtp path, page 88](#)

- [show gprs gtp pdp-context](#), page 89
- [show gprs gtp statistics](#), page 94
- [show gprs gtp status](#), page 97
- [subscription-required](#), page 99
- [use-interface](#), page 100

