



# ATM Conditional Debug Support

---

**First Published: May 07, 2004**

**Last Updated: November 25, 2009**

Most ATM debugging commands are implemented either at the system level or at the interface level. The ATM Conditional Debug Support feature allows debugging to be limited specifically to an ATM interface, to a virtual channel identifier (VCI), or to a virtual path identifier/virtual channel identifier (VPI/VCI) pair, through use of the **debug condition interface** command.

## Finding Feature Information

For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the “[Feature Information for ATM Conditional Debug Support](#)” section on page 7.

Use Cisco Feature Navigator to find information about platform support and Cisco IOS XE software image support. To access Cisco Feature Navigator, go to <http://www.cisco.com/go/cfn>. An account on Cisco.com is not required.

## Contents

- [Prerequisites for ATM Conditional Debug Support, page 2](#)
- [Restrictions for ATM Conditional Debug Support, page 2](#)
- [Information About ATM Conditional Debug Support, page 2](#)
- [How to Configure ATM Conditional Debugging on ATM Interfaces, page 3](#)
- [Configuration Examples for ATM Conditional Debug Support, page 4](#)
- [Additional References, page 5](#)
- [Feature Information for ATM Conditional Debug Support, page 7](#)



---

**Americas Headquarters:**

**Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA**

## Prerequisites for ATM Conditional Debug Support

One or more ATM-encapsulated interfaces must be enabled, and one or more of the following **debug** commands must be enabled, to use the ATM Conditional Debug Support feature:

- **debug atm arp**
- **debug atm counters**
- **debug atm errors**
- **debug atm events**
- **debug atm oam**
- **debug atm packet**
- **debug atm state**

## Restrictions for ATM Conditional Debug Support

- Only the ATM debugging commands listed in the “[Prerequisites for ATM Conditional Debug Support](#)” section on page 2 can use the ATM Conditional Debug Support feature.
- Conditional debugging for virtual circuits (VCs) can be enabled only for permanent virtual circuits (PVCs). Switched virtual circuits (SVCs) are not supported.

## Information About ATM Conditional Debug Support

- [ATM Debugging Extended to the Virtual Circuit Level](#)

### ATM Debugging Extended to the Virtual Circuit Level

The ATM **debug** commands are implemented either at the interface level or at the system level. The **debug** command output at these levels is not very useful when the user is interested in a particular set of VCs.

The Cisco IOS XE software has the infrastructure to support conditional debugging based on various filters that are set at the command-line interface (CLI). The conditional debugging infrastructure can filter out or suppress unwanted messages from the output of any existing **debug** command. The ATM Conditional Debug Support feature extends this infrastructure to support conditional debugging at the ATM VC level by extending the **debug condition interface** command with keywords that address specific virtual circuits. This feature can be implemented on top of conventional debugging, so that backward compatibility is ensured and at the same time applications can take advantage of conditional debugging where required. However, the extended **debug condition interface** command has priority over the older version of the command; that is, a debug condition setting using the older **debug condition interface** command will be discarded as soon as a new debug condition is enabled on a virtual circuit.

# How to Configure ATM Conditional Debugging on ATM Interfaces

- [Enabling Debugging for the ATM Interface](#) (required)

## Enabling Debugging for the ATM Interface

Perform this task to enable conditional debugging on a set of specified interfaces.

### Prerequisites

You must enable ATM debugging and specify the conditions (interface, VCI, or VPI/VCI pair) for the ATM Conditional Debug Support feature to work.

### SUMMARY STEPS

1. `enable`
2. `debug atm [arp | counters | errors | events | oam | packet | state]`
3. `debug condition interface interface-type interface-number [vc {vci | vpi/vci}]`

### DETAILED STEPS

	Command or Action	Purpose
Step 1	<code>enable</code>  <b>Example:</b> Router> enable	Enables privileged EXEC mode.  • Enter your password if prompted.
Step 2	<code>debug atm [arp   counters   errors   events   oam   packet   state]</code>  <b>Example:</b> Router# debug atm state	Displays various ATM events.
Step 3	<code>debug condition interface interface-type interface-number [vc {vci   vpi/vci}]</code>  <b>Example:</b> Router# debug condition interface ATM1/1/0 vc 10/100	Limits output for debugging according to the interface or ATM VC number.

# Configuration Examples for ATM Conditional Debug Support

- [Enabling Debugging for a Specific ATM Interface and VPI/VCI Pair: Example, page 4](#)
- [Enabling Debugging for a Specific VCI: Example, page 4](#)

## Enabling Debugging for a Specific ATM Interface and VPI/VCI Pair: Example

The following example shows how to enable an ATM interface, specify an IP address for the interface, enable conditional debugging for that interface with a VPI/VCI pair of 10/100, and verify that debugging has been enabled:

Enter configuration commands, one per line. End with CNTL/Z.

```
Router(config)# interface atm 1/1/0.100 point-to-point
Router(config-if)# ip address 10.0.0.5 255.255.255.0
Router(config-if)# pvc 10/100
Router(config-if-atm-vc)# no shutdown
Router(config-if)# exit
Router(config)# exit
Router#
Router# debug atm state
```

ATM VC States debugging is on

```
Router# debug condition interface ATM1/1/0 vc 10/100
```

```
Condition 1 set
Router#
```

## Enabling Debugging for a Specific VCI: Example

The following example shows how to enable conditional debugging on a specific VCI. Note that when you enable conditional debugging on a specific VCI alone, the VPI value is automatically set to 0.

```
Router# debug condition interface atm 1/0 vc 4335
```

Condition 1 set

```
Router# configure terminal
```

Enter configuration commands, one per line. End with CNTL/Z.

```
Router(config)# interface atm 1/0
Router(config-if)# pvc 4335
Router(config-if-atm-vc)# end
Router#
```

```
*Jul 12 21:46:52.487: atmdx_setup_vc(ATM1/0): vc=5, vpi=0, vci=4335, config_status=0
*Jul 12 21:46:52.487: atmdx_setup_cos(ATM1/0): vc=5, wred_name=, max_q=0
*Jul 12 21:46:52.487: ATM VC Debug: Condition 1, atm-vc 0/4335 AT1/0 triggered, count 1
*Jul 12 21:46:52.487: ATM1/0 Current Active VC count 4

*Jul 12 21:46:52.487: ATM VC notification event 0
*Jul 12 21:46:52.487: atmdx_platform_set_vc_state(ATM1/0): Setting the VC 5 state to UP
*Jul 12 21:46:52.487: ATM: PVC activated, ATM1/0 VCD 5 (0/4335)
*Jul 12 21:46:52.487: ATM VC notification event 2
*Jul 12 21:46:52.487: %SYS-5-CONFIG_I: Configured from console by console
```

```
Router# show atm vc
```

```
Codes: DN - DOWN, IN - INACTIVE
```

Interface	VCD / Name	VPI	VCI Type	Encaps	SC	Peak Kbps	Av/Min Kbps	Burst Cells	St
1/0	1	0	16 PVC	ILMI	UBR	149760			UP
1/0.10	4	0	100 PVC	SNAP	UBR	149760			UP
1/0	5	0	4335 PVC	SNAP	UBR	149760			UP
1/0.1	one	1	40 PVC	SNAP	UBR	149760			UP
1/0	2	3	100 PVC-A	SNAP	VBR	1000	1000	0	IN
4/ima1	1	23	34 PVC	SNAP	UBR	0			IN

## Additional References

### Related Documents

Related Topic	Document Title
Conditionally triggered debugging	“Conditionally Triggered Debugging” chapter in the <i>Cisco IOS Debug Command Reference</i>
ATM Overview	<i>Overview of the ATM SPAs</i>
ATM commands: complete command syntax, defaults, command mode, command history, usage guidelines, and examples.	<i>Cisco IOS Asynchronous Transfer Mode Command Reference</i>

### Standards

Standard	Title
None	—

### MIBs

MIB	MIBs Link
None	To locate and download MIBs for selected platforms, Cisco IOS XE software releases, and feature sets, use Cisco MIB Locator found at the following URL: <a href="http://www.cisco.com/go/mibs">http://www.cisco.com/go/mibs</a>

### RFCs

RFC	Title
None	—

## Technical Assistance

Description	Link
<p>The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.</p> <p>To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds.</p> <p>Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.</p>	<p><a href="http://www.cisco.com/cisco/web/support/index.html">http://www.cisco.com/cisco/web/support/index.html</a></p>

# Feature Information for ATM Conditional Debug Support

Table 1 lists the release history for this feature.

Use Cisco Feature Navigator to find information about platform support and software image support. Cisco Feature Navigator enables you to determine which Cisco IOS XE software images support a specific software release, feature set, or platform. To access Cisco Feature Navigator, go to <http://www.cisco.com/go/cfn>. An account on Cisco.com is not required.



## Note

Table 1 lists only the Cisco IOS XE software release that introduced support for a given feature in a given Cisco IOS XE software release train. Unless noted otherwise, subsequent releases of that Cisco IOS XE software release train also support that feature.

**Table 1** Feature Information for ATM Conditional Debug Support

Feature Name	Releases	Feature Information
ATM Conditional Debug Support	Cisco IOS XE Release 2.3	ATM Conditional Debug Support feature allows debugging to be limited specifically to an ATM interface, to a VCI, or to a VPI/VCI pair.  The following commands are introduced or modified in the feature: <b>debug condition interface</b> , <b>show debug</b> .

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks). Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2004-2009 Cisco Systems, Inc. All rights reserved.

