



Configuring Enhanced Object Tracking

First Published: May 2, 2005
Last Updated: March 31, 2009

Before the introduction of the Enhanced Object Tracking feature, the Hot Standby Router Protocol (HSRP) had a simple tracking mechanism that allowed you to track the interface line-protocol state only. If the line-protocol state of the interface went down, the HSRP priority of the router was reduced, allowing another HSRP router with a higher priority to become active.

The Enhanced Object Tracking feature separates the tracking mechanism from HSRP and creates a separate standalone tracking process that can be used by other Cisco IOS processes as well as HSRP. This feature allows tracking of other objects in addition to the interface line-protocol state.

A client process, such as HSRP, Virtual Router Redundancy Protocol (VRRP), or Gateway Load Balancing Protocol (GLBP), can now register its interest in tracking objects and then be notified when the tracked object changes state.

Finding Feature Information

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the [“Feature Information for Enhanced Object Tracking”](#) section on page 30.

Use Cisco Feature Navigator to find information about platform support and Cisco IOS and Catalyst OS software image support. To access Cisco Feature Navigator, go to <http://www.cisco.com/go/cfn>. An account on Cisco.com is not required.

Contents

- [Information About Enhanced Object Tracking, page 2](#)
- [How to Configure Enhanced Object Tracking, page 4](#)
- [Configuration Examples for Enhanced Object Tracking, page 23](#)
- [Additional References, page 28](#)



Americas Headquarters:
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

© 2005–2009 Cisco Systems, Inc. All rights reserved.

- [Feature Information for Enhanced Object Tracking, page 30](#)
- [Glossary, page 33](#)

Information About Enhanced Object Tracking

Before you configure the Enhanced Object Tracking feature, you should understand the following concepts:

- [Feature Design of Enhanced Object Tracking, page 2](#)
- [Enhanced Object Tracking and Embedded Event Manager, page 2](#)
- [EOT Support for Carrier Delay, page 3](#)
- [Enhanced Object Tracking for Mobile IP Applications, page 3](#)
- [Benefits of Enhanced Object Tracking, page 3](#)

Feature Design of Enhanced Object Tracking

Enhanced Object Tracking provides complete separation between the objects to be tracked and the action to be taken by a client when a tracked object changes. Thus, several clients such as HSRP, VRRP, or GLPB can register their interest with the tracking process, track the same object, and each take different action when the object changes.

Each tracked object is identified by a unique number that is specified on the tracking command-line interface (CLI). Client processes use this number to track a specific object.

The tracking process periodically polls the tracked objects and notes any change of value. The changes in the tracked object are communicated to interested client processes, either immediately or after a specified delay. The object values are reported as either up or down.

You can also configure a combination of tracked objects in a list and a flexible method for combining objects using Boolean logic. This functionality includes the following capabilities:

- **Threshold**—The tracked list can be configured to use a weight or percentage threshold to measure the state of the list. Each object in a tracked list can be assigned a threshold weight. The state of the tracked list is determined by whether or not the threshold has been met.
- **Boolean “and” function**—When a tracked list has been assigned a Boolean “and” function, it means that each object defined within a subset must be in an up state so that the tracked object can become up.
- **Boolean “or” function**—When the tracked list has been assigned a Boolean “or” function, it means that at least one object defined within a subset must be in an up state so that the tracked object can become up.

Enhanced Object Tracking and Embedded Event Manager

Beginning with Cisco IOS Release 12.4(2)T, Enhanced Object Tracking (EOT) is now integrated with Embedded Event Manager (EEM) to allow EEM to report on status change of a tracked object and to allow EOT to track EEM objects. A new type of tracking object—a stub object—is created. The stub object can be modified by an external process through a defined Application Programming Interface (API). See the [“Embedded Event Manager Overview”](#) document in the *Cisco IOS Network Management Configuration Guide* for more information on how EOT works with EEM.

EOT Support for Carrier Delay

The EOT Support for Carrier Delay feature enables Enhanced Object Tracking (EOT) to consider the carrier-delay timer when tracking the status of an interface.

If a link fails, by default there is a two-second timer that must expire before an interface and the associated routes are declared as being down. If a link goes down and comes back up before the carrier delay timer expires, the down state is effectively filtered, and the rest of the software on the switch is not aware that a link-down event occurred. You can configure the carrier-delay seconds command in interface configuration mode to extend the timer up to 60 seconds.

When EOT is configured on an interface, the tracking may detect the interface is down before a configured carrier-delay timer has expired. This is because EOT looks at the interface state and does not consider the carrier delay timer. Use the **carrier-delay** command in tracking configuration mode to enable tracking to consider the carrier-delay timer configured on an interface.

Enhanced Object Tracking for Mobile IP Applications

The Enhanced Object Tracking Support for Mobile IP feature enables EOT to monitor the presence of Home Agent, Packet Data Serving Node (PDSN), or Gateway GPRS Support Node (GGSN) traffic on a router for mobile wireless applications.

When a redundant pair of Home Agents running HSRP between them loses connectivity, both HSRP nodes become active. Once the connectivity is restored between the two nodes, a graceful way is needed to restore proper HSRP states without losing Home Agent bindings. During the time of no connectivity, one of the nodes will continue to process Home Agent, GGSN, or PDSN traffic while the other will not. The node that continues to process traffic needs to remain active once connectivity is restored. To ensure that the active node remains in the active state, the priority of the HSRP group member that does not process Home Agent traffic is reduced. Reducing the priority of the node that is not processing Home Agent traffic ensures that this node will become the standby after connectivity is restored. When connectivity is restored, the normal Home Agent state synchronization will get all bindings back into the inactive node and, depending on the preempt configuration, it may switch over again. This state synchronization ensures that no Mobile IP, GGSN, or PDSN bindings are lost.

For more information on configuring Mobile IP services, see the following Cisco IOS configuration guides:

Cisco IOS Mobile Wireless Home Agent Configuration Guide

Cisco IOS Mobile Wireless Gateway GPRS Support Node Configuration Guide

Cisco IOS Mobile Wireless Packet Data Serving Node Configuration Guide

Cisco IOS IP Mobility Configuration Guide

Benefits of Enhanced Object Tracking

- Increases the availability and speed of recovery of a network.
- Decreases network outages and their duration.
- Provides a scalable solution that allows other client processes such as VRRP and GLBP the ability to track objects individually or as a list of objects. Prior to the introduction of this functionality, the tracking process was embedded within HSRP.

How to Configure Enhanced Object Tracking

The following sections describe configuration tasks for Enhanced Object Tracking:

- [Tracking the Line-Protocol State of an Interface, page 4](#) (optional)
- [Tracking the IP-Routing State of an Interface, page 6](#) (optional)
- [Tracking IP-Route Reachability, page 8](#) (optional)
- [Tracking the Threshold of IP-Route Metrics, page 9](#) (optional)
- [Tracking IP SLAs Operations, page 12](#) (optional)
- [Configuring a Tracked List and Boolean Expression, page 16](#) (optional)
- [Configuring a Tracked List and Threshold Weight, page 18](#) (optional)
- [Configuring a Tracked List and Threshold Percentage, page 19](#) (optional)
- [Configuring the Track List Defaults, page 21](#) (optional)
- [Configuring Tracking for Mobile IP Applications, page 21](#)

Tracking the Line-Protocol State of an Interface

Perform this task to track the line-protocol state of an interface.

Tracking the IP-routing state of an interface using the **track interface ip routing** command can be more useful in some situations than just tracking the line-protocol state using the **track interface line-protocol** command, especially on interfaces for which IP addresses are negotiated. See the “[Tracking the IP-Routing State of an Interface](#)” section for more information.

You can optionally configure EOT to consider the carrier-delay timer when tracking the line-protocol state of an interface by using the **carrier-delay** command in tracking configuration mode.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **track timer interface** *seconds*
4. **track** *object-number* **interface** *type number* **line-protocol**
5. **carrier-delay**
6. **delay** {**up** *seconds* [**down** *seconds*] | [**up** *seconds*] **down** *seconds*}
7. **end**
8. **show track** *object-number*

DETAILED STEPS

| | Command or Action | Purpose |
|--------|--|--|
| Step 1 | enable Example: Router> enable | Enables privileged EXEC mode. <ul style="list-style-type: none">Enter your password if prompted. |
| Step 2 | configure terminal Example: Router# configure terminal | Enters global configuration mode. |
| Step 3 | track timer interface <i>seconds</i> Example: Router(config)# track timer interface 5 | (Optional) Specifies the interval in which the tracking process polls the tracked object. <ul style="list-style-type: none">The default interval that the tracking process polls interface objects is 1 second. |
| Step 4 | track object-number interface <i>type number line-protocol</i> Example: Router(config)# track 3 interface ethernet 0/1 line-protocol | Tracks the line-protocol state of an interface and enters tracking configuration mode. |
| Step 5 | carrier-delay Example: Router(config-track)# carrier-delay | (Optional) Enables EOT to consider the carrier-delay timer when tracking the status of an interface. |
| Step 6 | delay {up <i>seconds</i> [down <i>seconds</i>] [up <i>seconds</i>] down <i>seconds</i> } Example: Router(config-track)# delay up 30 | (Optional) Specifies a period of time (in seconds) to delay communicating state changes of a tracked object. |
| Step 7 | end Example: Router(config-track)# end | Exits to privileged EXEC mode. |
| Step 8 | show track <i>object-number</i> Example: Router# show track 3 | (Optional) Displays tracking information. <ul style="list-style-type: none">Use this command to verify the configuration. See the display output in the “Examples” section. |

Examples

The following example shows the state of the line protocol on an interface when it is tracked:

```
Router# show track 3

Track 3
  Interface Ethernet0/1 line-protocol
  Line protocol is Up
    1 change, last change 00:00:05
```

```
Tracked by:  
HSRP Ethernet0/3 1
```

Tracking the IP-Routing State of an Interface

Perform this task to track the IP-routing state of an interface. An IP-routing object is considered up when the following criteria exist:

- IP routing is enabled and active on the interface.
- The interface line-protocol state is up.
- The interface IP address is known. The IP address is configured or received through the Dynamic Host Configuration Protocol (DHCP) or IP Control Protocol (IPCP) negotiation.

Interface IP routing will go down when one of the following criteria exist:

- IP routing is disabled globally.
- The interface line-protocol state is down.
- The interface IP address is unknown. The IP address is not configured or received through DHCP or IPCP negotiation.

Tracking the IP-routing state of an interface using the **track interface ip routing** command can be more useful in some situations than just tracking the line-protocol state using the **track interface line-protocol** command, especially on interfaces for which IP addresses are negotiated. For example, on a serial interface that uses the Point-to-Point Protocol (PPP), the line protocol could be up (link control protocol [LCP] negotiated successfully), but IP could be down (IPCP negotiation failed).

The **track interface ip routing** command supports the tracking of an interface with an IP address acquired through any of the following methods:

- Conventional IP address configuration
- PPP/IPCP
- DHCP
- Unnumbered interface

You can optionally configure EOT to consider the carrier-delay timer when tracking the IP-routing state of an interface by using the **carrier-delay** command in tracking configuration mode.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **track timer interface *seconds***
4. **track *object-number* interface *type number* ip routing**
5. **carrier-delay**
6. **delay {up *seconds* [down *seconds*] | [up *seconds*] down *seconds*}**
7. **end**
8. **show track *object-number***

DETAILED STEPS

| | Command or Action | Purpose |
|--------|---|---|
| Step 1 | enable Example: Router> enable | Enables privileged EXEC mode. <ul style="list-style-type: none">Enter your password if prompted. |
| Step 2 | configure terminal Example: Router# configure terminal | Enters global configuration mode. |
| Step 3 | track timer interface seconds Example: Router(config)# track timer interface 5 | (Optional) Specifies the interval in which the tracking process polls the tracked object. <ul style="list-style-type: none">The default interval that the tracking process polls interface objects is 1 second. |
| Step 4 | track object-number interface type number ip routing Example: Router(config)# track 1 interface ethernet 0/1 ip routing | Tracks the IP-routing state of an interface and enters tracking configuration mode. <ul style="list-style-type: none">IP-route tracking tracks an IP route in the routing table and the ability of an interface to route IP packets. |
| Step 5 | carrier-delay Example: Router(config-track)# carrier-delay | (Optional) Enables EOT to consider the carrier-delay timer when tracking the status of an interface. |
| Step 6 | delay {up seconds [down seconds] [up seconds] down seconds} Example: Router(config-track)# delay up 30 | (Optional) Specifies a period of time (in seconds) to delay communicating state changes of a tracked object. |
| Step 7 | end Example: Router(config-track)# end | Returns to privileged EXEC mode. |
| Step 8 | show track object-number Example: Router# show track 1 | Displays tracking information. <ul style="list-style-type: none">Use this command to verify the configuration. See the display output in the “Examples” section. |

Examples

The following example shows the state of IP routing on an interface when it is tracked:

```
Router# show track 1

Track 1
  Interface Ethernet0/1 ip routing
  IP routing is Up
  1 change, last change 00:01:08
```

Tracked by:
HSRP Ethernet0/3 1

Tracking IP-Route Reachability

Perform this task to track the reachability of an IP route. A tracked object is considered up when a routing table entry exists for the route and the route is accessible.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **track timer ip route *seconds***
4. **track *object-number* ip route *ip-address/prefix-length* reachability**
5. **delay {up *seconds* [down *seconds*] | [up *seconds*] down *seconds*}**
6. **ip vrf *vrf-name***
7. **end**
8. **show track *object-number***

DETAILED STEPS

| | Command or Action | Purpose |
|--------|--|--|
| Step 1 | enable Example: Router> enable | Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted. |
| Step 2 | configure terminal Example: Router# configure terminal | Enters global configuration mode. |
| Step 3 | track timer ip route <i>seconds</i> Example: Router(config)# track timer ip route 20 | (Optional) Specifies the interval in which the tracking process polls the tracked object. <ul style="list-style-type: none"> • The default interval that the tracking process polls IP-route objects is 15 seconds. |
| Step 4 | track <i>object-number</i> ip route <i>ip-address/prefix-length</i> reachability Example: Router(config)# track 4 ip route 10.16.0.0/16 reachability | Tracks the reachability of an IP route and enters tracking configuration mode. |

| | Command or Action | Purpose |
|--------|--|---|
| Step 5 | delay { up <i>seconds</i> [down <i>seconds</i>] [up <i>seconds</i>] down <i>seconds</i> } Example: Router(config-track)# delay up 30 | (Optional) Specifies a period of time (in seconds) to delay communicating state changes of a tracked object. |
| Step 6 | ip vrf <i>vrf-name</i> Example: Router(config-track)# ip vrf VRF2 | (Optional) Configures a VPN routing and forwarding (VRF) table. |
| Step 7 | end Example: Router(config-track)# end | Returns to privileged EXEC mode. |
| Step 8 | show track <i>object-number</i> Example: Router# show track 4 | (Optional) Displays tracking information. <ul style="list-style-type: none"> Use this command to verify the configuration. See the display output in the “Examples” section. |

Examples

The following example shows the state of the reachability of an IP route when it is tracked:

```
Router# show track 4

Track 4
  IP route 10.16.0.0 255.255.0.0 reachability
  Reachability is Up (RIP)
  1 change, last change 00:02:04
  First-hop interface is Ethernet0/1
  Tracked by:
    HSRP Ethernet0/3 1
```

Tracking the Threshold of IP-Route Metrics

Perform this task to track the threshold of IP route metrics.

Scaled Route Metrics

The **track ip route** command enables tracking of a route in the routing table. If a route exists in the table, the metric value is converted into a number. To provide a common interface to tracking clients, route metric values are normalized to the range from 0 to 255, where 0 is connected and 255 is inaccessible. Scaled metrics can be tracked by setting thresholds. Up and down state notification occurs when the thresholds are crossed. The resulting value is compared against threshold values to determine the tracking state as follows:

- State is up if the scaled metric for that route is less than or equal to the up threshold.
- State is down if the scaled metric for that route is greater than or equal to the down threshold.

Tracking uses a per-protocol configurable resolution value to convert the real metric to the scaled metric. Table 1 shows the default values used for the conversion. You can use the **track resolution** command to change the metric resolution default values.

Table 1 **Metric Conversion**

| Route Type ¹ | Metric Resolution |
|--|-------------------|
| Static | 10 |
| Enhanced Interior Gateway Routing Protocol (EIGRP) | 2560 |
| Open Shortest Path First (OSPF) | 1 |
| Intermediate System-to-Intermediate System (IS-IS) | 10 |

1. RIP is scaled directly to the range from 0 to 255 because its maximum metric is less than 255.

For example, a change in 10 in an IS-IS metric results in a change of 1 in the scaled metric. The default resolutions are designed so that approximately one 2-Mbps link in the path will give a scaled metric of 255.

Scaling the very large metric ranges of EIGRP and IS-IS to a 0 to 255 range is a compromise. The default resolutions will cause the scaled metric to go above the maximum limit with a 2-Mbps link. However, this scaling allows a distinction between a route consisting of three Fast-Ethernet links and a route consisting of four Fast-Ethernet links.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **track timer ip route** *seconds*
4. **track resolution ip route** { **eigrp** *resolution-value* | **isis** *resolution-value* | **ospf** *resolution-value* | **static** *resolution-value* }
5. **track object-number ip route** *ip-address/prefix-length* **metric threshold**
6. **delay** { **up** *seconds* [**down** *seconds*] | [**up** *seconds*] **down** *seconds* }
7. **ip vrf** *vrf-name*
8. **threshold metric** { **up** *number* [**down** *number*] | **down** *number* [**up** *number*] }
9. **end**
10. **show track** *object-number*

DETAILED STEPS

| | Command or Action | Purpose |
|--------|---|--|
| Step 1 | enable Example: Router> enable | Enables privileged EXEC mode. <ul style="list-style-type: none"> Enter your password if prompted. |
| Step 2 | configure terminal Example: Router# configure terminal | Enters global configuration mode. |
| Step 3 | track timer ip route seconds Example: Router(config)# track timer ip route 20 | (Optional) Specifies the interval in which the tracking process polls the tracked object. <ul style="list-style-type: none"> The default interval that the tracking process polls IP-route objects is 15 seconds. |
| Step 4 | track resolution ip route {eigrp resolution-value isis resolution-value ospf resolution-value static resolution-value} Example: Router(config)# track resolution ip route eigrp 300 | (Optional) Specifies resolution parameters for a tracked object. <ul style="list-style-type: none"> Use this command to change the default metric resolution values. |
| Step 5 | track object-number ip route ip-address/prefix-length metric threshold Example: Router(config)# track 6 ip route 10.16.0.0/16 metric threshold | Tracks the scaled metric value of an IP route to determine if it is above or below a threshold. <ul style="list-style-type: none"> The default down value is 255, which equates to an inaccessible route. The default up value is 254. |
| Step 6 | delay {up seconds [down seconds] [up seconds] down seconds} Example: Router(config-track)# delay up 30 | (Optional) Specifies a period of time (in seconds) to delay communicating state changes of a tracked object. |
| Step 7 | ip vrf vrf-name Example: Router(config-track)# ip vrf VRF1 | (Optional) Configures a VRF table. |
| Step 8 | threshold metric {up number [down number] down number [up number]} Example: Router(config-track)# threshold metric up 254 down 255 | (Optional) Sets a metric threshold other than the default value. |

| | Command or Action | Purpose |
|---------|--|---|
| Step 9 | <code>end</code> Example: Router(config-track)# end | Exits to privileged EXEC mode. |
| Step 10 | <code>show track object-number</code> Example: Router# show track 6 | (Optional) Displays tracking information. <ul style="list-style-type: none"> Use this command to verify the configuration. See the display output in the “Examples” section. |

Examples

The following example shows the metric threshold of an IP route when it is tracked:

```
Router# show track 6

Track 6
  IP route 10.16.0.0 255.255.0.0 metric threshold
  Metric threshold is Up (RIP/6/102)
    1 change, last change 00:00:08
  Metric threshold down 255 up 254
  First-hop interface is Ethernet0/1
  Tracked by:
    HSRP Ethernet0/3 1
```

Tracking IP SLAs Operations

Perform the following tasks to track Cisco IOS IP Service Level Agreements (SLAs) operations:

- [Tracking the State of an IP SLAs Operation, page 13](#)
- [Tracking the Reachability of an IP SLAs IP Host, page 14](#)

Object tracking of IP SLAs operations allows tracking clients to track the output from IP SLAs objects and use the provided information to trigger an action.

Cisco IOS IP SLAs is a network performance measurement and diagnostics tool that uses active monitoring. Active monitoring is the generation of traffic in a reliable and predictable manner to measure network performance. Cisco IOS software uses IP SLAs to collect real-time metrics such as response time, network resource availability, application performance, jitter (interpacket delay variance), connect time, throughput, and packet loss.

These metrics can be used for troubleshooting, for proactive analysis before problems occur, and for designing network topologies.

Every IP SLAs operation maintains an operation return-code value. This return code is interpreted by the tracking process. The return code can return OK, OverThreshold, and several other return codes. Different operations can have different return-code values, so only values common to all operation types are used.

Two aspects of an IP SLAs operation can be tracked: state and reachability. The difference between these aspects relates to the acceptance of the OverThreshold return code. [Table 2](#) shows the state and reachability aspects of IP SLAs operations that can be tracked.

Table 2 Comparison of State and Reachability Operations

| Tracking | Return Code | Track State |
|--------------|--------------------------|-------------|
| State | OK | Up |
| | (all other return codes) | Down |
| Reachability | OK or OverThreshold | Up |
| | (all other return codes) | Down |

Tracking the State of an IP SLAs Operation

Perform this task to track the state of an IP SLAs operation.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **track** *object-number* **rtr** *operation-number* **state**
or
track *object-number* **ip sla** *operation-number* **state**
4. **delay** { **up** *seconds* [**down** *seconds*] | [**up** *seconds*] **down** *seconds* }
5. **end**
6. **show track** *object-number*

DETAILED STEPS

| | Command or Action | Purpose |
|--------|--|---|
| Step 1 | enable Example: Router> enable | Enables privileged EXEC mode. <ul style="list-style-type: none">• Enter your password if prompted. |
| Step 2 | configure terminal Example: Router# configure terminal | Enters global configuration mode. |

| | Command or Action | Purpose |
|--------|--|---|
| Step 3 | <p>Cisco IOS Releases Prior to 12.4(20)T and 12.2(33)SX11 <code>track object-number rtr operation-number state</code></p> <p>Cisco IOS Release 12.4(20)T, 12.2(33)SX11 or Later Releases <code>track object-number ip sla operation-number state</code></p> <p>Example: Cisco IOS Releases Prior to 12.4(20)T and 12.2(33)SX11: Router(config)# track 2 rtr 4 state</p> <p>Example: Cisco IOS Release 12.4(20)T, 12.2(33)SX11 or Later Releases Router(config)# track 2 ip sla 4 state</p> | <p>Tracks the state of an IP SLAs object and enters tracking configuration mode.</p> <p>Note Effective with Cisco IOS Release 12.4(20)T, and Cisco IOS Release 12.2(33)SX11, the <code>track rtr</code> command was replaced by the <code>track ip sla</code> command. The <code>track rtr</code> command will be removed in a future release and is available only to aid the update of existing configurations to the <code>track ip sla</code> command.</p> |
| Step 4 | <p><code>delay {up seconds [down seconds] [up seconds] down seconds}</code></p> <p>Example: Router(config-track)# delay up 60 down 30</p> | <p>(Optional) Specifies a period of time (in seconds) to delay communicating state changes of a tracked object.</p> |
| Step 5 | <p><code>end</code></p> <p>Example: Router(config-track)# end</p> | <p>Exits to privileged EXEC mode.</p> |
| Step 6 | <p><code>show track object-number</code></p> <p>Example: Router# show track 2</p> | <p>(Optional) Displays tracking information.</p> <ul style="list-style-type: none"> Use this command to verify the configuration. See the display output in the “Examples” section of this task. |

Examples

The following example shows the state of the IP SLAs tracking:

```
Router# show track 2

Track 2
  IP SLA 1 state
  State is Down
    1 change, last change 00:00:47
  Latest operation return code: over threshold
  Latest RTT (milliseconds) 4
  Tracked by:
    HSRP Ethernet0/1 3
```

Tracking the Reachability of an IP SLAs IP Host

Perform this task to track the reachability of an IP host.

SUMMARY STEPS

1. `enable`

2. **configure terminal**
3. **track** *object-number* **rtr** *operation-number* **reachability**
or
track *object-number* **ip sla** *operation-number* **reachability**
4. **delay** {**up** *seconds* [**down** *seconds*] | [**up** *seconds*] **down** *seconds*}
5. **end**
6. **show track** *object-number*

DETAILED STEPS

| | Command or Action | Purpose |
|---------------|--|--|
| Step 1 | enable Example: Router> enable | Enables privileged EXEC mode. • Enter your password if prompted. |
| Step 2 | configure terminal Example: Router# configure terminal | Enters global configuration mode. |
| Step 3 | Cisco IOS Releases Prior to 12.4(20)T and 12.2(33)SX11: track <i>object-number</i> rtr <i>operation-number</i> reachability Cisco IOS Release 12.4(20)T, 12.2(33)SX11 or Later Releases track <i>object-number</i> ip sla <i>operation-number</i> reachability Example: Cisco IOS Releases Prior to 12.4(20)T and 12.2(33)SX11: Router(config)# track 2 rtr 4 reachability Example: Cisco IOS Release 12.4(20)T, 12.2(33)SX11 or Later Releases Router(config)# track 2 ip sla 4 reachability | Tracks the reachability of an IP SLAs IP host and enters tracking configuration mode. Note Effective with Cisco IOS Release 12.4(20)T and Cisco IOS Release 12.2(33)SX11 the track rtr command was replaced by the track ip sla command. The track rtr command will be removed in a future release and is available only to aid the update of existing configurations to the track ip sla command. |
| Step 4 | delay { up <i>seconds</i> [down <i>seconds</i>] [up <i>seconds</i>] down <i>seconds</i> } | (Optional) Specifies a period of time (in seconds) to delay communicating state changes of a tracked object. |
| | Example: Router(config-track)# delay up 30 down 10 | |

| | Command or Action | Purpose |
|--------|--|--|
| Step 5 | <code>end</code> Example: Router(config-track)# end | Exits to privileged EXEC mode. |
| Step 6 | <code>show track object-number</code> Example: Router# show track 3 | (Optional) Displays tracking information. <ul style="list-style-type: none"> Use this command to verify the configuration. See the display output in the “Examples” section of this task. |

Examples

The following example shows whether the route is reachable:

```
Router# show track 3

Track 3
  IP SLA 1 reachability
  Reachability is Up
    1 change, last change 00:00:47
  Latest operation return code: over threshold
  Latest RTT (milliseconds) 4
  Tracked by:
    HSRP Ethernet0/1 3
```

Configuring a Tracked List and Boolean Expression

Perform this task to configure a tracked list of objects and a Boolean expression to determine the state of the list. A tracked list contains one or more objects. The Boolean expression enables two types of calculations by using either “and” or “or” operators. For example, when tracking two interfaces using the “and” operator, up means that *both* interfaces are up, and down means that *either* interface is down.

You may also configure a tracked list state to be measured using a weight or percentage threshold. See “Configuring a Tracked List and Threshold Weight” section on page 18 and “Configuring a Tracked List and Threshold Percentage” section on page 19.



Note

The “not” operator is specified for one or more objects and negates the state of the object.

Prerequisites

An object must exist before it can be added to a tracked list.

SUMMARY STEPS

- enable**
- configure terminal**
- track track-number list boolean {and | or}**
- object object-number [not]**

5. `delay {up seconds [down seconds] | [up seconds] down seconds}`
6. `end`

DETAILED STEPS

| | Command or Action | Purpose |
|---------------|---|--|
| Step 1 | <p><code>enable</code></p> <p>Example: Router> enable</p> | <p>Enables privileged EXEC mode.</p> <ul style="list-style-type: none"> • Enter your password if prompted. |
| Step 2 | <p><code>configure terminal</code></p> <p>Example: Router# configure terminal</p> | <p>Enters global configuration mode.</p> |
| Step 3 | <p><code>track track-number list boolean {and or}</code></p> <p>Example: Router(config-track)# track 100 list boolean and</p> | <p>Configures a tracked list object and enters tracking configuration mode. The keywords are as follows:</p> <ul style="list-style-type: none"> • boolean—Specifies that the state of the tracked list is based on a Boolean calculation. The keywords are as follows: <ul style="list-style-type: none"> – and—Specifies that the list is up if all objects are up, or down if one or more objects are down. For example when tracking two interfaces, up means that both interfaces are up, and down means that either interface is down. – or—Specifies that the list is up if at least one object is up. For example, when tracking two interfaces, up means that either interface is up, and down means that both interfaces are down. |
| Step 4 | <p><code>object object-number [not]</code></p> <p>Example: Router(config-track)# object 3 not</p> | <p>Specifies the object to be tracked. The <i>object-number</i> argument has a valid range from 1 to 500. There is no default. The optional not keyword negates the state of the object.</p> <p>Note The example means that when object 3 is up, the tracked list detects object 3 as down.</p> |
| Step 5 | <p><code>delay {up seconds [down seconds] [up seconds] down seconds}</code></p> <p>Example: Router(config-track)# delay up 3</p> | <p>(Optional) Specifies a tracking delay in seconds between up and down states.</p> |
| Step 6 | <p><code>end</code></p> <p>Example: Router(config-track)# end</p> | <p>Returns to privileged EXEC mode.</p> |

Configuring a Tracked List and Threshold Weight

Perform this task to configure a list of tracked objects, to specify that weight be used as the threshold, and to configure a weight for each of its objects. A tracked list contains one or more objects. Using a threshold weight, the state of each object is determined by comparing the total weight of all objects that are up against a threshold weight for each object.

You can also configure a tracked list state to be measured using a Boolean calculation or threshold percentage. See the “[Configuring a Tracked List and Boolean Expression](#)” section on page 16 and the “[Configuring a Tracked List and Threshold Percentage](#)” section on page 19.

Prerequisites

An object must exist before it can be added to a tracked list.

Restrictions

You cannot use the Boolean “not” operator in a weight or percentage threshold list.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **track** *track-number* **list threshold weight**
4. **object** *object-number* [**weight** *weight-number*]
5. **threshold weight** {**up** *number* **down** *number* | **up** *number* | **down** *number*}
6. **delay** {**up** *seconds* [**down** *seconds*] | [**up** *seconds*] **down** *seconds*}
7. **end**

DETAILED STEPS

| | Command or Action | Purpose |
|--------|---|--|
| Step 1 | enable Example: Router> enable | Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted. |
| Step 2 | configure terminal Example: Router# configure terminal | Enters global configuration mode. |
| Step 3 | track <i>track-number</i> list threshold weight Example: Router(config-track)# track 100 list threshold weight | Configures a tracked list object and enters tracking configuration mode. The keywords are as follows: <ul style="list-style-type: none"> • threshold—Specifies that the state of the tracked list is based on a threshold. • weight—Specifies that the threshold is based on a specified weight. |

| | Command or Action | Purpose |
|--------|--|--|
| Step 4 | object <i>object-number</i> [weight <i>weight-number</i>] Example: Router(config-track)# object 3 weight 30 | Specifies the object to be tracked. The <i>object-number</i> argument has a valid range from 1 to 500. There is no default. The optional weight keyword specifies a threshold weight for each object. |
| Step 5 | threshold weight { up <i>number</i> down <i>number</i> up <i>number</i> down <i>number</i> } Example: Router(config-track)# threshold weight up 30 | Specifies the threshold weight. The keywords and arguments are as follows: <ul style="list-style-type: none"> • up <i>number</i>—Valid range is from 1 to 255. • down <i>number</i>—Range depends upon what you select for the up keyword. For example, if you configure 25 for up, you will see a range from 0 to 24 for down. |
| Step 6 | delay { up <i>seconds</i> [down <i>seconds</i>] [up <i>seconds</i>] down <i>seconds</i> } Example: Router(config-track)# delay up 3 | (Optional) Specifies a tracking delay in seconds between up and down states. |
| Step 7 | end Example: Router(config-track)# end | Returns to privileged EXEC mode. |

Configuring a Tracked List and Threshold Percentage

Perform this task to configure a tracked list of objects, to specify that a percentage will be used as the threshold, and to specify a percentage for each object in the list. A tracked list contains one or more objects. Using the threshold percentage, the state of the list is determined by comparing the assigned percentage of each object to the list.

You may also configure a tracked list state to be measured using a Boolean calculation or threshold weight. See [“Configuring a Tracked List and Boolean Expression”](#) section on page 16 and [“Configuring a Tracked List and Threshold Weight”](#) section on page 18.

Prerequisites

An object must exist before it can be added to a tracked list.

Restrictions

You cannot use the Boolean “not” operator in a weight or percentage threshold list.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **track** *track-number* **list threshold percentage**
4. **object** *object-number*

5. **threshold percentage** {**up number** [**down number**] | **down number** [**up number**]}
6. **delay** {**up seconds** [**down seconds**] | [**up seconds**] **down seconds**}
7. **end**

DETAILED STEPS

| | Command or Action | Purpose |
|--------|--|--|
| Step 1 | <p>enable</p> <p>Example: Router> enable</p> | <p>Enables privileged EXEC mode.</p> <ul style="list-style-type: none"> • Enter your password if prompted. |
| Step 2 | <p>configure terminal</p> <p>Example: Router# configure terminal</p> | <p>Enters global configuration mode.</p> |
| Step 3 | <p>track track-number list threshold percentage</p> <p>Example: Router(config-track)# track 100 list threshold percentage</p> | <p>Configures a tracked list object and enters tracking configuration mode. The keywords are as follows:</p> <ul style="list-style-type: none"> • threshold—Specifies that the state of the tracked list is based on a threshold. • percentage—Specifies that the threshold is based on a percentage. |
| Step 4 | <p>object object-number</p> <p>Example: Router(config-track)# object 3</p> | <p>Specifies the object to be tracked. The <i>object-number</i> argument has a valid range from 1 to 500. There is no default.</p> |
| Step 5 | <p>threshold percentage {up number [down number] down number [up number]}</p> <p>Example: Router(config-track)# threshold percentage up 30</p> | <p>Specifies the threshold percentage. The keywords and arguments are as follows:</p> <ul style="list-style-type: none"> • up number—Valid range is from 1 to 100. • down number—Range depends upon what you have selected for the up keyword. For example, if you specify 25 as up, a range from 26 to 100 is displayed for the down keyword. |
| Step 6 | <p>delay {up seconds [down seconds] [up seconds] down seconds}</p> <p>Example: Router(config-track)# delay up 3</p> | <p>(Optional) Specifies a tracking delay in seconds between up and down states.</p> |
| Step 7 | <p>end</p> <p>Example: Router(config-track)# end</p> | <p>Returns to privileged EXEC mode.</p> |

Configuring the Track List Defaults

Perform this task to configure a default delay value for a tracked list, a default object, and default threshold parameters for a tracked list.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **track** *track-number*
4. **default** {**delay** | **object** *object-number* | **threshold percentage**}
5. **end**

DETAILED STEPS

| | Command or Action | Purpose |
|--------|--|--|
| Step 1 | enable Example: Router> enable | Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted. |
| Step 2 | configure terminal Example: Router# configure terminal | Enters global configuration mode. |
| Step 3 | track <i>track-number</i> Example: Router(config)# track 3 | Enters tracking configuration mode. |
| Step 4 | default { delay object <i>object-number</i> threshold percentage } | Specifies a default delay value for a tracked list, a default object, and default threshold parameters for a tracked list. The keywords and arguments are as follows: <ul style="list-style-type: none"> • delay—Reverts to the default delay. • object <i>object-number</i>—Specifies a default object for the track list. The valid range is from 1 to 500. • threshold percentage—Specifies a default threshold percentage. |
| Step 5 | end Example: Router(config-track)# end | Returns to privileged EXEC mode. |

Configuring Tracking for Mobile IP Applications

Perform this task to configure a tracked list of Mobile IP application objects.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **track *track-number* application home-agent**
4. **exit**
5. **track *track-number* application pdsn**
6. **exit**
7. **track *track-number* application ggsn**
8. **end**

DETAILED STEPS

| | Command or Action | Purpose |
|---------------|--|--|
| Step 1 | enable Example: Router> enable | Enables privileged EXEC mode. <ul style="list-style-type: none"> • Enter your password if prompted. |
| Step 2 | configure terminal Example: Router# configure terminal | Enters global configuration mode. |
| Step 3 | track <i>track-number</i> application home-agent Example: Router(config)# track 100 application home-agent | (Optional) Tracks the presence of Home Agent traffic on a router. |
| Step 4 | exit Example: Router(config-track)# exit | Returns to global configuration mode. |
| Step 5 | track <i>track-number</i> application pdsn Example: Router(config)# track 100 application pdsn | (Optional) Tracks the presence of PDSN traffic on a router. |
| Step 6 | exit Example: Router(config-track)# exit | Returns to global configuration mode. |

| | Command or Action | Purpose |
|--------|---|---|
| Step 7 | <code>track track-number application ggsn</code> Example: Router(config)# track 100 application ggsn | (Optional) Tracks the presence of GGSN traffic on a router. |
| Step 8 | <code>end</code> Example: Router(config)# end | Returns to privileged EXEC mode. |

Configuration Examples for Enhanced Object Tracking

This section provides the following configuration examples:

- [Interface Line Protocol: Example, page 23](#)
- [Interface IP Routing: Example, page 24](#)
- [IP-Route Reachability: Example, page 25](#)
- [IP-Route Threshold Metric: Example, page 25](#)
- [IP SLAs IP Host Tracking: Example, page 25](#)
- [Boolean Expression for a Tracked List: Example, page 26](#)
- [Threshold Weight for a Tracked List: Example, page 27](#)
- [Threshold Percentage for a Tracked List: Example, page 27](#)
- [Mobile IP Application Tracking: Example, page 28](#)

Interface Line Protocol: Example

The following example is very similar to the IP-routing example. Instead, the tracking process is configured to track the line-protocol state of serial interface 1/0. HSRP on Ethernet interface 0/0 then registers with the tracking process to be informed of any changes to the line-protocol state of serial interface 1/0. If the line protocol on serial interface 1/0 goes down, the priority of the HSRP group is reduced by 10.

Router A Configuration

```
track 100 interface serial1/0 line-protocol
!
interface Ethernet0/0
 ip address 10.1.0.21 255.255.0.0
 standby 1 preempt
 standby 1 ip 10.1.0.1
 standby 1 priority 110
 standby 1 track 100 decrement 10
```

Router B Configuration

```
track 100 interface serial1/0 line-protocol
!
interface Ethernet0/0
 ip address 10.1.0.22 255.255.0.0
```

```
standby 1 preempt
standby 1 ip 10.1.0.1
standby 1 priority 105
standby 1 track 100 decrement 10
```

Interface IP Routing: Example

In the following example, the tracking process is configured to track the IP-routing capability of serial interface 1/0. HSRP on Ethernet interface 0/0 then registers with the tracking process to be informed of any changes to the IP-routing state of serial interface 1/0. If the IP-routing state on serial interface 1/0 goes down, the priority of the HSRP group is reduced by 10.

In the following example, EOT is configured to take the carrier-delay timer into consideration when tracking the state of serial interface 1/0.

If both serial interfaces are operational, Router A will be the HSRP active router because it has the higher priority. However, if IP on serial interface 1/0 in Router A fails, the HSRP group priority will be reduced and Router B will take over as the active router, thus maintaining a default virtual gateway service to hosts on the 10.1.0.0 subnet.

See [Figure 1](#) for a sample topology.

Figure 1 Topology for IP-Routing Support



Router A Configuration

```
track 100 interface serial1/0 ip routing
  carrier-delay
!
interface Ethernet0/0
  ip address 10.1.0.21 255.255.0.0
  standby 1 preempt
  standby 1 ip 10.1.0.1
  standby 1 priority 110
  standby 1 track 100 decrement 10
```

Router B Configuration

```
track 100 interface serial1/0 ip routing
  carrier-delay
!
interface Ethernet0/0
  ip address 10.1.0.22 255.255.0.0
  standby 1 preempt
  standby 1 ip 10.1.0.1
  standby 1 priority 105
  standby 1 track 100 decrement 10
```

IP-Route Reachability: Example

In the following example, the tracking process is configured to track the reachability of IP route 10.2.2.0/24:

Router A Configuration

```
track 100 ip route 10.2.2.0/24 reachability
!
interface Ethernet0/0
 ip address 10.1.1.21 255.255.255.0
 standby 1 preempt
 standby 1 ip 10.1.1.1
 standby 1 priority 110
 standby 1 track 100 decrement 10
```

Router B Configuration

```
track 100 ip route 10.2.2.0/24 reachability
!
interface Ethernet0/0
 ip address 10.1.1.22 255.255.255.0
 standby 1 preempt
 standby 1 ip 10.1.1.1
 standby 1 priority 105
 standby 1 track 100 decrement 10
```

IP-Route Threshold Metric: Example

In the following example, the tracking process is configured to track the threshold metric of IP route 10.2.2.0/24:

Router A Configuration

```
track 100 ip route 10.2.2.0/24 metric threshold
!
interface Ethernet0/0
 ip address 10.1.1.21 255.255.255.0
 standby 1 preempt
 standby 1 ip 10.1.1.1
 standby 1 priority 110
 standby 1 track 100 decrement 10
```

Router B Configuration

```
track 100 ip route 10.2.2.0/24 metric threshold
!
interface Ethernet0/0
 ip address 10.1.1.22 255.255.255.0
 standby 1 preempt
 standby 1 ip 10.1.1.1
 standby 1 priority 105
 standby 1 track 100 decrement 10
```

IP SLAs IP Host Tracking: Example

The following example shows how to configure IP host tracking for IP SLAs operation 1 in Cisco IOS releases prior to Cisco IOS Release 12.4(20)T and Cisco IOS Release 12.2(33)SXII:

```

ip sla 1
 icmp-echo 10.51.12.4
 timeout 1000
 frequency 3
 threshold 2
 request-data-size 1400
 exit
ip sla schedule 1 start-time now life forever
 exit
track 2 rtr 1 state
track 3 rtr 1 reachability
 exit
interface ethernet0/1
 ip address 10.21.0.4 255.255.0.0
 no shutdown
 standby 3 ip 10.21.0.10d
 standby 3 priority 120
 standby 3 preempt
 standby 3 track 2 decrement 10
 standby 3 track 3 decrement 10

```

The following example shows how to configure IP host tracking for IP SLAs operation 1 in Cisco IOS Release 12.4(20)T, Cisco IOS Release 12.2(33)SXII and later releases:

```

ip sla 1
 icmp-echo 10.51.12.4
 timeout 1000
 frequency 3
 threshold 2
 request-data-size 1400
 exit
ip sla schedule 1 start-time now life forever
 exit
track 2 ip sla 1 state
track 3 ip sla 1 reachability
 exit
interface ethernet0/1
 ip address 10.21.0.4 255.255.0.0
 no shutdown
 standby 3 ip 10.21.0.10d
 standby 3 priority 120
 standby 3 preempt
 standby 3 track 2 decrement 10
 standby 3 track 3 decrement 10

```

Boolean Expression for a Tracked List: Example

In the following example, a track list object is configured to track two serial interfaces when both serial interfaces are up and when either serial interface is down:

```

track 1 interface serial2/0 line-protocol
track 2 interface serial2/1 line-protocol
 exit
track 100 list boolean and
 object 1
 object 2

```

In the following example, a track list object is configured to track two serial interfaces when either serial interface is up and when both serial interfaces are down:

```

track 1 interface serial2/0 line-protocol

```

```
track 2 interface serial2/1 line-protocol
  exit
track 101 list boolean or
  object 1
  object 2
```

The following configuration example shows that tracked list 4 has two objects and one object state is negated (if the list is up, the list detects that object 2 is down):

```
track 4 list boolean and
  object 1
  object 2 not
```

Threshold Weight for a Tracked List: Example

In the following example, three serial interfaces in tracked list 100 are configured with a threshold weight of 20 each. The down threshold is configured to 0 and the up threshold is configured to 40:

```
track 1 interface serial2/0 line-protocol
track 2 interface serial2/1 line-protocol
track 3 interface serial2/2 line-protocol
  exit
track 100 list threshold weight
  object 1 weight 20
  object 2 weight 20
  object 3 weight 20
  threshold weight down 0 up 40
```

The above example means that the track-list object goes down only when all three serial interfaces go down, and only comes up again when at least two serial interfaces are up (since $20+20 \geq 40$). The advantage of this configuration is that it prevents the track-list object from coming up if two interfaces are down and the third interface is flapping.

The following configuration example shows that if object 1 and object 2 are down, then track list 4 is up, because object 3 satisfies the up threshold value of up 30. But, if object 3 is down, both objects 1 and 2 need to be up in order to satisfy the threshold weight.

```
track 4 list threshold weight
  object 1 weight 15
  object 2 weight 20
  object 3 weight 30
  threshold weight up 30 down 10
```

This configuration may be useful to you if you have two small bandwidth connections (represented by object 1 and 2) and one large bandwidth connection (represented by object 3). Also the down 10 value means that once the tracked object is up, it will not go down until the threshold value is lower or equal to 10, which in this example means that all connections are down.

Threshold Percentage for a Tracked List: Example

In the following example, four serial interfaces in track list 100 are configured for an up threshold percentage of 75. The track list is up when 75 percent of the serial interfaces are up and down when fewer than 75 percent of the serial interfaces are up.

```
track 1 interface serial2/0 line-protocol
track 2 interface serial2/1 line-protocol
track 3 interface serial2/2 line-protocol
track 4 interface serial2/3 line-protocol
```

```

exit
track 100 list threshold percentage
object 1
object 2
object 3
object 4
threshold percentage up 75

```

Mobile IP Application Tracking: Example

The following example shows how to configure EOT to track Mobile IP, GGSN, and PDSN traffic on a router:

```

track 1 application home-agent
exit
track 2 application ggsn
exit
track 3 application pdsn

```

Additional References

The following sections provide references related to Enhanced Object Tracking.

Related Documents

| Related Topic | Document Title |
|---|---|
| Embedded Event Manager | “Embedded Event Manager Overview” module |
| HSRP concepts and configuration tasks | “Configuring HSRP” module |
| GLBP concepts and configuration tasks | “Configuring GLBP” module |
| VRRP concepts and configuration tasks | “Configuring VRRP” module |
| GLBP, HSRP, and VRRP commands: complete command syntax, command mode, command history, defaults, usage guidelines, and examples | Cisco IOS IP Application Services Command Reference |

Standards

| Standards | Title |
|---|-------|
| No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature. | — |

MIBs

| MIBs | MIBs Link |
|---|--|
| No new or modified MIBs are supported by this feature, and support for existing MIBs has not been modified by this feature. | To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL: http://www.cisco.com/go/mibs |

RFCs

| RFCs | Title |
|---|-------|
| No new or modified RFCs are supported by this feature, and support for existing RFCs has not been modified by this feature. | — |

Technical Assistance

| Description | Link |
|---|---|
| <p>The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.</p> <p>To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds.</p> <p>Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.</p> | http://www.cisco.com/techsupport |

Feature Information for Enhanced Object Tracking

Table 3 lists the features in this module and provides links to specific configuration information. Only features that were introduced or modified in Cisco IOS Releases 12.2(1) or 12.0(3)S or later appear in the table.

Not all commands may be available in your Cisco IOS software release. For details on when support for specific commands was introduced, see the command reference documents.

Use Cisco Feature Navigator to find information about platform support and software image support. Cisco Feature Navigator enables you to determine which Cisco IOS and Catalyst OS software images support a specific software release, feature set, or platform. To access Cisco Feature Navigator, go to <http://www.cisco.com/go/cfn>. An account on Cisco.com is not required.

Table 3 Feature Information for Enhanced Object Tracking

| Feature Name | Releases | Feature Configuration Information |
|---|--|---|
| Enhanced Tracking Support | 12.2(15)T 12.2(25)S 12.2(28)SB 12.2(33)SRA 12.2(33)SXH | <p>The Enhanced Tracking Support feature separates the tracking mechanism from HSRP and creates a separate standalone tracking process that can be used by other Cisco IOS processes as well as HSRP. This feature allows tracking of other objects in addition to the interface line-protocol state.</p> <p>The following sections provide information about this feature:</p> <ul style="list-style-type: none"> • Tracking the Line-Protocol State of an Interface, page 4 • Tracking the IP-Routing State of an Interface, page 6 • Tracking IP-Route Reachability, page 8 • Tracking the Threshold of IP-Route Metrics, page 9 <p>The following commands were introduced or modified by this feature: debug track, delay tracking, ip vrf, show track, standby track, threshold metric, track interface, track ip route, track timer.</p> |
| FHRP—Enhanced Object Tracking of IP SLAs Operations | 12.3(4)T 12.2(25)S 12.2(27)SBC 12.2(33)SRA 12.2(33)SXH | <p>This feature enables First Hop Redundancy Protocols (FHRPs) and other Enhanced Object Tracking (EOT) clients to track the output from IP SLAs objects and use the provided information to trigger an action.</p> <p>The following section provides information about this feature:</p> <ul style="list-style-type: none"> • Tracking IP SLAs Operations, page 12 • IP SLAs IP Host Tracking: Example, page 25 <p>The following command was introduced by this feature: track rtr.</p> |

Table 3 Feature Information for Enhanced Object Tracking (continued)

| Feature Name | Releases | Feature Configuration Information |
|---|--|--|
| FHRP—EOT Deprecation of rtr Keyword | 12.4(20)T 12.2(33)SXI1 | <p>This feature replaces the track rtr command with the track ip sla command.</p> <p>The following sections provide information about this feature:</p> <ul style="list-style-type: none"> • Tracking IP SLAs Operations, page 12 • IP SLAs IP Host Tracking: Example, page 25 <p>The following command was introduced by this feature: track ip sla.</p> |
| FHRP—Object Tracking List | 12.3(8)T 12.2(30)S 12.2(33)SRA 12.2(31)SB2 12.2(33)SXH | <p>This feature enhances the tracking capabilities to enable the configuration of a combination of tracked objects in a list, and a flexible method of combining objects using Boolean logic.</p> <p>The following sections provide information about this feature:</p> <ul style="list-style-type: none"> • Configuring a Tracked List and Boolean Expression, page 16 • Configuring a Tracked List and Threshold Weight, page 18 • Configuring a Tracked List and Threshold Percentage, page 19 • Configuring the Track List Defaults, page 21 <p>The following commands were introduced or modified by this feature: show track, threshold percentage, threshold weight, track list, track resolution.</p> |
| FHRP—Enhanced Object Tracking Integration with Embedded Event Manager | 12.4(2)T 12.2(33)SRB 12.2(33)SXI | <p>EOT is now integrated with EEM to allow EEM to report on a status change of a tracked object and to allow EOT to track EEM objects.</p> <p>The following section provides information about this feature:</p> <ul style="list-style-type: none"> • Enhanced Object Tracking and Embedded Event Manager, page 2 <p>The following commands were introduced or modified by this feature: action track read, action track set, default-state, event resource, event rf, event track, show track, track stub.</p> |

Table 3 Feature Information for Enhanced Object Tracking (continued)

| Feature Name | Releases | Feature Configuration Information |
|---|-----------|---|
| FHRP—Enhanced Object Tracking Support for Mobile IP | 12.4(11)T | <p>The FHRP—Enhanced Object Tracking Support for Mobile IP feature provides new tracking objects needed by mobile wireless applications to track the presence of Home Agent, GGSN, or PDSN traffic on a router.</p> <p>The following sections provide information about this feature:</p> <ul style="list-style-type: none"> • Enhanced Object Tracking for Mobile IP Applications, page 3 • Configuring Tracking for Mobile IP Applications, page 21 • Mobile IP Application Tracking: Example, page 28 <p>The following command was introduced by this feature: track application.</p> |
| EOT Support for Carrier Delay | 12.4(9)T | <p>The EOT Support for Carrier Delay feature enables Enhanced Object Tracking (EOT) to consider the carrier-delay timer when tracking the status of an interface.</p> <p>The following sections provide information about this feature:</p> <ul style="list-style-type: none"> • EOT Support for Carrier Delay, page 3 • Tracking the Line-Protocol State of an Interface, page 4 • Tracking the IP-Routing State of an Interface, page 6 • Interface IP Routing: Example, page 24 <p>The following commands were introduced or modified by this feature: carrier-delay (tracking), show track.</p> |

Glossary

DHCP—Dynamic Host Configuration Protocol. DHCP is a protocol that delivers IP addresses and configuration information to network clients.

GLBP—Gateway Load Balancing Protocol. Provides automatic router backup for IP hosts that are configured with a single default gateway on an IEEE 802.3 LAN. Multiple first-hop routers on the LAN combine to offer a single virtual first-hop IP router while sharing the IP packet forwarding load. Other routers on the LAN may act as redundant (GLBP) routers that will become active if any of the existing forwarding routers fail.

GGSN—Gateway GPRS Support Node. A wireless gateway that allows mobile cell phone users to access the public data network (PDN) or specified private IP networks. The GGSN function is implemented on the Cisco routers.

GPRS—General Packet Radio Service. A 2.5G mobile communications technology that enables mobile wireless service providers to offer their mobile subscribers with packet-based data services over GSM networks.

GSM network—Global System for Mobile Communications network. A digital cellular technology that is used worldwide, predominantly in Europe and Asia. GSM is the world's leading standard in digital wireless communications.

Home Agent—A Home Agent is a router on the home network of the Mobile Node (MN) that maintains an association between the home IP address of the MN and its care-of address, which is the current location of the MN on a foreign or visited network. The HA redirects packets by tunneling them to the MN while it is away from the home network.

HSRP—Hot Standby Router Protocol. Provides high network availability and transparent network topology changes. HSRP creates a Hot Standby router group with a lead router that services all packets sent to the Hot Standby address. The lead router is monitored by other routers in the group, and if it fails, one of these standby routers inherits the lead position and the Hot Standby group address.

IPCP—IP Control Protocol. The protocol used to establish and configure IP over PPP.

LCP—Link Control Protocol. The protocol used to establish, configure, and test data-link connections for use by PPP.

PDSN—Packet Data Serving Node. The Cisco PDSN is a standards-compliant, wireless gateway that enables packet data services in a Code Division Multiplex Access (CDMA) environment. Acting as an access gateway, the Cisco PDSN provides simple IP and Mobile IP access, foreign-agent support, and packet transport for Virtual Private Networks (VPN).

PPP—Point-to-Point Protocol. Provides router-to-router and host-to-network connections over synchronous and asynchronous circuits. PPP is most commonly used for dial-up Internet access. Its features include address notification, authentication via CHAP or PAP, support for multiple protocols, and link monitoring.

VRF—VPN routing and forwarding instance. A VRF consists of an IP routing table, a derived forwarding table, a set of interfaces that use the forwarding table, and a set of rules and routing protocols that determine what goes into the forwarding table. In general, a VRF includes the routing information that defines a customer VPN site that is attached to a provider edge router.

VRRP—Virtual Router Redundancy Protocol. Eliminates the single point of failure inherent in the static default routed environment. VRRP specifies an election protocol that dynamically assigns responsibility for a virtual router to one of the VRRP routers on a LAN. The VRRP router that controls the IP addresses associated with a virtual router is called the master, and forwards packets sent to these IP addresses. The

election process provides dynamic failover in the forwarding responsibility should the master become unavailable. Any of the virtual router IP addresses on a LAN can then be used as the default first-hop router by end hosts.

CCDE, CCENT, CCSI, Cisco Eos, Cisco HealthPresence, Cisco IronPort, the Cisco logo, Cisco Lumin, Cisco Nexus, Cisco Nurse Connect, Cisco Pulse, Cisco StackPower, Cisco StadiumVision, Cisco TelePresence, Cisco Unified Computing System, Cisco WebEx, DCE, Flip Channels, Flip for Good, Flip Mino, Flipshare (Design), Flip Ultra, Flip Video, Flip Video (Design), Instant Broadband, and Welcome to the Human Network are trademarks; Changing the Way We Work, Live, Play, and Learn, Cisco Capital, Cisco Capital (Design), Cisco:Financed (Stylized), Cisco Store, and Flip Gift Card are service marks; and Access Registrar, Aironet, AllTouch, AsyncOS, Bringing the Meeting To You, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, CCVP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Collaboration Without Limitation, Continuum, EtherFast, EtherSwitch, Event Center, Explorer, Fast Step, Follow Me Browsing, FormShare, GainMaker, GigaDrive, HomeLink, iLYNX, Internet Quotient, IOS, iPhone, iQuick Study, IronPort, the IronPort logo, Laser Link, LightStream, Linksys, MediaTone, MeetingPlace, MeetingPlace Chime Sound, MGX, Networkers, Networking Academy, Network Registrar, PCNow, PIX, PowerKEY, PowerPanels, PowerTV, PowerTV (Design), PowerVu, Prisma, ProConnect, ROSA, ScriptShare, SenderBase, SMARTnet, Spectrum Expert, StackWise, The Fastest Way to Increase Your Internet Quotient, TransPath, WebEx, and the WebEx logo are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0908R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

©2005–2009 Cisco Systems, Inc. All rights reserved.