



DSP Operational State Notifications

The DSP Operational State Notifications feature enables notifications to be generated when digital signaling processor (DSP) failure and recovery events occur. These notifications help facilitate troubleshooting and lessen downtime.

This feature module describes updates to the Cisco DSP Management MIB (CISCO-DSP-MGMT-MIB) for enabling and generating DSP operational state notifications. Also described is how to enable the feature either using the command-line interface (CLI) or by modifying settings at the network management device.

History for the DSP Operational State Notifications Feature

Release	Modification
12.4(4)T	This feature was introduced.

Finding Support Information for Platforms and Cisco IOS Software Images

Use Cisco Feature Navigator to find information about platform support and Cisco IOS software image support. Access Cisco Feature Navigator at <http://www.cisco.com/go/fn>. You must have an account on Cisco.com. If you do not have an account or have forgotten your username or password, click **Cancel** at the login dialog box and follow the instructions that appear.

Contents

- [Prerequisites for DSP Operational State Notifications, page 2](#)
- [Information About DSP Operational State Notifications, page 2](#)
- [How to Enable DSP Operational State Notifications, page 2](#)
- [Configuration Examples for DSP Operational State Notifications, page 4](#)
- [Additional References, page 5](#)
- [Command Reference, page 5](#)



Americas Headquarters:
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

© 2007 Cisco Systems, Inc. All rights reserved.

Prerequisites for DSP Operational State Notifications

- Familiarity with the CISCO-DSP-MGMT-MIB and Simple Network Management Protocol (SNMP).

Information About DSP Operational State Notifications

To enable DSP operational state notifications when a DSP fails and when it recovers, you should understand the following concepts:

- [CISCO-DSP-MGMT-MIB, page 2](#)
- [DSP Operational State Notification, page 2](#)
- [Benefits of DSP Operational State Notifications, page 2](#)

CISCO-DSP-MGMT-MIB

The CISCO-DSP-MGMT-MIB monitors DSP resources and status.

DSP Operational State Notification

A DSP notification consists of a DSP ID that indicates which DSP is affected and an operational state that indicates whether the DSP has failed or recovered.

When this feature is configured using the **snmp-server enable traps dsp oper-state** command, a notification is generated when a single DSP fails instead of after all DSPs have failed. For example, a DSP fails, and you lose your voice calls. In a DSP failure notification, the problem is identified. If no DSP failure notification is generated, a network management station (NMS) has to poll the router for configuration and status information to diagnose the problem.

Benefits of DSP Operational State Notifications

The DSP Operational State Notifications feature enables the generation of notifications when DSP failure and recovery events occur. These notifications help facilitate troubleshooting and lessen downtime because an NMS does not have to poll the router for configuration and status information to diagnose the problem..

How to Enable DSP Operational State Notifications

DSP operational state notifications can be configured in two ways. To configure these notifications, perform one of the following tasks:

- [Enabling DSP Operational State Notifications from the CLI, page 3](#)
- [Enabling DSP Operational State Notifications Using an SNMP Application, page 3](#)

Enabling DSP Operational State Notifications from the CLI

Perform this task to enable DSP operational state notifications from the CLI.

SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **snmp-server enable traps** *[notification type][vrrp]*
4. **end**
5. **exit**

DETAILED STEPS

	Command or Action	Purpose
Step 1	enable Example: Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none">• Enter your password if prompted.
Step 2	configure terminal Example: Router# configure terminal	Enters global configuration mode.
Step 3	snmp-server enable traps <i>[notification-type] [vrrp]</i> Example: Router(config)# snmp-server enable traps dsp oper-state	Enables the generation of DSP notifications made up of the DSP ID that indicates which DSP is affected and the operational state that indicates whether the DSP has failed or recovered.
Step 4	end Example: Router(config)# end	Returns the device to privileged EXEC mode.
Step 5	exit Example: Router# exit	Returns the device to user EXEC mode.

Enabling DSP Operational State Notifications Using an SNMP Application

Perform this task to enable DSP operational state notifications using your SNMP application.

SUMMARY STEPS

1. **setany -v2c 1.4.198.75 test cdspEnableOperStateNotification.0 -i 1**

DETAILED STEPS

Step 1 `setany -v2c 1.4.198.75 test cdspEnableOperStateNotification.0 -i 1`

This SNMP command sets the enable operation state notification object identifier (OID) to true.

After entering this command, the system returns the following response:

`cdspEnableOperStateNotification.0 = true(1)`.

Configuration Examples for DSP Operational State Notifications

- [Enabling DSP Operational State Notifications Using the CLI: Example, page 4](#)
- [Enabling DSP Operational State Notifications Using an SNMP Application: Example, page 4](#)

Enabling DSP Operational State Notifications Using the CLI: Example

The following sample configuration code shows how to enable DSP operational state notifications using the CLI:

```
Router> enable
Router# configure terminal
Router(config)# snmp-server enable traps dsp oper-state
```

The following example shows a typical DSP failure notification:

```
*Jun 1 02:37:05.720:SNMP:V1 Trap, ent cdspMIBNotificationPrefix, addr 1.4.198.75, gentrap
6, spectrap 2
cdspOperState.37 = 2
entPhysicalEntry.7.37 = DSP (C549) 1/2/0
```

The following example shows a typical DSP recover notification:

```
*Jun 1 02:37:10.820:SNMP:V1 Trap, ent cdspMIBNotificationPrefix, addr 1.4.198.75, gentrap
6, spectrap 2
cdspOperState.37 = 1
entPhysicalEntry.7.37 = DSP (C549) 1/2/0
```

Enabling DSP Operational State Notifications Using an SNMP Application: Example

The following sample configuration code shows how to enable DSP operational state notifications from your SNMP application:

In your SNMP application, you type the following command:

```
setany -v2c 1.4.198.75 test cdspEnableOperStateNotification.0 -i 1
```

The application shows the following response:

```
cdspEnableOperStateNotification.0 = true(1)
```

Additional References

The following sections provide references related to the DSP Operational State Notifications feature.

Related Documents

Related Topic	Document Title
Network management commands	Cisco IOS Network Management Command Reference

MIBs

MIB	MIBs Link
<ul style="list-style-type: none"> CISCO-DSP-MGMT-MIB CISCO-DSP-MGMT-CAPABILITY-MIB 	<p>To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL:</p> <p>http://www.cisco.com/go/mibs</p>

Technical Assistance

Description	Link
The Cisco Technical Support website contains thousands of pages of searchable technical content, including links to products, technologies, solutions, technical tips, and tools. Registered Cisco.com users can log in from this page to access even more content.	http://www.cisco.com/techsupport

Command Reference

The following commands are introduced or modified in the feature or features documented in this module. For information about these commands, see the *Cisco IOS Network Management Command Reference* at http://www.cisco.com/en/US/docs/ios/netmgmt/command/reference/nm_book.html. For information about all Cisco IOS commands, go to the Command Lookup Tool at <http://tools.cisco.com/Support/CLILookup> or to the *Cisco IOS Master Commands List*.

- snmp-server enable traps**

CCDE, CCENT, Cisco Eos, Cisco Lumin, Cisco Nexus, Cisco StadiumVision, Cisco TelePresence, Cisco WebEx, the Cisco logo, DCE, and Welcome to the Human Network are trademarks; Changing the Way We Work, Live, Play, and Learn and Cisco Store are service marks; and Access Registrar, Aironet, AsyncOS, Bringing the Meeting To You, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, CCVP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Collaboration Without Limitation, EtherFast, EtherSwitch, Event Center, Fast Step, Follow Me Browsing, FormShare, GigaDrive, HomeLink, Internet Quotient, IOS, iPhone, iQuick Study, IronPort, the IronPort logo, LightStream, Linksys, MediaTone, MeetingPlace, MeetingPlace Chime Sound, MGX, Networkers, Networking Academy, Network Registrar, PCNow, PIX, PowerPanels, ProConnect, ScriptShare, SenderBase, SMARTnet, Spectrum Expert, StackWise, The Fastest Way to Increase Your Internet Quotient, TransPath, WebEx, and the WebEx logo are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0809R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

© 2007 Cisco Systems, Inc. All rights reserved.