



# Configuring System Logging Counts

---

This document describes the System Logging (error logging) count enhancement feature in Cisco IOS Release 12.2(8)T. It includes the following sections:

- [Feature Overview, page 1](#)
- [Finding Feature Information, page 2](#)
- [Supported Standards, MIBs, and RFCs, page 2](#)
- [Configuration Tasks, page 2](#)
- [Configuration Examples, page 3](#)
- [Feature Information for Event Tracer, page 4](#)

## Feature Overview

The Cisco IOS logging facility allows you to save error messages locally or to a remote host. When these error messages exceed the capacity of the local buffer dedicated to storing them, the oldest messages are removed. To provide you with more information about messages that have occurred and may have been removed from the local buffer, an error log counter tabulates the occurrences of each error message, and time-stamps the most recent occurrence.

These messages are further sorted by message facility. Messages from each message facility are grouped together and totaled in the count. If a message is rate-limited, the count is incremented based on the actual messages that have occurred.

The **service timestamps** command configuration determines the format of the “Last Time” column in the **show logging** command output. Use the **service timestamps** command to configure the time-stamp format in the “Last Time” column.

## Benefits

- Provides detailed information regarding system messages, including the most recent time the message occurred.
- Alerts you to a potential problem with the system if you see the same error message occurring repeatedly.



---

**Americas Headquarters:**  
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

## Related Features and Technologies

- Cisco IOS Logging

## Finding Feature Information

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the “[Feature Information for Event Tracer](#)” section on page 4.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to <http://www.cisco.com/go/cfn>. An account on Cisco.com is not required.

## Supported Standards, MIBs, and RFCs

### Standards

No new or modified standards are supported by this feature.

### MIBs

No new MIBs are supported by this feature

To obtain lists of supported MIBs by platform and Cisco IOS release, and to download MIB modules, go to the Cisco MIB website on Cisco.com at the following URL:

<http://www.cisco.com/public/sw-center/netmgmt/cmtk/mibs.shtml>

### RFCs

No new or modified RFCs are supported by this feature.

## Configuration Tasks

See the following sections for configuration tasks for this feature. Each task in the list is identified as either required or optional.

- [Enabling the Error Log Count Capability](#) (required)

## Enabling the Error Log Count Capability

To enable the error log count capability, use the following command in global configuration mode:

Command	Purpose
Router(config)# <b>logging count</b>	Enables the error log count capability.

## Verifying the Error Log Count Capability

Enter the **show logging count** command to view information about syslog error messages.

```
Router# show logging count
```

```

Facility      Message Name                               Sev Occur   Last Time
=====
SYS          BOOTTIME                                   6    1 00:00:12
SYS          RESTART                                    5    1 00:00:11
SYS          CONFIG_I                                   5    3 1d00h
-----
SYS TOTAL                                         5

LINEPROTO    UPDOWN                                     5   13 00:00:19
-----
LINEPROTO TOTAL                                 13

LINK         UPDOWN                                     3    1 00:00:18
LINK         CHANGED                                    5   12 00:00:09
-----
LINK TOTAL                                       13

SNMP         COLDSTART                                  5    1 00:00:11
-----
SNMP TOTAL                                       1

```

## Configuration Examples

This section provides the following configuration example:

- [Enabling the Error Log Count Capability: Example](#)

### Enabling the Error Log Count Capability: Example

In the following example, the error log count capability is enabled:

```

Router# logging count

Building configuration...
Current configuration : 2507 bytes
!
! Last configuration change at 14:53:38 UTC Tue Feb 5 2002
!
.
.
.
hostname router
!
logging count
logging buffered notifications

```

# Feature Information for Event Tracer

**Table 1**      *Feature Information for Event Tracer*

Feature Name	Releases	Feature Information
Event Tracer	12.2(8)T	The Cisco IOS logging facility allows you to save error messages locally or to a remote host.  The following commands were introduced or modified: <b>logging count, show logging.</b>

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks). Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2005 Cisco Systems, Inc. All rights reserved.