



# Using Multilink PPP over ATM Links

---

**First Published: May 2, 2005**  
**Last Updated: October 2, 2009**

Multilink PPP is a method that is used to reduce latency and jitter for real-time traffic. This module contains conceptual information and configuration tasks for using Multilink PPP over ATM links.

## Finding Feature Information

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the “[Feature Information for Using Multilink PPP over ATM Links](#)” section on page 15.

Use Cisco Feature Navigator to find information about platform support and Cisco IOS and Catalyst OS software image support. To access Cisco Feature Navigator, go to <http://www.cisco.com/go/cfn>. An account on Cisco.com is not required.

## Contents

- [Prerequisites for Using Multilink PPP over ATM Links](#), page 2
- [Restrictions for Using Multilink PPP over ATM Links](#), page 2
- [Information About Using Multilink PPP over ATM Links](#), page 2
- [How to Configure Multilink PPP over ATM Links](#), page 3
- [Configuration Examples for Using Multilink PPP over ATM Links](#), page 11
- [Where to Go Next](#), page 13
- [Additional References](#), page 13
- [Feature Information for Using Multilink PPP over ATM Links](#), page 15
- [Glossary](#), page 17



---

**Americas Headquarters:**  
**Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA**

# Prerequisites for Using Multilink PPP over ATM Links

## Knowledge

- Be familiar with the concepts in the [“Reducing Latency and Jitter for Real-Time Traffic Using Multilink PPP”](#) module.

## Enable a Queueing Mechanism

- Multilink PPP uses first-in first-out (FIFO) queueing for queueing and interleaving packets. Other queueing mechanisms such as low latency queueing (LLQ), weighted fair queueing (WFQ), and class-based weighted fair queueing (CBWFQ) can be used. If you want to use one of these alternative mechanisms, enable it before configuring Multilink.

# Restrictions for Using Multilink PPP over ATM Links

## VoIP Support

- Only Voice over IP (VoIP) is supported; Voice over ATM is not supported.

## ATM Network Modules Supported

- Multilink PPP over ATM must use the following ATM network modules:
  - Multiport T1/E1 ATM Network Module with Inverse Multiplexing over ATM
  - ATM OC-3 Network Module
  - Enhanced ATM Port Adapter

# Information About Using Multilink PPP over ATM Links

To use Multilink PPP over ATM links, you should understand the following concepts:

- [MQC and Multilink PPP over ATM Links, page 2](#)
- [Virtual Template Interfaces, page 3](#)
- [Multilink Group Interfaces, page 3](#)

## MQC and Multilink PPP over ATM Links

Before using Multilink PPP over ATM links, a policy map must be created. (See the [“Prerequisites” section on page 6](#).) Policy maps are created using the Modular Quality of Service (QoS) Command-Line Interface (CLI) (MQC).

The MQC is a CLI structure that allows users to create traffic polices (policy maps) and attach these policy maps to interfaces. A policy map contains a traffic class and one or more QoS features. A traffic class is used to classify traffic. The QoS features in the traffic policy determine how to treat the classified traffic.

For more information about MQC, see the [“Applying QoS Features Using the MQC”](#) module.

## Virtual Template Interfaces

A virtual template interface is a logical interface that is configured with generic configuration information for a specific purpose or a configuration common to specific users, plus router-dependent information. The template takes the form of a list of Cisco IOS interface commands that are applied to virtual access interfaces, as needed.

For more information about virtual template interfaces, see the [“Configuring Virtual Template Interfaces”](#) module.

## Multilink Group Interfaces

A multilink group interface is a collection of interfaces that are bundled together in the multilink PPP configuration. With a multilink group interface, you can bundle interfaces into logical multilink groups.

For more information about multilink group interfaces and multilink groups, see the [“Configuring Media-Independent PPP and Multilink PPP”](#) module.

# How to Configure Multilink PPP over ATM Links

This section contains the procedures for configuring Multilink PPP over ATM links.

**Note**

While the first two procedures are listed as optional, you must choose one or the other according to the Cisco router that you are using in your network.

- [Configuring Multilink PPP over ATM Links on a Virtual Template Interface, page 3](#) (optional; applies only if you are using the Cisco 7500 series router or the Cisco 7600 series router)  
or
- [Configuring Multilink PPP over ATM Links on a Multilink Group Interface, page 6](#) (optional)
- [Associating the Virtual Template Interface with an ATM PVC, page 9](#) (required)
- [Verifying the Multilink PPP over ATM Links Configuration, page 10](#) (optional)

## Configuring Multilink PPP over ATM Links on a Virtual Template Interface

To configure Multilink PPP over ATM links on a virtual template interface, complete the following steps.

**Note**

These steps apply if you are using the Cisco 7500 series router or the Cisco 7600 series router only. If you are using another series of Cisco router, do not complete these steps. Instead, advance to the [“Configuring Multilink PPP over ATM Links on a Multilink Group Interface”](#) section on page 6.

## Prerequisites

Before proceeding with this task, you must create a policy map. The policy map contains the configuration parameters used to apply a specific QoS feature, such as distributed LLQ (dLLQ), to the network traffic. To create a policy map and configure the appropriate QoS feature, use the MQC as described in the “MQC and Multilink PPP over ATM Links” section on page 2.

## SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **interface virtual-template** *number*
4. **bandwidth** *kbps*
5. **ip address** *ip-address mask [secondary]*
6. **service-policy output** *policy-map-name*
7. **service-policy input** *policy-map-name*
8. **ppp multilink**
9. **ppp multilink fragment delay** *milliseconds [microseconds]*
10. **ppp multilink interleave**
11. **end**

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
Step 2	<b>configure terminal</b>  <b>Example:</b> Router# configure terminal	Enters global configuration mode.
Step 3	<b>interface virtual-template</b> <i>number</i>  <b>Example:</b> Router(config)# interface virtual-template 4	Creates a virtual template and enters interface configuration mode. <ul style="list-style-type: none"> <li>• Enter the virtual template number.</li> </ul>
Step 4	<b>bandwidth</b> <i>kbps</i>  <b>Example:</b> Router(config-if)# bandwidth 32	Sets the bandwidth value for an interface. <ul style="list-style-type: none"> <li>• Enter the bandwidth value in kilobits per second.</li> </ul>
Step 5	<b>ip address</b> <i>ip-address mask [secondary]</i>  <b>Example:</b> Router(config-if)# ip address 10.10.100.1 255.255.255.0	Sets a primary IP address for an interface. This command can also set the optional secondary IP address for an interface. <ul style="list-style-type: none"> <li>• Enter the primary IP address (and, optionally, the secondary IP address).</li> </ul>

	Command or Action	Purpose
Step 6	<p><b>service-policy output</b> <i>policy-map-name</i></p> <p><b>Example:</b> Router(config-if)# service-policy output policy1</p>	<p>Attaches the previously created QoS traffic policy (policy map). See the “Prerequisites” section on page 6. The policy map evaluates and applies QoS features for traffic <i>leaving</i> the interface.</p> <ul style="list-style-type: none"> <li>Enter the policy map name.</li> </ul>
Step 7	<p><b>service-policy input</b> <i>policy-map-name</i></p> <p><b>Example:</b> Router(config-if)# service-policy input policy1</p>	<p>Attaches the previously created QoS traffic policy (policy map). See the “Prerequisites” section on page 6. The policy map evaluates and applies QoS features for traffic <i>entering</i> the interface.</p> <ul style="list-style-type: none"> <li>Enter the policy map name.</li> </ul>
Step 8	<p><b>ppp multilink</b></p> <p><b>Example:</b> Router(config-if)# ppp multilink</p>	<p>Enables Multilink PPP (MLP) on the interface.</p>
Step 9	<p><b>ppp multilink fragment delay</b> <i>milliseconds</i> <i>[microseconds]</i></p> <p><b>Example:</b> Router(config-if)# ppp multilink fragment delay 20</p>	<p>Specifies a maximum size in units of time for packet fragments on an MLP bundle.</p> <ul style="list-style-type: none"> <li>Enter the maximum amount of time, in milliseconds.</li> </ul> <p><b>Note</b> The fragment delay can be calculated using the following formula:</p> $\text{fragment delay} = (\text{fragment size} * 8) / \text{bandwidth}$
Step 10	<p><b>ppp multilink interleave</b></p> <p><b>Example:</b> Router(config-if)# ppp multilink interleave</p>	<p>Enables interleaving of packets among the fragments of larger packets on a multilink bundle.</p>
Step 11	<p><b>end</b></p> <p><b>Example:</b> Router(config-if)# end</p>	<p>(Optional) Exits interface configuration mode and returns to privileged EXEC mode.</p>

## Configuring Multilink PPP over ATM Links on a Multilink Group Interface

To configure Multilink PPP over ATM Links on a Multilink Group Interface, complete the following steps.



### Note

If you are using the Cisco 7500 series router or the Cisco 7600 series router, do not complete these steps. Instead, complete the steps in [“Configuring Multilink PPP over ATM Links on a Virtual Template Interface”](#) section on page 3.

## Prerequisites

Before proceeding with this task, you must create a policy map. The policy map contains the configuration parameters used to apply a specific QoS feature, such as distributed LLQ (dLLQ), to the network traffic. To create a policy map and configure the appropriate QoS feature, use the MQC as described in [“MQC and Multilink PPP over ATM Links”](#) section on page 2.

## SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **interface multilink** *multilink-bundle-number*
4. **ip address** *ip-address mask* [**secondary**]
5. **service-policy output** *policy-map-name*
6. **service-policy input** *policy-map-name*
7. **ppp multilink fragment delay** *milliseconds* [*microseconds*]
8. **ppp multilink interleave**
9. **ppp multilink multiclass**
10. **end**

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
Step 2	<b>configure terminal</b>  <b>Example:</b> Router# configure terminal	Enters global configuration mode.
Step 3	<b>interface multilink</b> <i>multilink-bundle-number</i>  <b>Example:</b> Router(config)# interface multilink 1	Creates a multilink bundle and enters interface configuration mode. <ul style="list-style-type: none"> <li>• Enter the multilink bundle number.</li> </ul>

	Command or Action	Purpose
Step 4	<p><b>ip address</b> <i>ip-address mask</i> [<b>secondary</b>]</p> <p><b>Example:</b> Router(config-if)# ip address 10.10.100.1 255.255.255.0</p>	<p>Sets a primary IP address for an interface. This command can also set the optional secondary IP address for an interface.</p> <ul style="list-style-type: none"> <li>Enter the primary IP address (and, optionally, the secondary IP address).</li> </ul>
Step 5	<p><b>service-policy output</b> <i>policy-map-name</i></p> <p><b>Example:</b> Router(config-if)# service-policy output policy1</p>	<p>Attaches the previously created QoS traffic policy (policy map). See the “Prerequisites” section on page 4. The policy map evaluates and applies QoS features for traffic <i>leaving</i> the interface.</p> <ul style="list-style-type: none"> <li>Enter the policy map name.</li> </ul>
Step 6	<p><b>service-policy input</b> <i>policy-map-name</i></p> <p><b>Example:</b> Router(config-if)# service-policy input policy1</p>	<p>Attaches the previously created QoS traffic policy (policy map). See the “Prerequisites” section on page 4. The policy map evaluates and applies QoS features for traffic <i>entering</i> the interface.</p> <ul style="list-style-type: none"> <li>Enter the policy map name.</li> </ul>
Step 7	<p><b>ppp multilink fragment delay</b> <i>milliseconds</i> [<i>microseconds</i>]</p> <p><b>Example:</b> Router(config-if)# ppp multilink fragment delay 20</p>	<p>Specifies a maximum size in units of time for packet fragments on a Multilink PPP (MLP) bundle.</p> <ul style="list-style-type: none"> <li>Enter the maximum amount of time, in milliseconds.</li> </ul>
Step 8	<p><b>ppp multilink interleave</b></p> <p><b>Example:</b> Router(config-if)# ppp multilink interleave</p>	<p>Enables interleaving of packets among the fragments of larger packets on a multilink bundle.</p>
Step 9	<p><b>ppp multilink multiclass</b></p> <p><b>Example:</b> Router(config-if)# ppp multilink multiclass</p>	<p>(Optional) Enables Multiclass Multilink PPP (MCMP) on an interface.</p> <p><b>Note</b> Use this command only if there are multiple links in the multilink bundle.</p>
Step 10	<p><b>end</b></p> <p><b>Example:</b> Router(config-if)# end</p>	<p>(Optional) Exits interface configuration mode and returns to privileged EXEC mode.</p>

## What to Do Next

After configuring Multilink PPP over ATM links on a multilink group interface, the next step is to associate the virtual template interface with the multilink group by completing the steps in the following section.

If you are using a Cisco 7500 series router or a Cisco 7600 series router, advance to the “Associating the Virtual Template Interface with an ATM PVC” section on page 9 to continue.

## Associating the Virtual Template Interface with the Multilink Group

To associate the virtual template interface with the multilink group, complete the following steps.

## SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **interface virtual-template** *number*
4. **no ip address** [*ip-address mask [secondary]*]
5. **ppp multilink group** *group-number*
6. **end**

## DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
Step 2	<b>configure terminal</b>  <b>Example:</b> Router# configure terminal	Enters global configuration mode.
Step 3	<b>interface virtual-template</b> <i>number</i>  <b>Example:</b> Router(config)# interface virtual-template 2	Creates a virtual template interface that can be configured and applied dynamically in creating virtual access interfaces, and enters interface configuration mode. <ul style="list-style-type: none"> <li>• Enter the number used to identify the virtual template interface.</li> </ul>
Step 4	<b>no ip address</b> [ <i>ip-address mask [secondary]</i> ]  <b>Example:</b> Router(config-if)# no ip address	Removes an IP address or disables IP processing.
Step 5	<b>ppp multilink group</b> <i>group-number</i>  <b>Example:</b> Router(config-if)# ppp multilink group 1	Restricts a physical link to joining only a designated multilink group interface. <ul style="list-style-type: none"> <li>• Enter the multilink group number.</li> </ul>
Step 6	<b>end</b>  <b>Example:</b> Router(config-if)# end	(Optional) Exits interface configuration mode and returns to privileged EXEC mode.

## Associating the Virtual Template Interface with an ATM PVC

To associate the virtual template interface with an ATM PVC, complete the following steps.

### SUMMARY STEPS

1. **enable**
2. **configure terminal**
3. **interface** *type number* [**name-tag**]
4. **pvc** [*name*] *vpi/vci* [**ces** | **ilmi** | **qsaal** | **smds** | **l2transport**]
5. **abr** *output-pcr output-mcr*
6. **vbr-nrt** *output-pcr output-scr output-mbs* [*input-pcr*] [*input-scr*] [*input-mbs*]
7. **protocol ppp virtual-template** *number*
8. **end**

### DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"><li>• Enter your password if prompted.</li></ul>
Step 2	<b>configure terminal</b>  <b>Example:</b> Router# configure terminal	Enters global configuration mode.
Step 3	<b>interface</b> <i>type number</i> [ <b>name-tag</b> ]  <b>Example:</b> Router(config)# interface atm2/0/0	Configures an interface type and enters interface configuration mode. <ul style="list-style-type: none"><li>• Enter the interface type and number.</li></ul>
Step 4	<b>pvc</b> [ <i>name</i> ] <i>vpi/vci</i> [ <b>ces</b>   <b>ilmi</b>   <b>qsaal</b>   <b>smds</b>   <b>l2transport</b> ]  <b>Example:</b> Router(config-if)# pvc cisco 0/16	Creates or assigns a name to an ATM permanent virtual circuit (PVC) and enters ATM virtual circuit configuration mode. <ul style="list-style-type: none"><li>• Enter the ATM PVC name, the network virtual path identifier, and the network virtual channel identifier.</li></ul>
Step 5	<b>abr</b> <i>output-pcr output-mcr</i>  <b>Example:</b> Router(config-if-atm-vc)# abr 100 80	(Optional) Selects available bit rate (ABR) QoS and configures the output peak cell rate (PCR) and output minimum guaranteed cell rate (MCR) for an ATM PVC. <ul style="list-style-type: none"><li>• Enter the output PCR and the output MCR.</li></ul>

	Command or Action	Purpose
Step 6	<b>vbr-nrt</b> <i>output-pcr output-scr output-mbs</i> <i>[input-pcr] [input-scr] [input-mbs]</i>  <b>Example:</b> Router(config-if-atm-vc)# vbr-nrt 1100 1100 100	(Optional) Configures the variable bit rate-nonreal time (VBR-NRT) quality of service (QoS) and specifies the output peak cell rate (PCR), the output sustainable cell rate (SCR), and the output maximum burst cell size (MBS) for an ATM PVC, PVC range, switched virtual circuit (SVC), VC class, or VC bundle member. <ul style="list-style-type: none"> <li>• Enter the output PCR, SCR, and MBS.</li> </ul>
Step 7	<b>protocol ppp virtual-template</b> <i>number</i>  <b>Example:</b> Router(config-if-atm-vc)# protocol ppp virtual-template 2	Specifies that PPP is established over the ATM PVC using the configuration from the specified virtual template. <ul style="list-style-type: none"> <li>• Enter the virtual-template number.</li> </ul>
Step 8	<b>end</b>  <b>Example:</b> Router(config-if-atm-vc)# end	(Optional) Exits ATM virtual circuit configuration mode and returns to privileged EXEC mode.

## Verifying the Multilink PPP over ATM Links Configuration

To verify the Multilink PPP over ATM Links configuration, complete the following steps.

### SUMMARY STEPS

1. **enable**
2. **show atm pvc** [*vpi/vci* | *name* | **interface atm** *interface-number* [*.subinterface-number multipoint*]] [**ppp**]
3. **show interfaces** [*type number*] [*first*] [*last*] [**accounting**]
4. **show ppp multilink** [**active** | **inactive** | **interface** *bundle-interface* | [**username** *name*] [**endpoint endpoint**]]
5. **show policy-map interface** *interface-name* [**vc** [*vpi*] *vci*] [**dlsi** *dlsi*] [**input** | **output**]
6. **exit**

### DETAILED STEPS

	Command or Action	Purpose
Step 1	<b>enable</b>  <b>Example:</b> Router> enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> <li>• Enter your password if prompted.</li> </ul>
Step 2	<b>show atm pvc</b> [ <i>vpi/vci</i>   <i>name</i>   <b>interface atm</b> <i>interface-number</i> [ <i>.subinterface-number multipoint</i> ]] [ <b>ppp</b> ]  <b>Example:</b> Router# show atm pvc	(Optional) Displays all ATM PVCs and traffic information.

	Command or Action	Purpose
Step 3	<code>show interfaces</code> [ <i>type number</i> ] [ <i>first</i> ] [ <i>last</i> ] [ <i>accounting</i> ]  <b>Example:</b> Router# show interfaces	(Optional) Displays statistics for all interfaces that are configured on the router or access server.
Step 4	<code>show ppp multilink</code> [ <i>active</i>   <i>inactive</i>   <i>interface bundle-interface</i>   [ <i>username name</i> ] [ <i>endpoint endpoint</i> ]]  <b>Example:</b> Router# show ppp multilink	(Optional) Displays bundle information for multilink bundles.
Step 5	<code>show policy-map interface</code> <i>interface-name</i> [ <i>vc</i> [ <i>vpi/</i> ] <i>vci</i> ] [ <i>dlci dlci</i> ] [ <i>input</i>   <i>output</i> ]  <b>Example:</b> Router# show policy-map interface serial0/0	(Optional) Displays the packet statistics of all classes that are configured for all service policies either on the specified interface or subinterface or on a specific PVC on the interface.
Step 6	<code>exit</code>  <b>Example:</b> Router# exit	(Optional) Exits privileged EXEC mode.

## Configuration Examples for Using Multilink PPP over ATM Links

This section contains the following examples:

- [Configuring Multilink PPP over ATM Links on a Virtual Template Interface: Example, page 11](#)
- [Configuring Multilink PPP over ATM Links on a Multilink Group Interface: Example, page 12](#)
- [Associating the Virtual Template Interface with the Multilink Group: Example, page 12](#)
- [Associating the Virtual Template Interface with an ATM PVC: Example, page 12](#)
- [Verifying the Multilink PPP over ATM Links Configuration: Example, page 12](#)

### Configuring Multilink PPP over ATM Links on a Virtual Template Interface: Example

The following is an example of configuring Multilink PPP over ATM links on a virtual template interface:

```
Router> enable
Router# configure terminal
Router(config)# interface virtual-template 4
Router(config-if)# bandwidth 32
```

```

Router(config-if)# ip address 10.10.100.1 255.255.255.0
Router(config-if)# service-policy output policy1
Router(config-if)# service-policy input policy1
Router(config-if)# ppp multilink
Router(config-if)# ppp multilink fragment delay 20
Router(config-if)# ppp multilink interleave
Router(config-if)# end

```

## Configuring Multilink PPP over ATM Links on a Multilink Group Interface: Example

The following is an example of configuring Multilink PPP over ATM links on a multilink group interface:

```

Router> enable
Router# configure terminal
Router(config)# interface multilink 1
Router(config-if)# ip address 10.10.100.1 255.255.255.0
Router(config-if)# service-policy output policy1
Router(config-if)# service-policy input policy1
Router(config-if)# ppp multilink fragment delay 20
Router(config-if)# ppp multilink interleave
Router(config-if)# ppp multilink multiclass
Router(config-if)# end

```

## Associating the Virtual Template Interface with the Multilink Group: Example

The following is an example of associating the virtual template interface with the multilink group:

```

Router> enable
Router# configure terminal
Router(config)# interface virtual-template 2
Router(config-if)# no ip address
Router(config-if)# ppp multilink group 1
Router(config-if)# end

```

## Associating the Virtual Template Interface with an ATM PVC: Example

The following is an example of associating the virtual template interface with an ATM PVC:

```

Router> enable
Router# configure terminal
Router(config)# interface atm2/0/0
Router(config-if)# pvc cisco 0/16
Router(config-if-atm-vc)# abr 100 80
Router(config-if-atm-vc)# protocol ppp virtual-template 2
Router(config-if-atm-vc)# end

```

## Verifying the Multilink PPP over ATM Links Configuration: Example

The following is an example of the `show ppp multilink` command output. In this example, one multilink bundle called 7206-2 is on the system. This bundle has two member links: one active link and one inactive link.

```

Router# show ppp multilink

Multilink1, bundle name is 7206-2
Endpoint discriminator is 7206-2
Bundle up for 00:00:24, 1/255 load
Receive buffer limit 12000 bytes, frag timeout 1000 ms
  0/0 fragments/bytes in reassembly list
  0 lost fragments, 0 reordered
  0/0 discarded fragments/bytes, 0 lost received
  0x0 received sequence, 0x0 sent sequence
Member links: 1 active, 1 inactive (max not set, min not set)
  Vi3, since 00:00:24
  PPPoATM link, ATM PVC 2/101 on ATM2/0/0
  Packets in ATM PVC Holdq: 0 , Particles in ATM PVC Tx Ring: 1
  Vt1 (inactive)

```

## Where to Go Next

To use Multilink PPP over Frame Relay, see the [“Using Multilink PPP over Frame Relay”](#) module.

To use Multilink PPP over dialer interface links, see the [“Using Multilink PPP over Dialer Interface Links”](#) module.

To use Multilink PPP over serial interface links, see the [“Using Multilink PPP over Serial Interface Links”](#) module.

## Additional References

The following sections provide references related to using Multilink PPP over ATM links.

## Related Documents

Related Topic	Document Title
QoS commands: complete command syntax, command modes, command history, defaults, usage guidelines, and examples	<a href="#">Cisco IOS Quality of Service Solutions Command Reference</a>
LLQ, WFQ, CBWFQ, PQ, CQ, FIFO, and other queueing mechanisms	<a href="#">“Configuring Weighted Fair Queueing”</a> module
MQC	<a href="#">“Applying QoS Features Using the MQC”</a> module
Multilink PPP configurations	<a href="#">“Configuring Media-Independent PPP and Multilink PPP”</a> module
Virtual template interfaces	<a href="#">“Configuring Virtual Template Interfaces”</a> module
Multilink PPP overview module	<a href="#">“Reducing Latency and Jitter for Real-Time Traffic Using Multilink PPP”</a> module
Multilink PPP over Frame Relay	<a href="#">“Using Multilink PPP over Frame Relay”</a> module
Multilink PPP over dialer interface links	<a href="#">“Using Multilink PPP over Dialer Interface Links”</a> module
Multilink PPP over serial interface links	<a href="#">“Using Multilink PPP over Serial Interface Links”</a> module

## Standards

Standard	Title
No new or modified standards are supported, and support for existing standards has not been modified.	—

## MIBs

MIB	MIBs Link
No new or modified MIBs are supported, and support for existing MIBs has not been modified.	To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL: <a href="http://www.cisco.com/go/mibs">http://www.cisco.com/go/mibs</a>

## RFCs

RFC	Title
RFC 1990	<i>The PPP Multilink Protocol (MP)</i>
RFC 2686	<i>Multiclass Extension to Multilink PPP (MCML)</i>

## Technical Assistance

Description	Link
<p>The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.</p> <p>To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds.</p> <p>Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.</p>	<a href="http://www.cisco.com/techsupport">http://www.cisco.com/techsupport</a>

# Feature Information for Using Multilink PPP over ATM Links

Table 1 lists the features in this module and provides links to specific configuration information.

For information on a feature in this technology that is not documented here, see the “[Reducing Latency and Jitter Using Multilink PPP Roadmap](#)” module.

Not all commands may be available in your Cisco IOS software release. For release information about a specific command, see the command reference documentation.

Use Cisco Feature Navigator to find information about platform support and software image support. Cisco Feature Navigator enables you to determine which Cisco IOS and Catalyst OS software images support a specific software release, feature set, or platform. To access Cisco Feature Navigator, go to <http://www.cisco.com/go/cfn>. An account on Cisco.com is not required.



**Note**

Table 1 lists only the Cisco IOS software release that introduced support for a given feature in a given Cisco IOS software release train. Unless noted otherwise, subsequent releases of that Cisco IOS software release train also support that feature..

**Table 1** Feature Information for Using Multilink PPP over ATM Links

Feature Name	Releases	Feature Information
Distributed Link Fragmentation and Interleaving for Frame Relay and ATM Interfaces on Cisco 7500 Series Routers	12.2(4)T	<p>The Distributed Link Fragmentation and Interleaving (dLFI) for Frame Relay and ATM Interfaces on Cisco 7500 Series Routers feature extends link fragmentation and interleaving functionality to VIP-enabled Cisco 7500 series routers.</p> <p>This feature was extensively rewritten from the perspective of using Multilink PPP for link fragmentation and interleaving over ATM interface links.</p> <p>The following sections provide information about this feature:</p> <ul style="list-style-type: none"> <li>• <a href="#">Information About Using Multilink PPP over ATM Links, page 2</a></li> <li>• <a href="#">How to Configure Multilink PPP over ATM Links, page 3</a></li> </ul>

**Table 1** Feature Information for Using Multilink PPP over ATM Links (continued)

Feature Name	Releases	Feature Information
Distributed Link Fragmentation and Interleaving over Leased Lines	12.2(8)T	<p>The Distributed Link Fragmentation and Interleaving over Leased Lines feature extends distributed link fragmentation and interleaving functionality to leased lines.</p> <p>This feature was extensively rewritten from the perspective of using Multilink PPP for link fragmentation and interleaving over ATM interface links.</p> <p>The following sections provide information about this feature:</p> <ul style="list-style-type: none"> <li>• <a href="#">Information About Using Multilink PPP over ATM Links, page 2</a></li> <li>• <a href="#">How to Configure Multilink PPP over ATM Links, page 3</a></li> </ul>
MLP LFI over ATM Configuration Scaling	12.2(25)S 12.2(27)SBA 15.0(1)M	<p>The MLP LFI over ATM Configuration Scaling feature supports the transport of real-time (voice) and non-real-time (data) traffic on lower-speed Frame Relay and ATM permanent virtual circuits (PVCs) without causing excessive delay of real-time traffic.</p> <p>The following sections provide information about this feature:</p> <ul style="list-style-type: none"> <li>• <a href="#">Information About Using Multilink PPP over ATM Links, page 2</a></li> <li>• <a href="#">How to Configure Multilink PPP over ATM Links, page 3</a></li> </ul> <p>The following commands were introduced or modified: <b>ppp multilink group</b></p>

# Glossary

**ATM**—Asynchronous Transfer Mode. The international standard for cell relay in which multiple service types (such as voice, video, or data) are conveyed in fixed-length (53-byte) cells. Fixed-length cells allow cell processing to occur in hardware, thereby reducing transit delays. ATM is designed to take advantage of high-speed transmission media, such as E3, SONET, and T3.

**PVC**—permanent virtual circuit (or connection). A virtual circuit that is permanently established. PVCs save bandwidth associated with circuit establishment and teardown in situations where certain virtual circuits must exist all the time. In ATM terminology, called a permanent virtual connection.

**virtual template interface**—A logical interface configured with generic configuration information for a specific purpose or configuration common to specific users, plus router-dependent information. The template takes the form of a list of Cisco IOS interface commands that are applied to virtual access interfaces, as needed.

---

CCDE, CCENT, CCSI, Cisco Eos, Cisco HealthPresence, Cisco IronPort, the Cisco logo, Cisco Lumin, Cisco Nexus, Cisco Nurse Connect, Cisco Pulse, Cisco StackPower, Cisco StadiumVision, Cisco TelePresence, Cisco Unified Computing System, Cisco WebEx, DCE, Flip Channels, Flip for Good, Flip Mino, Flipshare (Design), Flip Ultra, Flip Video, Flip Video (Design), Instant Broadband, and Welcome to the Human Network are trademarks; Changing the Way We Work, Live, Play, and Learn, Cisco Capital, Cisco Capital (Design), Cisco:Financed (Stylized), Cisco Store, and Flip Gift Card are service marks; and Access Registrar, Aironet, AllTouch, AsyncOS, Bringing the Meeting To You, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, CCVP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Collaboration Without Limitation, Continuum, EtherFast, EtherSwitch, Event Center, Explorer, Fast Step, Follow Me Browsing, FormShare, GainMaker, GigaDrive, HomeLink, iLYNX, Internet Quotient, IOS, iPhone, iQuick Study, IronPort, the IronPort logo, Laser Link, LightStream, Linksys, MediaTone, MeetingPlace, MeetingPlace Chime Sound, MGX, Networkers, Networking Academy, Network Registrar, PCNow, PIX, PowerKEY, PowerPanels, PowerTV, PowerTV (Design), PowerVu, Prisma, ProConnect, ROSA, ScriptShare, SenderBase, SMARTnet, Spectrum Expert, StackWise, The Fastest Way to Increase Your Internet Quotient, TransPath, WebEx, and the WebEx logo are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0908R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

© 2005–2009 Cisco Systems, Inc. All rights reserved.

