



Symbols

- ? command [4-2](#)
- ? command (ROM Monitor) [A-29](#)

A

- abbreviated commands, entering [4-2](#)
- abort command [2-31](#)
- aborting command output [4-7](#)
- admin command [B-5](#)
- admin configuration mode [2-18](#)
- admin EXEC mode [2-18](#)
- Admin package features [5-3](#)
- alarm correlation, logging [3-11](#)
- alarm logging
 - correlation [3-11](#)
 - locations [3-11](#)
 - severity levels [3-11](#)
- aliases [4-16](#)
- alphanumeric LED display, illustration (16-slot chassis) [1-6, 2-3](#)
- alphanumeric LED display, illustration (8-slot chassis) [1-7, 2-4](#)
- alphanumeric LED display, illustration (PRP-2) [1-8, 2-5](#)
- anchor characters [D-4](#)
- asynchronous operation, install command [5-26](#)

B

- Base package features [5-4](#)
- BGP, configuration limits [3-22](#)
- boot command (ROM Monitor) [A-14, A-25](#)
- BOOT variable [A-12](#)

- bring up
 - hardware, first time [1-5](#)
 - verifying status [1-12](#)

C

- capitalization, keyboard shortcuts [4-19](#)
- card type, displayed in prompt [2-11](#)
- characters
 - anchor [D-4](#)
 - parentheses for pattern recall [D-4](#)
 - pattern ranges [D-2](#)
 - special [D-2](#)
 - underscore wildcard [D-4](#)
- chassis
 - multiple-chassis system [1-1](#)
 - number, displayed in prompt [2-11](#)
- Cisco IOS XR software
 - initial startup [1-4](#)
 - supported hardware [1-1](#)
- Cisco IOS XR Software Selector tool [5-16](#)
- cisco-support user group [2-13](#)
- clear command [7-18](#)
- clear configuration commit command [3-9](#)
- clear configuration sessions command [7-21](#)
- CLI
 - identifying command mode [2-15](#)
 - introduction [1-2](#)
 - logging in [2-10](#)
 - prompt [2-11](#)
- clock, router [2-38](#)
- clock and scheduler card *See* CSC
- clock set command [2-39](#)

- clock timezone command [2-39](#)
- clock update-calendar command [2-40](#)
- command-line interface *See* CLI
- command mode
 - admin configuration [2-18](#)
 - administration EXEC [2-18](#)
 - CLI prompt [2-15](#)
 - configuration submodes [2-16](#)
 - EXEC [2-16](#)
 - global configuration [2-16](#)
 - interface configuration [2-17](#)
 - navigation [2-14](#)
 - navigation example [2-19](#)
 - ROM monitor mode [2-18](#)
 - router configuration [2-17](#)
 - router submode configuration [2-17](#)
- commands
 - abbreviated [4-2](#)
 - aliases [4-16](#)
 - applying templates [4-14](#)
 - completing a partial command [4-4](#)
 - creating templates [4-12](#)
 - identifying syntax errors [4-4](#)
 - more prompt, responding to [4-6](#)
 - no form [4-4](#)
 - on-screen help [4-2](#)
 - output
 - filtering [4-8](#)
 - halting [4-7](#)
 - narrowing [4-8](#)
 - redirecting to a file [4-7](#)
 - recall deleted entries [4-18](#)
 - redisplaying [4-18](#)
 - wildcards [4-11](#)
 - wrapped lines, editing [4-5](#)
- commit command [2-21](#)
- commit force command [7-19](#)
- commitIDs
 - clearing [3-9](#)
 - displaying [3-4](#)
 - displaying changes [3-6](#)
 - loading changes [3-8](#)
- committing a configuration [2-21](#)
- committing packages [5-36](#)
- complex expressions [D-3](#)
- config-register command [6-15](#)
- config-register command (ROM Monitor) [A-27](#)
- configuration
 - clearing changes [2-29](#)
 - committing [2-21](#)
 - displaying [2-23](#)
 - displaying errors [2-28](#)
 - ending a session [2-30](#)
 - limiting [3-17](#)
 - limits
 - BGP [3-22](#)
 - IS-IS [3-19](#)
 - MPLS [3-27](#)
 - multicast [3-26](#)
 - OSPF [3-19](#)
 - other [3-27](#)
 - RPL [3-24](#)
 - static routes [3-18](#)
 - merged configuration, displaying [2-23, 2-27](#)
 - overview [2-20](#)
 - reloading a failed configuration [2-29](#)
 - running configuration
 - displaying [2-24, 2-25](#)
 - locking [2-31](#)
 - unlocking [2-31](#)
 - target configuration
 - displaying [2-27](#)
 - introduction [2-21](#)
 - loading from a file [3-10](#)
 - saving to a file [3-10](#)
- configuration files, storage [2-23](#)
- configuration mode, entering EXEC commands [2-18](#)
- configurations, single and multiple-chassis [1-1](#)

configuration submodes [2-16](#)
 configuration templates
 applying [4-14](#)
 creating [4-12](#)
 configure exclusive command [2-32](#)
 confreg command (ROM Monitor) [A-30, A-31, A-32, C-6, C-7](#)
 connection
 CLI prompt [2-11](#)
 Console port
 connection [2-3](#)
 illustration (16-slot chassis) [1-6, 2-3](#)
 illustration (8-slot chassis) [1-7, 1-8, 2-4, 2-5](#)
 console port, connecting to [1-5](#)
 consolidated switch fabric cards *See* CSFC
 controller fabric plane command [6-21](#)
 controllers command [6-15](#)
 copy command [B-4, C-5](#)
 copy ftp command [5-27](#)
 copy rcp command [5-27](#)
 copy tftp command [5-27](#)
 correlation, alarm logging [3-11](#)
 CPU0 module [2-11](#)
 Craft Works Interface *See* CWI
 CSC
 removing and replacing [6-22](#)
 CSFC
 removing and replacing [6-27](#)
 cursor movement [4-19](#)
 CWI
 introduction [1-2](#)

D

debug command [7-5](#)
 debugging
 disabling for all services, all sessions [7-6](#)
 disabling for all services, one session [7-6](#)
 disabling for a service [7-6](#)
 displaying features [7-5](#)

 displaying status [7-5](#)
 enabling [7-5](#)
 DEFAULT_GATEWAY variable [A-12](#)
 dir command [B-4, C-5](#)
 disk0: [5-19](#)
 disk1:
 PIE file archive [5-17](#)
 reinstalling vm files [A-16](#)
 domain name, configuration [3-1](#)
 domain name command [3-2](#)
 domain name server, configuration [3-1](#)
 domain name-server command [3-2](#)
 drives, formatting [6-16](#)

E

end command [2-31](#)
 environment variables
 BOOT [A-12](#)
 DEFAULT_GATEWAY [A-12](#)
 displaying [A-30](#)
 introduction [A-2](#)
 IP_ADDRESS [A-12](#)
 IP_SUBNET_MASK [A-12](#)
 saving [A-31](#)
 TURBOBOOT [A-3, A-4, A-13](#)
 errors
 displaying configuration errors [2-28](#)
 syntax [4-4](#)
 Ethernet interface
 configuring [2-33](#)
 connection, illustration (16-slot chassis) [1-6, 2-3](#)
 connection, illustration (8-slot chassis) [1-7, 1-8, 2-4, 2-5](#)
 displaying [2-35](#)
 EXEC commands, entering in configuration mode [2-18](#)
 EXEC mode [2-16](#)
 exit command [2-30, B-5, B-6](#)
 expressions
 complex [D-3](#)

regular [D-1](#)
 extensible markup language *See* XML

F

file

redirecting output to [4-7](#)

file storage

flash disk0: [5-19](#)

flash disk1:

PIE file archive [5-17](#)

reinstalling vm files [A-16](#)

file transfer protocols, supported [5-27](#)

File Transfer Protocol *See* FTP

filters, command output [4-8](#)

flash disk

disk0: [5-19](#)

disk1:

PIE file archive [5-17](#)

reinstalling vm files [A-16](#)

flash disk0:

configuration file storage [2-23](#)

format bootflash

command [B-7](#)

format command [6-16](#)

formatting drives [6-16](#)

Forwarding package features [5-5](#)

FTP [5-27](#)

G

global configuration mode [2-16](#)

group command [3-17](#)

H

halting command output [4-7](#)

hardware

displaying status [6-1](#)

documentation [xv](#)

help command (ROM Monitor) [A-29](#)

history, commands [4-17](#)

hostname

configuration [2-32](#)

displayed in prompt [2-11](#)

hostname command [2-32](#)

HTTP server configuration [3-2](#)

hw-module location command [6-12, 6-15, 6-24, 6-25, B-7](#)

install activate command [5-30, 5-32](#)

install activate command, test option [5-38](#)

install add command [5-28](#)

install add ftp: command [5-29, 5-33](#)

install add rcp: command [5-29, 5-33](#)

install add tftp: command [5-29, 5-33](#)

install command, synchronous and asynchronous operation [5-26](#)

install commit command [5-36, 5-37](#)

install deactivate command [5-37](#)

install remove command [5-37](#)

install rollback committed command [5-34, 5-35](#)

interface configuration mode [2-17](#)

interface MgmtEth command [2-36](#)

interface preconfigure command [6-17, 6-18](#)

interfaces, verifying operation [7-21](#)

IP_ADDRESS variable [A-12](#)

IP_SUBNET_MASK variable [A-12](#)

ipv4 access-list oor ace threshold command [3-27](#)

ipv4 access-list oor acl threshold command [3-27](#)

ipv4 address command [2-36](#)

ipv6 access-list oor ace threshold command [3-27](#)

ipv6 access-list oor acl threshold command [3-27](#)

IS-IS, configuration limits [3-19](#)

K

keyboard shortcuts

- capitalization [4-19](#)
- command history [4-18](#)
- cursor movement [4-19](#)
- deleting text [4-20](#)
- recalling deleted entries [4-18](#)
- transposing letters [4-20](#)

L

line card

- removal [6-17](#)
- replacement [6-18, 6-19](#)

Line Card package features [5-6](#)line wrap, editing long lines [4-5](#)load command [3-10](#)load commit changes command [3-8](#)load rollback changes command [3-8, 3-9](#)

logging

- alarm correlation [3-11](#)
- configuration [3-12](#)
- output locations [3-11](#)
- severity levels [3-11](#)

logging buffered command [3-11, 3-13](#)logging command [3-12](#)logging console command [3-11, 3-13](#)logging monitor command [3-11](#)logging trap command [3-11, 3-12](#)logical router, logging in [2-10](#)log in, router [2-10](#)long lines, editing [4-5](#)low memory warning, removing configurations [7-18](#)configuration [2-35](#)configuring [2-33](#)connection illustration (16-slot chassis) [2-3](#)connection illustration (8-slot chassis) [2-4](#)displaying [2-35](#)establishing a connection through [2-9](#)name syntax [2-33](#)maximum external-sa command [3-26](#)maximum group-mappings autorp command [3-26](#)maximum groups command [3-26](#)maximum groups per-interface command [3-26](#)maximum interfaces command [3-20](#)maximum-paths command (BGP) [3-23](#)maximum-paths command (IS-IS) [3-19](#)maximum paths command (OSPF) [3-20](#)maximum peer-external-sa command [3-26](#)maximum-prefix command [3-22](#)maximum redistributed-prefix command (OSPF) [3-20](#)maximum-redistributed-prefixes command (IS-IS) [3-19](#)maximum register-states command [3-26](#)maximum route-interfaces command [3-26](#)maximum routes command [3-26](#)

memory

displaying system memory [7-17](#)low memory warnings [7-16](#)management [3-17](#)removing configurations [7-18](#)merged configuration, displaying [2-23, 2-27](#)

mode

admin configuration [2-18](#)admin EXEC [2-18](#)configuration submodes [2-16](#)EXEC [2-16](#)global configuration [2-16](#)interface configuration [2-17](#)ROM monitor [2-18](#)router configuration [2-17](#)router submode configuration [2-17](#)

modem connection

MManageability package features [5-10](#)

Management Ethernet interface

illustration (16-slot chassis) [1-6, 2-3](#)
 illustration (8-slot chassis) [1-7, 1-8, 2-4, 2-5](#)
 module [6-4](#)
 module, number displayed in prompt [2-11](#)
 monitor processes command [7-8, 7-12](#)
 monitor threads command [7-8](#)
 More prompt [4-6](#)
 MPLS
 configuration limits [3-27](#)
 package features [5-9](#)
 mpls traffic-eng maximum tunnels command [3-27](#)
 MSC
 removal [6-17](#)
 multicast, configuration limits [3-26](#)
 Multicast package features [5-8](#)

N

name
 router, configuring [2-32](#)
 router name displayed in prompt [2-11](#)
 netadmin user group [2-13](#)
 network connection, overview [2-3](#)
 no, command form [4-4](#)
 node
 administrative shutdown [6-15](#)
 power cycle [6-12](#)
 reload [6-12](#)
 shutdown [6-12](#)
 no debug command [7-6](#)
 no hw-module node command [6-21](#)
 nonactive target configuration [2-21](#)

O

OIR [6-17](#)
 for switch fabric cards [6-19](#)
 online insertion and removal [6-17](#)

operator user group [2-13](#)
 OS package features [5-3](#)
 OSPF, configuration limits [3-19](#)

P

package
 activation
 impact on running configuration [5-21](#)
 introduction [5-19](#)
 addition, introduction [5-19](#)
 committing a package set [5-19](#)
 deactivation [5-37](#)
 impact on running configuration [5-21](#)
 removal [5-37](#)
 rollback [5-19](#)
 package installation envelope files *See* PIE files
 packages
 committing [5-36](#)
 partial command, entry [4-4](#)
 password, recovering root [A-21](#)
 password command [3-16](#)
 pattern
 alternation [D-4](#)
 multiple-character [D-3](#)
 recall [D-4](#)
 performance route processor (PRP) [1-1](#)
 PIE files [5-11](#)
 archive on flash disk1: [5-17](#)
 names [5-11](#)
 version numbers [5-11](#)
 ping command [7-3](#)
 PLIM
 removal [6-17](#)
 replacement [6-18, 6-19](#)
 power cycle [6-12](#)
 power on, first time [1-5](#)
 Primary LED illustration (16-slot chassis) [1-6, 2-3](#)
 Primary LED illustration (8-slot chassis) [1-7, 2-4](#)

process [7-7](#)
 process command [7-14](#)
 process mandatory command [7-14](#)
 process mandatory reboot command [7-14](#)

R

rack, displayed in prompt [2-11](#)
 rack number [6-4](#)
 rcp [5-27](#)
 redirecting command output [4-7, 4-8](#)
 redundancy
 automatic failover [6-10](#)
 commands [6-10](#)
 manual switchover [6-11](#)
 primary RP [6-9](#)
 standby RP [6-9](#)
 redundancy switchover command [6-10, 6-11, B-6, C-6, C-7](#)
 reload
 router [A-26](#)
 software [6-12](#)
 reload command [6-10, 6-13, B-7](#)
 Remote Copy Protocol *See* rcp
 resource management [3-17](#)
 rollback
 committed software [5-34](#)
 configuration, overview [3-3](#)
 configuration rollback failure [3-4](#)
 history log, displaying [3-5](#)
 loading changes to the target configuration [3-8](#)
 package incompatibility [3-4](#)
 points, displaying [5-34](#)
 points, rolling back [5-35](#)
 previewing changes [3-6](#)
 procedure [3-7](#)
 rollback configuration command [3-7](#)
 rollback configuration to command [7-20](#)
 rollback for packages
 introduction [5-19](#)
 ROM monitor
 commands [A-29](#)
 downgrades [B-2, C-2](#)
 exiting [A-31](#)
 manually halt initialization during reload [A-28](#)
 options [A-29](#)
 recovering the root password [A-21](#)
 reinstalling Cisco IOS XR software [A-2](#)
 reinstalling vm files [A-10, A-16](#)
 reloading the router [A-26](#)
 resetting the configuration register [A-26](#)
 ROMMON A and ROMMON B, startup [B-1](#)
 upgrades
 basics [B-1, C-1](#)
 example [B-8, C-10](#)
 files [B-2](#)
 procedure [B-3, C-2, C-4](#)
 troubleshooting tips [B-7](#)
 version, displaying [B-4, C-3, C-5, C-6](#)
 ROM monitor mode [2-18](#)
 ROMMON *See* ROM monitor
 root-ldr user group [2-13](#)
 root password, recovering [A-21](#)
 root-system user group [2-13](#)
 route maximum ipv4 command [3-18](#)
 route maximum ipv6 command [3-18](#)
 route processors
 faceplate illustration (16-slot chassis) [1-6, 2-3](#)
 faceplate illustration (8-slot chassis) [1-7, 2-4](#)
 faceplate illustration (PRP-2) [1-8, 2-5](#)
 router
 clock setting [2-38](#)
 halt initialization [A-28](#)
 name configuration [2-32](#)
 name displayed in prompt [2-11](#)
 reloading [A-26](#)
 verifying status [1-12](#)
 router configuration mode [2-17](#)
 router submode configuration [2-17](#)

- Routing package features [5-7](#)
 - RPL, configuration limits [3-24](#)
 - rpl maximum lines command [3-24](#)
 - rpl maximum policies command [3-24](#)
 - RP reload [6-10](#)
 - running configuration
 - displaying [2-24, 2-25](#)
 - locking [2-31](#)
 - unlocking [2-31](#)
-
- S**
- secret command [3-16](#)
 - Security package features [5-10](#)
 - service processor *See* SP
 - session
 - configuration overview [2-20](#)
 - ending [2-30](#)
 - set command (ROM Monitor) [A-30](#)
 - SFC
 - removing and replacing [6-22](#)
 - SFTP [5-27](#)
 - shortcuts
 - capitalization [4-19](#)
 - command history [4-18](#)
 - cursor movement [4-19](#)
 - deleting text [4-20](#)
 - recalling deleted entries [4-18](#)
 - transposing letters [4-20](#)
 - show aaa userdb command [3-15](#)
 - show aaa usergroup command [2-14, 3-15](#)
 - show bgp neighbor command [3-22](#)
 - show clock command [2-40](#)
 - show configuration command [3-10, 4-6, 7-2](#)
 - show configuration commit changes command [3-6, 7-19](#)
 - show configuration commit history [7-18](#)
 - show configuration commit history command [3-5, 7-18](#)
 - show configuration commit list [7-20](#)
 - show configuration commit list command [3-4, 7-20](#)
 - show configuration failed command [7-14](#)
 - show configuration failed noerror command [7-15](#)
 - show configuration failed startup command [7-15](#)
 - show configuration rollback changes [7-20](#)
 - show configuration rollback changes command [3-6](#)
 - show configuration rollback changes to command [7-20](#)
 - show configuration sessions command [2-31, 7-21](#)
 - show context command [7-2](#)
 - show controller command [7-2](#)
 - show controller fabric plane all command [6-21](#)
 - show controllers command [6-15](#)
 - show debug command [7-2, 7-5](#)
 - show debug condition command [7-6](#)
 - show diag command [6-1](#)
 - show environment command [1-13, 4-6, 6-5, 7-2](#)
 - show exception command [7-2](#)
 - show hosts command [3-2](#)
 - show igmp summary command [3-26](#)
 - show install active command [5-23, 5-25](#)
 - show install active detail command [5-23](#)
 - show install active location command [5-25](#)
 - show install command [7-2](#)
 - show install committed command [5-25](#)
 - show install rollback ? command [5-34](#)
 - show install rollback command [5-35](#)
 - show interface command [7-21](#)
 - show interfaces command [6-17, 7-2](#)
 - show interfaces MgmtEth command [2-37](#)
 - show ipv4 access-lists command [3-27](#)
 - show ipv4 interface brief command [7-21](#)
 - show ipv4 interface command [7-21](#)
 - show isis adjacency command [3-19](#)
 - show isis route command [3-19](#)
 - show logging command [3-13, 7-2, B-5](#)
 - show memory command [7-2, 7-17](#)
 - show memory summary command [7-17, 7-18](#)
 - show mpls traffic-eng maximum tunnels command [3-27](#)
 - show msdp summary command [3-26](#)
 - show ospf command [3-20](#)

- show pim summary command [3-26](#)
- show platform command [1-14, 4-6, 6-3, 6-10, 6-20, 6-23, 7-2, B-5](#)
- show process blocked command [7-2](#)
- show processes abort command [7-8](#)
- show processes blocked command [7-8](#)
- show processes boot command [7-8](#)
- show processes command [7-8, 7-9, 7-10](#)
- show processes cpu command [7-8](#)
- show processes dynamic command [7-8](#)
- show processes failover command [7-8](#)
- show processes log command [7-8](#)
- show processes memory command [7-9, 7-11](#)
- show processes startup command [7-9](#)
- show redundancy command [1-15, 6-8, 6-9, 6-10, 6-14, 7-2](#)
- show rpl maximum lines command [3-24](#)
- show rpl max policies command [3-24](#)
- show running-config command [4-6, 6-17, 7-2](#)
- show running-config route maximum command [3-18](#)
- show running-config router ospf command [3-20](#)
- show task supported command [2-12, 3-15](#)
- show tech-support command [4-6, 7-3](#)
- show tracebacks command [7-3](#)
- show user all command [6-20, 6-23](#)
- show user command [2-14, 7-3](#)
- show user group command [2-14, 6-19, 6-23](#)
- show user tasks command [2-14](#)
- show variables boot command [6-13, 6-14, 7-2](#)
- show version command [1-13, 4-6, 6-3, 7-3](#)
- shutdown [6-12](#)
- Simple Network Management Protocol [1-4](#)
- single-chassis system [1-1](#)
- slot, number displayed in prompt [2-11](#)
- slot number [6-4](#)
- SMU [5-11](#)
 - filenames [5-13](#)
 - version numbers [5-13](#)
- SNMP (Simple Network Management Protocol) [1-4](#)
- software, documentation [xv](#)
- Software Maintenance Update *See* SMU
- software packages
 - activating
 - on all cards [5-30](#)
 - on a single card [5-32](#)
 - activation
 - impact on running configuration [5-21](#)
 - impact on system [5-21](#)
 - prerequisites [5-22](#)
 - active packages
 - displaying all [5-23](#)
 - displaying for a card [5-25](#)
 - adding from router [5-28](#)
 - available packages [5-1](#)
 - Cisco IOS XR Software Selector tool [5-16](#)
 - committing [5-36](#)
 - configuration rollback failure [3-4](#)
 - copying, adding, and activating in one step [5-33](#)
 - copying and adding from network server [5-29](#)
 - copying to the router [5-27](#)
 - deactivation
 - impact on running configuration [5-21](#)
 - impact on system [5-21](#)
 - prerequisites [5-22](#)
 - described [5-1](#)
 - displaying committed versions [5-25](#)
 - downgrading [5-20](#)
 - impact of version changes [5-21](#)
 - management overview [5-18](#)
 - obtaining installable PIE files [5-16](#)
 - optional [5-8](#)
 - PIE files [5-11](#)
 - removing inactive software [5-37](#)
 - rollback [5-34, 5-35](#)
 - SMUs [5-13](#)
 - upgrading [5-20](#)
 - version numbers [5-11](#)
- SP [6-4](#)
- special characters [D-2](#)

- SSH File Transfer Protocol [5-27](#)
 - start up
 - hardware, first time [1-5](#)
 - verifying status [1-12](#)
 - static route, configuration limits [3-18](#)
 - Status LED illustration (16-slot chassis) [1-6, 2-3](#)
 - Status LED illustration (8-slot chassis) [1-7, 2-4](#)
 - stopping command output [4-7](#)
 - submodes, configuration [2-16](#)
 - switch fabric cards
 - Cisco XR 12000 Series routers
 - removing and replacing [6-22](#)
 - CRS-1routers
 - removing and replacing [6-19](#)
 - switch fabric card *See* SFC [6-22](#)
 - sync command (ROM Monitor) [A-31](#)
 - synchronous operation
 - install command [5-26](#)
 - syntax
 - anchor characters [D-4](#)
 - character pattern ranges [D-2](#)
 - complex regular expressions [D-3](#)
 - error identification [4-4](#)
 - pattern alternation [D-4](#)
 - pattern recall [D-4](#)
 - regular expressions [D-1](#)
 - special characters [D-2](#)
 - wildcard underscore [D-4](#)
 - sysadmin user group [2-13](#)
 - displaying [2-27](#)
 - loading from a file [3-10](#)
 - saving to a file [3-10](#)
 - tar utility [A-5](#)
 - task group, introduction [2-12](#)
 - task ID, introduction [2-12](#)
 - task IDs
 - displaying [2-13](#)
 - Telnet server configuration [3-2](#)
 - templates
 - applying [4-14](#)
 - creating [4-12](#)
 - terminal connection, illustration (16-slot chassis) [1-6, 2-3](#)
 - terminal connection, illustration (8-slot chassis) [1-7, 1-8, 2-4, 2-5](#)
 - terminal history command [4-18](#)
 - terminal server, establishing a connection through [2-7](#)
 - terminal settings, default values [1-10, 2-6, 2-8](#)
 - TFTP
 - introduction [5-27](#)
 - server, reinstalling vm files [A-10](#)
 - TFTP_FILE environment variables
 - TFTP_FILE [A-12](#)
 - TFTP_FILE variable [A-12](#)
 - thread [7-7, 7-9, 7-12](#)
 - time, setting the router clock [2-38](#)
 - time zone, setting the router clock [2-38](#)
 - traceroute command [7-3](#)
 - Trivial File Transfer Protocol *See* TFTP
 - troubleshooting
 - basic commands [7-2](#)
 - displaying system memory information [7-17](#)
 - errors at startup [7-15](#)
 - failed commit operation [7-14](#)
 - low memory warnings [7-16](#)
 - processes and threads [7-7](#)
 - ROM monitor upgrades [B-7](#)
 - TURBOBOOT variable [A-3, A-4, A-13](#)
 - type, card type displayed in prompt [2-11](#)
-
- T**
- tab key [4-4](#)
 - tar files
 - introduction [A-5](#)
 - names [A-6](#)
 - version numbers [A-6](#)
 - target configuration [2-21](#)
 - clearing changes [2-29](#)

U

- undebbug all command [7-6](#)
- underscore wildcard character [D-4](#)
- upgrade rommon A command [B-5](#)
- upgrade rommon B command [B-6](#)
- user access
 - task IDs, displaying [2-13](#)
- user accounts
 - configuration overview [3-15](#)
 - creating [3-16](#)
- user groups
 - assigning to a user [3-16](#)
 - displaying [2-13](#)
 - introduction [2-12](#)
 - predefined [2-13](#)
- user interfaces
 - CLI [1-2](#)
 - CWI [1-2](#)
 - SNMP [1-4](#)
 - XML API [1-3](#)
- username command [3-16](#)

V

- vm files
 - names [A-9](#)
 - reinstalling from a TFTP server [A-10](#)
 - reinstalling from disk1: [A-16](#)
 - version numbers [A-9](#)

W

- warning, low memory [7-16](#)
- wildcards [4-11](#)

X

- XML
 - API [1-3](#)
 - host service configuration [3-2](#)

