



Distributed Route Processor Commands on Cisco IOS XR Software

DRPs can be installed individually or in pairs. This module describes the commands used to create redundant DRP pairs.

DRP Overview

The distributed route processor (DRP) card and its associated physical layer interface module (PLIM) function as an additional route processor (RP) in the Cisco CRS-1. The DRP does not perform any of the control and management functions performed by the RP; therefore, it can never be the designated shelf controller (DSC) in a multishelf system. However, the DRP can be configured for the following purposes:

- The DRP can act as the designated secure domain router shelf controller (DSDRSC) in a secure domain router (SDR). An SDR is a part of the Cisco CRS-1 routing system that functions as a complete router, running its own routing protocols and forwarding IP packets between its interfaces.
- DRPs are not supported on the Cisco XR 12000 Series Router in Cisco IOS XR Software Release 3.3.0.
- SDRs were previously known as Logical Routers (LRs). The name was changed for Release 3.3.0.
- The DRP can provide additional processing capacity for any of the routing processes that run on the RP (for example, BGP, OSPF, IS-IS, MPLS, LDP, IP multicast, and so on).

Related Documents

For additional information, refer to the following Cisco Systems documents:

Related Topic	Document Title
Instructions to use of DRPs in a secure domain router configuration	<i>Configuring Secure Domain Routers on Cisco IOS XR Software.</i> This module is part of the <i>Cisco IOS XR System Management Configuration Guide</i> .
Instructions to configure process placement and DRPs.	<i>Process Placement on Cisco IOS XR Software.</i> This module is part of the <i>Cisco IOS XR System Management Configuration Guide</i> .
DRP hardware description and requirements.	<i>Cisco CRS-1 Carrier Routing System 16-Slot Line Card Chassis System Description</i>
Instructions to install DRP and DRP PLIM cards.	<i>Installing the Cisco CRS-1 Carrier Routing System 16-Slot Line Card Chassis</i>

location (drp)

To assign nodes to a DRP pair, use the **location** command in DRP pairing configuration mode. To remove the node from a DRP pair, use the **no** form of this command.

location *partially-qualified-nodeid* *partially-qualified-nodeid*

no location

Syntax Description

partially-qualified-nodeid Specifies the nodes to be assigned to the specified DRP pair.

The *node-id* argument is entered in the *rack/slot/** notation. Nodeids are always specified at the slot level, so the wildcard (*) is used to specify the CPU.

Defaults

No default behavior or values

Command Modes

DRP pairing configuration

Command History

Release	Modification
Release 3.3.0	This command was introduced on the Cisco CRS-1.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **location** command in DRP pairing configuration mode to assign nodes to a DRP pair. The following rules apply to DRP pairing assignments:

- To create a DRP pair name, use the **pairing (drp)** command.
- Two nodes are assigned to each DRP pair. For example: **location 0/2/* 0/3/***.
- DRPs are always specified at a slot level. The wildcard (*) is used to specify the CPU.
- To be added to a DRP pair, the *node-id* must belong to the owner SDR. If a node is already assigned to a non-owner SDR, the node must be removed from the non-owner SDR before it can be assigned to a DRP pair.
- A *node-id* cannot be used by more than one DRP pair.
- Only two nodes can be assigned to a DRP pair. In the following example, only the last **location 0/0/* 0/4/*** will take effect.

```
(admin-config)# pairing pair1
(admin-config-pairing:pair1)# location 0/1/* 0/4/*
(admin-config-pairing:pair1)# location 0/0/* 0/4/*
(admin-config-pairing:pair1)# commit
```

- Use the **no** form of the **location** command to remove both nodes from the DRP pair. Removing a node from a DRP pair implicitly returns it to the owner SDR. When a node has been removed from an SDR, it can be reassigned to another SDR.

Task ID	Task ID	Operations
	system	read, write

Examples

The following example shows how to enter DRP pairing configuration mode, create a DRP pair named “drp1”, and assign node 0/3/* and node 0/4/* to the DRP pair:

```
RP/0/1/CPU0:router# admin
RP/0/1/CPU0:router(admin)# configure
RP/0/1/CPU0:router(admin-config)# pairing drp1
RP/0/1/CPU0:router(admin-config-pairing:drp1)# location 0/3/* 0/4/*
```

The following example shows how to remove a DRP pair:

```
RP/0/1/CPU0:router# admin
RP/0/1/CPU0:router(admin)# configure
RP/0/1/CPU0:router(admin-config)# pairing drp1
RP/0/1/CPU0:router(admin-config-pairing:drp1)# no location
```

Related Commands

Command	Description
sdr	Creates an SDR or modifies an existing SDR.
pairing (drp)	Creates a DRP pair name or modifies an existing DRP pair (Cisco CRS-1 only).
location (SDR)	Adds or removes a node from a secure domain router configuration.
pair (SDR)	Adds or removes a DRP pair from a secure domain router configuration (Cisco CRS-1 only).

pairing (drp)

To specify a distributed route processor (DRP) pair and enter DRP pairing configuration mode, use the **pairing** command in Administration configuration mode. To remove a named DRP pair from the configuration, use the **no** form of this command.

pairing *pair-name*

no pairing *pair-name*

Syntax Description

<i>pair-name</i>	Name of the DRP pair. The name can a maximum of 32 alphanumeric characters. The characters “_” or “-” are also allowed. All other characters are invalid.
------------------	---

Defaults

No default behavior or values

Command Modes

DRP pairing configuration

Command History

Release	Modification
Release 3.3.0	This command was introduced on the Cisco CRS-1 router.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes the proper task IDs. For detailed information about user groups and task IDs, see the *Configuring AAA Services on Cisco IOS XR Software* module of the *Cisco IOS XR System Security Configuration Guide*.

Use the **pairing** *pair-name* command to create a DRP pair or modify an existing DRP pair.



Note

The *pair-name* argument creates a DRP pair if the *pair-name* specified does not already exist.

After the **pairing** *pair-name* command is issued, the router enters DRP pairing configuration mode. From DRP pairing configuration mode, you can specify the nodes for the DRP pair using the **location (drp)** command. The locations specified are added to the DRP pair, or modify the existing pair.

Use the **no** form of the command to remove a DRP pair configuration. When a DRP pair is removed from the configuration, the nodes are returned to the owner SDR.

Task ID

Task ID	Operations
system	read, write

Examples

The following example shows how to enter DRP pairing configuration mode to configure a DRP pair:

```
RP/0/1/CPU0:router# admin
```

```
RP/0/1/CPU0:router(admin)# configure  
RP/0/1/CPU0:router(admin-config)# pairing drp1  
RP/0/1/CPU0:router(admin-config-pairing:drp1)# location 0/3/* 0/4/*
```

The following example shows how to remove a DRP pair:

```
RP/0/1/CPU0:router# admin  
RP/0/1/CPU0:router(admin)# configure  
RP/0/1/CPU0:router(admin-config)# no pairing drp1
```

Related Commands

Command	Description
location (drp)	Adds or removes nodes from a DRP pair.
sdr	Creates or modifies an existing secure domain router.
location (SDR)	Adds or removes a node from an SDR configuration.
pair (SDR)	Adds or removes a DRP pair from an SDR configuration.

■ pairing (drp)