



Monitor Performance

This chapter explains how to enable and view performance monitoring statistics for the Cisco ONS 15454 SDH. Performance monitoring (PM) parameters are used by service providers to gather, store, and set threshold and report performance data for early detection of problems. For more PM information, details, and definitions refer to the *Cisco ONS 15454 SDH Troubleshooting Guide*.

Before You Begin

Before performing any of the following procedures, investigate all alarms and clear any trouble conditions. Refer to the *Cisco ONS 15454 SDH Troubleshooting Guide* as necessary.

This section lists the chapter procedures (NTPs). Turn to a procedure for applicable tasks (DLPs).

1. [NTP-D257 Change the PM Display, page 8-2](#)—Complete as needed to change the displayed PM counts.
2. [NTP-D195 Monitor Electrical Performance, page 8-3](#)—Complete as needed to monitor electrical performance.
3. [NTP-D198 Monitor Ethernet Performance, page 8-4](#)—Complete as needed to monitor Ethernet performance.
4. [NTP-D289 Create or Delete Ethernet RMON Thresholds, page 8-5](#)—Complete as needed to monitor Ethernet performance.
5. [NTP-D254 Monitor STM-N Performance, page 8-5](#)—Complete as needed to monitor optical (STM-N) performance.
6. [NTP-D301 Monitor FC_MR-4 Performance, page 8-6](#)—Complete as needed to monitor FC_MR-4 performance.
7. [NTP-D302 Create or Delete FC_MR-4 RMON Thresholds, page 8-6](#)—Complete as needed to monitor FC_MR-4 performance.



Note

For additional information regarding PM parameters, refer to ITU G.826, Telcordia GR-820-CORE, Telcordia GR-499-CORE, and Telcordia GR-253-CORE.

NTP-D257 Change the PM Display

Purpose	This procedure changes the display of PM counts by selecting drop-down menu or radio button options in the Performance window.
Tools/Equipment	None
Prerequisite Procedures	Before you monitor performance, be sure you have created the appropriate circuits and provisioned the card according to your specifications. For more information, see Chapter 6, “Create Circuits and Low-Order Tunnels” and Chapter 11, “Change Card Settings.”
Required/As Needed	As needed
Onsite/Remote	Onsite or remote
Security Level	Retrieve or higher

-
- Step 1** Complete the “[DLP-D60 Log into CTC](#)” task on page 17-47 at the node that you want to monitor. If you are already logged in, continue with Step 2.
- Step 2** In node view, double-click the electrical, Ethernet, optical (STM-N), multirate transport, or DWDM card where you want to view PM counts. The card view appears.
- Step 3** As needed, use the following tasks to change the display of PM counts:
- [DLP-D124 Refresh PM Counts at 15-Minute Intervals](#), page 18-11
 - [DLP-D125 Refresh PM Counts at One-Day Intervals](#), page 18-11
 - [DLP-D259 Refresh Ethernet PM Counts at a Different Time Interval](#), page 19-42
 - [DLP-D126 View Near-End PM Counts](#), page 18-12
 - [DLP-D127 View Far-End PM Counts](#), page 18-13
 - [DLP-D458 Monitor PM Counts for a Selected Signal](#), page 21-38
 - [DLP-D129 Reset Current PM Counts](#), page 18-13
 - [DLP-D459 Clear Selected PM Counts](#), page 21-39
 - [DLP-D457 Refresh E-Series and G-Series Ethernet PM Counts](#), page 21-37
 - [DLP-D260 Set Auto-Refresh Interval for Displayed PM Counts](#), page 19-42
 - [DLP-D261 Refresh PM Counts for a Different Port](#), page 19-43


Stop. You have completed this procedure.

NTP-D195 Monitor Electrical Performance

Purpose	This procedure enables you to view node near-end or far-end performance during selected time intervals on an electrical card and port to detect possible performance problems.
Tools/Equipment	None
Prerequisite Procedures	Before you monitor performance, be sure you have created the appropriate circuits and provisioned the card according to your specifications. For more information, see Chapter 6, “Create Circuits and Low-Order Tunnels” and Chapter 11, “Change Card Settings.”
Required/As Needed	As needed
Onsite/Remote	Onsite
Security Level	Retrieve or higher

- Step 1** Complete the “[DLP-D60 Log into CTC](#)” task on page 17-47 at the node that you want to monitor. If you are already logged in, continue with [Step 2](#).
- Step 2** In node view, double-click the electrical card where you want to view PM counts. The card view appears.
- Step 3** Click the **Performance** tab ([Figure 8-1](#)).

Figure 8-1 Viewing Performance Monitoring Information



Step 4 View the PM parameter names that appear on the left portion of the window in the Param column. The PM parameter values appear on the right portion of the window in the Curr (current), and Prev-*n* (previous) columns. For PM parameter definitions, refer to the “Performance Monitoring” chapter in the *Cisco ONS 15454 SDH Troubleshooting Guide*.

To refresh, reset, or clear PM counts, see the “[NTP-D257 Change the PM Display](#)” procedure on [page 8-2](#).

Stop. You have completed this procedure.

NTP-D198 Monitor Ethernet Performance

Purpose	This procedure enables you to view node transmit and receive performance during selected time intervals on an Ethernet card and port to detect possible performance problems.
Tools/Equipment	None
Prerequisite Procedures	Before you monitor performance, be sure you have created the appropriate circuits and provisioned the card according to your specifications. For more information, see Chapter 6, “Create Circuits and Low-Order Tunnels” and Chapter 11, “Change Card Settings.”
Required/As Needed	As needed
Onsite/Remote	Onsite
Security Level	Retrieve or higher

Step 1 Complete the “[DLP-D60 Log into CTC](#)” task on [page 17-47](#) at the node that you want to monitor. If you are already logged in, continue with [Step 2](#).

Step 2 Complete the “[DLP-D256 View Ethernet Statistics PM Parameters](#)” task on [page 19-38](#).

Step 3 Complete the “[DLP-D257 View Ethernet Utilization PM Parameters](#)” task on [page 19-39](#).

Step 4 Complete the “[DLP-D258 View Ethernet History PM Parameters](#)” task on [page 19-41](#).

Step 5 Complete the “[DLP-D348 View ML-Series Ether Ports PM Parameters](#)” task on [page 20-57](#).

Step 6 Complete the “[DLP-D349 View ML-Series POS Ports PM Parameters](#)” task on [page 20-58](#).

Stop. You have completed this procedure.

NTP-D289 Create or Delete Ethernet RMON Thresholds

Purpose	This procedure creates or deletes Ethernet remote monitoring (RMON) thresholds for the ONS 15454 SDH.
Tools/Equipment	None
Prerequisite Procedures	None
Required/As Needed	As needed
Onsite/Remote	Onsite or remote
Security Level	Provisioning or higher

Step 1 Complete the [“DLP-D60 Log into CTC” task on page 17-47](#). If you are already logged in, continue with Step 2.

Step 2 Perform any of the following tasks as needed:

- [DLP-D441 Create Ethernet RMON Alarm Thresholds, page 21-31](#)
- [DLP-D436 Delete Ethernet RMON Alarm Thresholds, page 21-28](#)

Stop. You have completed this procedure.

NTP-D254 Monitor STM-N Performance

Purpose	This procedure enables you to view node near-end or far-end performance during selected time intervals on an STM-N card and port to detect possible performance problems.
Tools/Equipment	None
Prerequisite Procedures	Before you monitor performance, be sure you have created the appropriate circuits and provisioned the card according to your specifications. For more information, see Chapter 6, “Create Circuits and Low-Order Tunnels” and Chapter 11, “Change Card Settings.”
Required/As Needed	As needed
Onsite/Remote	Onsite or remote
Security Level	Retrieve or higher

Step 1 Complete the [“DLP-D60 Log into CTC” task on page 17-47](#) at the node that you want to monitor. If you are already logged in, continue with Step 2.

Step 2 Complete the [“DLP-D121 Enable Pointer Justification Count Performance Monitoring” task on page 18-7](#) as needed to enable or disable clock synchronization monitoring.

Step 3 Complete the [“DLP-D122 Enable Intermediate Path Performance Monitoring” task on page 18-9](#) as needed to enable or disable monitoring of VC4 traffic through intermediate nodes.

Step 4 Complete the [“DLP-D421 View STM-N PM Parameters” task on page 21-2](#).

**Note**

To refresh, reset, or clear PM counts, see the [“NTP-D257 Change the PM Display” procedure on page 8-2.](#)

Stop. You have completed this procedure.

NTP-D301 Monitor FC_MR-4 Performance

Purpose	This procedure enables you to view node transmit and receive performance during selected time intervals on an FC_MR-4 card and port to detect possible performance problems.
Tools/Equipment	None
Prerequisite Procedures	Before you monitor performance, be sure you have created the appropriate circuits and provisioned the card according to your specifications. For more information, see Chapter 6, “Create Circuits and Low-Order Tunnels” and Chapter 11, “Change Card Settings.”
Required/As Needed	As needed
Onsite/Remote	Onsite or remote
Security Level	Retrieve or higher

- Step 1** Complete the [“DLP-D60 Log into CTC” task on page 17-47](#) at the node that you want to monitor. If you are already logged in, continue with Step 2.
- Step 2** Complete the [“DLP-D460 View FC_MR-4 Statistics PM Parameters” task on page 21-40.](#)
- Step 3** Complete the [“DLP-D461 View FC_MR-4 Utilization PM Parameters” task on page 21-41.](#)
- Step 4** Complete the [“DLP-D462 View FC_MR-4 History PM Parameters” task on page 21-42.](#)

Stop. You have completed this procedure.

NTP-D302 Create or Delete FC_MR-4 RMON Thresholds

Purpose	This procedure creates or deletes FC_MR-4 remote monitoring (RMON) thresholds for the ONS 15454 SDH.
Tools/Equipment	None
Prerequisite Procedures	None
Required/As Needed	As needed
Onsite/Remote	Onsite or remote
Security Level	Provisioning or higher

- Step 1** Complete the [“DLP-D60 Log into CTC” task on page 17-47.](#) If you are already logged in, continue with Step 2.

Step 2 Perform any of the following tasks as needed:

- [DLP-D465 Create FC_MR-4 RMON Alarm Thresholds, page 21-45](#)
- [DLP-D466 Delete FC_MR-4 RMON Alarm Thresholds, page 21-49](#)

Stop. You have completed this procedure.
