



---

## Symbols

? (help) command [B-2](#)

---

## Numerics

100Mbps LED (Cisco 3631 rear panel) [A-8](#)

100Mbps LED (Cisco 3660 rear panel) [A-10](#)

---

## A

AC power connection [3-27](#)

ACTIVE LED (Cisco 3620, 3640, 3660) [A-7](#)

ACTIVITY LED (Cisco 3631 front panel) [A-8](#)

ACT LED (Cisco 3631 rear panel) [A-8](#)

AIMs, installing [1-5](#)

asynchronous serial baud rates [2-13](#)

auxiliary port

connecting to [3-46 to 3-49](#)

description of [2-9](#)

---

## B

baud rate

asynchronous serial [2-13](#)

modem [3-46](#)

setting for console terminal [C-3, C-5](#)

boot command [B-5](#)

boothelper [B-4](#)

booting from Flash memory [C-6](#)

boot system command [C-2](#)

bracket attachment

for rack-mounting [3-5 to 3-13](#)

for wall-mounting [3-18](#)

---

## C

cables, provided [2-7](#)

Caution symbol, meaning of [ix](#)

chassis

desktop installation [3-3](#)

dimensions [1-12 to 1-15](#)

grounding [3-19 to 3-26](#)

rack-mounting [3-3 to 3-17](#)

Cisco 2600 series routers

card slots (figure) [1-11](#)

unit numbers (figure) [1-11](#)

Cisco 3600 series routers

unit numbers (figure) [1-8](#)

Cisco IOS software

locating documentation [xv](#)

recovering images [B-9](#)

commands

? (help) [B-2](#)

boot [B-5](#)

configuration-register [B-2, B-7](#)

confreg [B-7](#)

context [B-7](#)

debugging [B-7](#)

dir [B-6](#)

frame [B-7](#)

help [B-6](#)

i (initialize) [B-6](#)

meminfo [B-6](#)

reload [B-2](#)  
 reset [B-6](#)  
 ROM monitor [B-1 to B-10](#)  
 stack [B-7](#)  
 sysret [B-7](#)  
 xmodem [B-9](#)  
 compact Flash memory cards, installing [1-6](#)  
 compliance [1-15](#)  
 configuration register  
   boot field [C-4](#)  
   changing settings [B-7, C-2](#)  
   enabling booting from Flash memory [C-6](#)  
 configuration-register command [B-2](#)  
 confreg command [B-7](#)  
 connections  
   AC power [3-27](#)  
   asynchronous/synchronous serial [2-13](#)  
   auxiliary port [2-9](#)  
   console port [2-9, 3-44](#)  
   DCE [2-11](#)  
   DC power [3-27 to 3-36](#)  
   DSU/CSU [2-14](#)  
   DTE [2-11](#)  
   Ethernet [2-10](#)  
   ISDN BRI [2-13](#)  
   modem [3-46](#)  
   network [2-10](#)  
   serial [2-11](#)  
   Token Ring [2-11](#)  
 console port  
   connecting to [3-43 to 3-46](#)  
   description of [2-9](#)  
 console speed, setting [B-10](#)  
 context command [B-7](#)  
 cooling recommendations [2-5](#)

---

## D

DCE connections [2-11](#)  
 DC power connections  
   Cisco 3620 and Cisco 3640 [3-28 to 3-29](#)  
   Cisco 3631 [3-30 to 3-32](#)  
   Cisco 3660 [3-32 to 3-36](#)  
 debugging commands [B-7](#)  
 desktop installation [3-3](#)  
 dev command [B-6](#)  
 dimensions, chassis [1-12 to 1-15](#)  
 dir command [B-6](#)  
 documentation  
   Cisco IOS software [xv](#)  
   conventions [viii](#)  
   obtaining [xvii](#)  
   on CD-ROM [xiv](#)  
   on the WEB [xiv](#)  
   related [xiv](#)  
 DRAM [1-6](#)  
 DSU/CSU connections [2-14](#)  
 DTE connections [2-11](#)

---

## E

electrical safety guidelines [2-1](#)  
 electrostatic discharge damage  
   See ESD.  
 EPROM-based memory [1-6](#)  
 error messages [A-10 to A-16](#)  
 ESD [2-2](#)  
 Ethernet cable types [2-10](#)

---

## F

FDX LED (Cisco 3660 rear panel) [A-10](#)  
 feet, installing [3-3](#)

## Figures

- auxiliary port connection [3-47 to 3-49](#)
  - bracket attachment for rack-mounting [3-6 to 3-13](#)
  - bracket attachment for wall-mounting [3-18](#)
  - brackets, rack-mounting [3-4, 3-5](#)
  - cable routing [3-42, 3-43](#)
  - chassis views [1-2 to 1-5](#)
  - console terminal connection [3-44 to 3-46](#)
  - DC power connections [3-29, 3-31](#)
  - DC wire routing [3-32, 3-35, 3-36](#)
  - Grounding Lug Fastened to Cisco 3660 Chassis [3-26](#)
  - ground lug attachment [3-19 to 3-26](#)
  - LEDs on front panel [A-4, A-5, A-7](#)
  - LEDs on rear panel [A-8, A-9](#)
  - modem connection [3-47 to 3-49](#)
  - rack-mounting brackets [3-4, 3-5](#)
  - rack-mounting the chassis [3-14 to 3-17](#)
  - rollover cable, identifying [3-50](#)
- Flash memory [1-6](#)
- booting from [C-6](#)
  - description of [1-6](#)
- frame command [B-7](#)

## G

- ground connection
  - for Cisco 3620 and Cisco 3640 [3-19](#)
  - for Cisco 3631 [3-24](#)
  - for Cisco 3660 [3-25](#)
- Grounding Lug Fastened to Cisco 3660 Chassis  
(figure) [3-26](#)

## H

- help command [B-6](#)
- high temperature, troubleshooting [A-3](#)
- humidity, specifications [1-12, 1-13, 1-14](#)

- i (initialize) command [B-6](#)
- installation
  - checklist [2-6](#)
  - desktop [3-3](#)
  - rack-mounting [3-3 to 3-17](#)
  - site requirements [2-4](#)
  - tools required [2-8](#)
- interface numbering [1-8 to 1-12](#)
  - Cisco 2600 series routers [1-8](#)
  - WAN interface cards [1-11](#)
- IOS software
  - locating documentation [xv](#)
  - recovering images [B-9](#)
- ISDN BRI [2-13 to 2-14](#)

## L

- LAN
  - connections [3-37 to 3-41](#)
  - interface types [2-10, 2-11](#)
- LEDs
  - ACTIVE [A-7](#)
  - front panel [A-4 to A-8](#)
  - interpretation of [A-2](#)
  - PCMCIA [A-7](#)
  - power supply [A-6](#)
  - READY [A-7](#)
  - rear panel [A-8 to A-10](#)
  - RPS [A-6](#)
  - system [A-6](#)
- lightning safety [2-2](#)
- LINK LED (Cisco 3631 rear panel) [A-8](#)
- LINK LED (Cisco 3660 rear panel) [A-10](#)

---

**M**

meminfo command [B-6](#)  
 memory [1-6 to 1-7](#)  
 modem connection [3-46](#)

---

**N**

netboot [B-4](#)  
 network connections [2-10](#)  
 network modules, installing [1-5](#)  
 nonvolatile random-access memory  
   See NVRAM.  
 NVRAM [1-6](#)

---

**P**

packing list [2-7](#)  
 PCMCIA cards [1-6](#)  
 PCMCIA LED (Cisco 3620, 3640, 3660) [A-7](#)  
 PCMCIA LED (Cisco 3660 rear panel) [A-9](#)  
 port numbering [1-8 to 1-12](#)  
 power  
   requirements [2-3](#)  
   specifications [1-12, 1-13, 1-14, 1-15](#)  
 POWER LED (Cisco 3631 front panel) [A-8](#)  
 Power LED (Cisco 3660 rear panel) [A-9](#)  
 power supply connections  
   AC [3-27](#)  
   DC for Cisco 3620 and Cisco 3640 [3-28](#)  
   DC for Cisco 3631 [3-30](#)  
   DC for Cisco 3660 [3-32](#)  
 power supply LEDs [A-6](#)  
 processor specifications [1-6, 1-7](#)

---

**R**

rack-mounting the chassis [3-3 to 3-17](#)  
 racks, equipment [2-5](#)  
 READY LED (Cisco 3620, 3640, 3660) [A-7](#)  
 rear panel  
   Cisco 2600 series (figure) [1-11](#)  
 record keeping, site log [2-7](#)  
 regulatory compliance [1-15](#)  
 reload command [B-2](#)  
 reset command [B-6](#)  
 rollover cable, identifying [3-50](#)  
 ROM monitor  
   commands [B-2 to B-8](#)  
   syntax [B-3](#)  
   using [B-1](#)  
 RPS LED [A-6](#)

---

**S**

safety  
   guidelines [2-1, 2-2](#)  
   warnings, translations of [ix](#)  
 SDRAM [1-6](#)  
 serial connections, considerations [2-11](#)  
 serial port specifications [2-12](#)  
 shared memory [1-6](#)  
 show hardware command [B-5](#)  
 show version command [B-5](#)  
 site  
   configuration [2-4](#)  
   environment [2-4](#)  
   log, record keeping [2-7](#)  
   requirements [2-3](#)  
 slot numbering [1-8 to 1-12](#)  
 software image recovery procedure [B-9](#)

## specifications

- Cisco 3620 [1-12](#)
  - Cisco 3631 [1-13](#)
  - Cisco 3640 [1-14](#)
  - Cisco 3660 [1-15](#)
  - memory [1-6](#)
  - processor [1-6](#)
  - serial ports [2-12](#)
  - system [1-12](#)
- stack command [B-7](#)
- static electricity damage [2-2](#)
- SYS/RPS LED (Cisco 3631 front panel) [A-8](#)
- sysret command [B-7](#)
- SYSTEM LED (Cisco 3660 rear panel) [A-9](#)

**T**

## Tables

- configuration register bits [C-2](#)
- configuration register settings for boot field [C-4](#)
- configuration register settings for broadcast address [C-5](#)
- configuration register settings for console terminal baud rate [C-5](#)
- DC wiring requirements [3-28, 3-30, 3-33](#)
- documents [xv](#)
- DTE and DCE devices [2-12](#)
- error messages for Cisco 3600 series [A-11, A-12](#)
- error messages for Cisco 3660 only [A-12 to A-16](#)
- ISDN-BRI cable specifications [2-14](#)
- LAN connections [3-38](#)
- LEDs, front panel [A-6 to A-8](#)
- LEDs, rear panel [A-8 to A-10](#)
- power requirements [2-3](#)
- related documents [xv](#)
- serial signal transmission specifications [2-13](#)
- specifications, memory [1-6, 1-7](#)
- specifications, system [1-12 to 1-15](#)
- voice connections [3-38](#)

- WAN connections [3-38](#)
  - telephone jacks, safety during installation [2-2](#)
  - temperature, operating [1-12 to 1-15](#)
  - TFTP server [B-4](#)
  - Token Ring connections [2-11](#)
  - tools required for installation [2-8](#)
- troubleshooting
- cables [A-3](#)
  - connections [A-3](#)
  - cooling system [A-2](#)
  - error messages [A-10 to A-16](#)
  - front panel LEDs [A-4 to A-8](#)
  - high temperature [A-3](#)
  - modules [A-3](#)
  - power system [A-2](#)
  - rear panel LEDs [A-8 to A-10](#)

**U**

## unit numbers

- Cisco 2600 series (figure) [1-11](#)
- Cisco 3600 series [1-8](#)

**V**ventilation [2-5](#)

## VICs

See voice interface cards.

voice interface cards, installing [1-5](#)**W**wall-mounting the router [3-18](#)

## WAN interface cards

Cisco 2600 series slot (figure) [1-11](#)

WAN interface cards, installing [1-5](#)

## Warnings

- DC power supply [3-31](#)
  - installation [2-1](#)
  - lightning activity [3-37](#)
  - main disconnection [3-51](#)
  - qualified personnel [3-1](#)
  - restricted access [3-1](#)
  - secure power cabling [3-28, 3-30](#)
  - SELV circuit [2-10](#)
  - TN power systems [2-3](#)
  - WAN port voltages [2-13](#)
- warnings, translations of [ix](#)
- WICs
- See WAN interface cards
- wiring
- AC power supplies [3-27](#)
  - DC power supplies [3-27 to 3-36](#)
  - telephone [2-2](#)

---

**X**

- xmodem command [B-9](#)