



Numerics

56-kbps DSU/CSU interface, configuring [2-22](#)

A

analog modem interface

 configuring [3-26](#)

 modem country codes [3-28](#)

asynchronous/synchronous serial interface

 configuring [3-5](#)

asynchronous interface, configuring [3-9](#)

atm-dxi map command [3-48](#)

ATM interface

 configuring [3-20](#)

 configuring PVCs [3-20](#)

 configuring SVCs [3-21](#)

 IMA interface configuration [3-22](#)

ATM T1/E1 interface configuration [3-23](#)

B

benefits [3-50](#)

boot

 ROM monitor [C-3](#)

C

caution symbol, meaning of [xiii](#)

Cisco 2600 series router

 WAN Interface Numbering [1-2](#)

Cisco 2600 series routers

 interface numbering [1-1](#)

 Voice Interface Numbering [1-4](#)

Cisco 3600 series routers

 interface numbering [1-4](#)

 unit numbers (figure) [1-9](#)

Cisco 3700 Series Interface Numbering [1-9](#)

Cisco 3725 Interface Numbering [1-9](#)

Cisco 3745 router interface numbering [1-10](#)

Cisco IOS

 about [1-13](#)

 command modes [1-13](#)

 enable mode [1-14](#)

 getting help [1-13](#)

 saving configuration changes [1-15](#)

 undo command [1-14](#)

 undo feature [1-14](#)

clock rate settings [3-8](#)

codec complexity configuration [3-17](#)

command modes, Cisco IOS [1-13](#)

commands

 configuration register [C-5](#)

 context [C-5](#)

 copy running-config [1-15](#)

 debugging [C-5](#)

 dir [C-3](#)

 exec-timeout [3-2](#)

 frame [C-5](#)

 half-duplex timer [3-7](#)

 help [1-13, C-4](#)

 meminfo [C-4](#)

 ping [3-29](#)

 reset [C-4](#)

 ROM monitor diagnostics [C-1](#)

 show config [3-2](#)

- show controllers 3-29
- show controllers atm 3-26
- show ima interface atm 3-26
- show interface async 3-28
- show interfaces 3-29
- show line 3-28
- show protocols 3-29
- show running-config 3-29
- show version 3-29
- stack C-5
- sysret C-5
- tftpdnld C-4
- undo 1-14
- xmodem C-8
- compress command 3-49
- compression
 - hardware 3-49
 - PPP 3-49
- configuration
 - before starting router 2-1
 - completing 2-23
 - global parameters 2-2
 - saving 2-23
 - timeout 3-2
 - verifying 3-29
 - voice over IP 4-2
 - voice over IP examples 4-3
- configuration, saving 1-15
- configuration example A-23
- configuration register
 - changing settings C-5
- configuration tasks 3-51
 - configure modem lines for dial-in and dial-out 3-57
 - configure the modem for dial-in 3-57
 - configure the modem for dial-out 3-57
 - configure the default IP pool information 3-57
 - configure the E1/T1 network module for ISDN PRI 3-51
 - configure channelized E1 ISDN PRI 3-51
 - configure channelized T1 ISDN PRI 3-52
 - configure the ISDN D-channel serial interfaces 3-53
 - configure the ISDN D-channel serial interface for E1 modules 3-53
 - configure the ISDN D-channel serial interface for T1 modules 3-54
 - configure the ISDN dialer interface 3-56
 - configure the LAN interface 3-55
 - configure the loopback interface 3-54
 - create the group asynchronous interface 3-55
- configuring
 - analog modem 3-26
 - asynchronous/synchronous serial interface 3-5
 - asynchronous interface 3-9
 - ATM interface 3-20
 - PVCs 3-20
 - SVCs 3-21
 - country codes 3-28
 - E1 interface 3-14
 - Ethernet interface 3-3
 - global parameters 2-2
 - high-density voice interface
 - codec complexity 3-17
 - IMA interface 3-22
 - ATM T1/E1 interface 3-23
 - IMA group interface 3-24
 - interface parameters 2-5
 - ISDN-BRI interface 3-10
 - ISDN BRI line 2-15
 - ISDN PRI interface 3-14
 - E1 interface 3-16
 - T1 interface 3-15
 - multiflex trunk interface 3-14
 - E1 interface 3-16
 - T1 interface 3-15
 - TDM connect 3-16
 - T1 (FT1) WAN interface 3-18
 - T1 interface 3-14
- context command C-5

conventions [xii](#)
 conventions, document [xii](#)

D

debugging commands [C-5](#)
 dir command [C-3](#)
 document
 conventions [xii](#)
 document conventions [xii](#)

E

E1/T1 ISDN PRI interface [3-15, 3-16](#)
 E1/T1 multiflex trunk interface [3-15, 3-16](#)
 E1 interface
 configuring [3-14](#)
 enable mode [1-14](#)
 encapsulation atm-dxi command [3-48](#)
 encapsulation ppp command
 configuring compression over [3-49](#)
 Ethernet interface, configuring [2-6, 3-3](#)

F

feature summary [3-50](#)
 frame command [C-5](#)

G

global configuration command mode [1-14](#)
 global parameters configuration [2-2](#)

H

half-duplex timer commands [3-7](#)
 hardware compression, displaying [3-49](#)
 help

 command [C-4](#)
 help, Cisco IOS [1-13](#)
 high-density voice interface
 codec complexity [3-17](#)
 host name
 configuring [3-2](#)
 show config command [3-2](#)
 verifying [3-2](#)
 hssi internal-clock command [3-48](#)
 HSSI network module
 benefits [3-46](#)
 configuration
 disabling fair queueing [3-48](#)
 examples [3-48](#)
 invoking ATM [3-47](#)
 specifying clocking [3-48](#)
 specifying encapsulation [3-47](#)
 specifying interface [3-47](#)
 task list [3-47](#)
 feature summary [3-46](#)

IMA interface
 configuring [3-22](#)
 configuring the ATM T1/E1 interface [3-23](#)
 configuring the IMA interface [3-24](#)
 IMA interface configuration [3-24](#)
 interface configuration command mode [1-14](#)
 interface numbering
 Cisco 2600 series routers [1-1](#)
 Cisco 3600 series routers [1-4](#)
 Cisco 3660 slot 0 [1-6, 1-8](#)
 WAN and LAN interface cards [1-2](#)
 ISDN BRI
 switch type, provisioning [2-15](#)
 ISDN BRI interface, configuring [3-10](#)
 ISDN BRI line, configuring [2-15](#)
 ISDN PRI interface

configuring [3-14](#)
 E1 configuration [3-16](#)
 T1 configuration [3-15](#)
 ISDN PRI switch types [3-52](#)
 ISDN provisioning by switch type (table) [2-16](#)
 ISDN switch types [3-12](#)

L

LAN Interface Numbering
 Cisco 2600 series router [1-2](#)

M

meminfo command [C-4](#)
 modem country codes [3-28](#)
 multiflex trunk interface
 configuring [3-14](#)
 E1 configuration [3-16](#)
 T1 configuration [3-15](#)
 TDM connect [3-16](#)

N

network modules
 configuring
 asynchronous/synchronous interface [2-9](#)
 E1/T1 ISDN PRI interface [2-17](#)
 Ethernet interface [2-6](#)
 Fast Ethernet interface [2-6](#)
 ISDN BRI interface [2-12](#)
 serial interface [2-7](#)
 Token Ring interface [2-7](#)
 note symbol, meaning of [xiii](#)

P

parameters

 configuring global [2-2](#)
 configuring interface [2-5](#)
 password
 configuring [3-2](#)
 show config command [3-2](#)
 verifying [3-2](#)

PPP

 compression [3-49](#)
 prerequisites [3-50](#)
 privileged EXEC command mode [1-14](#)
 provisioning ISDN switch types [2-15](#)
 PVC configuration [3-20](#)

R

recovering boot and system images [C-8](#)
 reset command [C-4](#)
 ROM
 monitor
 diagnostics [C-5](#)
 router
 rear view
 Cisco 3620 (figure) [1-5](#)
 Cisco 3631 (figure) [1-6](#)
 Cisco 3640 (figure) [1-5](#)
 Cisco 3660 (figure) [1-5](#)

S

saving configuration changes [1-15](#)
 script, setup [2-2](#)
 service profile identifier
 See SPID
 setup command facility [2-2](#)
 setup script, using [2-2](#)
 show config command [3-2](#)
 show process cpu command [3-49](#)
 Slot numbering - Cisco 3745 [1-11](#)

Slot numbering for Cisco 3600 series router [1-4](#)

slot numbering for Cisco 3725 [1-9](#)

SPID [2-17](#)

SPIDs [2-17](#)

stack command [C-5](#)

SVC configuration [3-21](#)

Symbols

Caution [xiii](#)

Note [xiii](#)

Timesaver [xiii](#)

Tips [xiii](#)

sysret command [C-5](#)

T

T1 (FT1) WAN interface, configuring [3-18](#)

T1 interface

configuring [3-14](#)

TDM cross-connect configuration [3-16](#)

tftpdnld command [C-4](#)

timeout, disabling [3-2](#)

timesaver symbol, meaning of [xiii](#)

tips symbol, meaning of [xiii](#)

U

undo feature, Cisco IOS [1-14](#)

unit numbers

Cisco 3600 series (figure) [1-9](#)

user EXEC command mode [1-14](#)

V

verifying

IMA configuration [3-26](#)

interface configuration [3-29](#)

modem configuration [3-28](#)

Voice Interface cards - Cisco 3700 series [1-11](#)

voice interface numbering

Cisco 2600 series routers [1-4](#)

Voice interface numbering for Cisco 3600 Series Routers [1-8](#)

Voice interface numbering for Cisco 3700 Series Routers [1-12](#)

voice over IP

configuration examples [4-3](#)

configuring [4-2](#)

configuring direct-inward dialing on a BRI port [4-10](#)

FXS-to-FXS connections [4-4](#)

linking PBX users with E&M trunk lines [4-6](#)

PSTN gateway access using FXO connections [4-8](#)

PSTN gateway access using FXO connections in PLAR mode [4-9](#)

W

WAN interface cards

Cisco 3600 series slot (figure) [1-8](#)

WAN interface cards - Cisco 3700 series [1-11](#)

WAN Interface Numbering

Cisco 2600 series routers [1-2](#)

X

xmodem command [C-8](#)

