



Send documentation comments to mdsfeedback-doc@cisco.com.

CHAPTER 11

I Commands

The commands in this chapter apply to the Cisco MDS 9000 Family of multilayer directors and fabric switches. All commands are shown here in alphabetical order regardless of command mode. See the “[About the CLI Command Modes](#)” section on page 1-3 to determine the appropriate mode for each command. For more information, refer to the *Cisco MDS 9000 Family Configuration Guide*.

in-order-guarantee

Send documentation comments to mdsfeedback-doc@cisco.com.

in-order-guarantee

To enable in-order delivery, use the **in-order-guarantee** command in configuration mode. To disable in-order delivery, use the **no** form of the command.

in-order-guarantee [vsan *vsan-id*]

no in-order-guarantee [vsan *vsan-id*]

Syntax Description	vsan <i>vsan-id</i>	Specifies a VSAN ID. The range is 1 to 4093.
Defaults	Disabled.	
Command Modes	Configuration mode.	
Command History	Release	Modification
	1.3(4)	This command was introduced.
Usage Guidelines	In-order delivery of data frames guarantees frame delivery to a destination in the same order that they were sent by the originator.	
Examples	<p>The following example shows how to enable in-order delivery for the entire switch.</p> <pre>switch# config terminal switch(config) # in-order-guarantee</pre> <p>The following example shows how to disable in-order delivery for the entire switch.</p> <pre>switch(config)# no in-order-guarantee</pre> <p>The following example shows how to enable in-order delivery for a specific VSAN.</p> <pre>switch(config)# in-order-guarantee vsan 3452</pre> <p>The following example shows how to disable in-order delivery for a specific VSAN.</p> <pre>switch(config)# no in-order-guarantee vsan 101</pre>	
Related Commands	Command	Description
	show in-order-guarantee	Displays the in-order-guarantee status.

Send documentation comments to mdsfeedback-doc@cisco.com.

initiator

To configure the initiator version and address, use the **initiator** command IKE configuration submode. To revert to the default, use the **no** form of the command.

initiator version *version* address *ip-address*

no initiator version *version* address *ip-address*

Syntax Description	<i>version</i> Specifies the protocol version number. The only valid value is 1. address <i>ip-address</i> Specifies the IP address for the IKE peer. The format is <i>A.B.C.D</i> .
---------------------------	--

Defaults	IKE version 2.
-----------------	----------------

Command Modes	IKE configuration submode.
----------------------	----------------------------

Command History	Release	Modification
	2.0(1b)	This command was introduced.

Usage Guidelines	To use this command, the IKE protocol must be enabled using the crypto ike enable command.
-------------------------	---

Examples	The following example shows how initiator information for the IKE protocol.
<pre>switch# config terminal switch(config)# crypto ike domain ipsec switch(config-ike-ipsec)# initiator version 1 address 10.1.1.1</pre>	

Related Commands	Command	Description
	crypto ike domain ipsec	Enters IKE configuration mode.
	crypto ike enable	Enables the IKE protocol.
	show crypto ike domain ipsec	Displays IKE information for the IPsec domain.

install all

Send documentation comments to mdsfeedback-doc@cisco.com.

install all

To upgrade all modules in any Cisco MDS 9000 family switch, use the **install all** command. This upgrade can happen nondisruptively or disruptively depending on the current configuration of your switch.

install all [{asm-sfn | kickstart | ssi | system} URL]

Syntax Description	asm-sfn <i>filename</i> Upgrades the ASM image.
system	Upgrades the system image.
ssi	Upgrades the SSI image.
kickstart	Upgrades the kickstart image.
URL	The location URL of the source file to be installed.

The following table lists the aliases for *URL*.

bootflash:	Source location for internal bootflash memory.
slot0:	Source location for the CompactFlash memory or PCMCIA card.
volatile:	Source location for the volatile file system.
tftp:	Source location for a Trivial File Transfer Protocol (TFTP) network server. The syntax for this URL is tftp:[//location]/directory]/filename .
ftp:	Source location for a File Transfer Protocol (FTP) network server. The syntax for this URL is ftp:[//location]/directory]/filename .
sftp:	Source location for a Secure Trivial File Transfer Protocol (SFTP) network server. The syntax for this URL is sftp:[//<username@>location]/directory]/filename .
scp:	Source location for a Secure Copy Protocol (SCP) network server. The syntax for this URL is scp:[//location]/directory]/filename .
<i>image-filename</i>	The name of the source image file.

Defaults	None.
-----------------	-------

Command Modes	EXEC mode.
----------------------	------------

Command History	Release	Modification
	1.0(3)	This command was introduced.
	1.2(2)	Added the asm-sfn keyword and made all keywords optional.
	2.0(1b)	Added the ssi keyword.

Usage Guidelines	The install all command upgrades all modules in any Cisco MDS 9000 Family switch. To copy a remote file, specify the entire remote path exactly as it is.
-------------------------	--

Send documentation comments to mdsfeedback-doc@cisco.com.

**Caution**

If a switchover is required when you issue the **install all** command from a Telnet or SSH session, all open sessions are terminated. If no switchover is required, the session remains unaffected. The software issues a self-explanatory warning at this point and provides the option to continue or terminate the installation.

See the *Cisco MDS 9000 Family Configuration Guide* for detailed procedures.

Examples

The following example displays the result of the **install all** command if the system and kickstart files are specified locally.

```
switch# install all sys bootflash:isan-1.3.1 kickstart bootflash:boot-1.3.1

Verifying image bootflash:/boot-1.3.1
[#####] 100% -- SUCCESS

Verifying image bootflash:/isan-1.3.1
[#####] 100% -- SUCCESS

Extracting "slc" version from image bootflash:/isan-1.3.1.
[#####] 100% -- SUCCESS

Extracting "ips" version from image bootflash:/isan-1.3.1.
[#####] 100% -- SUCCESS

Extracting "system" version from image bootflash:/isan-1.3.1.
[#####] 100% -- SUCCESS

Extracting "kickstart" version from image bootflash:/boot-1.3.1.
[#####] 100% -- SUCCESS

Extracting "loader" version from image bootflash:/boot-1.3.1.
[#####] 100% -- SUCCESS
```

Compatibility check is done:

Module	bootable	Impact	Install-type	Reason
1	yes	non-disruptive	rolling	
2	yes	disruptive	rolling	Hitless upgrade is not supported
3	yes	disruptive	rolling	Hitless upgrade is not supported
4	yes	non-disruptive	rolling	
5	yes	non-disruptive	reset	
6	yes	non-disruptive	reset	

Images will be upgraded according to following table:

Module	Image	Running-Version	New-Version	Upg-Required
1	slc	1.3(2a)	1.3(1)	yes
1	bios	v1.1.0(10/24/03)	v1.1.0(10/24/03)	no
2	ips	1.3(2a)	1.3(1)	yes
2	bios	v1.1.0(10/24/03)	v1.1.0(10/24/03)	no
3	ips	1.3(2a)	1.3(1)	yes
3	bios	v1.1.0(10/24/03)	v1.1.0(10/24/03)	no
4	slc	1.3(2a)	1.3(1)	yes
4	bios	v1.1.0(10/24/03)	v1.1.0(10/24/03)	no
5	system	1.3(2a)	1.3(1)	yes

install all

Send documentation comments to mdsfeedback-doc@cisco.com.

```

5   kickstart          1.3(2a)           1.3(1)        yes
5     bios             v1.1.0(10/24/03)    v1.1.0(10/24/03)    no
5     loader           1.2(2)            1.2(2)        no
6     system           1.3(2a)           1.3(1)        yes
6     kickstart         1.3(2a)           1.3(1)        yes
6     bios             v1.1.0(10/24/03)    v1.1.0(10/24/03)    no
6     loader           1.2(2)            1.2(2)        no

Do you want to continue with the installation (y/n)? [n] y

Install is in progress, please wait.

Syncing image bootflash:/boot-1.3.1 to standby.
[#####] 100% -- SUCCESS

Syncing image bootflash:/isan-1.3.1 to standby.
[#####] 100% -- SUCCESS
Jan 18 23:40:03 Hacienda %VSHD-5-VSHD_SYSLOG_CONFIG_I: Configuring console from

Performing configuration copy.
[#####] 100% -- SUCCESS

Module 6: Waiting for module online.
|
Auto booting bootflash:/boot-1.3.1 bootflash:/isan-1.3.1...
Booting kickstart image: bootflash:/boot-1.3.1....
.....Image verification OK

Starting kernel...
INIT: version 2.78 booting
Checking all filesystems..r.r.. done.
Loading system software
Uncompressing system image: bootflash:/isan-1.3.1
CCCCCCCCCC
CCCCCCCCCC
CCCCCCCCCC
CCCCCCCCCC
INIT: Entering runlevel: 3

```

The following example displays the file output continuation of the **install all** command on the console of the standby supervisor module.

```

Hacienda(standby)#

Auto booting bootflash:/boot-1.3.1 bootflash:/isan-1.3.1...
Booting kickstart image: bootflash:/boot-1.3.1...
.....Image verification OK

Starting kernel...
INIT: version 2.78 booting
Checking all filesystems..r.r.. done.
Loading system software
Uncompressing system image: bootflash:/isan-1.3.1
CCCCCCCCCC
CCCCCCCCCC
CCCCCCCCCC
CCCCCCCCCC
INIT: Entering runlevel: 3

Continue on installation process, please wait.
The login will be disabled until the installation is completed.

Module 6: Waiting for module online.
Jan 18 23:43:02 Hacienda %PORT-5-IF_UP: Interface mgmt0 is up
Jan 18 23:43:19 Hacienda %LICMGR-3-LOG_LIC_NO_LIC: No license(s) present for feature
FM_SERVER_PKG. Application(s) shutdown in 53 days.

```

Send documentation comments to mdsfeedback-doc@cisco.com.

```

Jan 18 23:43:19 Hacienda %LICMGR-3-LOG_LIC_NO_LIC: No license(s) present for feature
ENTERPRISE_PKG. Application(s) shutdown in 50 days.
Jan 18 23:43:19 Hacienda %LICMGR-3-LOG_LIC_NO_LIC: No license(s) present for feature
SAN_EXTN_OVER_IP. Application(s) shutdown in 50 days.
Jan 18 23:43:19 Hacienda %LICMGR-3-LOG_LICAPP_NO_LIC: Application port-security running
without ENTERPRISE_PKG license, shutdown in 50 days
Jan 18 23:43:19 Hacienda %LICMGR-4-LOG_LICAPP_EXPIRY_WARNING: Application Roles evaluation
license ENTERPRISE_PKG expiry in 50 days
Jan 18 23:44:54 Hacienda %BOOTVAR-5-NEIGHBOR_UPDATE_AUTOCOPY: auto-copy supported by
neighbor, starting...

Module 1: Non-disruptive upgrading.
[#] 0%Jan 18 23:44:56 Hacienda %MODULE-5-STANDBY_SUP_OK: Supervisor 5
is standby
Jan 18 23:44:55 Hacienda %IMAGE_DNLD-SLOT1-2-IMG_DNLD_STARTED: Module image download
process. Please wait until completion...
Jan 18 23:45:12 Hacienda %IMAGE_DNLD-SLOT1-2-IMG_DNLD_COMPLETE: Module image download
process. Download successful.
Jan 18 23:45:48 Hacienda %MODULE-5-MOD_OK: Module 1 is online
[#####] 100% -- SUCCESS

Module 4: Non-disruptive upgrading.
[#] 0%Jan 18 23:46:12 Hacienda %IMAGE_DNLD-SLOT4-2-IMG_DNLD_STARTED:
Module image download process. Please wait until completion...
Jan 18 23:46:26 Hacienda %IMAGE_DNLD-SLOT4-2-IMG_DNLD_COMPLETE: Module image download
process. Download successful.
Jan 18 23:47:02 Hacienda %MODULE-5-MOD_OK: Module 4 is online
[#####] 100% -- SUCCESS

Module 2: Disruptive upgrading.
...
-- SUCCESS

Module 3: Disruptive upgrading.
...
-- SUCCESS

Install has been successful.

MDS Switch
Hacienda login:
```

The following example displays the result of the **install all** command if the system and kickstart files are specified remotely.

```

switch# install all system
scp://user@171.69.16.26/tftpboot/HKrel/qa/vegas/final/m9500-sf1ek9-mz.1.3.2a.bin kickstart
scp://user@171.69.16.26/tftpboot/HKrel/qa/vegas/final/m9500-sf1ek9-kickstart-mz.1.3.2a.bin
For scp://user@171.69.16.26, please enter password:
For scp://user@171.69.16.26, please enter password:

Copying image from
scp://user@171.69.16.26/tftpboot/HKrel/qa/vegas/final/m9500-sf1ek9-kickstart-mz.1.3.2a.bin
to bootflash:///m9500-sf1ek9-kickstart-mz.1.3.2a.bin.
[#####] 100% -- SUCCESS

Copying image from
scp://user@171.69.16.26/tftpboot/HKrel/qa/vegas/final/m9500-sf1ek9-mz.1.3.2a.bin to
bootflash:///m9500-sf1ek9-mz.1.3.2a.bin.
[#####] 100% -- SUCCESS

Verifying image bootflash:///m9500-sf1ek9-kickstart-mz.1.3.2a.bin
[#####] 100% -- SUCCESS
```

install all

Send documentation comments to mdsfeedback-doc@cisco.com.

```

Verifying image bootflash:///m9500-sf1ek9-mz.1.3.2a.bin
[#####] 100% -- SUCCESS

Extracting "slc" version from image bootflash:///m9500-sf1ek9-mz.1.3.2a.bin.
[#####] 100% -- SUCCESS

Extracting "ips" version from image bootflash:///m9500-sf1ek9-mz.1.3.2a.bin.
[#####] 100% -- SUCCESS

Extracting "system" version from image bootflash:///m9500-sf1ek9-mz.1.3.2a.bin.
[#####] 100% -- SUCCESS

Extracting "kickstart" version from image
bootflash:///m9500-sf1ek9-kickstart-mz.1.3.2a.bin.
[#####] 100% -- SUCCESS

Extracting "loader" version from image bootflash:///m9500-sf1ek9-kickstart-mz.1.3.2a.bin.
[#####] 100% -- SUCCESS

```

Compatibility check is done:

Module	bootable	Impact	Install-type	Reason
1	yes	non-disruptive	rolling	
2	yes	disruptive	rolling	Hitless upgrade is not supported
3	yes	non-disruptive	rolling	
4	yes	non-disruptive	rolling	
5	yes	non-disruptive	reset	
6	yes	non-disruptive	reset	
7	yes	non-disruptive	rolling	
8	yes	non-disruptive	rolling	
9	yes	disruptive	rolling	Hitless upgrade is not supported

Images will be upgraded according to following table:

Module	Image	Running-Version	New-Version	Upg-Required
1	slc	1.3(1)	1.3(2a)	yes
1	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
2	ips	1.3(1)	1.3(2a)	yes
2	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
3	slc	1.3(1)	1.3(2a)	yes
3	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
4	slc	1.3(1)	1.3(2a)	yes
4	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
5	system	1.3(1)	1.3(2a)	yes
5	kickstart	1.3(1)	1.3(2a)	yes
5	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
5	loader	1.2(2)	1.2(2)	no
6	system	1.3(1)	1.3(2a)	yes
6	kickstart	1.3(1)	1.3(2a)	yes
6	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
6	loader	1.2(2)	1.2(2)	no
7	slc	1.3(1)	1.3(2a)	yes
7	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
8	slc	1.3(1)	1.3(2a)	yes
8	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no
9	ips	1.3(1)	1.3(2a)	yes
9	bios	v1.1.0(10/24/03)	v1.0.8(08/07/03)	no

Do you want to continue with the installation (y/n)? [n]

Send documentation comments to mdsfeedback-doc@cisco.com.

Related Commands	Command	Description
	install module bios	Upgrades the supervisor or switching module BIOS.
	install module loader	Upgrades the bootloader on the active or standby supervisor or modules.
	show version	Displays software image version information.

install license

Send documentation comments to mdsfeedback-doc@cisco.com.

install license

To program the supervisor or switching module BIOS, use the **install license** command.

install license [bootflash: | slot0: | volatile:] file-name

Syntax Description	bootflash: Source location for the license file.
slot0:	Source location for the license file.
volatile:	Source location for the license file.
<i>file-name</i>	The name of the license file.

Defaults	None.
-----------------	-------

Command Modes	EXEC mode.
----------------------	------------

Command History	Release	Modification
	1.2(1)	This command was introduced.

Usage Guidelines	If a target file name is provided after the source URL, the license file is installed with that name. Otherwise, the filename in the source URL is used. This command also verifies the license file before installing it.
-------------------------	--

Examples	The following example installs a file named license-file which resides in the bootflash: directory.. switch# install license bootflash:license-file
-----------------	---

Related Commands	Command	Description
	show license	Displays license information.

Send documentation comments to mdsfeedback-doc@cisco.com.

install module bios

To program the supervisor or switching module BIOS, use the **install module bios** command.

install module *module-number* bios {system [bootflash: | slot0: | volatile: | *system-image*]}

Syntax Description	<table border="0"> <tr> <td><i>module-number</i></td><td>From slot 1 to 9 in a Cisco MDS 9500 Series switch. From slot 1 to 2 in a Cisco MDS 9200 Series switch.</td></tr> <tr> <td>system</td><td>Specifies the system image to use (optional). If system is not specified, the current running image is used.</td></tr> <tr> <td>bootflash:</td><td>Source location for internal bootflash memory</td></tr> <tr> <td>slot0:</td><td>Source location for the CompactFlash memory or PCMCIA card.</td></tr> <tr> <td>volatile:</td><td>Source location for the volatile file system.</td></tr> <tr> <td><i>system-image</i></td><td>The name of the system or kickstart image.</td></tr> </table>	<i>module-number</i>	From slot 1 to 9 in a Cisco MDS 9500 Series switch. From slot 1 to 2 in a Cisco MDS 9200 Series switch.	system	Specifies the system image to use (optional). If system is not specified, the current running image is used.	bootflash:	Source location for internal bootflash memory	slot0:	Source location for the CompactFlash memory or PCMCIA card.	volatile:	Source location for the volatile file system.	<i>system-image</i>	The name of the system or kickstart image.
<i>module-number</i>	From slot 1 to 9 in a Cisco MDS 9500 Series switch. From slot 1 to 2 in a Cisco MDS 9200 Series switch.												
system	Specifies the system image to use (optional). If system is not specified, the current running image is used.												
bootflash:	Source location for internal bootflash memory												
slot0:	Source location for the CompactFlash memory or PCMCIA card.												
volatile:	Source location for the volatile file system.												
<i>system-image</i>	The name of the system or kickstart image.												

Defaults None.

Command Modes EXEC mode.

Command History	Release	Modification
	1.0(3)	This command was introduced.

Usage Guidelines If the BIOS is upgraded, you need to reboot to make the new BIOS effective. You can schedule the reboot at a convenient time so traffic will not be impacted.

The console baud rate automatically reverts to the default rate (9600) after any BIOS upgrade.

The URL is always the system image URL in the supervisor module, and points to the bootflash: or slot0: directories.

Examples The following example shows how to perform a nondisruptive upgrade for the system.

```
switch# install module 1 bios
Started bios programming .... please wait
###
BIOS upgrade succeeded for module 1
```

In this example, the switching module in slot 1 was updated.

install module epld

Send documentation comments to mdsfeedback-doc@cisco.com.

install module epld

To upgrade the electrically programmable logical devices (EPLDs) module, use the **install module epld** command. This command is only for supervisor modules, not switching modules.

install module *module-number* epld [*bootflash*: | *ftp*: | *scp*: | *sftp*: | *tftp*: | *volatile*:]

Syntax Description

<i>module-number</i>	Enters the number for the standby supervisor modules or any other line card.
bootflash:	Source location for internal bootflash memory.
ftp	Local/Remote URI containing EPLD Image.
scp	Local/Remote URI containing EPLD Image.
sftp	Local/Remote URI containing EPLD Image.
tftp	Local/Remote URI containing EPLD Image.
volatile:	Source location for the volatile file system.

Defaults

None.

Command Modes

EXEC mode.

Command History

Release	Modification
1.2(1)	This command was introduced.

Usage Guidelines

Issue this command from the active supervisor module to update any other module.

If you forcefully upgrade a module that is not online, all EPLDs are forcefully upgraded. If the module is not present in the switch, an error is returned. If the module is present, the command process continues.

Do not insert or extract any modules while an EPLD upgrade or downgrade is in progress.

Examples

The following example upgrades the EPLDs for the module in slot 2.

```
switch# install module 2 epld scp://user@10.6.16.22/users/dino/epld.img

The authenticity of host '10.6.16.22' can't be established.
RSA1 key fingerprint is 55:2e:1f:0b:18:76:24:02:c2:3b:62:dc:9b:6b:7f:b7.
Are you sure you want to continue connecting (yes/no)? yes
Warning: Permanently added '10.6.16.22' (RSA1) to the list of known hosts.
user@10.6.16.22's password:
epld.img          100% | ****|*****|*****|*****| 1269 KB    00:00

Module Number          2
EPLD                  Curr Ver   New Ver
-----
Power Manager          0x06
XBUS IO                0x07      0x08
```

Send documentation comments to mdsfeedback-doc@cisco.com.

```
UD chip Fix          0x05
Sahara             0x05      0x05

Module 2 will be powered down now!!
Do you want to continue (y/n) ? y
\ <-----progress twirl
Module 2 EPLD upgrade is successful
```

The following example forcefully upgrades the EPLDs for the module in slot 2.

```
switch# install module 2 epld scp://user@10.6.16.22/epld-img-file-path
```

```
Module 2 is not online, Do you want to continue (y/n) ? y
cchetty@171.69.16.22's password:
epld.img      100% |*****| 1269 KB    00:00
\ <-----progress twirl
Module 2 EPLD upgrade is successful
```

Related Commands

Command	Description
show version module <i>number</i> epld	Displays the current EPLD versions.
show version epld	Displays the available EPLD versions.

install module loader

Send documentation comments to mdsfeedback-doc@cisco.com.

install module loader

To upgrade the bootloader on either the active or standby supervisor module, use the **install module loader** command. This command is only for supervisor modules, not switching modules.

install module *module-number* loader kickstart [bootflash: | slot0: | volatile: | kickstart-image]

Syntax Description	<table border="0"> <tr> <td><i>module-number</i></td><td>Enters the module number for the active or standby supervisor modules (only slot 5 or 6).</td></tr> <tr> <td>kickstart</td><td>Specifies the kickstart image to use.</td></tr> <tr> <td>bootflash:</td><td>Source location for internal bootflash memory</td></tr> <tr> <td>slot0:</td><td>Source location for the CompactFlash memory or PCMCIA card.</td></tr> <tr> <td>volatile:</td><td>Source location for the volatile file system.</td></tr> <tr> <td><i>kickstart-image</i></td><td>The name of the kickstart image.</td></tr> </table>	<i>module-number</i>	Enters the module number for the active or standby supervisor modules (only slot 5 or 6).	kickstart	Specifies the kickstart image to use.	bootflash:	Source location for internal bootflash memory	slot0:	Source location for the CompactFlash memory or PCMCIA card.	volatile:	Source location for the volatile file system.	<i>kickstart-image</i>	The name of the kickstart image.
<i>module-number</i>	Enters the module number for the active or standby supervisor modules (only slot 5 or 6).												
kickstart	Specifies the kickstart image to use.												
bootflash:	Source location for internal bootflash memory												
slot0:	Source location for the CompactFlash memory or PCMCIA card.												
volatile:	Source location for the volatile file system.												
<i>kickstart-image</i>	The name of the kickstart image.												

Defaults None.

Command Modes EXEC mode.

Command History	Release	Modification
	1.0(3)	This command was introduced.

Usage Guidelines Before issuing the **install module loader** command, be sure to read the release notes to verify compatibility issues between the boot loader and the kickstart or system images.

If you install a loader version that is the same as the currently-installed version, the loader will not be upgraded. When both the current version and the installed version are the same, use the **init system** command to force a loader upgrade.

Examples The following example shows how to perform a non disruptive upgrade for the system.

```
switch# install module 6 loader bootflash:kickstart_image
```

This example displays the command being issued on the standby supervisor module in slot 6.

Related Commands	Command	Description
	show version	Verify the output before and after the upgrade.

Send documentation comments to mdsfeedback-doc@cisco.com.

install ssi

To perform a nondisruptive upgrade of the SSI image on an SSM, use the **install ssi** command.

```
install ssi {bootflash: | slot0: | modflash:}file-name module slot
```

Syntax Description

bootflash:	Source location for the SSI boot image file.
slot0:	Source location for the SSI boot image file.
modflash:	Source location for the SSI boot image file.
<i>file-name</i>	Specifies the SSI boot image file name.
module slot	Specifies the module slot number.

Defaults

None.

Command Modes

EXEC mode.

Command History

Release	Modification
2.1(2)	This command was introduced.

Usage Guidelines

You can use the **install ssi** command to upgrade or downgrade the SSI boot image if the SSM is only configured for Fibre Channel switching. If your SSM is configured for VSFN or Intelligent Storage Services, you must use the **boot** command to reconfigure the SSI boot variable and reload the module.

The **install ssi** command implicitly sets the SSI boot variable.

Examples

The following example installs the SSI boot image on the module in slot 2.

```
switch# install ssi bootflash:lm9000-ek9-ssi-mz.2.1.2.bin module 2
```

Related Commands

Command	Description
show boot	Displays the current contents of boot variables.
show module	Verifies the status of a module.
boot	Configures the boot variables.

interface

Send documentation comments to mdsfeedback-doc@cisco.com.

interface

To configure an interface on the Cisco MDS 9000 Family of switches, use the **interface** command in configuration mode.

interface {cpp | fc | fc-tunnel | fcip | gigabitethernet | iscsi | mgmt | port-channel | svc | vsan}

Syntax Description	
cpp	Configures a Control Plane Process (CPP) interface for the Advanced Services Module (ASM)—see the interface cpp command.
fc	Configures a Fiber Channel interface—see the interface fc command.
fc-tunnel	Configures a Fiber Channel link interface—see the interface fc-tunnel command.
fcip	Configures a Fibre Channel over IP (FCIP) interface—see the interface fcip command.
gigabitethernet	Configures a Gigabit Ethernet interface—see the interface gigabitethernet command.
iscsi	Configures an iSCSI interface—see the interface iscsi command.
mgmt	Configures a management interface—see the interface mgmt command.
port-channel	Configures a PortChannel interface—see the interface port-channel command.
svc	Configures a SAN Volume Controller (SVC) interface for the Caching Services Module (CSM)—see the interface svc command.
vsan	Configures a VSAN interface—see the interface vsan command.

Defaults	Disabled.
Command Modes	Configuration mode

Command History	Release	Modification
	1.0(2)	This command was introduced.

Usage Guidelines	You can specify a range of interfaces by issuing a command with the following example format: interface fc1/1 - 5 , fc2/5 - 7 The spaces are required before and after the dash (-) and before and after the comma (,).
-------------------------	--

Examples	The following example selects the mgmt 0 interface and enters interface configuration submode.
	<pre>switch# config terminal switch(config)# interface mgmt 0 switch(config-if)# </pre>

Send documentation comments to mdsfeedback-doc@cisco.com.

Related Commands	Command	Description
	show interface	Displays an interface configuration for a specified interface.

interface fc

Send documentation comments to mdsfeedback-doc@cisco.com.

interface fc

To configure a Fibre Channel interface on the Cisco MDS 9000 Family of switches, use the **interface fc** command in EXEC mode. To revert to defaults, use the **no** form of the command.

```
interface fc slot/port
    channel-group {group-id [force] | auto}
    fdomain rcf-reject vsan vsan-id
    fspf {cost link-cost vsan vsan-id | ficon portnumber portnumber | dead-interval seconds vsan
    vsan-id | hello-interval seconds vsan vsan-id | passive vsan vsan-id | retransmit-interval
    seconds vsan vsan-id}

interface fc slot/port
    no channel-group {group-id [force] | auto}
    no fdomain rcf-reject vsan vsan-id
    no fspf {cost link_cost vsan vsan-id | ficon portnumber portnumber | dead-interval seconds
    vsan vsan-id | hello-interval seconds vsan vsan-id | passive vsan vsan-id | retransmit-interval
    seconds vsan vsan-id}
```

Syntax Description	
slot/port	Specifies a slot number and port number.
channel-group	Adds to or removes from a Port Channel.
group-id	Specifies a Port Channel group number from 1 to 128.
force	Forcefully adds a port.
auto	Enables autocreation of port channels.
fdomain	Enters the interface submode.
rcf-reject	Configures the rcf-reject flag.
vsan vsan-id	Specifies the VSAN ID. The range is 1 to 4093.
fspf	Configures FSPF parameters.
cost link-cost	Configures FSPF link cost. The range is 1 to 65535.
dead-interval seconds	Configures FSPF dead interval in seconds. The range is 2 to 65535.
ficon	Configures FICON parameters.
portnumber portnumber	Configures the FICON port number for this interface.
hello-interval seconds	Configures FSPF hello-interval. The range is 1 to 65535.
passive	Enables or disables FSPF on the interface.
retransmit-interval seconds	Configures FSPF retransmit interface in seconds. The range is 1 to 65535.
Defaults	Disabled.
Command Modes	Configuration mode.

Send documentation comments to mdsfeedback-doc@cisco.com.

Command History	Release	Modification
	1.0(2)	This command was introduced.
	2.0(1b)	Added the auto option to the channel-group keyword.

Usage Guidelines

You can specify a range of interfaces by issuing a command with the following example format:

interfacespacefc1/1space-space5space,spacefc2/5space-space7

Refer to the *Cisco MDS 9000 Family Configuration Guide* for information on port number allocation.

Use the **no shutdown** command to enable the interface.

The **channel-group auto** command enables autocreation of port channels. If autocreation of port channels is enabled for an interface, you must first disable this configuration before downgrading to earlier software versions or before configuring the interface in a manually configured channel group.

Examples

The following example configures ports 1 to 4 in Fibre Channel interface 9.

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# int fc9/1 - 4
```

The following example enables the Fibre Channel interface.

```
switch# config terminal
switch(config)# interface fc1/1
switch(config-if)# no shutdown
```

The following example assigns the FICON port number to the selected Fibre Channel interface.

```
switch# config terminal
switch(config)# interface fc1/1
switch(config-if)# ficon portnumber 15
```

Related Commands

Command	Description
show interface	Displays an interface configuration for a specified interface.
shutdown	Disables and enables an interface.

 interface fc-tunnel

Send documentation comments to mdsfeedback-doc@cisco.com.

interface fc-tunnel

To configure a Fibre Channel tunnel and facilitate RSPAN traffic in the Cisco MDS 9000 Family of switches, use the **interface fc-tunnel** command. To remove a configured tunnel or revert to factory defaults, use the **no** form of the command.

```

interface fc-tunnel number
  destination ip-address
  explicit-path path-name
  source ip-address]

no interface fc-tunnel number
  no destination ip-address |
  no explicit-path path-name
  no source ip-address

no interface fc-tunnel number

```

Syntax Description	<table border="0"> <tr> <td><i>number</i></td><td>Specifies a tunnel ID range from 1 to 255.</td></tr> <tr> <td>destination <i>ip-address</i></td><td>Maps the IP address of the destination switch</td></tr> <tr> <td>explicit-path <i>path-name</i></td><td>Specifies a name for the explicit path. Maximum length is 16 alphanumeric characters.</td></tr> <tr> <td>source <i>ip-address</i></td><td>Maps the IP address of the source switch</td></tr> </table>	<i>number</i>	Specifies a tunnel ID range from 1 to 255.	destination <i>ip-address</i>	Maps the IP address of the destination switch	explicit-path <i>path-name</i>	Specifies a name for the explicit path. Maximum length is 16 alphanumeric characters.	source <i>ip-address</i>	Maps the IP address of the source switch
<i>number</i>	Specifies a tunnel ID range from 1 to 255.								
destination <i>ip-address</i>	Maps the IP address of the destination switch								
explicit-path <i>path-name</i>	Specifies a name for the explicit path. Maximum length is 16 alphanumeric characters.								
source <i>ip-address</i>	Maps the IP address of the source switch								

Defaults	None.
-----------------	-------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	1.2(1)	This command was introduced.

Usage Guidelines	None.
-------------------------	-------

Examples	The following example initiates the FC tunnel (100) in the source switch (switch S).
-----------------	--

```

switch(config)# config terminal
switch(config)# interface fc-tunnel 100
switch(config-if)#

```

The following example maps the IP address of the source switch (switch S) to the FC tunnel (100).

```
switchS(config-if)# source 10.10.10.1
```

Send documentation comments to mdsfeedback-doc@cisco.com.

The following example maps the IP address of the destination switch (switch D) to the FC tunnel (100).

```
switch(config-if)# destination 10.10.10.2
```

The following example enables traffic flow through this interface.

```
switch(config-if)# no shutdown
```

The following example references the configured path in the source switch (switch S).

```
switch# config t
switch(config)# interface fc-tunnel 100
switch(config)# explicit-path Path1
```

Related Commands	Command	Description
	show interface fc-tunnel	Displays an FC tunnel interface configuration for a specified interface.
	fc-tunnel explicit-path	Configures a new or existing next-hop path.

■ **interface fcip**

Send documentation comments to mdsfeedback-doc@cisco.com.

interface fcip

To configure a Fibre Channel over IP Protocol (FCIP) interface on the Cisco MDS 9000 Family of switches, use the **interface fcip** command. To disable a FCIP interface, use the **no** form of the command.

```
interface fcip interface_number
  bport
  bport-keepalives
  channel-group number [force]
  fcdomain rcf-reject vsan vsan-id
  ficon portnumber portnumber |
  fspf {cost link-cost | dead-interval seconds | hello-interval seconds | passive |
    retransmit-interval seconds} vsan vsan-id
    passive-mode
    peer-info ipaddr ip-address [port number]
    qos control-value data data-value
    special-frame peer-wwn pwwn-id
    tcp-connections number
    time-stamp [acceptable-diff number]
    use-profile profile-id

interface fcip interface_number
  no bport
  no bport-keepalives
  no channel-group number [force]
  no fcdomain rcf-reject vsan vsan-id
  no ficon portnumber portnumber
  no fspf {cost link-cost | dead-interval seconds | hello-interval seconds | passive |
    retransmit-interval seconds} vsan vsan-id
    no qos control-value data data-value
    no passive-mode
    no peer-info ipaddr ip-address [port number]
    no special-frame peer-wwn pwwn-id
    no tcp-connections number
    no time-stamp [acceptable-diff number]
    no use-profile profile-id
```

Syntax Description

interface-number	Configures the specified interface from 1 to 255.
bport	Sets the B port mode.
bport-keepalives	Sets the B port keepalive responses.
channel-group <i>number</i>	Specifies a PortChannel number from 1 to 128.
force	Forcefully adds a port.
fcdomain	Enters the fcdomain mode for this FCIP interface
rcf-reject	Configures the rcf-reject flag.
vsan <i>vsan-id</i>	Specifies a VSAN ID. The range is 1 to 4093.
fspf	Configures FSPF parameters.
cost <i>link-cost</i>	Enters FSPF link cost. The range is 1 to 65535
dead-interval <i>seconds</i>	Specifies the dead interval in seconds. The range is 1 to 65535.

Send documentation comments to mdsfeedback-doc@cisco.com.

ficon	Configures FICON parameters.
portnumber portnumber	Configures the FICON port number for this interface.
hello-interval seconds	Specifies FSPF hello-interval in seconds. The range is 1 to 65535.
passive	Enables or disables FSPF on the interface.
retransmit-interval	Specifies FSPF retransmit interface in seconds. The range is 1 to 65535.
passive-mode	Configures a passive connection.
peer-info	Configures the peer information.
ipaddr ip-address	Specifies the peer IP address.
port number	Specifies the peer port number. The range is 1 to 65535.
qos	Configures the differentiated services code point (DSCP) value to mark all IP packets.
control control-value	Specifies the control value for DSCP.
data data-value	Specifies the data value for DSCP.
special-frame	Configures special frames.
peer-wwn pwwn-id	Specifies the peer WWN for special frames.
switchport	Configures switchport parameters.
tcp-connections number	Specifies the number of TCP connection attempts. Valid values are 1 or 2.
time-stamp	Configures time-stamp.
acceptable-diff number	Specifies the acceptable time difference for time-stamps. The range is 1 to 60000.
use-profile profile-id	Specifies the interface using an existing profile ID. The range is 1 to 255.

Defaults

Disabled

Command Modes

Configuration mode

Command History

Release	Modification
1.1(1)	This command was introduced.
1.3(1)	Added the ficon portnumber subcommand.
2.0(1b)	Added the qos subcommand.

Usage Guidelines

You can specify a range of interfaces by issuing a command with the following example format:

interface fcip1space-space5space,spacefcip10space-space12space

Refer to the *Cisco MDS 9000 Family Configuration Guide* for information on port number allocation.

■ **interface fcip**

Send documentation comments to mdsfeedback-doc@cisco.com.

Examples

The following example selects an FCIP interface and enters interface configuration submode.

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# interface fcip 1
switch(config-if)#

```

The following example assigns the FICON port number to the selected FCIP interface.

```
switch# config terminal
switch(config)# interface fcip 51
switch(config-if)# ficon portnumber 234
```

Related Commands

Command	Description
show interface fcip	Displays an interface configuration for a specified FCIP interface.

Send documentation comments to mdsfeedback-doc@cisco.com.

interface gigabitethernet

To configure an Gigabit Ethernet interface on the Cisco MDS 9000 Family of switches, use the **interface gigabitethernet** command. To revert to the default values, use the **no** form of the command.

```
interface gigabitethernet slot/port
  cdp enable
  channel-group group-id [force]
  isns profile-name
```

```
interface gigabitethernet slot/port
  no cdp enable
  no channel-group
  no isns profile-name
```

Syntax Description	
slot/port	Specifies a slot number and port number.
cdp enable	Enables Cisco Discovery Protocol (CDP) configuration parameters.
channel-group group-id	Adds to or removes from a PortChannel. The range is 1 to 128.
force	Forcefully adds a port.
isns profile-name	Specifies the profile name to tag the interface. Maximum length is 64 characters.

Defaults	Disabled.
-----------------	-----------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	1.0(3a)	This command was introduced.
	1.1(1a)	Added the channel-group subcommand.
	1.3(1)	Added the isns subcommand.

Usage Guidelines	You can specify a range of interfaces by issuing a command with the following example format: interface gigabitethernet1/1space-space2space,spacegigabitethernet3/1space-space2
-------------------------	---

Examples	The following example configures the Gigabit Ethernet interface at slot 4 port 1. switch# config terminal switch(config)# interface gigabitethernet 4/1 switch(config-if)#
-----------------	---

 interface gigabitethernet

Send documentation comments to mdsfeedback-doc@cisco.com.

The following example enters a IP address and subnet mask for the selected Gigabit Ethernet interface.

```
switch(config-if)# ip address 10.1.1.100 255.255.255.0
```

The following example changes the IP maximum transmission unit (MTU) value for the selected Gigabit Ethernet interface.

```
switch(config-if)# switchport mtu 3000
```

The following example creates a VR ID for the selected Gigabit Ethernet interface, configures the virtual IP address for the VR ID (VRRP group), and assigns a priority.

```
switch(config-if)# vrrp 100
switch(config-if-vrrp)# address 10.1.1.100
switch(config-if-vrrp)# priority 10
```

The following example adds the selected Gigabit Ethernet interface to a channel group. If the channel group does not exist, it is created, and the port is shut down.

```
switch(config-if)# channel-group 10
gigabitethernet 4/1 added to port-channel 10 and disabled
please do the same operation on the switch at the other end of the port-channel, then do
"no shutdown" at both ends to bring them up
```

Related Commands

Command	Description
show interface	Displays an interface configuration for a specified interface.

Send documentation comments to mdsfeedback-doc@cisco.com.

interface iscsi

To configure an iSCSI interface on the Cisco MDS 9000 Family of switches, use the **interface iscsi** command. To revert to default values, use the **no** form of the command.

```
interface iscsi slot/port
  mode {pass-thru | store-and-forward}
    tcp qos value

interface iscsi slot/port
  no mode {pass-thru | store-and-forward | cut-thru}
  no tcp qos value

no interface iscsi slot/port
```

Syntax Description

<i>slot/port</i>	Specifies a slot number and port number.
mode	Configures a forwarding mode.
pass-thru	Forwards one frame at a time.
store-and-forward	Forwards data in one assembled unit (default).
cut-thru	Forwards one frame at a time without waiting for the exchange to complete.
tcp qos value	Configures the differentiated services code point (DSCP) value to apply to all outgoing IP packets. The range is 0 to 63.

Defaults

Disabled.

The TCP QoS default is 0.

The forwarding mode default is **store-and-forward**.

Command Modes

Configuration mode.

Command History

Release	Modification
1.3(1)	This command was introduced.
2.1(1)	Added the cut-thru option for the mode subcommand.

Usage Guidelines

To configure iSCSI interface, enable iSCSI using the **iscsi enable** command.

You can specify a range of interfaces by issuing a command with the following example format:
interface iscsi space fc1/1space-space5space,spacefc2/5space-space7

```
■ interface iscsi
```

Send documentation comments to mdsfeedback-doc@cisco.com.

Examples

The following example enables the iSCSI feature.

```
switch# config t
switch(config)# iscsi enable
```

The following example enables the store-and-forward mode for iSCSI interfaces 9/1 to 9/4.

```
switch(config)# interface iscsi 9/1 - 4
switch(config-if)# mode store-and-forward
```

The following example reverts to using the default pass-thru mode for iSCSI interface 9/1.

```
switch(config)# interface iscsi 9/1
switch(config-if)# mode pass-thru
```

Related Commands

Command	Description
iscsi enable	Enables iSCSI.
show interface	Displays an interface configuration for a specified interface.

Send documentation comments to mdsfeedback-doc@cisco.com.

interface mgmt

To configure a management interface on the Cisco MDS 9000 Family of switches, use the **interface mgmt** command in configuration mode.

interface mgmt *number*

Syntax Description	<i>number</i>	Specifies the management interface number which is 0.
---------------------------	---------------	---

Defaults	Disabled.
-----------------	-----------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	1.0(2)	This command was introduced.

Usage Guidelines	When you try to shutdown a management interface(mgmt0), a follow-up message confirms your action before performing the operation. Use the force option to bypass this confirmation, if required.
-------------------------	---

Examples	The following example configures the management interface, displays the options available for the configured interface, and exits to configuration mode.
-----------------	--

```
switch# config terminal
switch(config)#
switch(config)# interface mgmt 0
switch(config-if)# exit
switch(config)#

```

The following example shuts down the interface without using the **force** option:

```
switch# config terminal
switch(config)# interface mgmt 0
switch(config-if)# shutdown
Shutting down this interface will drop all telnet sessions.
Do you wish to continue (y/n)? y
```

The following example shuts down the interface using the **force** option:

```
switch# config terminal
switch(config)# interface mgmt 0
switch(config-if)# shutdown force
switch(config-if)#

```

■ interface mgmt

Send documentation comments to mdsfeedback-doc@cisco.com.

Related Commands	Command	Description
	show interface mgmt	Displays interface configuration for specified interface.

Send documentation comments to mdsfeedback-doc@cisco.com.

interface port-channel

To configure a PortChannel interface on the Cisco MDS 9000 Family of switches, use the **interface port-channel** command.

```
interface port-channel number
    channel mode active
    fcdomain rcf-reject vsan vsan-id
    fspf [cost link_cost | dead-interval seconds | ficon portnumber portnumber | hello-interval
          seconds | isns profile-name | passive | retransmit-interval seconds]

interface port-channel number
    no channel mode active
    no fcdomain rcf-reject vsan vsan-id
    no fspf [cost link_cost | dead-interval seconds | ficon portnumber portnumber | hello-interval
          seconds | isns profile-name | passive | retransmit-interval seconds]

no interface port-channel number
```

Syntax Description	
number	Enter PortChannel number. The range is 1 to 128.
channel mode active	Configures the channel mode for the PortChannel interface
fcdomain	Enter the interface submode
rcf-reject	Configure the rcf-reject flag
vsan	Specify the vsan range
vsan-id	The ID of the VSAN is from 1 to 4093.
fspf	Configure FSPF parameters
cost	Configure FSPF link cost
link_cost	Enter FSPF link cost 1-65535
dead-interval	Configure FSPF dead interval
seconds	Enter dead interval (in sec) 2-65535
ficon	Configures FICON parameters.
portnumber portnumber	Configures the FICON port number for this interface.
hello-interval	Configure FSPF hello-interval
seconds	Enter hello interval (in sec) 1-65535
isns	Tags this interface to the Internet Storage Name Service (iSNS) profile.
profile-name	Specifies the profile name to tag the interface.
passive	Enable/disable FSPF on the interface
retransmit-interval	Configure FSPF retransmit interface
seconds	Enter retransmit interval (in sec) 1-65535

Defaults	Disabled
Command Modes	Configuration mode

■ **interface port-channel**

Send documentation comments to mdsfeedback-doc@cisco.com.

Command History	Release	Modification
	1.0(2)	This command was introduced.
	1.3(1)	Added channel mode active subcommand.

Usage Guidelines Refer to the *Cisco MDS 9000 Family Configuration Guide* for information on port number allocation.

Examples The following example enters configuration mode and configures a PortChannel interface.

```
switch# config terminal
switch(config)# interface port-channel 32
switch(config-if)#

```

The following example assigns the FICON port number to the selected PortChannel port.

```
switch# config terminal
switch(config)# interface Port-channel 1
switch(config-if)# ficon portnumber 234

```

Related Commands	Command	Description
	show interface	Displays interface configuration for specified interface.

Send documentation comments to mdsfeedback-doc@cisco.com.

interface vsan

To configure a VSAN interface on the Cisco MDS 9000 Family of switches, use the **interface vsan** command. To remove a VSAN interface, use the **no** form of the command.

interface vsan *vsan-id*

no interface vsan *vsan-id*

Syntax Description	<i>vsan-id</i>	Specifies the VSAN ID. The range is 1 to 4093.
Defaults	Disabled.	
Command Modes	Configuration mode.	
Command History	Release	Modification
	1.0(2)	This command was introduced.
Usage Guidelines	None.	
Examples	The following example selects a VSAN interface and enters interface configuration submode.	
	<pre>switch# config terminal switch(config)# interface vsan 1 switch(config-if)# </pre>	
Related Commands	Command	Description
	show interface	Displays interface configuration for specified interface.

ip access-group

Send documentation comments to mdsfeedback-doc@cisco.com.

ip access-group

To create an access group to use an access list, use the **ip access-group** command in interface mode. Use the **no** form of this command to negate a previously issued command or revert to factory defaults.

ip access-group *group-name* [in | out]

Syntax Description	<table border="0"> <tr> <td>group-name</td><td>Specifies the IP access-group name. Maximum length is 64 alphanumeric characters and the text is case insensitive.</td></tr> <tr> <td>in</td><td>Specifies that the group is for ingress traffic.</td></tr> <tr> <td>out</td><td>Specifies that the group is for egress traffic.</td></tr> </table>	group-name	Specifies the IP access-group name. Maximum length is 64 alphanumeric characters and the text is case insensitive.	in	Specifies that the group is for ingress traffic.	out	Specifies that the group is for egress traffic.
group-name	Specifies the IP access-group name. Maximum length is 64 alphanumeric characters and the text is case insensitive.						
in	Specifies that the group is for ingress traffic.						
out	Specifies that the group is for egress traffic.						

Defaults Groups are created for both ingress and egress traffic.

Command Modes Interface mode.

Command History	Release	Modification
	1.2(1)	This command was introduced.

Usage Guidelines The access-group command controls access to an interface. Each interface can only be associated with one access list. The access group becomes active on creation.

We recommend creating all rules in an access list, before creating the access group that uses this access-list.

If you create an access group before an access-list, all packets in that interface are dropped, because the access list is empty.

The access-group configuration for the ingress traffic applies to both local and remote traffic. The access-group configuration for the egress traffic applies only to local traffic. You can create a different access-group for each type of traffic.

Examples The following example creates an access group called aclPermit for both the ingress and egress traffic (default)

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# ip access-list aclPermit permit ip any any
switch(config)# interface Gigabitethernet 3/1
switch(config-if)# ip access-group aclPermit
```

The following example deletes the access group called aclPermit.

```
switch(config-if)# no ip access-group aclPermit
```

Send documentation comments to mdsfeedback-doc@cisco.com.

The following example creates an access group called aclDenyTcp (if it does not already exist) for ingress traffic.

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# ip access-list aclDenyTcp deny tcp any any
switch(config)# interface gigabitetherent 3/1
switch(config-if)# ip access-group aclDenyTcp in
```

The following example deletes the access group called aclDenyTcp for ingress traffic.

```
switch(config-if)# no ip access-group aclDenyTcp in
```

The following example creates an access group called aclPermitUdp (if it does not already exist) for local egress traffic.

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# ip access-list aclPermitUdp permit udp 192.168.32.0 0.0.7.255 any
switch(config)# interface gigabitetherent 3/1
switch(config-if)# ip access-group aclPermitUdp out
```

The following example deletes the access group called aclPermitUdp for local egress traffic.

```
switch(config-if)# no ip access-group aclPermitUdp out
```

Related Commands

Command	Description
ip access-list	Configures IP access control lists.
show ip access-list	Displays the IP-ACL configuration information.

ip access-list

Send documentation comments to mdsfeedback-doc@cisco.com.

ip access-list

To configure IP access control lists (ACLs), use the **ip access-list** command in configuration mode. To negate a previously issued command or revert to factory defaults, use the **no** form of the command.

```
ip access-list list-name {deny | permit} ip-protocol
    {src-addr src-wildcard}
    {dest-addr dest-wildcard | operator port-value}
    [operator port port-value]
    [established | icmp-type icmp-value]
    [tos ]
    [log-deny]
```

Syntax Description	
<i>list-name</i>	Identifies the IP-ACL with an integer ranging from 1 to 256.
deny	Denies access if the conditions match.
permit	Provides access if the conditions match.
<i>ip-protocol</i>	Specifies the name or number (integer range from 0 to 255) of an IP protocol. The IP protocol name can be icmp , ip , tcp , or udp .
<i>src-addr</i>	Specifies the network from which the packet is sent. There are two ways to specify the source: <ul style="list-style-type: none"> • A 32-bit quantity in four-part, dotted-decimal format • A keyword any as an abbreviation for a destination and a destination-wildcard of 0.0.0.0 255.255.255.255
<i>src-wildcard</i>	Applies the wildcard bits to the source. Each wildcard bit set to zero indicates that the corresponding bit position in the packet's IP address must exactly match the bit value in the corresponding position of the packet's ip address or it will not be considered a match to this access list. There are two ways to specify the destination wildcard: <ul style="list-style-type: none"> • A 32-bit quantity in four-part, dotted-decimal format • A keyword any as an abbreviation for a destination and a destination-wildcard of 0.0.0.0 255.255.255.255
<i>dest-addr</i>	Specifies the network from which the packet is sent. There are two ways to specify the destination: <ul style="list-style-type: none"> • A 32-bit quantity in four-part, dotted-decimal format • A keyword any as an abbreviation for a destination and a destination-wildcard of 0.0.0.0 255.255.255.255
<i>dest-wildcard</i>	Applies the wildcard bits to the destination. There are two ways to specify the destination wildcard: <ul style="list-style-type: none"> • A 32-bit quantity in four-part, dotted-decimal format • A keyword any as an abbreviation for a destination and a destination-wildcard of 0.0.0.0 255.255.255.255

Send documentation comments to mdsfeedback-doc@cisco.com.

operator	Compares source or destination ports and has the following options: any = Any destination IP eq = Equal source port gt = Greater than and including source port lt = Less than and including source port range port = Source port range <i>port-value</i>
port <i>port-value</i>	Specifies the decimal number (ranging from 0 to 65535) or one of the following names to indicate a TCP or UDP port. The TCP port names are: dns, ftp, ftp-data, http, ntp, radius, sftp, smtp, snmp, snmp-trap, ssh, syslog, tacacs-ds, telnet, wbem-http, wbem-https, and www. The UDP port names are: dns, ftp, ftp-data, http, ntp, radius, sftp, smtp, snmp, snmp-trap, ssh, syslog, tacacs-ds, telnet, tftp, wbem-http, wbem-https, and www.
icmp-type <i>icmp-value</i>	Filters ICMP packets by ICMP message type. The range is 0 to 255. The types include: echo, echo-reply, redirect, time-exceeded, traceroute, and unreachable.
established	Indicates an established connection for the TCP protocol. A match occurs if the TCP datagram has the ACK, FIN, PSH, RST, SYN or URG control bits set. The non-matching case is that of the initial TCP datagram to form a connection.
tos <itos-value< i=""></itos-value<>	Filters packets by the following type of service level: normal-service (0), monetary-cost (1), reliability (2), throughput (4), and delay (8).
log-deny	Sends an information logging message to the console about the packet that is denied entry.

Defaults Denied.

Command Modes Configuration mode.

Command History

Release	Modification
1.2(1)	This command was introduced.

Usage Guidelines

Using the **log-deny** option at the end of the individual ACL entries shows the ACL number and whether the packet was permitted or denied, in addition to port-specific information. This option causes an information logging message about the packet that matches the dropped entry (or entries).

Examples

The following example configures the an IP-ACL called aclPermit and permits IP traffic from any source address to any destination address

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# ip access-list aclPermit permit ip any any
```

ip access-list

Send documentation comments to mdsfeedback-doc@cisco.com.

The following example removes the IP-ACL called aclPermit.

```
switch(config-if)# no ip access-group aclPermit
```

The following example updates aclPermit to deny TCP traffic from any source address to any destination address.

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# ip access-list aclPermit deny tcp any any
```

The following example defines an IP-ACL that permits this network. Subtracting 255.255.248.0 (normal mask) from 255.255.255.255 yields 0.0.7.255.

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# ip access-list aclPermitUdp permit udp 192.168.32.0 0.0.7.255 any
```

The following example permits all IP traffic from and to the specified networks.

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# ip access-list aclPermitIpToServer permit ip 10.1.1.0 0.0.0.255 172.16.1.0
0.0.0.255
```

The following example denies TCP traffic from 1.2.3.0 through source port 5 to any destination.

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/
switch(config)# ip access-list aclDenyTcpIpPrt5 deny tcp 1.2.3.0 0.0.0.255 eq port 5 any
```

The following example removes this entry from the IP-ACL.

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/
switch(config)# no ip access-list aclDenyTcpIpPrt5 deny tcp 1.2.3.0 0.0.0.255 eq port 5
any
```

Related Commands

Command	Description
show ip access-list	Displays the IP-ACL configuration information.

Send documentation comments to mdsfeedback-doc@cisco.com.

ip address (FCIP profile configuration submode)

To assign the local IP address of a Gigabit Ethernet interface to the FCIP profile, use the **ip address** command. To remove the IP address, use the **no** form of the command.

ip address *address*

no ip address *address*

Syntax Description	<i>address</i>	Specifies the IP address.								
Defaults	Disabled									
Command Modes	FCIP profile configuration submode									
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>1.3(1)</td><td>This command was introduced.</td></tr> </tbody> </table>		Release	Modification	1.3(1)	This command was introduced.				
Release	Modification									
1.3(1)	This command was introduced.									
Usage Guidelines	To create a FCIP profile, you must assign a local IP address of a Gigabit Ethernet interface to the FCIP profile.									
Examples	<p>The following example assigns the local IP address of a Gigabit Ethernet interface to the FCIP profile.</p> <pre>switch# config terminal switch(config)# fcip profile 5 switch(config-profile)# ip address 10.5.1.1</pre>									
Related Commands	<table border="1"> <thead> <tr> <th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td>show fcip profile</td><td>Displays information about the FCIP profile.</td></tr> <tr> <td>interface fcip <i>interface_number</i> use-profile <i>profile-id</i></td><td>Configures the interface using an existing profile ID from 1 to 255.</td></tr> <tr> <td>show interface fcip</td><td>Displays an interface configuration for a specified FCIP interface.</td></tr> </tbody> </table>		Command	Description	show fcip profile	Displays information about the FCIP profile.	interface fcip <i>interface_number</i> use-profile <i>profile-id</i>	Configures the interface using an existing profile ID from 1 to 255.	show interface fcip	Displays an interface configuration for a specified FCIP interface.
Command	Description									
show fcip profile	Displays information about the FCIP profile.									
interface fcip <i>interface_number</i> use-profile <i>profile-id</i>	Configures the interface using an existing profile ID from 1 to 255.									
show interface fcip	Displays an interface configuration for a specified FCIP interface.									

 ip address (interface configuration submode)

Send documentation comments to mdsfeedback-doc@cisco.com.

ip address (interface configuration submode)

To assign an IP address to a Gigabit Ethernet interface, use the **ip address** command in interface configuration submode. To remove the IP address, use the **no** form of the command.

ip address *address netmask*

no ip address *address netmask*

Syntax Description	<i>address</i> Specifies the IP address. <i>netmask</i> Specifies the network mask.
---------------------------	--

Defaults	None.
-----------------	-------

Command Modes	Interface configuration submode
----------------------	---------------------------------

Command History	Release	Modification
	1.1(2)	This command was introduced.

Usage Guidelines	None.
-------------------------	-------

Examples	The following example assigns an IP address to a Gigabit Ethernet interface.
-----------------	--

```
switch# config terminal
switch(config)# interface gigabitethernet 1/2
switch(config-profile)# ip address 10.5.1.1 255.255.0.0
```

Related Commands	Command	Description
	show fcip profile	Displays information about the FCIP profile.
	interface fcip <i>interface_number</i>	Configures the interface using an existing profile ID from 1 to 255.
	use-profile <i>profile-id</i>	
	show interface fcip	Displays an interface configuration for a specified FCIP interface.

Send documentation comments to mdsfeedback-doc@cisco.com.

ip-compression

To enable compression on the FCIP link, use the **ip-compression** command in interface configuration submode. To disable compression, use the **no** form of the command.

ip-compression [auto | mode1 | mode2 | mode3]

no ip-compression [auto | mode1 | mode2 | mode3]

Syntax Description	auto Enables automatic compression setting. mode1 Enables fast compression for the following high bandwidth links: — IPS-4 and IPS-8, less than 100 Mbps — MPS-14/2, up to 1 Gbps mode2 Enables moderate compression for medium bandwidth links less than 25 Mbps. mode3 Enables compression for bandwidth links less than 10 Mbps.
--------------------	--

Defaults	Disabled.						
Command Modes	Interface configuration submode.						
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>1.3(1)</td> <td>This command was introduced.</td> </tr> <tr> <td>2.0(1b)</td> <td>Changed the keywords from high-throughput and high-comp-ratio to mode1, mode2, and mode3.</td> </tr> </tbody> </table>	Release	Modification	1.3(1)	This command was introduced.	2.0(1b)	Changed the keywords from high-throughput and high-comp-ratio to mode1 , mode2 , and mode3 .
Release	Modification						
1.3(1)	This command was introduced.						
2.0(1b)	Changed the keywords from high-throughput and high-comp-ratio to mode1 , mode2 , and mode3 .						

Usage Guidelines	<p>When no compression mode is entered in the command, the default is auto.</p> <p>The FCIP compression feature introduced in Cisco SAN-OS Release 1.3 allows IP packets to be compressed on the FCIP link if this feature is enabled on that link. By default the FCIP compression is disabled. When enabled, the software defaults to using the auto mode (if a mode is not specified).</p> <p>Cisco SAN-OS Release 2.0(1b) and later, you can configure FCIP compression using one of the following modes:</p> <ul style="list-style-type: none"> • mode1 is a fast compression mode for high bandwidth links (> 25 Mbps) • mode2 is a moderate compression mode for moderately low bandwidth links (between 10 and 25 Mbps) • mode3 is a high compression mode for low bandwidth links (< 10 Mbps) • auto (default) mode picks the appropriate compression scheme based on the bandwidth of the link (the bandwidth of the link configured in the FCIP profile's TCP parameters)
------------------	---

ip-compression

Send documentation comments to mdsfeedback-doc@cisco.com.

The IP compression feature behavior differs between the IPS module(s) and the MPS-14/2 module—while **mode2** and **mode3** perform software compression in both modules, **mode1** performs hardware-based compression in MPS-14/2 modules, and software compression in IPS-4 and IPS-8 modules.

In Cisco MDS SAN-OS Release 2.1(1a) and later, the **auto** mode option uses a combination of compression modes to effectively utilize the WAN bandwidth. The compression modes change dynamically to maximize the WAN bandwidth utilization.

Examples

The following example enables faster compression.

```
switch# config terminal
switch(config) interface fcip 1
switch(config-if)# ip-compression mode1
```

The following example enables automatic compression by default.

```
switch(config-if)# ip-compression
```

The following example disables compression.

```
switch(config-if)# no ip-compression
```

Related Commands

Command	Description
show interface fcip	Displays an interface configuration for a specified FCIP interface.

Send documentation comments to mdsfeedback-doc@cisco.com.

ip default-gateway

To configure the IP address of the default gateway, use the **ip default-gateway** command. To disable the IP address of the default gateway, use the **no** form of the command.

ip default-gateway *destination-ip-address* [**interface** **cpp** *slot_number/processor-number/vsan-id*]

no ip default-gateway *destination-ip-address* [**interface** **cpp** *slot/processor-number/vsan-id*]

Syntax Description

<i>destination-ip-address</i>	Specifies the IP address,
interface	Configures an interface.
cpp	Specifies a virtualization IPFC interface.
<i>slot</i>	Specifies a slot number of the ASM.
<i>processor-number</i>	Specifies the processor number for the IPFC interface. The current processor number is always 1.
<i>vsan-id</i>	Specifies the ID of the management VSAN. The range 1 to 4093.

Defaults

None.

Command Modes

Configuration mode.

Command History

	Release	Modification
1.0(2)		This command was introduced.

Usage Guidelines

None.

Examples

The following examples configures the IP default gateway to 1.1.1.4.

```
switch# config terminal
switch(config)# ip default-gateway 1.1.1.4
```

Related Commands

	Command	Description
	show ip route	Displays the IP address of the default gateway.

ip default-network

Send documentation comments to mdsfeedback-doc@cisco.com.

ip default-network

To configure the IP address of the default network, use the **ip default-network** command in configuration mode. To disable the IP address of the default network, use the **no** form of the command.

ip default-network *ip-address*

no ip default-network *ip-address*

Syntax Description	<i>ip-address</i>	Specifies the IP address of the default network.				
Defaults	None.					
Command Modes	Configuration mode.					
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>1.0(2)</td> <td>This command was introduced.</td> </tr> </tbody> </table>		Release	Modification	1.0(2)	This command was introduced.
Release	Modification					
1.0(2)	This command was introduced.					
Usage Guidelines	None.					
Examples	<p>The following examples configures the IP address of the default network to 1.1.1.4.</p> <pre>switch# config terminal switch(config)# ip default-network 1.1.1.4</pre>					

Send documentation comments to mdsfeedback-doc@cisco.com.

ip domain-list

To configure the IP domain list, use the **ip domain-list** command in configuration mode. To disable the IP domain list, use the **no** form of the command.

ip domain-list *domain-name*

no ip domain-list *domain-name*

Syntax Description	<i>domain-name</i>	Specifies the domain name for the IP domain list. Maximum length is 80 characters.
Defaults	None.	
Command Modes	Configuration mode.	
Command History	Release	Modification
	1.0(2)	This command was introduced.
Usage Guidelines	None.	

Examples The following example configures the IP domain list.

```
switch# config terminal
switch(config)# ip domain myList
```

■ ip domain-lookup

Send documentation comments to mdsfeedback-doc@cisco.com.

ip domain-lookup

To enable the DNS server lookup feature, use the **ip domain-lookup** command in configuration mode. Use the **no** form of this command to disable this feature.

ip domain-lookup

no ip domain-lookup

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes Configuration mode.

Command History	Release	Modification
	1.0(2)	This command was introduced.

Usage Guidelines Instead of IP addresses, you can configure the switch using meaningful names. The configured name automatically looks up the corresponding IP address.

Examples The following example configures a DNS server lookup feature.

```
switch# config terminal
switch(config)# ip domain-lookup
```

Send documentation comments to mdsfeedback-doc@cisco.com.

ip domain-name

To configure a domain name, use the **ip domain-name** command in configuration mode. To delete a domain name, use the **no** form of the command.

ip domain-name *domain-name*

no ip domain-name *domain-name*

Syntax Description	<i>domain-name</i>	Specifies the domain name.
Defaults	None.	
Command Modes	Configuration mode.	
Command History	Release	Modification
	1.0(2)	This command was introduced.
Usage Guidelines	None.	
Examples	The following example configures a domain name.	
	<pre>switch# config terminal switch(config)# ip domain-name MyDomain</pre>	

ip name-server

Send documentation comments to mdsfeedback-doc@cisco.com.

ip name-server

To configure a name server, use the **ip name-server** command in configuration mode. To disable this feature, use the **no** form of the command.

ip name-server *ip-address*

no ip name-server *ip-address*

Syntax Description	<i>ip-address</i>	Specifies the IP address for the name server.
Defaults	None.	
Command Modes	Configuration mode.	
Command History	Release	Modification
	1.0(2)	This command was introduced.
Usage Guidelines	You can configure a maximum of six servers. By default, no server is configured.	
Examples	<p>The following example configures a name server with an IP address of 1.1.1.4.</p> <pre>switch# config terminal switch(config)# ip name-server 1.1.1.4</pre> <p>The following example specifies the first address (15.1.0.1) as the primary server and the second address (15.2.0.0) as the secondary server.</p> <pre>switch(config)# ip name-server 15.1.0.1 15.2.0.0</pre> <p>The following example deletes the configured server(s) and reverts to factory default.</p> <pre>switch(config)# no ip name-server</pre>	

Send documentation comments to mdsfeedback-doc@cisco.com.

ip route

To configure a static route, use the **ip route** command in configuration mode.

```
ip route ip-address subnet-mask [nexthop_ip-address] [interface {gigabitethernet slot lport |
mgmt 0 | port-channel channel-id | vsan vsan-id} | distance distance-number]

no ip route ip-address subnet-mask [nexthop_ip-address] [interface {gigabitethernet slot lport |
mgmt 0 | port-channel channel-id | vsan vsan-id} | distance distance-number]
```

Syntax Description		
<i>ip-address</i>	Specifies the IP address for the route.	
<i>subnet-mask</i>	Specifies the subnet mask for the route.	
<i>nexthop_ip-address</i>	Specifies the IP address of the next hop switch.	
interface	Configures the interface associated with the route.	
gigabitethernet slot lport	Specifies a Gigabit Ethernet interface at a port and slot.	
mgmt 0	Specifies the management interface (mgmt 0).	
port-channel channel-id	Specifies a PortChannel interface. The range is 1 to 128.	
vsan vsan-id	Specifies a VSAN ID. The range is 1 to 4093.	
distance distance-number	Specifies the distance metric for this route. It can be from 0 to 32766.	

Defaults None.

Command Modes Configuration mode.

Command History	Release	Modification
	1.0(2)	This command was introduced.

Usage Guidelines None.

Examples The following examples shows how to configure a static route.

```
switch# config terminal
switch(config)# IP route 10.0.0.0 255.0.0.0 20.20.20.10 distance 10 interface vsan 1
```

Related Commands	Command	Description
	show ip route	Displays the IP address routes configured in the system.

ip routing

Send documentation comments to mdsfeedback-doc@cisco.com.

ip routing

To enable the IP forwarding feature, use the **ip routing** command in configuration mode. To disable this feature, use the **no** form of the command.

ip routing

no ip routing

Syntax Description This command has no arguments or keywords.

Defaults Disabled.

Command Modes Configuration mode.

Command History	Release	Modification
	1.0(2)	This command was introduced.

Usage Guidelines None.

Examples The following example enables the IP forwarding feature.

```
switch# config terminal
switch(config)# ip routing
```

Send documentation comments to mdsfeedback-doc@cisco.com.

iscsi authentication

To configure the default authentication method for iSCSI, use the **iscsi authentication** command. To revert to the default, use the **no** form of the command.

```
iscsi authentication {chap | chap-none | none | username username password [0 | 7] password}  
no iscsi authentication {chap | chap-none | none | username}
```

Syntax Description	chap-none	Configure either the CHAP or no authentication.
	chap	Configures the Challenge Handshake Authentication Protocol (CHAP) authentication method.
	none	Specifies that no authentication is required for the selected interface
	username <i>username</i>	Assigns CHAP username to be used when switch is authenticated.
	password	Configures the password for the username.
	0	Specifies that the password is a cleartext CHAP password.
	7	Specifies that the password is an encrypted CHAP password.
	<i>password</i>	Specifies a password for the username.

Defaults

chap-none

The default password is a cleartext password.

Command Modes

Configuration mode

Command History

Release	Modification
1.1(1)	This command was introduced.
2.0(1b)	Added the username option.

Usage Guidelines

By default, the Cisco MDS 9000 Family switch accepts an iSCSI initiator with either no authentication or CHAP authentication. If CHAP authentication is always required, use the **iscsi authentication chap** command. If no authentication is always required, use the **iscsi authentication none** command.

Use the **chap-none** option to override the global configuration which might have been configured to allow only one option—either CHAP or none—not both.

Examples

The following example configures CHAP only for ISCSI authentication.

```
switch# config terminal  
switch(config)# iscsi authentication chap
```

iscsi authentication

Send documentation comments to mdsfeedback-doc@cisco.com.

Related Commands	Command	Description
	show iscsi global	Displays all iSCSI initiators configured by the user.

Send documentation comments to mdsfeedback-doc@cisco.com.

iscsi duplicate-wwn-check

To check the current running configuration for conflicts between iSCSI initiators' static WWN allocation and what the system thinks is available in its WWN pool, use the **iscsi duplicate-wwn-check** command in configuration mode.

iscsi duplicate-wwn-check

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes Configuration mode.

Command History	Release	Modification
	2.1(2)	This command was introduced.

Usage Guidelines Prior to Cisco MDS SAN-OS Release 2.1(2), WWNs assigned to static iSCSI initiators by the system can be inadvertently returned to the system when an upgrade fails or the system software is manually downgraded (that is, when you manually boot up an older Cisco MDS SAN-OS release without using the **install all** command). In these instances, the system can later assign those WWNs to other iSCSI initiators (dynamic or static) and cause conflicts.

As of Cisco MDS SAN-OS Release 2.1(2), you can use the **iscsi duplicate-wwn-check** command to check for and remove any configured WWNs that belong to the system.

Examples The following example shows how to check the current running configuration for conflicts between iSCSI initiators' static WWN allocation and what the system thinks is available in its WWN pool.

```
switch# config terminal
Enter configuration command, one per line. End with CNTL/Z.
switch(config)# iscsi duplicate-wwn-check

List of Potential WWN Conflicts:
-----
Node : iqn.test-local-nwnn:1-local-pwnn:1
      nWWN : 22:03:00:0d:ec:02:cb:02
      pWWN : 22:04:00:0d:ec:02:cb:02
```

The following example shows how to remove the conflicting nWWN and pWWN.

```
switch(config)# iscsi initiator name iqn.test-local-nwnn:1-local-pwnn:1
switch(config-iscsi-init)# no static nWWN 22:03:00:0d:ec:02:cb:02
switch(config-iscsi-init)# no static pWWN 22:04:00:0d:ec:02:cb:02
```

■ **iscsi duplicate-wwn-check**

Send documentation comments to mdsfeedback-doc@cisco.com.

Related Commands	Command	Description
	iscsi initiator name	Assigns an iSCSI name and changes to iSCSI initiator configuration submode.
	static	Assigns persistent WWNs to an iSCSI initiator in iSCSI initiator configuration submode.
	show iscsi initiator	Displays information about configured iSCSI initiators.

Send documentation comments to mdsfeedback-doc@cisco.com.

iscsi enable

To enable the iSCSI feature in any Cisco MDS switch, issue the **iscsi enable** command. To disable this feature, use the **no** form of the command.

iscsi enable

no iscsi enable

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes Configuration mode

Command History	Release	Modification
	1.3(1)	This command was introduced.

Usage Guidelines The configuration and verification commands for the iSCSI feature are only available when iSCSI is enabled on a switch. When you disable this feature, all related configurations are automatically discarded.

Examples The following command enables the iSCSI feature.

```
switch(config)# iscsi enable
```

The following command disables the iSCSI feature (default).

```
switch(config)# no iscsi enable
```

 iscsi import target fc

Send documentation comments to mdsfeedback-doc@cisco.com.

iscsi import target fc

To allow dynamic mapping of Fibre Channel targets, use the **iscsi import target fc** command. To disable this feature, use the **no** form of the command.

iscsi import target fc

no iscsi import target fc

Syntax Description This command has no arguments or keywords.

Defaults Disabled

Command Modes Configuration mode

Command History	Release	Modification
	1.1(1)	This command was introduced.

Usage Guidelines This command directs iSCSI to dynamically import all Fibre Channel targets into iSCSI.

Examples The following example allows dynamic mapping of Fibre Channel targets.

```
switch# config terminal
switch(config)# iscsi import target fc
```

The following example disables dynamic mapping of Fibre Channel targets.

```
switch(config)# no iscsi import target fc
```

Related Commands

Command	Description
show iscsi global	Displays all iSCSI initiators configured by the user..

Send documentation comments to mdsfeedback-doc@cisco.com.

iscsi initiator idle-timeout

To configure the iSCSI initiator idle timeout, use the **iscsi initiator idle-timeout** command. To revert to the default, use the **no** form of the command.

iscsi initiator idle-timeout *seconds*

no iscsi initiator idle-timeout *seconds*

Syntax Description	<i>seconds</i>	Specifies the timeout in seconds. The range is 0 to 3600.
Defaults	300 seconds	
Command Modes	Configuration mode	
Command History	Release	Modification
	1.3	This command was introduced.
Usage Guidelines	When the idle timeout value is set to 0, the initiator information is cleared immediately after the last session from the initiator terminates.	
Examples	<p>The following example configures the iSCSI initiator idle timeout to 180 seconds.</p> <pre>switch# config terminal switch(config)# iscsi initiator idle-timeout 180</pre> <p>The following example reverts the default value of 300 seconds.</p> <pre>switch# config terminal switch(config)# no iscsi initiator idle-timeout 240</pre>	
Related Commands	Command	Description
	show iscsi global	Displays global iSCSI configuration information.

 iscsi initiator ip-address

Send documentation comments to mdsfeedback-doc@cisco.com.

iscsi initiator ip-address

To assign persistent WWNs to an iSCSI initiator or assign an iSCSI initiator into VSANs other than the default VSAN, use the **iscsi initiator ip-address** command. To revert to the default, use the **no** form of the command.

```
iscsi initiator ip-address ipaddress
  static {nwwn | pwwn} {wwn-id | system-assign number}
  vsan vsan-id

iscsi initiator ip-address ipaddress
  no static {nwwn | pwwn} {wwn-id | system-assign number}
  no vsan vsan-id

no iscsi initiator ip-address ipaddress
```

Syntax Description	<table border="0"> <tr> <td><i>ipaddress</i></td><td>Specifies the initiator IP address.</td></tr> <tr> <td>nwwn</td><td>Configures the initiator node WWN hex value.</td></tr> <tr> <td>pwwn</td><td>Configures the peer WWN for special frames.</td></tr> <tr> <td><i>wwn-id</i></td><td>Enters the pWWN or nWWN ID.</td></tr> <tr> <td>system-assign <i>number</i></td><td>Generates the nWWN value automatically. The number ranges from 1 to 64.</td></tr> <tr> <td>vsan <i>vsan-id</i></td><td>Specifies a VSAN ID. The range is 1 to 4093.</td></tr> </table>	<i>ipaddress</i>	Specifies the initiator IP address.	nwwn	Configures the initiator node WWN hex value.	pwwn	Configures the peer WWN for special frames.	<i>wwn-id</i>	Enters the pWWN or nWWN ID.	system-assign <i>number</i>	Generates the nWWN value automatically. The number ranges from 1 to 64.	vsan <i>vsan-id</i>	Specifies a VSAN ID. The range is 1 to 4093.
<i>ipaddress</i>	Specifies the initiator IP address.												
nwwn	Configures the initiator node WWN hex value.												
pwwn	Configures the peer WWN for special frames.												
<i>wwn-id</i>	Enters the pWWN or nWWN ID.												
system-assign <i>number</i>	Generates the nWWN value automatically. The number ranges from 1 to 64.												
vsan <i>vsan-id</i>	Specifies a VSAN ID. The range is 1 to 4093.												

Defaults	Disabled.
-----------------	-----------

Command Modes	Configuration mode
----------------------	--------------------

Command History	Release	Modification
	1.1(1)	This command was introduced.

Usage Guidelines	Under a circumstance where an iSCSI initiator needs to have a persistent binding to FC WWNs, this command should be used. Also, an iSCSI initiator can be put into multiple VSANs. An iSCSI host can become a member of one or more VSANs.
-------------------------	--

Examples	The following command configures an iSCSI initiator, using the IP address of the initiator node.
	switch(config)# iscsi initiator ip address 10.50.1.1

The following command deletes the configured iSCSI initiator.

```
switch(config)# no iscsi initiator ip address 10.5.0.0
```

Send documentation comments to mdsfeedback-doc@cisco.com.

The following command uses the switch's WWN pool to allocate the nWWN for this iSCSI initiator and keeps it persistent.

```
switch(config-(iscsi-init))# static nWWN system-assign
```

The following command assigns the user provided WWN as nWWN for the iSCSI initiator. You can only specify one nWWN for each iSCSI node.

```
switch(config-(iscsi-init))# nWWN 20:00:00:05:30:00:59:11
```

The following command uses the switch's WWN pool to allocate two pWWNs for this iSCSI initiator and keeps it persistent.

```
switch(config-(iscsi-init))# static pWWN system-assign 2
```

The following command assigns the user provided WWN as pWWN for the iSCSI initiator.

```
switch(config-(iscsi-init))# pWWN 21:00:00:20:37:73:3b:20
```

Related Commands	Command	Description
	show iscsi initiator	Displays information about configured iSCSI initiators.

iscsi initiator name

Send documentation comments to mdsfeedback-doc@cisco.com.

iscsi initiator name

To configure an iSCSI initiator name and change to iSCSI configuration mode, use the **iscsi initiator name** command. To revert to factory defaults, use the **no** form of the command.

iscsi initiator name *name*

no iscsi initiator name *name*

Syntax Description	name	Enters the initiator name to be used. The minimum length is 16 characters and maximum is 223 characters.
---------------------------	-------------	--

Defaults	Disabled
-----------------	----------

Command Modes	Configuration mode
----------------------	--------------------

Command History	Release	Modification
	1.3(2)	This command was introduced.

Usage Guidelines	Under a circumstance where an iSCSI initiator needs to have a persistent binding to FC WWNs, this command should be used. Also, an iSCSI initiator can be put into multiple VSANs. An iSCSI host can become a member of one or more VSANs.
-------------------------	--

Examples	The following example configures an iSCSI initiator using the iSCSI name of the initiator node.
-----------------	---

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# iscsi initiator name iqn.1987-02.com.cisco.initiator
```

Related Commands	Command	Description
	show iscsi initiator	Displays information about configured iSCSI initiators.

Send documentation comments to mdsfeedback-doc@cisco.com.

iscsi interface vsan-membership

To configure VSAN membership for iSCSI interfaces, use the **iscsi interface vsan-membership** command. Use the **no** form of this command to disable this feature or to revert to factory defaults.

iscsi interface vsan-membership

no iscsi interface vsan-membership

Syntax Description This command has no arguments or keywords.

Defaults Disabled.

Command Modes Configuration mode

Command History	Release	Modification
	1.3(1)	This command was introduced.

Usage Guidelines If the **iscsi interface vsan-membership** command is disabled, you will not be able to configure iSCSI VSAN membership.

Examples The following command enables the iSCSI interface VSAN membership.

```
switch# config terminal
switch(config)# iscsi interface vsan-membership
```

The following command disables the iSCSI interface VSAN membership (default).

```
switch(config)# no iscsi interface vsan-membership
```

Related Commands	Command	Description
	show iscsi initiator	Displays information about configured iSCSI initiators.

 iscsi save-initiator

Send documentation comments to mdsfeedback-doc@cisco.com.

iscsi save-initiator

To permanently save the automatically-assigned nWWN/pWWN mapping, use the **iscsi save-initiator** command.

iscsi save-initiator [ip-address *ip-address* | name *name*]

Syntax Description	ip-address <i>ip-address</i> Specifies the initiator IP address. name <i>name</i> Specifies the initiator name to be used from 1 to 255 characters. The minimum length is 16 characters.
---------------------------	---

Defaults	If initiator name or IP address is not specified, the nWWN/pWWN mapping for all initiators becomes permanent.
-----------------	---

Command Modes	Configuration mode
----------------------	--------------------

Command History	Release	Modification
	1.3(1)	This command was introduced.

Usage Guidelines	After executing the iscsi save-initiator command, issue the copy running-config startup-config to save the nWWN/pWWN mapping across switch reboots.
-------------------------	---

Examples	The following example shows how to save the nWWN/pWWN mapping for all the initiators.
-----------------	---

```
switch(config)# iscsi save-initiator
```

The following example shows how to save the nWWN/pWWN mapping for an initiator named iqn.1987-02.com.cisco.initiator.

```
switch(config)# iscsi save-initiator name iqn.1987-02.com.cisco.initiator
```

Related Commands	Command	Description
	iscsi initiator	Configures an iSCSI initiator.
	show iscsi initiator	Displays information about configured iSCSI initiators.

Send documentation comments to mdsfeedback-doc@cisco.com.

iscsi virtual-target name

To create a static iSCSI virtual target, use the **iscsi virtual-target** command. To revert to the default values, use the **no** form of the command.

```

iscsi virtual-target name name
  advertise interface {gigabitethernet slot/port[.subinterface] | port-channel
    channel-id[.subinterface]}
  all-initiator-permit
  initiator {initiator-name | ip-address ipaddress [netmask]} permit
  pwwn pwwn-id [fc-lun number iscsi-lun number [secondary-pwwn pwwn-id [sec-lun
    number]]] | secondary-pwwn pwwn-id]
  revert-primary-port
  trespass

iscsi virtual-target name name
  no advertise interface {gigabitethernet slot/port[.subinterface] | port-channel
    channel-id[.subinterface]}
  no all-initiator-permit
  no initiator {initiator-name | ip-address ipaddress [netmask]} permit
  no pwwn pwwn-id [fc-lun number iscsi-lun number [secondary-pwwn pwwn-id [sec-lun
    number]]] | secondary-pwwn pwwn-id]
  no revert-primary-port
  no trespass

no iscsi virtual-target name name

```

Syntax Description	
<i>name</i>	Enters the virtual target name to be used. The minimum length is 16 characters and maximum of 223 bytes.
advertise interface	Advertises the virtual target name on the specified interface.
gigabitethernet <i>slot/port[.subinterface]</i>	Selects the Gigabit Ethernet interface or subinterface to configure.
port-channel <i>channel-id[.subinterface]</i>	Selects the Port Channel interface or subinterface to configure.
all-initiator-permit	Enables all iSCSI initiator access to this target.
initiator	Configures specific iSCSI initiator access to this target.
<i>initiator-name</i>	Specifies the iSCSI initiator name to be used access a specified target. Maximum length is 255 characters.
ip-address <i>ip-address</i>	Specifies the iSCSI initiator IP address.
<i>ip-subnet</i>	Specifies all initiators in the subnet.
permit	Permits access to the specified target.
pwwn <i>pwwn-id</i>	Specifies the peer WWN ID for special frames.
secondary-pwwn <i>pwwn-id</i>	Specifies the secondary pWWN ID.
fc-lun <i>number</i>	Specifies the Fibre Channel Logical Unit Number (LUN).
iscsi-lun <i>number</i>	Specifies the iSCSI virtual target number.
sec-lun <i>number</i>	Specifies the secondary Fibre Channel LUN.
trespass	Moves LUNs forcefully from one port to another.

iscsi virtual-target name

Send documentation comments to mdsfeedback-doc@cisco.com.

Defaults Disabled.

Command Modes Configuration mode.

Command History

Release	Modification
1.1(1)	This command was introduced.
1.3(1)	Added revert-to-primary and trespass subcommands.

Usage Guidelines

This command is used to configure a static iSCSI target for access by iSCSI initiators. A virtual target may contain a subset of LUs of an FC target or one whole FC target.

Do not specify the LUN if you wish to map the whole Fibre Channel target to an iSCSI target. All Fibre Channel LUN targets are exposed to iSCSI.

One iSCSI target cannot contain more than one Fibre Channel target.

Examples

The follow example creates a static virtual target and enters ISCSI target configuration submode.

```
switch# config terminal
switch(config)# iscsi virtual-target name 0123456789ABDEFGHI
switch(config-iscsi-tgt)#

```

The following command advertises the virtual target only on the specified interface. By default, it is advertised on all interfaces in all IPS modules.

```
switch(config-iscsi-tgt)# advertise interface gigabitethernet 4/1
```

The following command maps a virtual target node to a Fibre Channel target.

```
switch(config-iscsi-tgt)# pWWN 26:00:01:02:03:04:05:06
```

The following command enters the secondary pWWN for the virtual target node.

```
switch(config-iscsi-tgt)# pWWN 26:00:01:02:03:04:05:06 secondary-pwwm
66:00:01:02:03:04:05:02
```

Use the LUN option to map different Fibre Channel LUNs to different iSCSI virtual targets. If you have already mapped the whole Fibre Channel target, you will not be able to use this option.

```
switch(config-iscsi-tgt)# pWWN 26:00:01:02:03:04:05:06 fc-lun 0 iscsi-lun 0
```

The following command allows the specified iSCSI initiator node to access this virtual target. You can issue this command multiple times to allow multiple initiators.

```
switch(config-iscsi-tgt)# initiator iqn.1987-02.com.cisco.initiator1 permit
```

The following command prevents the specified initiator node from accessing virtual targets.

```
switch(config-iscsi-tgt)# no initiator iqn.1987-02.com.cisco.initiator1 permit
```

The following command allows the specified IP address to access this virtual target:

```
switch(config-iscsi-tgt)# initiator ip-address 10.50.1.1 permit
```

Send documentation comments to mdsfeedback-doc@cisco.com.

The following command prevents the specified IP address from accessing virtual targets:

```
switch(config-iscsi-tgt)# no initiator ip-address 10.50.1.1 permit
```

The following command allows all initiators in this subnetwork to access this virtual target:

```
switch(config-iscsi-tgt)# initiator ip-address 10.50.0.0 255.255.255.0 permit
```

The following command prevents all initiators in this subnetwork from accessing virtual targets:

```
switch(config-iscsi-tgt)# no initiator ip-address 10.50.0.0 255.255.255.0 permit
```

The following command allows all initiator nodes to access this virtual target.

```
switch(config-iscsi-tgt)# all-initiator-permit
```

The following command prevents any initiator node from accessing virtual targets.

```
switch(config-iscsi-tgt)# no all-initiator-permit
```

The following command configures a primary and secondary port and moves the LUNs from one port to the other using the **trespass** command.

```
switch# config terminal
switch(config)#iscsi virtual-target name iqn.1987-02.com.cisco.initiator
switch(config-iscsi-tgt)# pwn 50:00:00:a1:94:cc secondary-pwn 50:00:00:a1:97:ac
switch(config-iscsi-tgt)# trespass
```

Related Commands

Command	Description
show iscsi virtual target	Displays information about iSCSI virtual targets.

Send documentation comments to mdsfeedback-doc@cisco.com.

iSNS

To tag a Gigabit Ethernet or PortChannel interface to an Internet Storage Name Service (iSNS) profile, use the **isns** command in interface configuration submode. To untag the interface, use the **no** form of the command.

isns *profile-name*

no isns *profile-name*

Syntax Description	<i>profile-name</i>	Specifies the iSNS profile name.
---------------------------	---------------------	----------------------------------

Defaults	Disabled.
-----------------	-----------

Command Modes	Interface configuration submode.
----------------------	----------------------------------

Command History	Release	Modification
	2.0(1b)	This command was introduced.

Usage Guidelines	To use this command, iSNS must be enabled using the isns-server enable command. Use the isns reregister command in EXEC mode to reregister associated iSNS objects (tagged to an iSNS profile) with the iSNS server.
-------------------------	---

Examples	The following example shows how to tag a Gigabit Ethernet interface to an iSNS profile.
-----------------	---

```
switch# config terminal
switch(config)# interface gigabitethernet 1/2
switch(config-if)# isns Profile1
```

The following example shows how to tag a PortChannel interface to an iSNS profile.

```
switch# config terminal
switch(config)# interface port-channel 2
switch(config-if)# isns Profile2
```

Related Commands	Command	Description
	isns-server enable	Enables the iSNS server.
	isns reregister	Reregisters the iSNS object.
	show interface gigabitetherne t	Displays configuration and status information for a specified Gigabit Ethernet interface.

Send documentation comments to mdsfeedback-doc@cisco.com.

Command	Description
show interface port-channel	Displays configuration and status information for a specified PortChannel interface.
show isns	Displays iSNS information.

isns distribute

Send documentation comments to mdsfeedback-doc@cisco.com.

isns distribute

To enable Cisco Fabric Services (CFS) distribution for Internet Storage Name Service (iSNS), use the **isns distribute** command. To disable this feature, use the **no** form of the command.

isns distribute

no isns distribute

Syntax Description This command has no other arguments or keywords.

Defaults Enabled.

Command Modes Configuration mode.

Command History

	Release	Modification
2.0(1b)		This command was introduced.

Usage Guidelines

To use this command, iSNS must be enabled using the **isns-server enable** command.

You can configure the pWWN and nWWN of iSCSI initiators and permit a group of iSCSI initiators to share a given nWWN/pWWN pair by using a proxy initiator. The number of iSCSI initiators that register with the iSNS server is more than the number of iSCSI targets that register with the iSNS server. To synchronize the iSCSI initiator entries across switches, you can distribute the iSCSI initiator configuration to iSNS servers across switches.

Examples

The following example shows how to initiate iSNS information distribution.

```
switch# config terminal
switch(config)# isns distribute
```

The following example shows how to cancel iSNS information distribution.

```
switch# config terminal
switch(config)# no isns distribute
```

Related Commands

Command	Description
isns-server enable	Enables the iSNS server.
show isns	Displays iSNS information.

Send documentation comments to mdsfeedback-doc@cisco.com.

isns esi retries

To configure the number of entity status inquiry (ESI) retry attempts, use the **isns esi retries** command in configuration mode. To revert to the default value, use the **no** form of the command.

isns esi retries *number*

no isns esi retries *number*

Syntax Description	<i>number</i>	Specifies the number of retries. The range is 0 to 10.						
Defaults	3 retries.							
Command Modes	Configuration mode.							
Command History	<table border="1"> <thead> <tr> <th>Release</th><th>Modification</th></tr> </thead> <tbody> <tr> <td>2.0(1b)</td><td>This command was introduced.</td></tr> </tbody> </table>		Release	Modification	2.0(1b)	This command was introduced.		
Release	Modification							
2.0(1b)	This command was introduced.							
Usage Guidelines	<p>To use this command, Internet Storage Name Service (iSNS) must be enabled using the isns-server enable command.</p> <p>The iSNS client queries the ESI port at user-configured intervals. Receipt of a response indicates that the client is still alive. Based on the configured value, the interval specifies the number of failed tries before which the client is deregistered from the server.</p>							
Examples	<p>The following example shows how change the ESI retries limit to eight.</p> <pre>switch# config terminal switch(config)# isns esi retries 8</pre>							
Related Commands	<table border="1"> <thead> <tr> <th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td>isns-server enable</td><td>Enables the iSNS server.</td></tr> <tr> <td>show isns</td><td>Displays iSNS information.</td></tr> </tbody> </table>		Command	Description	isns-server enable	Enables the iSNS server.	show isns	Displays iSNS information.
Command	Description							
isns-server enable	Enables the iSNS server.							
show isns	Displays iSNS information.							

isns profile name

Send documentation comments to mdsfeedback-doc@cisco.com.

isns profile name

To create an Internet Storage Name Service (iSNS) profile and enter iSNS profile configuration submode, use the **isns profile name** command in configuration mode. To delete the iSNS profile, use the **no** form of the command.

isns profile name *profile-name*

no isns profile name *profile-name*

Syntax Description	<i>profile-name</i>	Specifies the profile name. Maximum length is 64 characters.
---------------------------	---------------------	--

Defaults	None.
-----------------	-------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	1.3(1)	This command was introduced.

Usage Guidelines	To use this command, iSNS must be enabled using the isns-server enable command.
-------------------------	--

Examples	The following example shows how to specify an iSNS profile name and enter iSNS profile configuration submode.
-----------------	---

```
switch# config terminal
switch(config)# isns profile name UserProfile
switch(config-isns-profile) #
```

Related Commands	Command	Description
	server	Configures a server IP address in an iSNS profile.
	show isns	Displays iSNS information.

Send documentation comments to mdsfeedback-doc@cisco.com.

isns reregister

To register all Internet Storage Name Service (iSNS) objects for an interface that is already tagged to an iSNS profile, use the **isns register** command.

isns reregister {gigabitethernet slot/number | port-channel channel-group}

Syntax Description	gigabitethernet slot/port Specifies tagged Gigabit Ethernet interface slot and port. port-channel channel-group Specifies tagged PortChannel group. The range is 1 to 128.
---------------------------	---

Defaults	None.
-----------------	-------

Command Modes	EXEC mode.
----------------------	------------

Command History	Release	Modification
	1.3(1)	This command was introduced.

Usage Guidelines	Use this command to reregister portals and targets with the iSNS server for a tagged interface.
-------------------------	---

Examples	The following command re-registers portal and targets for a tagged interface: switch# isns reregister gigabitethernet 1/4
-----------------	---

Related Commands	Command	Description
	show isns profile	Displays details for configured iSNS profiles.

isns-server enable

Send documentation comments to mdsfeedback-doc@cisco.com.

isns-server enable

To enable the Internet Storage Name Service (iSNS) server, use the **isns-server enable** command in configuration mode. To disable iSNS, use the **no** form of the command.

isns-server enable

no isns-server enable

Syntax Description This command has no other arguments or keywords.

Defaults Disabled.

Command Modes Configuration mode.

Command History	Release	Modification
	2.0(1b)	This command was introduced.

Usage Guidelines Performing the **isns-server enable** command enables the commands used to configure iSNS.

Examples The following example shows how to enable iSNS.

```
switch# config terminal
switch(config)# isns-server enable
```

The following example shows how to disable iSNS.

```
switch# config terminal
switch(config)# no isns-server enable
```

Related Commands

Command	Description
isns distribute	Enables iSNS distributed support.
isns esi retries	Configures ESI retry attempts.
isns profile name	Creates and configures iSNS profiles.
server	Configures iSNS server attributes.
show isns	Displays iSNS information.

Send documentation comments to mdsfeedback-doc@cisco.com.

ivr abort

To discard an Inter-VSAN Routing (IVR) CFS distribution session in progress, use the **ivr abort** command in configuration mode.

ivr abort

Syntax Description This command has no other arguments or keywords.

Defaults None.

Command Modes Configuration mode.

Command History	Release	Modification
	2.0(1b)	This command was introduced.

Usage Guidelines None.

Examples The following example shows how to discard an IVR CFS distribution session in progress.

```
switch# config terminal
switch(config)# ivr abort
```

Related Commands	Command	Description
	ivr distribute	Enables CFS distribution for IVR.
	show ivr	Displays IVR CFS distribution status and other details.

ivr commit

Send documentation comments to mdsfeedback-doc@cisco.com.

ivr commit

To apply the pending configuration pertaining to the Inter-VSAN Routing (IVR) Cisco Fabric Services (CFS) distribution session in progress in the fabric, use the **ivr commit** command in configuration mode.

ivr commit

Syntax Description This command has no other arguments or keywords.

Defaults None.

Command Modes Configuration mode.

Command History	Release	Modification
	2.0(1b)	This command was introduced.

Usage Guidelines None.

Examples The following example shows how to apply an IVR configuration to the switches in the fabric.

```
switch# config terminal
switch(config)# ivr commit
```

Related Commands	Command	Description
	ivr distribute	Enables CFS distribution for IVR.
	show ivr	Displays IVR CFS distribution status and other details.

Send documentation comments to mdsfeedback-doc@cisco.com.

ivr copy auto-topology user-configured-topology

To copy the automatically discovered Inter-VSAN Routing (IVR) VSAN topology into the user configured topology, use the **ivr copy auto-topology user-configured-topology** command in EXEC mode.

ivr copy auto-topology user-configured-topology

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC configuration mode.

Command History	Release	Modification
	2.1(1a)	This command was introduced.

Usage Guidelines After using the **ivr copy auto-topology user-configured-topology** command to copy the automatically discovered VSAN topology into the user configured topology you must use the **ivr commit** command to apply the pending configuration changes to the IVR topology using Cisco Fabric Services (CFS) distribution.

Examples The following example copies the automatically discovered VSAN topology into the user configured topology.

```
switch# ivr copy auto-topology user-configured-topology
```

Related Commands	Command	Description
	ivr commit	Applies the changes to the IVR topology.
	show ivr vsan topology	Displays the IVR VSAN topology configuration

■ **ivr distribute**

Send documentation comments to mdsfeedback-doc@cisco.com.

ivr distribute

To enable Cisco Fabric Services (CFS) distribution for Inter-VSAN Routing (IVR), use the **ivr distribute** command. To disable this feature, use the **no** form of the command.

ivr distribute

no ivr distribute

Syntax Description This command has no other arguments or keywords.

Defaults Disabled.

Command Modes Configuration mode.

Command History

	Release	Modification
2.0(1b)		This command was introduced.

Usage Guidelines None.

Examples

The following example shows how to enable IVR fabric distribution.

```
switch# config terminal
switch(config)# ivr distribute
```

Related Commands

Command	Description
ivr commit	Commits temporary IVR configuration changes to the active configuration.
show ivr	Displays IVR CFS distribution status and other details.

Send documentation comments to mdsfeedback-doc@cisco.com.

ivr enable

To enable the Inter-VSAN Routing (IVR) feature, use the **ivr enable** command in configuration mode. To disable this feature, use the **no** form of the command.

ivr enable

no ivr enable

Syntax Description This command has no arguments or keywords.

Defaults Disabled.

Command Modes Configuration mode.

Command History	Release	Modification
	1.3(1)	This command was introduced.

Usage Guidelines The IVR feature must be enabled in all edge switches in the fabric that participate in the IVR.

The configuration and display commands for the IVR feature are only available when IVR is enabled on a switch.

When you disable this configuration, all related configurations are automatically discarded.

Examples The following command enters the configuration mode and enables the IVR feature on this switch.

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# ivr enable
```

Related Commands	Command	Description
	show ivr	Displays IVR feature information.

 ivr fcdomain database autonomous-fabric-num

Send documentation comments to mdsfeedback-doc@cisco.com.

ivr fcdomain database autonomous-fabric-num

To create IVR persistent FC IDs, use the **ivr fcdomain database autonomous-fabric-num** command. To delete the IVR fcdomain entry for a given AFID and VSAN, use the **no** form of the command.

ivr fcdomain database autonomous-fabric-num *afid-num* *vsan* *vsan-id*

no ivr fcdomain database autonomous-fabric-num *afid-num* *vsan* *vsan-id*

Syntax Description	<i>afid-num</i> Specifies the current AFID. The range is 1 to 64. <i>vsan</i> <i>vsan-id</i> Specifies the current VSAN. The range is 1 to 4093.
---------------------------	---

Defaults	None.
-----------------	-------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	2.1(2)	This command was introduced.

Usage Guidelines	None.
-------------------------	-------

Examples The following example shows how to enter IVR fcdomain database configuration submode for AFID 10 and VSAN 20.

```
switch# config t
switch(config)# ivr fcdomain database autonomous-fabric-num 10 vsan 20
switch(config) fcdomain#
```

The following example shows how to delete all persistent FC ID database entries for AFID 10 and VSAN 20.

```
switch# config t
switch(config)# no ivr fcdomain database autonomous-fabric-num 10 vsan 20
```

Related Commands	Command	Description
	show ivr fcdomain database	Displays IVR fcdomain database entry information.

Send documentation comments to mdsfeedback-doc@cisco.com.

ivr nat

To explicitly enable Network Address Translation (NAT) functionality for Inter-VSAN Routing (IVR), use the **ivr nat** command in configuration mode. To disable this feature, use the **no** form of the command.

ivr nat

no ivr nat

Syntax Description This command has no arguments or keywords.

Defaults Disabled.

Command Modes Configuration mode.

Command History

Release	Modification
2.1(1a)	This command was introduced.

Usage Guidelines

The **ivr nat** command allows you to explicitly enable NAT functionality of IVR. Upgrading to SAN-OS Release 2.x from SAN-OS Release 1.3.x does not automatically enable the Fibre Channel NAT functionality. This command also allows you to continue to operate in non-NAT mode even in SAN-OS Release 2.x and later.



Note

You might need to operate in non-NAT mode to support proprietary protocols that embed FCIDs in the frame payloads.

Examples

The following example shows how to explicitly enable NAT functionality for IVR.

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# ivr nat
```

Related Commands

Command	Description
show ivr	Displays IVR feature information.

ivr refresh

Send documentation comments to mdsfeedback-doc@cisco.com.

ivr refresh

To refresh devices being advertised by Inter-VSAN Routing (IVR), use the **ivr refresh** command in EXEC mode.

ivr refresh

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC mode.

Command History	Release	Modification
	2.0(2)	This command was introduced.

Usage Guidelines None.

Examples The following example shows refresh devices being advertised by IVR.

```
switch# ivr refresh
```

Related Commands	Command	Description
	ivr enable	Enables the Inter-VSAN Routing (IVR) feature.
	ivr withdraw domain	Withdraws an overlapping virtual domain from a specified VSAN.

Send documentation comments to mdsfeedback-doc@cisco.com.

ivr service-group name

To configure an Inter-VSAN Routing (IVR) service group, use the **ivr service-group name** command in configuration mode. To disable this feature, use the **no** form of the command.

ivr service-group name *service-group*

no ivr service-group name *service-group*

Syntax Description	<i>service-group</i> Specifies the service group name.	
Defaults	Disabled.	
Command Modes	Configuration mode.	
Command History	Release	Modification
	2.1(1a)	This command was introduced.
Usage Guidelines	In a complex network topology, you might only have a few IVR-enabled VSANs. To reduce the amount of traffic to non-IVR-enabled VSANs, you can configure a service group that restricts the traffic to the IVR-enabled VSANs. Only one service group allowed in a network. When a new IVR-enabled switch is added to the network, you must update the service group to include the new VSANs. Before configuring an IVR service group, you must enable the following:	
	<ul style="list-style-type: none"> • IVR using the ivr enable command • IVR distribution using the ivr distribute command • Automatic IVR topology discovery using the ivr vsan-topology auto command. 	
	Using the autonomous-fabric-id (IVR service group configuration) command, you can restrict the IVR traffic to the AFIDs and VSANs configured in the service group.	
Examples	The following example shows how to configure an IVR service group and change to IVR service group configuration mode.	
	<pre>switch# config terminal Enter configuration commands, one per line. End with CNTL/Z. switch(config)# ivr enable switch(config)# ivr vsan-topology auto → switch(config)# ivr service-group name serviceGroup1 switch(config-ivr-sg)# </pre>	

■ ivr service-group name

Send documentation comments to mdsfeedback-doc@cisco.com.

Related Commands	Command	Description
	ivr enable	Enables the Inter-VSAN Routing (IVR) feature
	ivr vsan-topology auto	Enables automatic discovery of the IVR topology.
	show ivr	Displays IVR feature information.

Send documentation comments to mdsfeedback-doc@cisco.com.

ivr virtual-fcdomain-add

To add the Inter-VSAN Routing (IVR) virtual domains in a specific VSAN(s) to the assigned domains list in that VSAN, use the **ivr virtual-fcdomain-add** command. To delete the IVR virtual domains, use the **no** form of the command.

ivr virtual-fcdomain-add vsan-ranges *vsan-range*

no ivr virtual-fcdomain-add vsan-ranges *vsan-range*

Syntax Description	vsan-ranges <i>vsan-range</i> Specifies the IVR VSANs or range of VSANs. The range of values for a VSAN ID is 1 to 4093.
---------------------------	---

Defaults	Disabled.
-----------------	-----------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	1.3(4)	This command was introduced.

Usage Guidelines	Use the no ivr virtual-fcdomain-add command to remove the currently active domains from the fcdomain manager list in a specified VSAN.
-------------------------	---

Examples	The following command adds the IVR virtual domains in VSAN 1.
-----------------	---

```
switch# config terminal
switch(config)# ivr virtual-fcdomain-add vsan-ranges 1
```

The following command reverts to the factory default of not adding IVR virtual domains.

```
switch# config terminal
switch(config)# ivr virtual-fcdomain-add vsan-ranges 1
```

Related Commands	Command	Description
	show ivr virtual-fcdomain-add-status	Displays the configured VSAN topology for a fabric.
	ivr withdraw domain	Removes overlapping domains.

ivr vsan-topology

Send documentation comments to mdsfeedback-doc@cisco.com.

ivr vsan-topology

To configure manual or automatic discovery of the Inter-VSAN Routing (IVR) topology, use the **ivr vsan-topology** command in configuration mode.

ivr vsan-topology {activate | auto}

Syntax Description	activate Configures manual discovery of the IVR topology and disables automatic discovery mode. auto Configures automatic discovery of the IVR topology.
---------------------------	---

Defaults	Disabled.
-----------------	-----------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	1.3(1)	This command was introduced.
	2.1(1a)	Added auto keyword.

Usage Guidelines	To use this command you must first enable IVR using the ivr enable command and configure the IVR database using the ivr vsan-topology database command.
-------------------------	---



Caution	Active IVR topologies cannot be deactivated. You can only switch to automatic topology discovery mode.
----------------	--

Examples	The following ivr vsan-topology activate command activates the VSAN topology database:
-----------------	---

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# ivr enable
switch(config)# ivr vsan-topology database
switch(config-ivr-topology-db)# autonomous-fabric-id 1 switch 20:00:00:00:30:00:3c:5e
vsan-ranges 2,2000
→ switch(config)# ivr vsan-topology activate
```

The following command enables VSAN topology database auto mode, which allows the switch to automatically discover the IVR topology.

```
→ switch(config)# ivr vsan-topology auto
```

Send documentation comments to mdsfeedback-doc@cisco.com.

Related Commands	Command	Description
	ivr enable	Enables the Inter-VSAN Routing (IVR) feature.
	autonomous-fabric-id (IVR topology database configuration)	Configure an autonomous phobic ID into the IVR topology database.
	show ivr	Displays IVR feature information.

ivr vsan-topology database

Send documentation comments to mdsfeedback-doc@cisco.com.

ivr vsan-topology database

To configure an Inter-VSAN Routing (IVR) topology database, use the **ivr vsan-topology database** command in configuration mode. To delete an IVR topology database, use the **no** form of the command.

ivr vsan-topology database

no ivr vsan-topology database

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes Configuration mode.

Command History	Release	Modification
	1.3(1)	This command was introduced.

Usage Guidelines To use this command you must first enable IVR using the **ivr enable** command.

You can have up to 64 VSANs (or 128 VSANs as of Cisco MDS SAN-OS Release 2.1(1a)) in an IVR topology. Specify the IVR topology using the following information:

- The switch WWNs of the IVR-enabled switches.
- A minimum of two VSANs to which the IVR-enabled switch belongs.
- The autonomous fabric ID (AFID), which distinguishes two VSANs that are logically and physically separate, but have the same VSAN number. Cisco MDS SAN-OS Release 1.3(1) and later supports only one default AFID (AFID 1) and thus does not support non-unique VSAN IDs in the network. As of Cisco MDS SAN-OS Release 2.1(1a), you can specify up to 64 AFIDs.



Note The use of a single AFID does not allow for VSANs that are logically and physically separate but have the same VSAN number in an IVR topology.



Caution You can only configure a maximum of 128 IVR-enabled switches and 64 distinct VSANs (or 128 distinct VSANs as of Cisco MDS SAN-OS Release 2.1(1a)) in an IVR topology.

The **no ivr vsan-topology database** command only clears the configured database, not the active database. You can only delete the user-defined entries in the configured database. Auto mode entries only exist in the active database.

Send documentation comments to mdsfeedback-doc@cisco.com.

Examples

The following command enters configuration mode, enables the IVR feature, enters the VSAN topology database, and configures the pWWN-VSAN association for VSANs 2 and 2000:

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# ivr enable
→ switch(config)# ivr vsan-topology database
switch(config-ivr-topology-db)# autonomous-fabric-id 1 switch 20:00:00:00:30:00:3c:5e
vsan-ranges 2,2000
```

Related Commands

Command	Description
ivr enable	Enables the Inter-VSAN Routing (IVR) feature.
autonomous-fabric-id (IVR topology database configuration)	Configure an autonomous phobic ID into the IVR topology database
show ivr	Displays IVR feature information.

■ **ivr withdraw domain*****Send documentation comments to mdsfeedback-doc@cisco.com.***

ivr withdraw domain

To withdraw overlapping virtual domain from a specified VSAN, use the **ivr withdraw domain** command in EXEC mode.

ivr withdraw domain *domain-id vsan vsan-id*

Syntax Description	domain-id Specifies the domain id. The range is 1 to 239. vsan <i>vsan-id</i> Specifies the VSAN ID. The range is 1 to 4093.
---------------------------	---

Defaults	None.
-----------------	-------

Command Modes	EXEC mode.
----------------------	------------

Command History	Release	Modification
	1.3(4)	This command was introduced.

Usage Guidelines	When you enable the ivr virtual-fcdomain-add command, links may fail to come up due to overlapping virtual domain identifiers. If so, temporarily withdraw the overlapping virtual domain from that VSAN using the ivr withdraw domain command in EXEC mode.
-------------------------	--

Examples	The following command withdraws overlapping domains.
-----------------	--

```
switch# ivr withdraw domain 10 vsan 20
```

Related Commands	Command	Description
	show ivr virtual-fcdomain-add-status	Displays the configured VSAN topology for a fabric.

Send documentation comments to mdsfeedback-doc@cisco.com.

ivr zone name

To configure a zone for Inter-VSAN Routing (IVR), use the **ivr zone name** command. To disable a zone for IVR, use the **no** form of the command.

ivr zone name *ivzs-name*

no ivr zone name *ivz-name*

Syntax Description	<i>ivz-name</i>	Specifies the IVZ name. Maximum length is 59 characters.
Defaults	None.	
Command Modes	Configuration mode.	
Command History	Release	Modification
	1.3(1)	This command was introduced.
Usage Guidelines	This command enters IVR zone configuration submode.	
Examples	The following command enters the configuration mode, enables the IVR feature, creates an IVZ, and adds a pWWN-VSAN member.	
	<pre>switch# config terminal switch(config)# ivr enable switch(config)# ivr zone name Ivz_vsan2-3 switch(config-ivr-zone)# member pwwn 21:00:00:e0:8b:02:ca:4a vsan 3</pre>	
Related Commands	Command	Description
	show ivr	Displays IVR feature information.

ivr zoneset

Send documentation comments to mdsfeedback-doc@cisco.com.

ivr zoneset

To configure a zoneset for Inter-VSAN Routing (IVR), use the **ivr zoneset** command. To revert to the factory defaults, use the **no** form of the command.

```
ivr zoneset {activate name ivzs-name [force] | name ivzs-name}
no ivr zoneset {activate name ivzs-name [force] | name ivzs-name}
```

Syntax Description	activate Activates a previously-configured IVZS. force Forces a IVZS activation name ivzs-name Specifies the IVZS name. Maximum length is 59 characters.
---------------------------	---

Defaults	None.
-----------------	-------

Command Modes	Configuration mode.
----------------------	---------------------

Command History	Release	Modification
	1.3(1)	This command was introduced.

Usage Guidelines	This command enters IVR zoneset configuration submode.
-------------------------	--

Examples	The following command enters the configuration mode, enables the IVR feature, creates an IVZS, adds a IVZ member, and activates the IVZS.
-----------------	---

```
switch# config terminal
switch(config)# ivr enable
switch(config)# ivr zoneset name Ivr_zoneset1
switch(config-ivr-zoneset)# member Ivz_vsan2-3
switch(config-ivr-zoneset)# exit
switch(config)# ivr zoneset activate name IVR_ZoneSet1
```

Related Commands	Command	Description
	show ivr	Displays IVR feature information.