

Send documentation comments to mdsfeedback-doc@cisco.com.

CHAPTER

17

P Commands

The commands in this chapter apply to the Cisco MDS 9000 Family of multilayer directors and fabric switches. All commands are shown here in alphabetical order regardless of command mode. See the “Command Modes” section to determine the appropriate mode for each command. For more information, refer to the *Cisco MDS 9000 Family Configuration Guide*.

passive-mode

Send documentation comments to mdsfeedback-doc@cisco.com.

passive-mode

To configure the required mode to initiate an IP connection, use the **passive-mode** command. To enable passive mode for the FCIP interface, use the **no** form of the command.

passive-mode

no passive-mode

Syntax Description This command has no keywords or arguments.

Defaults Disabled

Command Modes Interface configuration submode

Command History This command was introduced in Cisco MDS SAN-OS Release 1.1(1).

Usage Guidelines Access this command from the `switch(config-if)#` submode.

By default, the active mode is enabled to actively attempt an IP connection.

If you enable the passive mode, the switch does not initiate a TCP connection and merely waits for the peer to connect to it.

Examples The following example enables passive mode on an FCIP interface.

```
switch# config terminal
switch(config)# interface fcip 1
switch(config-if)# passive-mode
```

Related Commands

Command	Description
show interface fcip	Displays an interface configuration for a specified FCIP interface.

Send documentation comments to mdsfeedback-doc@cisco.com.

peer-info ipaddr

To configure the peer information for the FCIP interface, use the **peer-info ipaddr** command. To remove the peer information for the FCIP interface, use the **no** form of the command.

peer-info ipaddr address [port number]

no peer-info ipaddr address [port number]

Syntax Description	ipaddr address Configures the peer IP address. port number Configures a peer port. The range is 1 to 65535.
---------------------------	--

Defaults	None.
-----------------	-------

Command Modes	Interface configuration submode
----------------------	---------------------------------

Command History	This command was introduced in Cisco MDS SAN-OS Release 1.1(1).
------------------------	---

Usage Guidelines	Access this command from the <code>switch(config-if)#</code> submode.
-------------------------	---

The basic FCIP configuration uses the peer's IP address to configure the peer information. You can also use the peer's port number, port profile ID, or port WWN to configure the peer information. If you do not specify a port, the default 3225 port number is used to establish connection.

Examples	The following command assigns an IP address to configure the peer information. Since no port is specified, the default port number, 3225, is used.
-----------------	--

```
switch# config terminal
switch(config)# interface fcip 10
switch(config-if)# peer-info ipaddr 10.1.1.1
```

The following command deletes the assigned peer port information.

```
switch(config-if)# no peer-info ipaddr 10.10.1.1
```

The following command assigns the IP address and sets the peer TCP port to 3000. The valid port number range is from 0 to 65535.

```
switch(config-if)# peer-info ipaddr 10.1.1.1 port 3000
```

The following command deletes the assigned peer port information.

```
switch(config-if)# no peer-info ipaddr 10.1.1.1 port 2000
```

peer-info ipaddr

Send documentation comments to mdsfeedback-doc@cisco.com.

Related Commands	Command	Description
	show interface fcip	Displays an interface configuration for a specified FCIP interface.

Send documentation comments to mdsfeedback-doc@cisco.com.

periodic-inventory notification

To enable the periodic inventory notification message dispatches, use the **periodic-inventory notification** command Call Home configuration submode. To revert to the default state, use the **no** form of the command.

periodic-inventory notification [interval days]

no periodic-inventory notification

Syntax Description	interval days	Specifies the notification interval. The range is 1 to 30.
---------------------------	----------------------	--

Defaults	Disabled.
-----------------	-----------

The initial default interval is 7 days.

Command Modes	Call Home configuration submode.
----------------------	----------------------------------

Command History	Release	Modification
	2.0(1b)	This command was introduced.

Usage Guidelines	None.
-------------------------	-------

Examples	The following example shows how to enable periodic inventory notification and use the default interval.
-----------------	---

```
switch# config terminal
switch(config)# callhome
switch(config-callhome)# periodic-inventory notification
```

The following example shows how to enable periodic inventory notification and set the interval to 10 days.

```
switch# config terminal
switch(config)# callhome
switch(config-callhome)# periodic-inventory notification interval 10
```

Related Commands	Command	Description
	callhome	Enters Call Home configuration submode.
	show callhome	Displays Call Home configuration information.

phone-contact

Send documentation comments to mdsfeedback-doc@cisco.com.

phone-contact

To configure the telephone contact number with the Call Home function, use the **phone-contact** command in Call Home configuration submode. To disable this feature, use the **no** form of the command.

phone-contact *number*

no phone-contact *number*

Syntax Description	<i>number</i>	(Optional) Configures the customer's phone number. Allows up to 20 alphanumeric characters in international phone format.
		Note Do not use spaces. Use the + prefix before the number.

Defaults	None.
-----------------	-------

Command Modes	Call Home configuration submode.
----------------------	----------------------------------

Command History	Release	Modification
	1.0(2)	This command was introduced.

Usage Guidelines	None.
-------------------------	-------

Examples	The following example shows how to configure the telephone contact number with the Call Home function.
-----------------	--

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# callhome
switch(config-callhome)# phone-contact +1-800-123-4567
```

Related Commands	Command	Description
	callhome	Configures the Call Home function.
	callhome test	Sends a dummy test message to the configured destination(s).
	show callhome	Displays configured Call Home information.

Send documentation comments to mdsfeedback-doc@cisco.com.

ping

To diagnose basic network connectivity, use the **ping** (packet internet groper) command in EXEC mode.

ping {host-name | system-address}

Syntax Description	<i>host-name</i> Host name of system to ping. Maximum length is 64 characters. <i>system-address</i> Address of system to ping.
---------------------------	--

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines The ping program sends an echo request packet to an address, and then awaits a reply. The ping output can help you evaluate path-to-host reliability, delays over the path, and whether the host can be reached or is functioning.

Verify connectivity to the TFTP server using the **ping** command.

To abnormally terminate a ping session, type the **Ctrl-C** escape sequence

Examples The following example pings system 192.168.7.27.

```
switch# ping 192.168.7.27
PING 192.168.7.27 (192.168.7.27): 56 data bytes
64 bytes from 192.168.7.27: icmp_seq=0 ttl=255 time=0.4 ms
64 bytes from 192.168.7.27: icmp_seq=1 ttl=255 time=0.2 ms
64 bytes from 192.168.7.27: icmp_seq=2 ttl=255 time=0.2 ms
64 bytes from 192.168.7.27: icmp_seq=3 ttl=255 time=0.2 ms

--- 192.168.7.27 ping statistics ---
13 packets transmitted, 13 packets received, 0% packet loss
round-trip min/avg/max = 0.2/0.2/0.4 ms
```

policy

Send documentation comments to mdsfeedback-doc@cisco.com.

policy

To enter IKE policy configuration and configure a policy for the IKE protocol, use the **policy** command in IKE configuration submode. To delete the policy, use the **no** form of the command.

policy priority

no policy priority

Syntax Description	<i>priority</i>	Specifies the priority for the IKE policy. The range is 1 to 255, where 1 is the high priority and 255 is the lowest.
Defaults	None.	
Command Modes	IKE configuration submode.	
Command History	Release	Modification
	2.0(1b)	This command was introduced.
Usage Guidelines	To use this command, the IKE protocol must be enabled using the crypto ike enable command.	
Examples	The following example shows how to configure a policy priority number for the IKE protocol. switch# config terminal switch(config)# crypto ike domain ipsec switch(config-ike-ipsec)# policy 1 switch(config-ike-ipsec-policy)#	
Related Commands	Command	Description
	crypto ike domain ipsec	Enters IKE configuration mode.
	crypto ike enable	Enables the IKE protocol.
	show crypto ike domain ipsec	Displays IKE information for the IPsec domain.

Send documentation comments to mdsfeedback-doc@cisco.com.

port

To assign the TCP port number of a Gigabit Ethernet interface to the FCIP profile or a listener peer port for a iSCSI interface, use the **port** command. Use the **no** form of the command to negate the command or revert to factory defaults.

port *number*

no port *number*

Syntax Description	port <i>number</i>	Configures a peer port. The range is 1 to 65535.										
Defaults	Disabled											
Command Modes	Fcip profile configuration submode Interface configuration submode											
Command History	This command was introduced in Cisco MDS SAN-OS Release 1.1(1).											
Usage Guidelines	Associates the profile with the assigned local port number. If a port number is not assigned for a FCIP profile, the default TCP port 3225 is used.											
Examples	The following example configures port 5000 on FCIP interface 5. <pre>switch# config terminal switch(config)# fcip profile 5 switch(config-profile)# port 5000</pre>											
	The following example configures port 4000 on iSCSI interface 2/1. <pre>switch# config terminal switch(config)# interface iscsi 2/1 switch(config-profile)# port 4000</pre>											
Related Commands	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>show fcip profile</td> <td>Displays information about the FCIP profile.</td> </tr> <tr> <td>interface fcip <i>interface_number</i></td> <td>Configures the interface using an existing profile ID from 1 to 255.</td> </tr> <tr> <td>use-profile <i>profile-id</i></td> <td></td> </tr> <tr> <td>show interface fcip</td> <td>Displays an interface configuration for a specified FCIP interface.</td> </tr> </tbody> </table>		Command	Description	show fcip profile	Displays information about the FCIP profile.	interface fcip <i>interface_number</i>	Configures the interface using an existing profile ID from 1 to 255.	use-profile <i>profile-id</i>		show interface fcip	Displays an interface configuration for a specified FCIP interface.
Command	Description											
show fcip profile	Displays information about the FCIP profile.											
interface fcip <i>interface_number</i>	Configures the interface using an existing profile ID from 1 to 255.											
use-profile <i>profile-id</i>												
show interface fcip	Displays an interface configuration for a specified FCIP interface.											

port-channel persistent

Send documentation comments to mdsfeedback-doc@cisco.com.

port-channel persistent

To convert an autocreated PortChannel to a persistent PortChannel, use the **port-channel persistent** command in EXEC mode.

port-channel *port-channel-id* persistent

Syntax Description	<i>port-channel-id</i>	Specifies the port channel ID. The range is 1 to 128.
---------------------------	------------------------	---

Defaults	None.
-----------------	-------

Command Modes	EXEC mode.
----------------------	------------

Command History	Release	Modification
	2.0(1b)	This command was introduced.

Usage Guidelines	This command is not reversible. A user-created channel group cannot be converted to an autocreated channel group. When the port-channel persistent command is applied to an autocreated channel group, the channel group number does not change and the member ports properties change to those of a user-created channel group. The channel mode remains active.
-------------------------	--

Examples	The following example shows how to change the properties of an autocreated channel group to a persistent channel group.
<pre>switch# port-channel 10 persistent</pre>	

Related Commands	Command	Description
	port-channel protocol	Enables the PortChannel protocol.
	show interface port-channel	Displays PortChannel interface information.
	show port-channel	Displays PortChannel information.

Send documentation comments to mdsfeedback-doc@cisco.com.

port-security

To configure port security features and reject intrusion attempts, use the **port-security** command in configuration mode. Use the **no** form of the command to negate the command or revert to factory defaults.

```

port-security
  {  

    activate vsan vsan-id [force | no-auto-learn] |  

    auto-learn vsan vsan-id |  

    database vsan vsan-id {any-wwn | pwwn wwn | nwwn wwn | swwn wwn} [fwwn wwn |  

    interface {fc slot/port | port-channel number} | swwn wwn [interface {fc slot/port |  

    port-channel number}]]}  

  

no port-security
  {  

    activate vsan vsan-id [force | no-auto-learn] |  

    auto-learn vsan vsan-id |  

    database vsan vsan-id {any-wwn | pwwn wwn | nwwn wwn | swwn wwn} [fwwn wwn |  

    interface {fc slot/port | port-channel number} | swwn wwn [interface {fc slot/port |  

    port-channel number}]]}

```

Syntax Description	activate	Activates a port security database for the specified VSAN and automatically enables auto-learn.
	auto-learn	Enables auto-learning for the specified VSAN.
	database	Enters the port security database configuration mode for the specified VSAN.
	any-wwn	Specifies any WWN to login to the switch.
	nwwn <i>wwn</i>	Specifies the node WWN as the Nx port connection.
	pwwn <i>wwn</i>	Specifies the port WWN as the Nx port connection.
	swwn <i>wwn</i>	Specifies the switch WWN as the xE port connection.
	fwwn <i>wwn</i>	Specifies a fabric WWN login.
	interface	Specifies the device or switch port interface through which each device is connected to the switch.
	fc <i>slot/port</i>	Specifies a Fibre Channel interface by the slot and port.
	port-channel <i>number</i>	Specifies a PortChannel interface. The range is 1 to 128.
	vsan <i>vsan-id</i>	Specifies the VSAN ID. The range is 1 to 4093.
	force	Forces the database activation.
	no-auto-learn	Disables the autolearn feature for the port security database.
Defaults	Disabled.	
Command Modes	Configuration mode.	

port-security

Send documentation comments to mdsfeedback-doc@cisco.com.

Command History	Release	Modification
	1.2(1)	This command was introduced.
	2.0(1b)	Add the optional swwn keyword to the subcommands under the port-security database vsan command.

Usage Guidelines

When you activate the port security feature, the **auto-learn** option is also automatically enabled. You can choose to activate the port-security feature and disable autolearn using the **port-security activate vsan number no-auto-learn** command. In this case, you need to manually populate the port security database by individually securing each port.

If the **auto-learn** option is enabled on a VSAN, you cannot activate the database for that VSAN without the **force** option.

Examples

The following example activates the port security database for the specified VSAN, and automatically enables autolearning.

```
switch# config terminal
switch(config)# port-security activate vsan 1
```

The following example deactivates the port security database for the specified VSAN, and automatically disables auto-learn.

```
switch# config terminal
switch(config)# no port-security activate vsan 1
```

The following example disables the auto-learn feature for the port security database in VSAN 1.

```
switch# config terminal
switch(config)# port-security activate vsan 1 no-auto-learn
```

The following example enables auto-learning so the switch can learn about any device that is allowed to access VSAN 1. These devices are logged in the port security active database.

```
switch# config terminal
switch(config)# port-security auto-learn vsan 1
```

The following example disables auto-learning and stops the switch from learning about new devices accessing the switch. Enforces the database contents based on the devices learnt up to this point.

```
switch# config terminal
switch(config)# no port-security auto-learn vsan 1
```

The following example enters the port security database mode for the specified VSAN.

```
switch# config terminal
switch(config)# port-security database vsan 1
switch(config-port-security) #
```

The following example configures any WWN to login through the specified interfaces.

```
switch(config-port-security) # any-wwn interface fc1/1 - fc1/8
```

The following example configures the specified pWWN to only log in through the specified fWWN.

```
switch(config-port-security) # pwwn 20:11:00:33:11:00:2a:4a fwwn 20:81:00:44:22:00:4a:9e
```

The following example deletes the specified pWWN configured in the previous step.

```
switch(config-port-security) # no pwwn 20:11:00:33:11:00:2a:4a fwwn 20:81:00:44:22:00:4a:9e
```

Send documentation comments to mdsfeedback-doc@cisco.com.

The following example configures the specified pWWN to only log in through the specified sWWN.

```
switch(config-port-security)# pwwn 20:11:00:33:11:00:2a:4a swwn 20:00:00:0c:85:90:3e:80
```

The following example deletes the specified pWWN configured in the previous step.

```
switch(config-port-security)# no pwwn 20:11:00:33:11:00:2a:4a swwn 20:00:00:0c:85:90:3e:80
```

The following example configures the specified nWWN to log in through the specified fWWN.

```
switch(config-port-security)# nwwn 26:33:22:00:55:05:3d:4c fwwn 20:81:00:44:22:00:4a:9e
```

The following example configures the specified pWWN to login through any port on the local switch.

```
switch(config-port-security)# pwwn 20:11:33:11:00:2a:4a:66
```

The following example configures the specified sWWN to only login through PortChannel 5.

```
switch(config-port-security)# swwn 20:01:33:11:00:2a:4a:66 interface port-channel 5
```

The following example configures any WWN to log in through the specified interface.

```
switch(config-port-security)# any-wwn interface fc3/1
```

The following example deletes the wildcard configured in the previous step.

```
switch(config-port-security)# no any-wwn interface fc2/1
```

The following example deletes the port security configuration database from the specified VSAN.

```
switch# config terminal
switch(config)# no port-security database vsan 1
switch(config)#
```

The following example forces the VSAN 1 port security database to activate despite conflicts.

```
switch(config)# port-security activate vsan 1 force
```

Related Commands

Command	Description
show port-security database	Displays configured port security information.

 port-security abort

Send documentation comments to mdsfeedback-doc@cisco.com.

port-security abort

To discard the port security Cisco Fabric Services (CFS) distribution session in progress, use the **port-security abort** command in configuration mode.

port-security abort vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i>	Specifies the VSAN ID. The range is 1 to 4093.
Defaults	None.	
Command Modes	Configuration mode.	
Command History	Release	Modification
	2.0(1b)	This command was introduced.
Usage Guidelines	None.	
Examples	The following example shows how to discard a port security CFS distribution session in progress. switch# config terminal switch(config)# port-security abort vsan 33	
Related Commands	Command	Description
	port-security distribute	Enables CFS distribution for port security.
	show port-security	Displays port security information.

Send documentation comments to mdsfeedback-doc@cisco.com.

port-security commit

To apply the pending configuration pertaining to the port security Cisco Fabric Services (CFS) distribution session in progress in the fabric, use the **port-security commit** command in configuration mode.

port-security commit vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i>	Specifies the VSAN ID. The range is 1 to 4093.
Defaults	None.	
Command Modes	Configuration mode.	
Command History	Release	Modification
	2.0(1b)	This command was introduced.
Usage Guidelines	None.	
Examples	The following example shows how to commit changes to the active port security configuration.	
	<pre>switch# config terminal switch(config)# port-security commit vsan 13</pre>	
Related Commands	Command	Description
	port-security distribute	Enables CFS distribution for port security.
	show port-security	Displays port security information.

port-security database

Send documentation comments to mdsfeedback-doc@cisco.com.

port-security database

To copy the port security database or to view the difference within the port security database, use the **port-security database** command in EXEC mode.

port-security database {copy | diff {active | config}} {vsan vsan-id}

Syntax Description	port-security Activates a port security database for the specified VSAN and automatically enables auto-learn. database Enters the port security database configuration mode for the specified VSAN. copy Copies the active database to the configuration database. diff Provides the difference between the active and configuration port security database. active Writes the active database to the configuration database. config Writes the configuration database to the active database. vsan vsan-id Specifies the VSAN ID. The ranges is 1 to 4093.
---------------------------	--

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.2(1).

Usage Guidelines If the active database is empty, the port-security database is empty.

Use the **port-security database diff active** command to resolve conflicts.

Examples The following example copies the active to the configured database.

```
switch# port-security database copy vsan 1
```

The following example provides the differences between the active database and the configuration database.

```
switch# port-security database diff active vsan 1
```

The following example provides information on the differences between the configuration database and the active database.

```
switch# port-security database diff config vsan 1
```

Send documentation comments to mdsfeedback-doc@cisco.com.

Related Commands	Command	Description
	port-security database	Copies and provides information on the differences within the port security database.
	show port-security database	Displays configured port security information.

port-security distribute

Send documentation comments to mdsfeedback-doc@cisco.com.

port-security distribute

To enable Cisco Fabric Services (CFS) distribution for port security, use the **port-security distribute** command. To disable this feature, use the **no** form of the command.

port-security distribute

no port-security distribute

Syntax Description This command has no other arguments or keywords.

Defaults Disabled.

Command Modes Configuration mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Command History	Release	Modification
	2.0(1b)	This command was introduced.

Usage Guidelines Before distributing the Fibre Channel timer changes to the fabric, the temporary changes to the configuration must be committed to the active configuration using the **port-security commit** command.

Examples The following example shows how to distribute the port security configuration to the fabric.

```
switch# config terminal
switch(config)# port-security distribute
```

Related Commands	Command	Description
	port-security commit	Commits the port security configuration changes to the active configuration.
	show port-security	Displays port security information.

Send documentation comments to mdsfeedback-doc@cisco.com.

port-security enable

To enable port security, use the **port-security enable** command in configuration mode. To disable port security, use the **no** form of the command.

port-security enable

no port-security enable

Syntax Description This command has no other arguments or keywords.

Defaults Disabled.

Command Modes Configuration mode.

Command History	Release	Modification
	2.0(1b)	This command was introduced.

Usage Guidelines Issuing the **port-security enable** command enables the other commands used to configure port security.

Examples The following example shows how to enable port security.

```
switch# config terminal
switch(config)# port-security enable
```

The following example shows how to disable port security.

```
switch# config terminal
switch(config)# no port-security enable
```

Related Commands	Command	Description
	show port-security	Displays port security information.

port-track enable

Send documentation comments to mdsfeedback-doc@cisco.com.

port-track enable

To enable port tracking for indirect errors, use the **port-track enable** command in configuration mode. To disable this feature, use the **no** form of the command.

port-track enable

no port-track enable

Syntax Description This command has no other arguments or keywords.

Defaults Disabled.

Command Modes Configuration mode.

Command History	Release	Modification
	2.0(1b)	This command was introduced.

Usage Guidelines The software brings the linked port down when the tracked port goes down. When the tracked port recovers from the failure and comes back up again, the tracked port is also brought up automatically (unless otherwise configured).

Examples The following example shows how to enable port tracking.

```
switch# config terminal
switch(config)# port-track enable
```

The following example shows how to disable port tracking.

```
switch# config terminal
switch(config)# no port-track enable
```

Related Commands	Command	Description
	show interface fc	Displays configuration and status information for a specified Fibre Channel interface.
	show interface port-channel	Displays configuration and status information for a specified PortChannel interface.

Send documentation comments to mdsfeedback-doc@cisco.com.

port-track force-shut

To force a shutdown of a tracked port, use the **port-track force-shut** command in interface configuration submode. To reenable the port tracking, use the **no** form of the command.

port-track force-shut

no port-track force-shut

Syntax Description This command has no other arguments or keywords.

Defaults None.

Command Modes Interface configuration submode.

Command History	Release	Modification
	2.0(1b)	This command was introduced.

Usage Guidelines Use the **port-track force-shut** to keep the linked port down, even though the tracked port comes back up. You must explicitly bring the port up when required using the **no port-track force-shut** command.

Examples The following example shows how to force the shutdown of an interface and the interfaces that it is tracking.

```
switch# config terminal
switch(config)# interface fc 1/2
switch(config-if)# oport-track force-shut
```

Related Commands	Command	Description
	port-track enable	Enables port tracking.
	show interface fc	Displays configuration and status information for a specified Fibre Channel interface.
	show interface port-channel	Displays configuration and status information for a specified PortChannel interface.

port-track interface

Send documentation comments to mdsfeedback-doc@cisco.com.

port-track interface

To enable port tracking for specific interfaces, use the **port-track interface** command in interface configuration submode. To disable this feature, use the **no** form of the command.

```
port-track interface {fc slot/port | fcip port | gigabitethernet slot/port | port-channel port}
[vsan vsan-id]
```

```
no port-track interface {fc slot/port | fcip port | gigabitethernet slot/port | port-channel port}
[vsan vsan-id]
```

Syntax Description	
fc slot/port	Specifies a Fibre Channel interface.
fcip port	Specifies a FCIP interface.
gigabitethernet slot/port	Specifies a Gigabit Ethernet interface.
port-channel port	Specifies a PortChannel interface. The range is 1 to 128.
vsan vsan-id	Specifies a VSAN ID. The range is 1 to 4093.

Defaults	None.
-----------------	-------

Command Modes	Interface configuration submode.
----------------------	----------------------------------

Command History	Release	Modification
	2.0(1b)	This command was introduced.

Usage Guidelines	When the ports that an interface is tracking goes down, the interface also goes down. When the tracked port comes backup, the linked interface also comes back up. Use the port-track force-shut command to keep the linked interface down.
-------------------------	--

Examples	The following example shows how to enable port tracking for specific interfaces.
-----------------	--

```
switch# config terminal
switch(config)# interface fc 1/2
switch(config-if)# port-track interface port-channel 2
switch(config-if)# port-track interface fcip 5
```

Related Commands	Command	Description
	port-track enable	Enables port tracking.
	port-track force-shut	Forcefully shuts an interface for port tracking.

Send documentation comments to mdsfeedback-doc@cisco.com.

Command	Description
show interface fc	Displays configuration and status information for a specified Fibre Channel interface.
show interface port-channel	Displays configuration and status information for a specified PortChannel interface.

portaddress

Send documentation comments to mdsfeedback-doc@cisco.com.

portaddress

To enable the FICON feature in a specified VSAN, use the **ficon vsan** command in configuration mode. To disable the feature or to revert to factory defaults, use the **no** form of the command.

```
portaddress portaddress
  block
  name string
  prohibit portaddress portaddress

portaddress portaddress
  no block
  no name string
  no prohibit portaddress portaddress
```

Syntax Description	<p>portnumber Specifies the FICON port number for this interface. The range is 0 to 254.</p> <p>block Blocks a port address.</p> <p>name string Configures a name for the port address. Maximum length is 24 characters.</p> <p>prohibit portaddress Prohibit communication with a portaddress.</p>
---------------------------	---

Defaults None.

Command Modes FICON configuration submode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

Usage Guidelines The **shutdown/no shutdown** port state is independent of the **block/no block** port state. If a port is shutdown, unblocking that port will not initialize the port.
You cannot block or prohibit CUP port (0XFE).
If you prohibit ports, the specified ports are prevented from communicating with each other. Unimplemented ports are always prohibited.

Examples The following example disables a port address and retains it in the operationally down state.

```
switch# config terminal
switch(config)# ficon vsan 2
switch(config-ficon)# portaddress 1
switch(config-ficon-portaddr)# block
```

Send documentation comments to mdsfeedback-doc@cisco.com.

The following example enables the selected port address and reverts to the factory default of the port address not being blocked.

```
switch(config-ficon-portaddr)# no block
```

The following example prohibits port address 1 in VSAN 2 from talking to ports 3.

```
switch(config-ficon-portaddr)# prohibit portaddress 3
```

The following example removes port address 5 from a previously-prohibited state.

```
switch(config-ficon-portaddr)# no prohibit portaddress 5
```

The following example assigns a name to the port address.

```
switch(config-ficon-portaddr)# name SampleName
```

The following example deletes a previously configured port address name.

```
switch(config-ficon-portaddr)# no name SampleName
```

Related Commands

Command	Description
show ficon	Displays configured FICON details.

 power redundancy-mode

Send documentation comments to mdsfeedback-doc@cisco.com.

power redundancy-mode

To configure the capacity of the power supplies on the Cisco MDS 9500 Family of switches, use the **power redundancy-mode** command in configuration mode. Use the **no** form of the command to negate the command or revert to factory defaults.

power redundancy-mode {combined [force] | redundant}

no power redundancy-mode {combined [force] | redundant}

Syntax Description	combined Configures power supply redundancy mode as combined. force Forces combined mode without prompting. redundant Configures power supply redundancy mode as redundant.
---------------------------	--

Defaults	Redundant mode.
-----------------	-----------------

Command Modes	Configuration mode
----------------------	--------------------

Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).
------------------------	---

Usage Guidelines	<ul style="list-style-type: none"> If power supplies with different capacities are installed in the switch, the total power available differs based on the configured mode: In redundant mode, the total power is the lesser of the two power supply capacities. This reserves enough power to keep the system powered on in case of a power supply failure. This is the recommended or default mode. In combined mode, the total power is twice the lesser of the two power supply capacities. In case of a power supply failure, the entire system could be shut down, depending on the power usage at that time. When a new power supply is installed, the switch automatically detects the power supply capacity. If the new power supply has a capacity that is lower than the current power usage in the switch and the power supplies are configured in redundant mode, the new power supply will be shut down. When you change the configuration from combined to redundant mode and the system detects a power supply that has a capacity lower than the current usage, the power supply is shut down. If both power supplies have a lower capacity than the current system usage, the configuration is not allowed.
-------------------------	--

Examples	The following examples demonstrate how the power supply redundancy mode could be set.
-----------------	---

```
switch(config)# power redundancy-mode combined
WARNING: This mode can cause service disruptions in case of a power supply failure.
Proceed ? [y/n] y
switch(config)# power redundancy-mode redundant
```

Send documentation comments to mdsfeedback-doc@cisco.com.

Related Commands	Command	Description
	show environment power	Displays status of power supply modules, power supply redundancy mode, and power usage summary.
	copy running-config startup-config	Copies all running configuration to the startup configuration.

poweroff module

Send documentation comments to mdsfeedback-doc@cisco.com.

poweroff module

To power off individual modules in the system, use the **poweroff module** command in configuration mode. Use the **no** form of this command to power up the specified module.

poweroff module *slot*

no poweroff module *slot*

Syntax Description	<i>slot</i> Specifies the slot number for the module.						
Defaults	None.						
Command Modes	Configuration mode.						
Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).						
Usage Guidelines	Use the poweroff module command to power off individual modules. The poweroff module command cannot be used to power off supervisor modules.						
Examples	The following example powers off and powers up module 1. <pre>switch# config terminal switch(config)# poweroff module 1 switch(config)# switch(config)# no poweroff module 1 switch(config)# </pre>						
Related Commands	<table border="1"> <thead> <tr> <th>Command</th><th>Description</th></tr> </thead> <tbody> <tr> <td>show module</td><td>Displays information for a specified module.</td></tr> <tr> <td>copy running-config startup-config</td><td>Copies all running configuration to the startup configuration.</td></tr> </tbody> </table>	Command	Description	show module	Displays information for a specified module.	copy running-config startup-config	Copies all running configuration to the startup configuration.
Command	Description						
show module	Displays information for a specified module.						
copy running-config startup-config	Copies all running configuration to the startup configuration.						

Send documentation comments to mdsfeedback-doc@cisco.com.

priority

To configure the priority in a QoS policy map class, use the **priority** command in QoS policy class map configuration submode. To disable this feature, use the **no** form of the command.

priority {high | low | medium}

no priority {high | low | medium}

Syntax Description	high Configures the frames matching the class-map as high priority.
	low Configures the frames matching the class-map as low priority. The default.
	medium Configures the frames matching the class-map as medium priority.

Defaults The default priority is low.

Command Modes QoS policy map class configuration submode.

Command History	Release	Modification
	1.3(1)	This command was introduced.

Usage Guidelines Before you can configure the priority in a QoS policy map class you must first:

- Enable the QoS data traffic feature using the **qos enable** command.
- Configure a QoS class map using the **qos class-map** command.
- Configure a QoS policy map using the **qos policy-map** command.
- Configure a QoS policy map class using the **class** command.

Examples The following example shows how to select the QoS policy class-map1 and configure the frame priority as high.

```
switch(config-pmap)# class class-map1
switch(config-pmap-c)# priority high
Operation in progress. Please check class-map parameters
switch(config-pmap-c)#

```

Related Commands	Command	Description
	qos enable	Enables the QoS data traffic feature on the switch.
	qos class-map	Configures a QoS class map.
	qos policy-map	Configure a QoS policy map.

■ priority

Send documentation comments to mdsfeedback-doc@cisco.com.

Command	Description
class	Configure a QoS policy map class.
show qos	Displays the current QoS settings.

Send documentation comments to mdsfeedback-doc@cisco.com.

purge fcdomain fcid

To purge persistent FCIDs, use the **purge fcdomain fcid** command in EXEC mode.

purge fcdomain fcid vsan *vsan-id*

Syntax Description	vsan <i>vsan-id</i>	Indicates that FCIDs are to be purged for a VSAN ID. The range is 1 to 4093.
Defaults	None.	
Command Modes	EXEC mode.	
Command History	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).	
Usage Guidelines	None.	
Examples	<p>The following example shows how to purge all dynamic, unused FCIDs in VSAN 4</p> <pre>switch# purge fcdomain fcid vsan 4 switch#</pre> <p>The following example shows how to purge all dynamic, unused FCIDs in VSANs 4, 5, and 6.</p> <pre>switch# purge fcdomain fcid vsan 3-5 switch#</pre>	

■ purge module

Send documentation comments to mdsfeedback-doc@cisco.com.

purge module

To delete configurations in the running configuration for nonexistent modules, use the **purge module** command in EXEC mode.

purge module *slot* running-config

Syntax Description	<table border="0"> <tr> <td><i>slot</i></td><td>Specifies the module slot number.</td></tr> <tr> <td>running-config</td><td>Purges the running configuration from the specified module.</td></tr> </table>	<i>slot</i>	Specifies the module slot number.	running-config	Purges the running configuration from the specified module.
<i>slot</i>	Specifies the module slot number.				
running-config	Purges the running configuration from the specified module.				

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.1(1).

Usage Guidelines This command cannot be issued on a supervisor module.

Examples The following example displays the output of the **purge module** command issued on the module in slot 8.

```
switch# purge module 8 running-config
switch#
```

Send documentation comments to mdsfeedback-doc@cisco.com.

pwd

To display the current directory location, use the **pwd** command in EXEC mode.

pwd

Syntax Description This command has no keywords or arguments.

Defaults None.

Command Modes EXEC mode.

Command History This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

Usage Guidelines None.

Examples The following example changes the directory and displays the current directory.

```
switch# cd bootflash:logs
switch# pwd
bootflash:/logs
```

Related Commands

Command	Description
cd	Changes the current directory to the specified directory.
dir	Displays the contents of a directory.

pwwn (DPVM database configuration submode)

Send documentation comments to mdsfeedback-doc@cisco.com.

pwwn (DPVM database configuration submode)

To add a device to a dynamic port VSAN membership (DPVM) database using the pWWN, use the **pwwn** command in DPVM database configuration submode. To remove a device from a DPVM database using the pWWN, use the **no** form of the command.

pwwn pwwn-id vsan vsan-id

no pwwn pwwn-id vsan vsan-id

Syntax Description	<p>pwwn-id Specifies the port WWN ID. The format is <i>hh:hh:hh:hh:hh:hh:hh</i>, where <i>h</i> is a hexadecimal number.</p> <p>vsan vsan-id Specifies the VSAN ID. The range is 1 to 4093.</p>
---------------------------	---

Defaults	None.
-----------------	-------

Command Modes	DPVM database configuration submode.
----------------------	--------------------------------------

Command History	Release	Modification
	2.0(1b)	This command was introduced.

Usage Guidelines	To use this command, DPVM must be enabled using the dpvm enable command.
-------------------------	---

Examples	The following example shows how to add an entry to the DPVM database.
-----------------	---

```
switch# config terminal
switch(config)# dpvm database
switch(config-dpvm-db)# pwwn 11:22:33:44:55:66:77:88 vsan 1
```

The following example shows how to delete an entry from the DPVM database.

```
switch(config-dpvm-db)# no pwwn 11:22:33:44:55:66:77:88 vsan 1
```

Related Commands	Command	Description
	dpvm database	Configures the DPVM database.
	show dpvm	Displays DPVM database information.

Send documentation comments to mdsfeedback-doc@cisco.com.

pwwn (fcdomain database configuration submode)

To map a pWWN to a persistent FC ID for IVR, use the **pwwn** command in IVR fcdomain database configuration submode. To remove the mapping for the pWWN, use the **no** form of the command.

pwwn pwwn-id fc-id

no pwwn pwwn-id

Syntax Description	<p>pwwn-id Specifies the pWWN ID. The format is <i>hh:hh:hh:hh:hh:hh:hh:hh</i>, where <i>h</i> is a hexadecimal number.</p> <p>fc-id Specifies the FC ID of the device.</p>
---------------------------	---

Defaults	None.
-----------------	-------

Command Modes	fcdomain database configuration submode.
----------------------	--

Command History	Release	Modification
	2.1(2)	This command was introduced.

Usage Guidelines	Only one FC ID can be mapped to a pWWN.
-------------------------	---

Examples	The following example shows how to map the pWWN to the persistent FC ID.
-----------------	--

```
switch# config t
switch(config)# ivr fcdomain database autonomous-fabric-num 10 vsan 20
switch(config-fcdomain)# native-autonomous-fabric-num 20 native-vsanc 30 domain 15
switch(config-fcdomain-fcid)# pwwn 11:22:33:44:55:66:77:88 0x123456
```

The following example shows how to remove the mapping between the pWWN and the FC ID.

```
switch# config t
switch(config)# ivr fcdomain database autonomous-fabric-num 10 vsan 20
switch(config-fcdomain)# native-autonomous-fabric-num 20 native-vsanc 30 domain 15
switch(config-fcdomain-fcid)# no pwwn 11:22:33:44:55:66:77:88
```

Related Commands	Command	Description
	ivr fcdomain database autonomous-fabric-num	Creates IVR persistent FC IDs.
	native-autonomous-fabric-num	Creates an IVR persistent FC ID database entry.
	show ivr fcdomain database	Displays IVR fcdomain database entry information.

■ pwwn (fcdomain database configuration submode)

Send documentation comments to mdsfeedback-doc@cisco.com.