

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

**CHAPTER 22**

## **T Commands**

---

The commands in this chapter apply to the Cisco MDS 9000 Family of multilayer directors and fabric switches. All commands are shown here in alphabetical order regardless of command mode. See the “Command Modes” section to determine the appropriate mode for each command. For more information, refer to the *Cisco MDS 9000 Family Configuration Guide*.

**tacacs+ abort**

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tacacs+ abort

To discard a TACACS+ Cisco Fabric Services (CFS) distribution session in progress, use the **tacacs+ abort** command in configuration mode.

**tacacs+ abort**

**Syntax Description** This command has no other arguments or keywords.

**Defaults** None.

**Command Modes** Configuration mode.

Command History	Release	Modification
	2.0(1b)	This command was introduced.

**Usage Guidelines** To use this command, TACACS+ must be enabled using the **tacacs+ enable** command.

**Examples** The following example shows how to discard a TACACS+ CFS distribution session in progress.

```
switch# config terminal
switch(config)# tacacs+ abort
```

Related Commands	Command	Description
	<b>show tacacs+</b>	Displays TACACS+ CFS distribution status and other details.
	<b>tacacs+ distribute</b>	Enables CFS distribution for TACACS+.
	<b>tacacs+ enable</b>	Enables TACACS+.

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tacacs+ commit

To apply the pending configuration pertaining to the TACACS+ Cisco Fabric Services (CFS) distribution session in progress in the fabric, use the **tacacs+ commit** command in configuration mode.

**tacacs+ commit**

**Syntax Description** This command has no other arguments or keywords.

**Defaults** None.

**Command Modes** Configuration mode.

Command History	Release	Modification
	2.0(1b)	This command was introduced.

**Usage Guidelines** To use this command, TACACS+ must be enabled using the **tacacs+ enable** command.

**Examples** The following example shows how to apply a TACACS+ configuration to the switches in the fabric.

```
switch# config terminal
switch(config)# tacacs+ commit
```

Related Commands	Command	Description
	<b>show tacacs+</b>	Displays TACACS+ CFS distribution status and other details.
	<b>tacacs+ enable</b>	Enables TACACS+.
	<b>tacacs+ distribute</b>	Enables CFS distribution for TACACS+.

■ tacacs+ distribute

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tacacs+ distribute

To enable Cisco Fabric Services (CFS) distribution for TACACS+, use the **tacacs+ distribute** command. To disable this feature, use the **no** form of the command.

**tacacs+ distribute**

**no tacacs+ distribute**

---

**Syntax Description** This command has no other arguments or keywords.

---

**Defaults** Disabled.

---

**Command Modes** Configuration mode.

---

Command History	Release	Modification
	2.0(1b)	This command was introduced.

---

**Usage Guidelines** To use this command, TACACS+ must be enabled using the **tacacs+ enable** command.

---

**Examples** The following example shows how to enable TACACS+ fabric distribution.

```
switch# config terminal
switch(config)# tacacs+ distribute
```

---

Related Commands	Command	Description
	<b>show tacacs+</b>	Displays TACACS+ CFS distribution status and other details.
	<b>tacacs+ commit</b>	Commits TACACS+ database changes to the fabric.
	<b>tacacs+ enable</b>	Enables TACACS+.

---

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tacacs+ enable

To enable TACACS+ in a switch, use the **tacacs+ enable** command in configuration mode. To disable this feature, use the **no** form of the command.

**tacacs+ enable**

**no tacacs+ enable**

**Syntax Description** This command has no arguments or keywords.

**Defaults** None.

**Command Modes** Configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** Further TACACS+ commands are only available when the TACACS+ feature is enabled. Using SHA-1 as the hash algorithm may prevent RADIUS or TACACS+ usage.

**Examples**

```
switch# config terminal
switch(config)# tacacs+ enable
```

Related Commands	Command	Description
	<b>show tacacs-server</b>	Displays TACACS+ server information.

■ tacacs-server host

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tacacs-server host

To configure TACACS+ server options on a switch, use the **tacacs-server host** command in configuration mode. Use the **no** form of the command to revert to factory defaults.

```
tacacs-server host {server-name | ip-address}
  [key [0|7] shared-secret] [port port-number] [timeout seconds]

no tacacs-server host {server-name | ip-address}
  [key [0|7] shared-secret] [port port-number] [timeout seconds]
```

Syntax Description	
<i>server-name</i>	Enters TACACS+ server DNS name. The maximum character size is 256.
<i>ip-address</i>	Enters TACACS+ server IP address.
<b>key</b>	TACACS+ server's shared secret.
<b>0</b>	Configures a preshared key specified in clear text (indicated by 0) to authenticate communication between the TACACS+ client and server. This is the default.
<b>7</b>	Configures a preshared key specified in encrypted text (indicated by 7) to authenticate communication between the TACACS+ client and server.
<i>shared secret</i>	Configures a preshared key to authenticate communication between the TACACS+ client and server.
<b>port port-number</b>	TACACS+ server port for authentication. The range is 1 to 65535.
<b>timeout</b>	TACACS+ server timeout period in seconds.
<b>seconds</b>	Specifies the time (in seconds) between retransmissions to the TACACS+ server. The range is 1 to 60 seconds.

**Defaults** Timeout: 1 second.

**Command Modes** Configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.3(1).

**Usage Guidelines** This command is only available when the TACACS+ feature is enabled using the **tacacs+ enable** command.

**Examples** The following example configures TACACS+ authentication.

```
switch# config terminal
switch(config)# tacacs-server host 10.10.2.3 key HostKey
switch(config)# tacacs-server host tacacs2 key 0 abcd
switch(config)# tacacs-server host tacacs3 key 7 1234
```

***Send documentation comments to mdsfeedback-doc@cisco.com.***

Related Commands	Command	Description
	show tacacs-server	Displays TACACS+ server information.
	tacacs+ enable	Enable TACACS+.

■ tacacs-server key

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tacacs-server key

To configure a global TACACS+ shared secret, use the **tacacs-server key** command. Use the **no** form of this command to removed a configured shared secret.

**tacacs-server key [0 | 7] shared-secret**

**no tacacs-server key [0 | 7] shared-secret**

Syntax Description	<b>key</b> Global TACACS+ shared secret. <b>0</b> Configures a preshared key specified in clear text (indicated by 0) to authenticate communication between the TACACS+ client and server. This is the default. <b>7</b> Configures a preshared key specified in encrypted text (indicated by 7) to authenticate communication between the TACACS+ client and server. <b>shared-secret</b> Configures a preshared key to authenticate communication between the TACACS+ client and server.
<b>Defaults</b>	None.
<b>Command Modes</b>	Configuration mode.
<b>Command History</b>	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).
<b>Usage Guidelines</b>	You need to configure the TACACS+ preshared key to authenticate the switch to the TACACS+ server. The length of the key is restricted to 65 characters and can include any printable ASCII characters (white spaces are not allowed). You can configure a global key to be used for all TACACS+ server configurations on the switch. You can override this global key assignment by explicitly using the <b>key</b> option in the <b>tacacs-server host</b> command.  This command is only available when the TACACS+ feature is enabled using the <b>tacacs+ enable</b> command.
<b>Examples</b>	The following example configures TACACS+ server shared keys.  <pre>switch# config terminal switch(config)# tacacs-server key AnyWord switch(config)# tacacs-server key 0 AnyWord switch(config)# tacacs-server key 7 public</pre>

***Send documentation comments to mdsfeedback-doc@cisco.com.***

Related Commands	Command	Description
	show tacacs-server	Displays TACACS+ server information.
	tacacs+ enable	Enable TACACS+.

**tacacs-server timeout**

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tacacs-server timeout

To specify the time between retransmissions to the TACACS+ servers, use the **tacacs-server timeout** command. You can revert the retransmission time to its default by issuing the **no** form of the command.

**tacacs-server timeout *seconds***

**notacacs-server timeout *seconds***

<b>Syntax Description</b>	<b>seconds</b> Specifies the time (in seconds) between retransmissions to the RADIUS server. The default is one (1) second and the valid range is 1 to 60 seconds.						
<b>Defaults</b>	None.						
<b>Command Modes</b>	Configuration mode.						
<b>Command History</b>	This command was introduced in Cisco MDS SAN-OS Release 1.3(2).						
<b>Usage Guidelines</b>	This command is only available when the TACACS+ feature is enabled using the <b>tacacs+ enable</b> command.						
<b>Examples</b>	The following example configures the TACACS+ server timeout value.  <pre>switch# config terminal switch(config)# tacacs-server timeout 30</pre>						
<b>Related Commands</b>	<table border="1"> <thead> <tr> <th><b>Command</b></th> <th><b>Description</b></th> </tr> </thead> <tbody> <tr> <td><b>show tacacs-server</b></td> <td>Displays TACACS+ server information.</td> </tr> <tr> <td><b>tacacs+ enable</b></td> <td>Enable TACACS+.</td> </tr> </tbody> </table>	<b>Command</b>	<b>Description</b>	<b>show tacacs-server</b>	Displays TACACS+ server information.	<b>tacacs+ enable</b>	Enable TACACS+.
<b>Command</b>	<b>Description</b>						
<b>show tacacs-server</b>	Displays TACACS+ server information.						
<b>tacacs+ enable</b>	Enable TACACS+.						

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tail

To display the last lines (tail end) of a specified file, use the **tail** command in EXEC mode.

**tail** *filename* [*number-of-lines*]

<b>Syntax Description</b>	<table border="0"> <tr> <td><i>filename</i></td><td>The name of the file for which you want to view the last lines.</td></tr> <tr> <td><i>number-of-lines</i></td><td>(Optional) The number of lines you want to view. The range is 0 to 80 lines.</td></tr> </table>	<i>filename</i>	The name of the file for which you want to view the last lines.	<i>number-of-lines</i>	(Optional) The number of lines you want to view. The range is 0 to 80 lines.
<i>filename</i>	The name of the file for which you want to view the last lines.				
<i>number-of-lines</i>	(Optional) The number of lines you want to view. The range is 0 to 80 lines.				

**Defaults** Displays the last 10 lines.

**Command Modes** EXEC mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

**Usage Guidelines** You need two separate CLI terminals to use this command. In one terminal, execute the run-script or any other desired command. In the other, issue the **tail** command for the mylog file. On the second terminal session, you will see the last lines of the mylog file (as it grows) that is being saved in response to the command issued in the first terminal.

If you specify a long file and would like to exit in the middle, enter **Ctrl-c** to exit this command.

**Examples** The following example displays the last lines (tail end) of a specified file.

```
switch# run-script slot0:test mylog
```

In another terminal, issue the **tail** command for the mylog file.

```
switch# tail mylog
config terminal
```

In the second CLI terminal, you see the last lines of the mylog file (as it grows) that is being saved in response to the command issued in the first terminal.

tcp cwm

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tcp cwm

To configure congestion window monitoring (CWM) TCP parameters, use the **tcp cwm** command. Use the **no** form of this command to disable this feature or revert to its factory defaults.

**tcp cwm [burstsize *size*]**

**no tcp cwm [burstsize *size*]**

<b>Syntax Description</b>	<b>burstsize <i>size</i></b> Specifies the burstsize ranging from 10 to 100 KB.						
<b>Defaults</b>	Enabled. The default FCIP burst size is 10 KB. The default iSCSI burst size is 50 KB						
<b>Command Modes</b>	FCIP profile configuration submode.						
<b>Command History</b>	This command was introduced in Cisco MDS SAN-OS Release 1.3(4).						
<b>Usage Guidelines</b>	Use these TCP parameters to control TCP retransmission behavior in a switch.						
<b>Examples</b>	<p>The following example configures a FCIP profile and enables congestion monitoring.</p> <pre>switch# config terminal switch(config)# fcip profile 5 switch(config-profile)# tcp cwm</pre> <p>The following example assigns the burstsize value at 20 KB:</p> <pre>switch(config-profile)# tcp cwm burstsize 20</pre> <p>The following example disables congestion monitoring.</p> <pre>switch(config-profile)# no tcp cwm</pre> <p>The following example leaves the CWM feature in an enabled state but changes the burstsize to the default of 10 KB.</p> <pre>switch(config-profile)# no tcp cwm burstsize 25</pre>						
<b>Related Commands</b>	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td><b>fcip profile</b></td> <td>Configures FCIP profile parameters.</td> </tr> <tr> <td><b>show fcip profile</b></td> <td>Displays FCIP profile information.</td> </tr> </tbody> </table>	Command	Description	<b>fcip profile</b>	Configures FCIP profile parameters.	<b>show fcip profile</b>	Displays FCIP profile information.
Command	Description						
<b>fcip profile</b>	Configures FCIP profile parameters.						
<b>show fcip profile</b>	Displays FCIP profile information.						

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tcp keepalive-timeout

To configure the interval between which the TCP connection verifies if the FCIP link is functioning, use the **tcp keepalive-timeout** command. Use the **no** form of this command to disable this feature or revert to its factory defaults.

**tcp keepalive-timeout** *seconds*

**no tcp keepalive-timeout** *seconds*

<b>Syntax Description</b>	<i>seconds</i> Specifies the time in seconds. The range is 1 to 7200.						
<b>Defaults</b>	60 seconds.						
<b>Command Modes</b>	FCIP profile configuration submode.						
<b>Command History</b>	This command was introduced in Cisco MDS SAN-OS Release 1.1(1).						
<b>Usage Guidelines</b>	This command can be used to detect FCIP link failures.						
<b>Examples</b>	The following example configures a FCIP profile:  <pre>switch# config terminal switch(config)# fcip profile 5 switch(config-profile)# </pre> The following example specifies the keepalive timeout interval for the TCP connection:  <pre>switch(config-profile)# tcp keepalive-timeout 120</pre>						
<b>Related Commands</b>	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td><b>fcip profile</b></td> <td>Configures FCIP profile parameters.</td> </tr> <tr> <td><b>show fcip profile</b></td> <td>Displays FCIP profile information.</td> </tr> </tbody> </table>	Command	Description	<b>fcip profile</b>	Configures FCIP profile parameters.	<b>show fcip profile</b>	Displays FCIP profile information.
Command	Description						
<b>fcip profile</b>	Configures FCIP profile parameters.						
<b>show fcip profile</b>	Displays FCIP profile information.						

---

tcp maximum-bandwidth-kbps

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tcp maximum-bandwidth-kbps

To manage the TCP window size in Kbps, use the **tcp maximum-bandwidth-kbps** command. Use the **no** form of this command to disable this feature or revert to its factory defaults.

```
tcp max-bandwidth-kbps bandwidth min-available-bandwidth-kbps threshold
    {round-trip-time-ms milliseconds | round-trip-time-us microseconds}
```

```
no tcp max-bandwidth-kbps bandwidth min-available-bandwidth-kbps threshold
    {round-trip-time-ms milliseconds | round-trip-time-us microseconds}
```

Syntax Description	
<b>bandwidth</b>	Specifies the Kbps bandwidth. The range is 1000 to 1000000.
<b>min-available-bandwidth-kbps</b>	Configures the minimum slow start threshold.
<b>threshold</b>	Specifies the Kbps threshold. The range is 1000 to 1000000.
<b>round-trip-time-ms milliseconds</b>	Configures the estimated round trip time across the IP network to reach the FCIP peer end point in milliseconds. The range is 0 to 300.
<b>round-trip-time-us microseconds</b>	Configures the estimated round trip time across the IP network to reach the FCIP peer end point in microseconds. The range is 0 to 300000.

---

### Defaults

Enabled.

The FCIP defaults are **max-bandwidth** = 1G, **min-available-bandwidth** = 500 Kbps, and **round-trip-time** = 1 ms.

The iSCSI defaults are **max-bandwidth** = 1G, **min-available-bandwidth** = 70 Kbps, and **round-trip-time** = 1 ms.

---

### Command Modes

FCIP profile configuration submode.

---

### Command History

This command was introduced in Cisco MDS SAN-OS Release 1.1(1).

---

### Usage Guidelines

The **maximum-bandwidth** option and the **round-trip-time** option together determine the window size. The **minimum-available-bandwidth** option and the **round-trip-time** option together determine the threshold below which TCP aggressively increases its size. After it reaches the threshold the software uses standard TCP rules to reach the maximum available bandwidth.

---

### Examples

The following example configures a FCIP profile:

```
switch# config terminal
switch(config)# fcip profile 5
switch(config-profile)#

```

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

The following example configures the maximum available bandwidth at 900 Kbps, the minimum slow start threshold as 300 Kbps, and the round trip time as 10 milliseconds:

```
switch(config-profile)# tcp max-bandwidth-kbps 900 min-available-bandwidth-kbps 300
round-trip-time-ms 10
```

The following example reverts to the factory defaults:

```
switch(config-profile)# no tcp max-bandwidth-kbps 900 min-available-bandwidth-kbps 300
round-trip-time-ms 10
```

The following example configures the maximum available bandwidth at 2000 Kbps, the minimum slow start threshold as 2000 Kbps, and the round trip time as 200 microseconds:

```
switch(config-profile)# tcp max-bandwidth-kbps 2000 min-available-bandwidth-kbps 2000
round-trip-time-us 200
```

#### Related Commands

Command	Description
<b>fcip profile</b>	Configures FCIP profile parameters.
<b>show fcip profile</b>	Displays FCIP profile information.

---

tcp maximum-bandwidth-mbps

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tcp maximum-bandwidth-mbps

To manage the TCP window size in Mbps, use the **tcp maximum-bandwidth-mbps** command. Use the **no** form of this command to disable this feature or revert to its factory defaults.

```
tcp max-bandwidth-mbps bandwidth min-available-bandwidth-mbps threshold
  {round-trip-time-ms milliseconds | round-trip-time-us microseconds}
```

```
no tcp max-bandwidth-mbps bandwidth min-available-bandwidth-mbps threshold
  {round-trip-time-ms milliseconds | round-trip-time-us microseconds}
```

Syntax Description	
<b>bandwidth</b>	Specifies the Mbps bandwidth. The range is 1 to 1000.
<b>min-available-bandwidth-mbps</b>	Configures the minimum slow start threshold.
<b>threshold</b>	Specifies the Mbps threshold. The range is 1 to 1000.
<b>round-trip-time-ms milliseconds</b>	Configures the estimated round trip time across the IP network to reach the FCIP peer end point in milliseconds. The range is 0 to 300.
<b>round-trip-time-us microseconds</b>	Configures the estimated round trip time across the IP network to reach the FCIP peer end point in microseconds. The range is 0 to 300000.

---

### Defaults

Enabled.

The FCIP defaults are **max-bandwidth** = 1G, **min-available-bandwidth** = 500 Kbps, and **round-trip-time** = 1 ms.

The iSCSI defaults are **max-bandwidth** = 1G, **min-available-bandwidth** = 70 Kbps, and **round-trip-time** = 1 ms.

---

### Command Modes

FCIP profile configuration submode.

---

### Command History

This command was introduced in Cisco MDS SAN-OS Release 1.1(1).

---

### Usage Guidelines

The **maximum-bandwidth** option and the **round-trip-time** option together determine the window size. The **minimum-available-bandwidth** option and the **round-trip-time** option together determine the threshold below which TCP aggressively increases its size. After it reaches the threshold the software uses standard TCP rules to reach the maximum available bandwidth.

---

### Examples

The following example configures a FCIP profile:

```
switch# config terminal
switch(config)# fcip profile 5
switch(config-profile)#

```

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

The following example configures the maximum available bandwidth at 900 Mbps, the minimum slow start threshold as 300 Mbps, and the round trip time as 10 milliseconds:

```
switch(config-profile)# tcp max-bandwidth-mbps 900 min-available-bandwidth-mbps 300
round-trip-time-ms 10
```

The following example reverts to the factory defaults:

```
switch(config-profile)# no tcp max-bandwidth-mbps 900 min-available-bandwidth-mbps 300
round-trip-time-ms 10
```

The following example configures the maximum available bandwidth at 2000 Mbps, the minimum slow start threshold as 2000 Mbps, and the round trip time as 200 microseconds:

```
switch(config-profile)# tcp max-bandwidth-mbps 2000 min-available-bandwidth-mbps 2000
round-trip-time-us 200
```

#### Related Commands

Command	Description
<b>fcip profile</b>	Configures FCIP profile parameters.
<b>show fcip profile</b>	Displays FCIP profile information.

---

tcp max-jitter

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tcp max-jitter

To estimate the maximum delay jitter experienced by the sender in microseconds, use the **tcp max-jitter** command. Use the **no** form of this command to disable this feature or revert to its factory defaults.

**tcp max-jitter microseconds**

**no tcp max-jitter microseconds**

<b>Syntax Description</b>	<i>microseconds</i> Specifies the delay time in microseconds ranging from 0 to 10000.
<b>Defaults</b>	Enabled. The default value is 100 microseconds for FCIP and 500 microseconds for iSCSI interfaces.
<b>Command Modes</b>	FCIP profile configuration submode.
<b>Command History</b>	This command was introduced in Cisco MDS SAN-OS Release 1.3(4).
<b>Usage Guidelines</b>	None.
<b>Examples</b>	The following example configures delay jitter time:  <pre>switch# config terminal Enter configuration commands, one per line. End with CNTL/Z. switch(config)# fcip profile 3 switch(config-profile)# tcp max-jitter 600 switch(config-profile)# do show fcip profile 3 FCIP Profile 3     Internet Address is 10.3.3.3 (interface GigabitEthernet2/3)     Tunnels Using this Profile: fcip3     Listen Port is 3225     TCP parameters         SACK is enabled         PMTU discovery is enabled, reset timeout is 3600 sec         Keep alive is 60 sec         Minimum retransmission timeout is 200 ms         Maximum number of re-transmissions is 4         Send buffer size is 0 KB         Maximum allowed bandwidth is 1000000 kbps         Minimum available bandwidth is 500000 kbps         Estimated round trip time is 1000 usec         Congestion window monitoring is enabled, burst size is 10 KB         <b>Configured maximum jitter is 600 us</b></pre>

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

Related Commands	Command	Description
	<b>fcip profile</b>	Configures FCIP profile parameters.
	<b>show fcip profile</b>	Displays FCIP profile information.

---

tcp max-retransmissions

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tcp max-retransmissions

To specify the maximum number of times a packet is retransmitted before TCP decides to close the connection, use the **tcp max-retransmissions** command. Use the **no** form of this command to disable this feature or revert to its factory defaults.

**tcp max-retransmissions** *number*

**no tcp max-retransmissions** *number*

<b>Syntax Description</b>	<i>number</i> Specifies the maximum number. The range is 1 to 8.						
<b>Defaults</b>	Enabled						
<b>Command Modes</b>	FCIP profile configuration submode.						
<b>Command History</b>	This command was introduced in Cisco MDS SAN-OS Release 1.1(1).						
<b>Usage Guidelines</b>	The default is 4 and the range is from 1 to 8 retransmissions.						
<b>Examples</b>	<p>The following example configures a FCIP profile:</p> <pre>switch# config terminal switch(config)# fcip profile 5</pre> <p>The following example specifies the maximum number of retransmissions :</p> <pre>switch(config-profile)# tcp max-retransmissions 6</pre>						
<b>Related Commands</b>	<table border="1"> <thead> <tr> <th><b>Command</b></th><th><b>Description</b></th></tr> </thead> <tbody> <tr> <td><b>fcip profile</b></td><td>Configures FCIP profile parameters.</td></tr> <tr> <td><b>show fcip profile</b></td><td>Displays FCIP profile information.</td></tr> </tbody> </table>	<b>Command</b>	<b>Description</b>	<b>fcip profile</b>	Configures FCIP profile parameters.	<b>show fcip profile</b>	Displays FCIP profile information.
<b>Command</b>	<b>Description</b>						
<b>fcip profile</b>	Configures FCIP profile parameters.						
<b>show fcip profile</b>	Displays FCIP profile information.						

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tcp min-retransmit-time

To control the minimum amount of time TCP waits before retransmitting, use the **tcp min-retransmit-time** command. Use the **no** form of this command to disable this feature or revert to its factory defaults.

**tcp min-retransmit-time** *milliseconds*

**no tcp min-retransmit-time** *milliseconds*

<b>Syntax Description</b>	<i>milliseconds</i> Specifies the time in milliseconds. The range is 200 to 5000.						
<b>Defaults</b>	300 milliseconds.						
<b>Command Modes</b>	FCIP profile configuration submode.						
<b>Command History</b>	This command was introduced in Cisco MDS SAN-OS Release 1.1(1).						
<b>Usage Guidelines</b>	None.						
<b>Examples</b>	<p>The following example configures a FCIP profile:</p> <pre>switch# config terminal switch(config)# fcip profile 5 switch(config-profile)# </pre> <p>The following example specifies the minimum TCP retransmit time for the TCP connection:</p> <pre>switch(config-profile)# tcp min-retransmit-time 500 </pre>						
<b>Related Commands</b>	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td><b>fcip profile</b></td> <td>Configures FCIP profile parameters.</td> </tr> <tr> <td><b>show fcip profile</b></td> <td>Displays FCIP profile information.</td> </tr> </tbody> </table>	Command	Description	<b>fcip profile</b>	Configures FCIP profile parameters.	<b>show fcip profile</b>	Displays FCIP profile information.
Command	Description						
<b>fcip profile</b>	Configures FCIP profile parameters.						
<b>show fcip profile</b>	Displays FCIP profile information.						

---

tcp pmtu-enable

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tcp pmtu-enable

To configure path MTU (PMTU) discovery, use the **tcp pmtu-enable** command. Use the **no** form of this command to disable this feature or revert to its factory defaults.

**tcp pmtu-enable [reset-timeout seconds]**

**no tcp pmtu-enable [reset-timeout seconds]**

<b>Syntax Description</b>	<b>reset-timeout seconds</b> Specifies the PMTU reset timeout. The range is 60 to 3600 seconds.
<b>Defaults</b>	Enabled. 3600 seconds.
<b>Command Modes</b>	FCIP profile configuration submode.
<b>Command History</b>	This command was introduced in Cisco MDS SAN-OS Release 1.1(1).
<b>Usage Guidelines</b>	None.

**Examples**      The following example configures a FCIP profile:

```
switch# config terminal
switch(config)# fcip profile 5
switch(config-profile)#
```

The following example disables PMTU discovery:

```
switch(config-profile)# no tcp pmtu-enable
```

The following example enables PMTU discovery with a default of 3600 seconds:

```
switch(config-profile)# tcp pmtu-enable
```

The following example specifies the PMTU reset timeout to 90 seconds:

```
switch(config-profile)# tcp pmtu-enable reset-timeout 90
```

The following example leaves the PMTU in an enabled state but changes the timeout to the default of 3600 seconds:

```
switch(config-profile)# no tcp pmtu-enable reset-timeout 600
```

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

Related Commands	Command	Description
	<b>fcip profile</b>	Configures FCIP profile parameters.
	<b>show fcip profile</b>	Displays FCIP profile information.

**tcp qos**

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tcp qos

To specify the differentiated services code point (DSCP) value to mark all IP packets (type of service—TOS field in the IP header) on an iSCSI interface, use the **tcp qos** command. Use the **no** form of this command to disable this feature or revert to its factory defaults.

**tcp qos value**

**no tcp qos value**

<b>Syntax Description</b>	<b>value</b>	Applies the control DSCP value to all outgoing frames in the control TCP connection.						
<b>Defaults</b>	0							
<b>Command Modes</b>		FCIP profile configuration submode.						
<b>Command History</b>		This command was introduced in Cisco MDS SAN-OS Release 1.1(1).						
<b>Usage Guidelines</b>		Use these TCP parameters to control TCP retransmission behavior in a switch.						
<b>Examples</b>		The following example configures the TCP QoS value on an iSCSI interface.  switch# <b>config terminal</b> switch(config)# <b>interface iscsi 1/2</b> switch(config-if)# <b>tcp qos 5</b>						
<b>Related Commands</b>	<table border="1"> <thead> <tr> <th><b>Command</b></th> <th><b>Description</b></th> </tr> </thead> <tbody> <tr> <td><b>fcip profile</b></td> <td>Configures FCIP profile parameters.</td> </tr> <tr> <td><b>show fcip profile</b></td> <td>Displays FCIP profile information.</td> </tr> </tbody> </table>		<b>Command</b>	<b>Description</b>	<b>fcip profile</b>	Configures FCIP profile parameters.	<b>show fcip profile</b>	Displays FCIP profile information.
<b>Command</b>	<b>Description</b>							
<b>fcip profile</b>	Configures FCIP profile parameters.							
<b>show fcip profile</b>	Displays FCIP profile information.							

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tcp qos control

To specify the differentiated services code point (DSCP) value to mark all IP packets (type of service—TOS field in the IP header), use the **tcp qos control** command. Use the **no** form of this command to disable this feature or revert to its factory defaults.

**tcp qos control value data value**

**no tcp qos control value data value**

<b>Syntax Description</b>	<table border="0"> <tr> <td><b>value</b></td><td>Applies the control DSCP value to all FCIP frames in the control TCP connection.</td></tr> <tr> <td><b>data value</b></td><td>Applies the data DSCP value applies to all FCIP frames in the data connection.</td></tr> </table>	<b>value</b>	Applies the control DSCP value to all FCIP frames in the control TCP connection.	<b>data value</b>	Applies the data DSCP value applies to all FCIP frames in the data connection.
<b>value</b>	Applies the control DSCP value to all FCIP frames in the control TCP connection.				
<b>data value</b>	Applies the data DSCP value applies to all FCIP frames in the data connection.				

**Defaults** Enabled.

**Command Modes** FCIP profile configuration submode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.1(1).

**Usage Guidelines** Use these TCP parameters to control TCP retransmission behavior in a switch.

**Examples** The following example configures a FCIP profile:

```
switch# config terminal
switch(config)# fcip profile 5
switch(config-profile) #
```

The following example configures the control TCP connection and data connection to mark all packets on that DSCP value:

```
switch(config-profile) # tcp qos control 3 data 5
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>fcip profile</b>	Configures FCIP profile parameters.
	<b>show fcip profile</b>	Displays FCIP profile information.

---

 ■ **tcp sack-enable**

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tcp sack-enable

To enable selective acknowledgment (SACK) to overcome the limitations of multiple lost packets during a TCP transmission, use the **tcp sack-enable** command. Use the **no** form of this command to disable this feature or revert to its factory defaults.

**tcp sack-enable**

**no tcp sack-enable**

---

**Syntax Description** This command has no arguments or keywords.

---

**Defaults** Enabled

---

**Command Modes** FCIP profile configuration submode.

---

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.1(1).

---

**Usage Guidelines** The receiving TCP sends back SACK advertisements to the sender. The sender can then retransmit only the missing data segments.

---

**Examples** The following example configures a FCIP profile:

```
switch# config terminal
switch(config)# fcip profile 5
switch(config-profile)#
```

The following example enables the SACK mechanism on the switch:

```
switch(config-profile)# tcp sack-enable
```

---

**Related Commands**

Command	Description
<b>fcip profile</b>	Configures FCIP profile parameters.
<b>show fcip profile</b>	Displays FCIP profile information.

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tcp send-buffer-size

To define the required additional buffering—beyond the normal send window size—that TCP allows before flow controlling the switch's egress path for the FCIP interface, use the **tcp send-buffer-size** command. Use the **no** form of this command to disable this feature or revert to its factory defaults.

**tcp send-buffer-size *size***

**no tcp send-buffer-size *size***

<b>Syntax Description</b>	<b>size</b> Specifies the buffer size in KB. The range is 0 to 8192.						
<b>Defaults</b>	Enabled. The default FCIP buffer size is 0 KB. The default iSCSI buffer size is 4096 KB						
<b>Command Modes</b>	FCIP profile configuration submode.						
<b>Command History</b>	This command was introduced in Cisco MDS SAN-OS Release 1.3(4).						
<b>Usage Guidelines</b>	None.						
<b>Examples</b>	The following example configures a FCIP profile:  <pre>switch# config terminal switch(config)# fcip profile 5 switch(config-profile)# </pre> The following example configures the advertised buffer size to 5000 KB :  <pre>switch(config-profile)# tcp send-buffer-size 5000 </pre>						
<b>Related Commands</b>	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td><b>fcip profile</b></td> <td>Configures FCIP profile parameters.</td> </tr> <tr> <td><b>show fcip profile</b></td> <td>Displays FCIP profile information.</td> </tr> </tbody> </table>	Command	Description	<b>fcip profile</b>	Configures FCIP profile parameters.	<b>show fcip profile</b>	Displays FCIP profile information.
Command	Description						
<b>fcip profile</b>	Configures FCIP profile parameters.						
<b>show fcip profile</b>	Displays FCIP profile information.						

**tcp-connection**

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tcp-connection

To configure the number of TCP connections for the FCIP interface, use the **tcp-connection** command. To revert to the default, use the **no** form of the command.

**tcp-connection** *number*

**no tcp-connection** *number*

<b>Syntax Description</b>	<i>number</i> Enters the number of attempts (1 or 2).				
<b>Defaults</b>	Two attempts.				
<b>Command Modes</b>	Interface configuration submode				
<b>Command History</b>	This command was introduced in Cisco MDS SAN-OS Release 1.1(1).				
<b>Usage Guidelines</b>	<p>Access this command from the <code>switch(config-if) #</code> submode.</p> <p>Use the <b>tcp-connection</b> option to specify the number of TCP connections from a FCIP link. By default, the switch tries two (2) TCP connections for each FCIP link.</p>				
<b>Examples</b>	The following example configures the TCP connections.				
	<pre>switch# config terminal switch(config)# interface fcip 50 switch(config-if)# tcp-connection 1 switch(config-if)# no tcp-connection 1</pre>				
<b>Related Commands</b>	<table border="1"> <thead> <tr> <th><b>Command</b></th> <th><b>Description</b></th> </tr> </thead> <tbody> <tr> <td><b>show interface fcip</b></td> <td>Displays an interface configuration for a specified FCIP interface.</td> </tr> </tbody> </table>	<b>Command</b>	<b>Description</b>	<b>show interface fcip</b>	Displays an interface configuration for a specified FCIP interface.
<b>Command</b>	<b>Description</b>				
<b>show interface fcip</b>	Displays an interface configuration for a specified FCIP interface.				

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## telnet

To log in to a host that supports Telnet, use the **telnet** command in EXEC mode.

**telnet {hostname | ip-address} [port]**

<b>Syntax Description</b>	<i>hostname</i> Specifies a host name. Maximum length is 64 characters. <i>ip-address</i> Specifies an IP address. <i>port</i> (Optional) Specifies a port number. The range is 0 to 2147483647.
---------------------------	--

<b>Defaults</b>	None.
-----------------	-------

<b>Command Modes</b>	EXEC mode.
----------------------	------------

<b>Command History</b>	This command was introduced in Cisco MDS SAN-OS Release 1.0(2).
------------------------	---

<b>Usage Guidelines</b>	None.
-------------------------	-------

<b>Examples</b>	The following example establishes a Telnet session to the specified IP address.
-----------------	---

```
switch# telnet 172.22.91.153
Trying 172.22.91.153...
Connected to 172.22.91.153.
Login:xxxxxxxxxx
Password:xxxxxxxxxx
switch#
```

<b>Related Commands</b>	<b>Command</b> <b>Description</b> <b>telnet server enable</b> Enables the Telnet server.
-------------------------	---

---

```
telnet server enable
```

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## telnet server enable

To enable the Telnet server if you wish to return to a Telnet connection from a secure SSH connection, use the **telnet server enable** command. To disable the Telnet server, use the **no** form of this command.

**telnet server enable**

**no telnet server enable**

---

**Syntax Description** This command has no arguments or keywords.

---

**Defaults** Enabled.

---

**Command Modes** Configuration mode.

---

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

---

**Usage Guidelines** None.

---

**Examples** The following example enables the Telnet server.

```
switch(config)# telnet server enable
updated
```

The following example disables the Telnet server.

```
switch(config)# no telnet server enable
updated
```

---

**Related Commands**

Command	Description
<b>telnet</b>	Logs in to a host that supports Telnet.

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## terminal

To configure terminal attributes, use the **terminal** command in EXEC mode. To revert to the defaults, use the **no** form of the command.

```
terminal {length lines | monitor | session-timeout | terminal-type type | tree-update |
           width integer}
```

```
terminal no {length | monitor | session-timeout | terminal-type | width}
```

Syntax Description	
<b>length</b> <i>lines</i>	Specifies the number of lines on the screen. The range is 0 to 512. Enter 0 to scroll continuously.
<b>monitor</b>	Copies Syslog output to the current terminal line.
<b>session-timeout</b>	Specifies the session timeout value in minutes. The range is 0 to 525600. Enter 0 to disable.
<b>terminal-type</b> <i>type</i>	Sets the terminal type. Maximum length is 80 characters.
<b>tree-update</b>	Updates the main parse tree.
<b>width</b> <i>integer</i>	Sets the width of the display terminal, from 0 to 80.

**Defaults** The default number of lines for the length is 24. The default width is 80 lines.

**Command Modes** EXEC

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

**Usage Guidelines** Remember that all terminal parameter-setting commands are set locally and do not remain in effect after a session is ended. You must perform this task at the EXEC prompt at each session to see the debugging messages.

If the length is not 24 and the width is not 80, then you need to set a length and width.

**Examples** The following example displays debug command output and error messages during the current terminal session.

```
switch# terminal monitor
Aug  8 10:32:42 sup48 % LOG_PLATFORM-5-PLATFORM_MOD_CFG_PWRDN: Module 1 powered down
Aug  8 10:32:42 sup48 % LOG_PLATFORM-5-PLATFORM_MOD_PWRDN: Module 1 powered down
Aug  8 10:32:42 sup48 % LOG_PLATFORM-5-PLATFORM_MOD_INSERT: Module 1 has been inserted
Aug  8 10:33:12 sup48 % LOG_PLATFORM-5-PLATFORM_MOD_PWRON: Module 1 powered up
Aug  8 10:33:13 sup48 % LOG_MODULE-5-MOD_REG_OK: LCM - Registration succeeded for module 1
Aug  8 10:38:15 sup48 % LOG_PLATFORM-5-PLATFORM_MOD_CFG_PWRDN: Module 1 powered down
Aug  8 10:38:15 sup48 % LOG_PLATFORM-5-PLATFORM_MOD_INSERT: Module 1 has been inserted
.....
```

**terminal**

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

The following example stops the current terminal monitoring session.

```
switch# terminal no monitor
```

Related Commands	Command	Description
	<b>show terminal</b>	Displays terminal configuration information.

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## time

To configure the time for the command schedule, use the **time** command. To disable this feature, use the **no** form of the command.

```
time { daily daily-schedule | monthly monthly-schedule | start {start-time | now} |
      weekly weekly-schedule }
```

```
no time
```

Syntax Description	Parameter	Description
	<b>daily</b> <i>daily-schedule</i>	Configures a daily command schedule. The format is <i>HH:MM</i> , where <i>HH</i> is hours (0 to 23) and <i>MM</i> is minutes (0 to 59). Maximum length is 5 characters.
	<b>monthly</b> <i>monthly-schedule</i>	Configures a monthly command schedule. The format is <i>dow:HH:MM</i> , where <i>dow</i> is the day of the month (1 to 31), <i>HH</i> is hours (0 to 23) and <i>MM</i> is minutes (0 to 59). Maximum length is 8 characters.
	<b>start</b>	Schedules a job to run at a future time.
	<i>start-time</i>	Specifies the future time to run the job. The format is <i>yyyy:mmm:dd:HH:MM</i> , where <i>yyyy</i> is the year, <i>mmm</i> is the month (jan to dec), <i>dd</i> is the day of the month (1 to 31), <i>HH</i> is hours (0 to 23) and <i>MM</i> is minutes (0 to 59). Maximum length is 18 characters.
	<b>now</b>	Starts the job two minutes after the command is entered.
	<b>weekly</b> <i>weekly-schedule</i>	Configures a weekly command schedule. The format is <i>dow:HH:MM</i> , where <i>dow</i> is the day of the week (1 to 7, Sun to Sat), <i>HH</i> is hours (0 to 23) and <i>MM</i> is minutes (0 to 59). Maximum length is 10 characters.

Defaults	Disabled.
Command Modes	Scheduler job configuration submode.

Command History	Release	Modification
	2.0(1b)	This command was introduced.

Usage Guidelines	To use this command, the command scheduler must be enabled using the <b>scheduler enable</b> command.
------------------	---

Examples	The following example shows how to configure a command schedule job to run every Friday at 2200.
----------	--

```
switch# config terminal
switch(config)# scheduler schedule name MySchedule
switch(config-schedule)# time weekly 6:22:00
```

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

The following example starts a command schedule job in two minutes and repeats every 24 hours.

```
switch(config-schedule)# time start now repeat 24:00
```

Related Commands	Command	Description
	<b>scheduler enable</b>	Enables the command scheduler.
	<b>scheduler schedule name</b>	Configures a schedule for the command scheduler.
	<b>show scheduler</b>	Displays schedule information.

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## time-stamp

To enable FCIP time stamps on a frame, use the **time-stamp** command. To disable this command for the selected interface, use the **no** form of the command.

**time-stamp [acceptable-diff *number*]**

**no time-stamp [acceptable-diff *number*]**

---

<b>Syntax Description</b>	<b>acceptable-diff <i>number</i></b> Configures the acceptable time difference for timestamps in milliseconds. The range is 500 to 10000.				
<b>Defaults</b>	Disabled.				
<b>Command Modes</b>	Interface configuration submode				
<b>Command History</b>	This command was introduced in Cisco MDS SAN-OS Release 1.1(1).				
<b>Usage Guidelines</b>	<p>Access this command from the <code>switch(config-if)#</code> submode.</p> <p>The <b>time-stamp</b> option instructs the switch to discard frames that are older than a specified time.</p>				
<b>Examples</b>	<p>The following example enables the timestamp for an FCIP interface.</p> <pre>switch# config terminal switch(config)# interface fcip 50 switch(config-if)# time-stamp switch(config-if)# time-stamp acceptable-diff 4000</pre>				
<b>Related Commands</b>	<table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td><b>show interface fcip</b></td> <td>Displays the configuration for a specified FCIP interface.</td> </tr> </tbody> </table>	Command	Description	<b>show interface fcip</b>	Displays the configuration for a specified FCIP interface.
Command	Description				
<b>show interface fcip</b>	Displays the configuration for a specified FCIP interface.				

---

**tlport alpa-cache**

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## tlport alpa-cache

To manually configure entries in an ALPA cache, use the **tlport alpa-cache** command

**tlport alpa-cache interface *interface* *pwwn* *pwwn* *alpa* *alpa***

**no tlport alpa-cache interface *interface* *pwwn* *pwwn***

<b>Syntax Description</b>	<b>interface <i>interface</i></b> Specifies a Fibre Channel interface. <b>pwwn <i>pwwn</i></b> Specifies the peer WWN ID for the ALPA cache entry. <b>alpa <i>alpa</i></b> Specifies the ALPA cache to which this entry is to be added.
---------------------------	---

<b>Defaults</b>	Disabled.
-----------------	-----------

<b>Command Modes</b>	Configuration mode.
----------------------	---------------------

<b>Command History</b>	This command was introduced in Cisco MDS SAN-OS Release 1.3(5).
------------------------	---

<b>Usage Guidelines</b>	Generally, ALPA cache entries are automatically populated when an ALPA is assigned to a device. Use this command only if you wish to manually add further entries.
-------------------------	--

<b>Examples</b>	The following example configures the specified pWWN as a new entry in this cache
<pre>switch# config terminal switch(config)# tlport alpa-cache interface fc1/2 pwwn 22:00:00:20:37:46:09:bd alpa 0x02</pre>	

<b>Related Commands</b>	<b>Command</b> <b>Description</b> <b>show tlport</b> Displays TL port information.
-------------------------	---

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## traceroute

To print the route an IP packet takes to a network host, use the **traceroute** command in EXEC mode.

**traceroute {hostname | ip-address}**

<b>Syntax Description</b>	<table border="0"> <tr> <td><i>host name</i></td><td>Specifies a host name. Maximum length is 64 characters.</td></tr> <tr> <td><i>ip-address</i></td><td>Specifies an IP address.</td></tr> </table>	<i>host name</i>	Specifies a host name. Maximum length is 64 characters.	<i>ip-address</i>	Specifies an IP address.
<i>host name</i>	Specifies a host name. Maximum length is 64 characters.				
<i>ip-address</i>	Specifies an IP address.				

**Defaults** None.

**Command Modes** EXEC mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

**Usage Guidelines** This command traces the route an IP packet follows to an internet host by launching UDP probe packets with a small TTL (time to live) then listening for an ICMP (Internet Control Message Protocol) “time exceeded” reply from a gateway.



**Note** Probes start with a TTL of one and increase by one until encountering an ICMP “port unreachable.” This means that the host was accessed or a maximum flag was hit. A line is printed showing the TTL, address of the gateway and round trip time of each probe. If the probe answers come from different gateways, the address of each responding system is printed.

**Examples** The following example prints the route IP packets take to the network host www.cisco.com.

```
switch# traceroute www.cisco.com
traceroute to www.cisco.com (171.71.181.19), 30 hops max, 38 byte packets
 1 kingfisher1-92.cisco.com (172.22.92.2)  0.598 ms  0.470 ms  0.484 ms
 2 nubulab-gw1-b1dg6.cisco.com (171.71.20.130)  0.698 ms  0.452 ms  0.481 ms
 3 172.24.109.185 (172.24.109.185)  0.478 ms  0.459 ms  0.484 ms
 4 sjc12-lab4-gw2.cisco.com (172.24.111.213)  0.529 ms  0.577 ms  0.480 ms
 5 sjc5-sbb4-gw1.cisco.com (171.71.241.174)  0.521 ms  0.495 ms  0.604 ms
 6 sjc12-dc2-gw2.cisco.com (171.71.241.230)  0.521 ms  0.614 ms  0.479 ms
 7 sjc12-dc2-cec-css1.cisco.com (171.71.181.5)  2.612 ms  2.093 ms  2.118 ms
 8 www.cisco.com (171.71.181.19)  2.496 ms *  2.135 ms
```

---

 transfer-ready-size

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## transfer-ready-size

To configure the target transfer ready size for SCSI write commands on a SAN tuner extension N port, use the **transfer-ready-size** command.

**transfer-ready-size** *bytes*

<b>Syntax Description</b>	<i>bytes</i>	Specifies the transfer ready size in bytes. The range is 0 to 2147483647.
---------------------------	--------------	---

<b>Defaults</b>	None.
-----------------	-------

<b>Command Modes</b>	SAN extension N port configuration submode.
----------------------	---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	2.0(1b)	This command was introduced.

<b>Usage Guidelines</b>	For a SCSI <b>write command-id</b> command with a larger transfer size, the target performs multiple transfers based on the specified transfer size.
-------------------------	--

<b>Examples</b>	The following example configures the transfer ready size on a SAN extension tuner N port.
<pre>switch# san-ext-tuner switch(san-ext)# nWWN 10:00:00:00:00:00:00:00 switch(san-ext)# nport pwwn 12:00:00:00:00:00:00:56 vsan 13 interface gigabitethernet 1/2 switch(san-ext-nport)# transfer-ready-size 512000</pre>	

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>nport pwwn</b>	Configures a SAN extension tuner N port.
	<b>san-ext-tuner</b>	Enables the SAN extension tuner feature.
	<b>show san-ext-tuner</b>	Displays SAN extension tuner information.
	<b>write command-id</b>	Configures a SCSI write command for a SAN extension tuner N port.

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## transport email

To configure the customer ID with the Call Home function, use the **transport email** command in Call Home configuration submode. To disable this feature, use the **no** form of the command.

**transport email {from *email-address* | reply-to *email-address* | smtp-server *ip-address* [port *port-number*]}**

**no transport email {from *email-address* | reply-to *email-address* | smtp-server *ip-address* [port *port-number*]}**

Syntax Description	<b>from <i>email-address</i></b> Specifies the from email address. For example: SJ-9500-1@xyz.com. The maximum length is 255 characters.
<b>reply-to <i>email-address</i></b>	Specifies the reply-to email address. For address, example: admin@xyz.com. The maximum length is 255 characters.
<b>smtp-server <i>ip-address</i></b>	Specifies the SMTP server address, either DNS name or IP address. The maximum length is 255 characters.
<b>port <i>port-number</i></b>	(Optional) Changes depending on the server location. The port usage defaults to 25 if no port number is specified.

**Defaults** None.

**Command Modes** Call Home configuration submode

Command History	Release	Modification
	1.0(2)	This command was introduced.

**Usage Guidelines** None.

**Examples** The following example configures the from and reply-to e-mail addresses.

```
switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# callhome
switch(config-callhome)# transport email from user@company1.com
switch(config-callhome)# transport email reply-to person@place.com
```

The following example configures the SMTP server and ports.

```
switch(config-callhome)# transport email smtp-server 192.168.1.1
switch(config-callhome)# transport email smtp-server 192.168.1.1 port 30
```

■ [transport email](#)

***Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).***

Related Commands	Command	Description
	<a href="#">callhome</a>	Configures the Call Home function.
	<a href="#">callhome test</a>	Sends a dummy test message to the configured destination(s).
	<a href="#">show callhome</a>	Displays configured Call Home information.

**Send documentation comments to [mdsfeedback-doc@cisco.com](mailto:mdsfeedback-doc@cisco.com).**

## trunk protocol enable

To configure the trunking protocol, use the **trunk protocol enable** command in configuration mode. To disable this feature, use the **no** form of the command.

**trunk protocol enable**

**no trunk protocol enable**

**Syntax Description** This command has no other arguments or keywords.

**Defaults** Enabled.

**Command Modes** Configuration mode.

**Command History** This command was introduced in Cisco MDS SAN-OS Release 1.0(2).

**Usage Guidelines** If the trunking protocol is disabled on a switch, no port on that switch can apply new trunk configurations. Existing trunk configurations are not affected—the TE port continues to function in trunking mode, but only supports traffic in VSANs that it negotiated previously (when the trunking protocol was enabled). Also, other switches that are directly connected to this switch are similarly affected on the connected interfaces. In some cases, you may need to merge traffic from different port VSANs across a non-trunking ISL. If so, you need to disable the trunking protocol.

**Examples** The following example shows how to disable the trunk protocol feature.

```
switch# config terminal
switch(config)# no trunk protocol enable
```

The following example shows how to enable the trunk protocol feature.

```
switch(config)# trunk protocol enable
```

### Related Commands

Command	Description
<b>show trunk protocol</b>	Displays the trunk protocol status.

■ trunk protocol enable

***Send documentation comments to mdsfeedback-doc@cisco.com.***