

Send documentation comments to mdsfeedback-doc@cisco.com



APPENDIX A

DMM CLI Command Reference

The Cisco MDS DMM feature provides a CLI suitable for scripting and advanced operations.

This appendix contains an alphabetical listing of commands that are unique to the Cisco MDS DMM feature.

For information about other commands that apply to the Cisco MDS 9000 Family of multilayer directors and fabric switches, refer to the *Cisco MDS 9000 Family CLI Configuration Guide*.

■ ssm enable feature dmm***Send documentation comments to mdsfeedback-doc@cisco.com***

ssm enable feature dmm

To enable DMM, use the **ssm enable feature dmm** command in configuration mode.

```
ssm enable feature dmm {force {interface fc slot/port | module slot} | interface fc slot/port | module slot}
```

Syntax Description	force	Forces a switching module reload.
	interface	Specifies the interface.
	fc slot/port	Specifies the Fiber Channel slot and port numbers.
	module slot	Specifies the SSM module slot number.

Defaults The DMM feature is disabled.

Command Modes Configuration mode.

Command History	Release	Modification
	3.2(1)	This command was introduced.

Usage Guidelines None.

Examples The following example shows how to enable DMM on a module:

```
switch# config t
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# ssm enable feature dmm module 1
```

The following example shows how to enable DMM on an interface:

```
switch# config t
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# ssm enable feature dmm interface fc 1/1 - 4
```

The following example shows how to force a reload on some of the ports on a line card:

```
switch# config t
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# ssm enable feature dmm force interface fc 1/1 - 8, fc 1/13 - 16
```

Related Commands

Command	Description
show ssm provisioning	Displays information about features provisioned on the SSM.
show dmm job	Displays DMM job information.

Send documentation comments to mdsfeedback-doc@cisco.com

dmm module job

To configure a data migration job, use the **dmm module mod-id job** command in configuration mode.

dmm module mod-id

```
job job-id create | destroy | get-vi vsan vsan-id | restart | schedule {hour hour min minute
day day month month year year | now | reset} | session | stop | validate | verify | finish
```

Syntax Description

module mod-id	Specifies the module ID.
job job-id	Specifies the job ID. The range is 0 to 18446744073709551615.
create	Creates the job and enters DMM job configuration submode.
destroy	Deletes the DMM job.
get-vi	Retrieves the VI for the DMM job.
vsan vsan-id	Specifies the VSAN ID. The range is 1 to 4093.
start	Starts the DMM job session.
schedule	Schedules the DMM job.
hour hour	Specifies the hour the DMM job starts. The range is 0 to 23.
min minute	Specifies the minute the DMM job starts. The range is 0 to 59.
day day	Specifies the day the DMM job starts. The range is 1 to 31.
month month	Specifies the month the DMM job starts. The range is 1 to 12.
year year	Specifies the year the DMM job starts. The range is 2000 to 2030.
now	Resets the schedule to start the DMM job immediately.
reset	Resets the DMM job to unscheduled.
session	Enables the Session Configuration submode.
stop	Stops the DMM job.
validate	Validates the DMM job data.
verify	Verifies the data migration for the specified job.
finish	Moves the Method 2 data migration job to completed state.

Defaults

None.

Command Modes

Configuration mode.

Command History

Release	Modification
3.3(1a)	Finish keyword is introduced.

Usage Guidelines

DMM must be enabled before you can create DMM jobs. Use the **ssm enable feature dmm** command to enable DMM.

dmm module job***Send documentation comments to mdsfeedback-doc@cisco.com***

The data migration job stops executing if it encounters any errors. To restart the migration, enter the **validate** command to validate the job configuration, then enter the **restart** command to restart the job.

Examples

The following example shows how to create a job with a schedule. The job is scheduled to start on Sunday, January 6, 2008 at 11:00 P.M.

```
switch# config t
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# dmm module 3 job 1 schedule hour 23 min 0 day 6 month 1 year 2008
```

The following example shows how to set the fast migration rate to 100 MB/s, the medium migration rate to 50 MB/s, and slow migration rate to 10 MB/s.

```
switch# config t
Enter configuration commands, one per line. End with CNTL/Z.
switch(config) dmm module 3 rate_of_migration fast 100 medium 50 slow 10
```

Related Commands

Command	Description
show dmm job	Displays DMM job information.
show dmm ip-peer	Displays the IP peers that the DMM port is connected to.

Send documentation comments to mdsfeedback-doc@cisco.com

attributes (DMM job configuration submode)

To set the attributes of a data migration job, use the **attributes** command in DMM job configuration submode.

attributes job_type {1 | 2} job_mode {1 | 2} job_rate {1 | 2 | 3 | 4} job_method {1|2}

Syntax Description	job_type {1 2} Specifies the job type. Specify 1 for a server type job and 2 for a storage type job.
	job_mode {1 2} Specifies the job mode. Specify 1 for an online job and 2 for an offline job.
	job_rate {1 2 3 4} Specifies the job rate. Specify 1 for the default rate, 2 for a slow rate, 3 for a medium rate, and 4 for a fast rate.
	job_method {1 2} Specifies the job method. Specify 1 for Method 1 and 2 for Method 2.

Defaults None.

Command Modes DMM job configuration submode.

Command History	Release	Modification
	3.3(1a)	This command was introduced.

Usage Guidelines None.

Examples The following example sets the job type to storage, the job mode to online, and the job rate to fast.

```
switch# config t
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# dmm module 3 job 1 create
Started New DMM Job Configuration.
Do not exit sub-mode until configuration is complete and committed
switch(config-dmm-job)# attributes job_type 2 job_mode 1 job_rate 4 job_method 1
switch(config-dmm-job)#

```

Related Commands	Command	Description
	show dmm ip-peer	Displays job information.
	show dmm svr-vt-login	Displays server VT login information.

commit (DMM job configuration submode)

Send documentation comments to mdsfeedback-doc@cisco.com

commit (DMM job configuration submode)

To commit a DMM job, use the **commit** command in DMM job configuration submode.

commit

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes DMM job configuration submode.

Command History	Release	Modification
	3.2(1)	This command was introduced.

Usage Guidelines You need to configure server HBA ports, storage ports, and job attributes before you commit the job.

Examples The following example shows how to commit a data migration job:

```
switch# config t
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# dmm module 3 job 1 destroy
switch(config-dmm-job)#
```

Related Commands	Command	Description
	ssm enable feature dmm	Enables DMM.
	show dmm job	Displays job information.

Send documentation comments to mdsfeedback-doc@cisco.com

peer (DMM job configuration submode)

To add peer SSM information to a job, use the **peer** command in DMM job configuration submode.

peer *ip-address*

Syntax Description	<i>ip-address</i>	Specifies the peer SSM IP address. The format for the IP address is <i>A.B.C.D.</i>
---------------------------	-------------------	---

Defaults	None.
-----------------	-------

Command Modes	DMM job configuration submode.
----------------------	--------------------------------

Command History	Release	Modification
	3.2(1)	This command was introduced.

Usage Guidelines	In a dual-fabric topology, the migration job runs on an SSM in each fabric. The two SSMs exchange messages over the management IP network, so each SSM needs the IP address of the peer.
-------------------------	--

Examples	The following example shows how to add peer SSM information to a job:
-----------------	---

```
switch# config t
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# dmm module 3 job 1 create
Started New DMM Job Configuration.
Do not exit sub-mode until configuration is complete and committed
switch(config-dmm-job)# peer 224.2.1.2
switch(config-dmm-job) #
```

Related Commands	Command	Description
	show dmm job	Displays job information.
	show dmm ip-peer	Displays a DMM port's IP peer.

server (DMM job configuration submode)

Send documentation comments to mdsfeedback-doc@cisco.com

server (DMM job configuration submode)

To add a server HBA port to the DMM job, use the **server** command in DMM job configuration submode.

server vsan vsan-id pwwn port-wwn

Syntax Description	vsan vsan-id Specifies the VSAN ID. The range is 1 to 4093. pwwn port-wwn Specifies the world-wide name (WWN) of the server HBA port. The format is hh:hh:hh:hh:hh:hh:hh:hh, where h is a hexadecimal number.
---------------------------	--

Defaults	None.
-----------------	-------

Command Modes	DMM job configuration submode.
----------------------	--------------------------------

Command History	Release	Modification
	3.2(1)	This command was introduced.

Usage Guidelines	None.
-------------------------	-------

Examples	The following example shows how to add server information to a DMM job:
-----------------	---

```
switch# config t
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# dmm module 3 job 1 create
Started New DMM Job Configuration.
Do not exit sub-mode until configuration is complete and committed
switch(config-dmm-job)# server vsan 3 pwwn 1d:22:3a:21:3c:44:3b:51
switch(config-dmm-job)#

```

Related Commands	Command	Description
	show dmm job	Displays job information.
	show dmm svrvt-login	Displays server VT login information.

Send documentation comments to mdsfeedback-doc@cisco.com

server (configure session submode)

To configure a data migration session, use the server command in session configuration submode.

```
server pw-wn src_tgt pw-wn src_lun src-lun dst_tgt pw-wn dst_lun dst-lun
```

Syntax Description	<p>pwwn pwwn Specifies the pWWN of the server. The format is hh:hh:hh:hh:hh:hh:hh, where h is a hexadecimal number.</p> <p>src_tgt pwwn Specifies the pWWN of the source target. The format is hh:hh:hh:hh:hh:hh:hh, where h is a hexadecimal number.</p> <p>src_lun src-lun Specifies the source LUN number in hex notation. The range is 0x0 to 0xffff.</p> <p>dst_tgt pwwn Specifies the pWWN of the destination target. The format is hh:hh:hh:hh:hh:hh:hh, where h is a hexadecimal number.</p> <p>dst_lun dst-lun Specifies the destination LUN in hex notation. The range is 0x0 to 0xffff.</p>
---------------------------	---

Defaults None.

Command Modes Configure session submode.

Command History	Release	Modification
	3.2(1)	This command was introduced.

Usage Guidelines None.

Examples The following example shows how to a source target, source LUN, destination target, and destination LUN in a session:

```
switch# config t
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# dmm module 3 job 1 session
switch(config-session)# server 12:13:1d:1c:2d:2d:3f:3a src_tgt 12:13:1d:1c:2d:2d:3f:3a
src_lun 0x1 dst_tgt 12:13:1d:1c:2d:2d:3f:3a dst_lun 0x5
```

Related Commands	Command	Description
	show dmm job	Displays job information.
	show dmm srvr-vt-login	Displays server VT login information.

storage (DMM job configuration submode)

Send documentation comments to mdsfeedback-doc@cisco.com

storage (DMM job configuration submode)

To add a storage port to a DMM job, use the **storage** command in DMM job configuration submode.

storage vsan vsan-id pwwn port-wwn {existing | new}

Syntax Description	vsan <i>vsan-id</i>	Specifies the VSAN ID. The range is 1 to 4093.
	pwwn <i>port-wwn</i>	Specifies the world-wide name of the storage port. The format is hh:hh:hh:hh:hh:hh:hh:hh, where h is a hexadecimal number.
	existing	Specifies a port on the existing storage.
	new	Specifies a port on the new storage.

Defaults None.

Command Modes DMM job configuration submode.

Command History	Release	Modification
	3.2(1)	This command was introduced.

Usage Guidelines None.

Examples The following example shows how to add storage information to a DMM job:

```
switch# config t
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# dmm module 3 job 1 create
Started New DMM Job Configuration.
Do not exit sub-mode until configuration is complete and committed
switch(config-dmm-job)# storage vsan 3 pwwn 1d:22:3a:21:3c:44:3b:51 existing
switch(config-dmm-job)#

```

Related Commands	Command	Description
	ssm enable feature dmm	Enables DMM.
	show dmm job	Displays job information.

Send documentation comments to mdsfeedback-doc@cisco.com

dmm module

To specify default DMM values for migration block size, number of migration blocks and fast migration speed, use the **dmm module** command in Configuration mode.

dmm module mod-id migration-block-size block-size

dmm module mod-id num-migration-blocks num-blocks

dmm module mod-id rate-of-migration fast migration-rate medium migration-rate slow migration-rate

Syntax Description

<i>mod-id</i>	Specifies the module ID.
<i>block-size</i>	Specifies the block size in MB.
<i>num-blocks</i>	Specifies the number of migration blocks per LUN.
<i>rate-of-migration</i>	Migration rate can be configured as slow, medium or fast.
fast migration-rate	Specifies the rate for fast migration. Units are Megabytes per second (MB/s).
medium migration-rate	Specifies the rate for medium migration. Units are MB/s.
slow migration-rate	Specifies the rate for slow migration. Units are MB/s.

Defaults

None.

Command Modes

Configuration mode.

Command History

Release	Modification
3.2(1)	This command was introduced.

Usage Guidelines

None.

Examples

The following example shows how to a job:

```
switch# config t
Enter configuration commands, one per line. End with CNTL/Z.
switch(config)# dmm module 3
```

Related Commands

Command	Description
show dmm job	Displays job information.
show dmm ip-peer	Displays a DMM port's IP peer.

■ **show dmm discovery-log**

Send documentation comments to mdsfeedback-doc@cisco.com

show dmm discovery-log

To display SCSI device discovery logs, use the **show dmm discovery-log** command in EXEC mode.

show dmm discovery-log {all | error}

Syntax Description	
all	Displays all entries in the Device Discovery SCSI log.
error	Displays error entries in the Device Discovery SCSI log.

Defaults	None.
-----------------	-------

Command Modes	EXEC mode.
----------------------	------------

Command History	Release	Modification
	3.2(1)	This command was introduced.

Usage Guidelines	You must connect to an SSM on your switch to execute DMM show commands. Use the show module command to determine the slot number of an SSM on your switch. Use the attach module slot command to connect to the SSM.
-------------------------	---

Examples	The following example displays error entries:
-----------------	---

```
switch# attach module 3
Attaching to module 3 ...
To exit type 'exit', to abort type '$.'
Bad terminal type: "ansi". Will assume vt100.
module-3# show dmm discovery-log error
005 State: 3
CDB: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Sts:0x02 SnsKey:0x02 AscAscq:0x0403
Time: 5 (ms)

LogIndex:26 HostPWWN:2c:fc:00:05:30:01:9e:88 TargetPWWN:50:06:01:62:30:60:36:64
OPC: 0x00 Lun:0x0000000000000006 State: 3
CDB: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
Sts:0x02 SnsKey:0x02 AscAscq:0x0403
Time: 4 (ms)
```

Related Commands	Command	Description
	ssm enable feature dmm	Enables the DMM feature.
	dmm module	Enables DMM configuration on a module.

Send documentation comments to mdsfeedback-doc@cisco.com

show dmm fp-port

To display front panel ports on a line card, use the **show dmm fp-port** command in EXEC mode.

show dmm fp-port

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC mode.

Command History	Release	Modification
	3.2(1)	This command was introduced.

Usage Guidelines You must connect to an SSM on your switch to execute DMM **show** commands. Use the **show module** command to determine the slot number of an SSM on your switch. Use the **attach module slot** command to connect to the SSM.

Examples The following example displays front panel ports:

```
switch# attach module 3
Attaching to module 3 ...
To exit type 'exit', to abort type '$.'
Bad terminal type: "ansi". Will assume vt100.
module-3# show dmm fp-port
Cisco DMM Front Panel Port Map
-----
Port      Index      Mirage Id      DPP Id
-----
 1          0            1            2
 2          1            1            2
 3          2            1            2
 4          3            1            2
 5          4            2            3
 6          5            2            3
 7          6            2            3
 8          7            2            3
 9          8            3            6
10         9            3            6
11        10            3            6
12        11            3            6
13        12            4            7
14        13            4            7
15        14            4            7
16        15            4            7
17        16            1            1
18        17            1            1
```

■ **show dmm fp-port**

Send documentation comments to mdsfeedback-doc@cisco.com

19	18	1	1
20	19	1	1
21	20	2	4
22	21	2	4
23	22	2	4
24	23	2	4
25	24	3	5
26	25	3	5
27	26	3	5
28	27	3	5
29	28	4	8
30	29	4	8
31	30	4	8
32	31	4	8

Related Commands

Command	Description
ssm enable feature dmm	Enables the DMM feature.
dmm module	Enables DMM configuration on a module.

Send documentation comments to mdsfeedback-doc@cisco.com

show dmm ip-peer

To display information about the IP peers the DMM interface is connected to, use the **show dmm ip-peer** command in EXEC mode.

show dmm ip-peer

Syntax Description This command has no arguments or keywords.

Defaults None.

Command Modes EXEC mode.

Command History	Release	Modification
	3.2(1)	This command was introduced.

Usage Guidelines You must connect to an SSM on your switch to execute DMM **show** commands. Use the **show module** command to determine the slot number of an SSM on your switch. Use the **attach module slot** command to connect to the SSM.

Examples The following example displays DMM IP peer information:

```
switch# attach module 3
Attaching to module 3 ...
To exit type 'exit', to abort type '$.'
Bad terminal type: "ansi". Will assume vt100.
module-3# show dmm ip-peer
```

Cisco DMM IP Peer Table					
No	Type	SD	IP Address	TCP	State
1	CONFIG_STATION	23	10.100.2.1		DOWN
2	PEER_SSM	22	10.100.1.20		UP
3	CONFIG_STATION	19	10.100.2.1		DOWN

Related Commands

Command	Description
ssm enable feature dmm	Enables the DMM feature.
dmm module	Enables DMM configuration on a module.

show dmm job

Send documentation comments to mdsfeedback-doc@cisco.com

show dmm job

To display DMM job information, use the **show dmm job** command in EXEC mode.

```
show dmm job job-id
  {detail |
   job-fsm-eventlog |
   job-infra-fsm-eventlog |
   lun_tokens tok-pwwn |
   session {[session_id sess-id] [session-event-log] |
   storage [tgt-pwwn tgt-pwwn] {vi-pwwn vi-pwwn} [lun-event-log lun-id | tgt-event-log]}}
```

Syntax Description	
<i>job-id</i>	Specifies the job ID. The range is 0 to 18446744073709551615.
detail	Displays detailed job information.
job-fsm-eventlog	Displays the Job FSM Event Log.
job-infra-fsm-eventlog	Displays the Job Infra FSM Event Log.
lun_tokens	Displays a list of job LUN tokens.
token <i>tok-pwwn</i>	Specifies the storage port world-wide name.
session	Displays job session information.
<i>session_id sess-id</i>	Specifies the job session. The range is 0 to 255.
session-event-log	Displays the Session FSM Event Log.
storage	Displays the storage ports discovered by DMM.
<i>tgt-pwwn tgt-pwwn</i>	Specifies the storage port world-wide name. The format is hh:hh:hh:hh:hh:hh:hh, where h is a hexadecimal number.
<i>vi-pwwn vi-pwwn</i>	Specifies the Virtual Initiator port world-wide name. The format is hh:hh:hh:hh:hh:hh:hh, where h is a hexadecimal number.
<i>lun-event-log lun-id</i>	Displays the Virtual Initiator and Target LUN FSM event log and specifies the LUN ID.
<i>tgt-event-log</i>	Displays the Virtual Initiator and Target FSM Event Log.

Defaults	None.
----------	-------

Command Modes	EXEC mode.
---------------	------------

Command History	Release	Modification
	3.2(1)	This command was introduced.

Usage Guidelines	You must connect to an SSM on your switch to execute DMM show commands. Use the show module command to determine the slot number of an SSM on your switch. Use the attach module slot command to connect to the SSM.
------------------	---

Send documentation comments to mdsfeedback-doc@cisco.com

Examples

The following example shows how to display a summary of all the jobs:

```
module-3# sh dmm job job-id 1205450497 detail
show dmm job job-id 1205450497 details
=====
          Data Mobility Manager Job Details
=====
Job Identifier : 1205450497
Job Name       : admin_2008/03/13-16:21
Job Type        : SERVER
Job Rate        : Default, no rate limiting
Job Mode        : ONLINE
Job Method      : METHOD-2
Job DPP         : 7
Peer SSM IP    : NOT_APPLICABLE
DMM GUI IP     : 10.1.0.25
Job FSM         : READY
Job Infra FSM   : DONE
-----
          Job Schedule Information
-----
Date           : 0 / 0/0 [Month/Day/Year]
Time           : 0:0 [Hour:Min]
-----
          Server Port List (Num Ports :1)
-----
Num  VSAN  Server pWWN           Virtual Initiator pWWN
-----
 1   100   21:01:00:e0:8b:28:5e:3e 20:40:00:0d:ec:0e:f4:03
-----
          Storage Port List (Num Ports :2)
-----
Num  VSAN  Storage pWWN          Type  Virtual Target pWWN
-----
 1   100   50:06:0e:80:04:2c:5c:54 NS    20:44:00:0d:ec:0e:f4:03
 2   100   50:06:0e:80:04:2c:5c:74 ES    20:42:00:0d:ec:0e:f4:03
-----
          DMM GUI PDU History
-----
Num  PDU Opcode             GUI IP     Rx                               Tx
-----
 1   DM_JOB_CREATE_REQ      10.1.0.25 Thu Mar 13 23:21:39 2008  Thu Mar 13 23:21:39
2008
 2   DM_JOB_INFRA_CREATE_REQ 10.1.0.25 Thu Mar 13 23:21:40 2008  Thu Mar 13 23:21:44
2008
 3   DM_JOB_LUNMAP_REQ      10.1.0.25 Thu Mar 13 23:21:45 2008  Thu Mar 13 23:21:45
2008
 4   DM_JOB_SESSION_ADD_REQ 10.1.0.25 Thu Mar 13 23:21:52 2008  Thu Mar 13 23:21:52
2008
 5   DM_JOB_SESSION_ADD_REQ 10.1.0.25 Thu Mar 13 23:21:53 2008  Thu Mar 13 23:21:53
2008
 6   DM_JOB_SESSION_ADD_REQ 10.1.0.25 Thu Mar 13 23:21:54 2008  Thu Mar 13 23:21:54
2008
 7   DM_JOB_SESSION_ADD_REQ 10.1.0.25 Thu Mar 13 23:21:55 2008  Thu Mar 13 23:21:55
2008
 8   DM_JOB_QUERY_REQ       10.1.0.25 Thu Mar 13 23:21:59 2008  Thu Mar 13 23:21:59
2008
-----
          Job Timing Information [since the last start operation]
```

■ show dmm job

Send documentation comments to mdsfeedback-doc@cisco.com

```
-----
Create Time      :Thu Mar 13 23:21:39 2008
Scheduled Time   :Not Applicable
Start Time       :Not Applicable
Finish-request Time :Not Applicable
Completed Time   :Not Applicable
Failed Time       :Not Applicable
Stopped Time      :Not Applicable
Verify Start Time :Not Applicable
Verify Completed Time :Not Applicable
Verify Failed Time :Not Applicable
```

Related Commands

Command	Description
ssm enable feature dmm	Enables the DMM feature.
dmm module	Enables DMM configuration on a module.

Send documentation comments to mdsfeedback-doc@cisco.com

show dmm srvr-vt-login

To display server virtual target login information, use the **show dmm srvr-vt-login** command in EXEC mode.

```
show dmm srvr-vt-login [job-id job-id] server-pwwn srvr-pwwn vt-pwwn vt-pwwn
{fc_rdrt-fsm-eventlog | login-fsm-eventlog}
```

Syntax Description	job-id <i>job-id</i>	Specifies the job ID. The range is 0 to 18446744073709551615.
server-pwwn <i>srvr-pwwn</i>		Specifies the server port world-wide name. The format is hh:hh:hh:hh:hh:hh, where h is a hexadecimal number.
vt-pwwn <i>vt-pwwn</i>		Specifies the Virtual Target port world-wide name. The format is hh:hh:hh:hh:hh:hh, where h is a hexadecimal number.
fc_rdrt-fsm-eventlog		Displays the Server Virtual Target FC-Redirect FSM Event Log.
login-fsm-eventlog		Displays the Server Virtual Target FSM Event Log.

Defaults None.

Command Modes EXEC mode.

Command History	Release	Modification
	3.2(1)	This command was introduced.

Usage Guidelines You must connect to an SSM on your switch to execute DMM **show** commands. Use the **show module** command to determine the slot number of an SSM on your switch. Use the **attach module slot** command to connect to the SSM.

Examples The following example shows how to display the server VT login summary:

```
switch# show dmm srvr-vt-login
=====
Data Mobility Manager Server VT Login Information
=====
Id Job Id    VSAN Srvr pWWN          Srvr FCID VT pWWN          VT FCID
State (FC Redirect/Login)
=====
1 1187978941 1 21:32:00:0d:ec:02:2d:82 0x660000 21:36:00:0d:ec:02:2d:82
0x660003 (READY/WAITING_PLOGI)
2 1187978941 1 21:32:00:0d:ec:02:2d:82 0x660000 21:34:00:0d:ec:02:2d:82
0x66000a (READY/WAITING_PLOGI)

Number of Logins :2
```

■ **show dmm svr-vt-login**

Send documentation comments to mdsfeedback-doc@cisco.com

The following example shows how to display the event log for a specified VT:

```
switch# show dmm svr-vt-login job-id 1187978941 server-pwwn 21:32:00:0d:ec:02:2d:82
vt-pwwn 21:36:00:0d:ec:02:2d:82 login-fsm-e
```

```
=====
Server/VT Login FSM Event Log -> Job Id : 1187978941 Server : 21:32:00:0d:ec:02:2d:82 VT
: 21:36:00:0d:ec:02:2d:82
=====

Log Entry: 1 time: Fri Aug 24 11:09:19 2007
Curr state: DMM_SRVR_VT_LOGIN_S_NULL
Triggered event: DMM_SRVR_VT_LOGIN_E_START_ACTION

Log Entry: 2 time: Fri Aug 24 11:09:19 2007
Curr state: DMM_SRVR_VT_LOGIN_S_WAITING_PLOGI
Triggered event: DMM_SRVR_VT_LOGIN_E_LOGIN_DONE_OK
```

Related Commands	Command	Description
	ssm enable feature dmm	Enables the DMM feature.
	dmm module	Enables DMM configuration on a module.

Send documentation comments to mdsfeedback-doc@cisco.com

show dmm vt

To display virtual target information, use the **show dmm vt** command in EXEC mode.

show dmm vt vt-job-id job-id pwwn vt-pwwn vt-fsm-eventlog

Syntax Description	<p>vt-job-id job-id Specifies the virtual target job ID. The range is 0 to 18446744073709551615.</p> <p>pwwn vt-pwwn Specifies the virtual target port world-wide name. The format is hh:hh:hh:hh:hh:hh:hh:hh, where h is a hexadecimal number.</p> <p>vt-fsm-eventlog Displays the Virtual Target FSM Event Log.</p>
---------------------------	--

Defaults	None.
-----------------	-------

Command Modes	EXEC mode.
----------------------	------------

Command History	Release	Modification
	3.2(1)	This command was introduced.

Usage Guidelines	You must connect to an SSM on your switch to execute DMM show commands. Use the show module command to determine the slot number of an SSM on your switch. Use the attach module slot command to connect to the SSM.
-------------------------	---

Examples	The following example displays virtual target information:
-----------------	--

```
switch# attach module 3
Attaching to module 3 ...
To exit type 'exit', to abort type '$.'
Bad terminal type: "ansi". Will assume vt100.
module-3# show dmm vt
=====
          Data Mobility Manager VT Information
=====
  Id Job Id      VT pWWN           VSAN FCID      IF-IDX     PORT   STATE
=====
  1 1177009472  2f:00:00:05:30:01:9e:88    3    0xee00a0  0x1110000  0x10   VT_UP
  2 1177009472  2c:fe:00:05:30:01:9e:88    3    0xee00a1  0x1110000  0x10   VT_UP
Number of VTs :2
```

Related Commands	Command	Description
	ssm enable feature dmm	Enables the DMM feature.
	dmm module	Enables DMM configuration on a module.

debug dmm-debug***Send documentation comments to mdsfeedback-doc@cisco.com***

debug dmm-debug

To enable debugging for DMM, use the **debug dmm-debug** command.

```
debug dmm-debug {all | common-err | common-ev | fsm | init | itl-err | itl-ev | job-err | job-ev |
msghndlr-err | msghndlr-ev | p2p-err | p2p-ev | timer | vi-lun-err | vi-lun-ev | vi-tgt-err |
vi-tgt-ev}
```

Syntax Description	
all	Enables all DMM debug options.
common-err	Enables debugging for DMM common errors.
common-ev	Enables debugging for DMM common events.
fsm	Enables debugging for DMM FSM.
init	Enables debugging for DMM initialization.
itl-err	Enables debugging for DMM ITL errors.
itl-ev	Enables debugging for DMM ITL events.
job-err	Enables debugging for DMM job errors.
job-ev	Enables debugging for DMM job events.
msghndlr-err	Enables debugging for DMM message handler errors.
msghndlr-ev	Enables debugging for DMM message handler events.
p2p-err	Enables debugging for DMM P2P errors.
p2p-ev	Enables debugging for DMM P2P events.
timer	Enables debugging for the DMM timer.
vi-lun-err	Enables debugging for Virtual Initiator LUN errors.
vi-lun-ev	Enables debugging for Virtual Initiator LUN events.
vi-tgt-err	Enables debugging for Virtual Initiator and Target errors.
vi-tgt-ev	Enables debugging for Virtual Initiator and Target events.

Defaults Debugging for DMM is disabled.

Command Modes EXEC mode.

Command History	Release	Modification
	3.2(1)	This command was introduced.

Usage Guidelines You must connect to an SSM on your switch to execute DMM debug commands. Use the **show module** command to determine the slot number of an SSM on your switch. Use the **attach module slot** command to connect to the SSM.

Send documentation comments to mdsfeedback-doc@cisco.com

Examples

The following example enables all the DMM debug options:

```
switch# debug dmm-debug all
```

Related Commands

Command	Description
ssm enable feature dmm	Enables the DMM feature.
dmm module	Configures DMM.

■ debug dmm-debug

Send documentation comments to mdsfeedback-doc@cisco.com