



## L Commands

---

This chapter describes the system management commands that begin with L.

# locator-led

To turn on the locator LED of a Fabric Extender, use the **locator-led** command. To turn off the locator LED, use the **no** form of this command.

```
locator-led {chassis pattern {long| medium | short} | fex fex_number}
```

```
no locator-led {chassis pattern {long| medium | short} | fex fex_number}
```

## Syntax Description

<b>chassis</b>	Specifies the Blink chassis LED.
<b>pattern</b>	Specifies the LED blink pattern.
<b>long</b>	Specifies a long LED blink.
<b>medium</b>	Specifies a medium LED blink.
<b>short</b>	Specifies a short LED blink.
<i>fex_number</i>	Fabric Extender number. The range is from 100 to 199.

## Command Default

None

## Command Modes

EXEC mode

## Command History

Release	Modification
5.0(2)N1(1)	This command was introduced.

## Usage Guidelines

Use the **locator-led** command to toggle the locator LED of a Fabric Extender, which allows you to easily identify the machine in a busy data center.

## Examples

This example shows how to turn on the locator LED for a specific Fabric Extender chassis:

```
switch# locator-led fex 100
switch#
```

This example shows how to turn off the locator beacon LED for a specific Fabric Extender chassis:

```
switch# no locator-led fex 100
switch#
```

## Related Commands

Command	Description
<b>show fex</b>	Displays all configured Fabric Extender chassis connected to the switch.
<b>show locator-led</b>	Displays the status of the locator LED in Fabric Extender modules.

# logging abort

To discard the pending changes to the syslog server configuration, use the **logging abort** command.

## logging abort

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** Global configuration mode

Command History	Release	Modification
	6.0(2)N1(1)	This command was introduced.

**Examples** This example shows how to discard the changes made to the syslog server configuration:

```
switch(config)# logging distribute
switch(config)# logging abort
switch(config)#
```

Related Commands	Command	Description
	<b>logging distribute</b>	Enables the distribution of the syslog server configuration to network switches using the CFS infrastructure.
	<b>show logging pending</b>	Displays the pending changes to the syslog server configuration.
	<b>show logging status</b>	Displays the logging status.

# logging commit

To commit the pending changes to the syslog server configuration for distribution to the switches in the fabric, use the **logging commit** command.

## logging commit

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** Global configuration mode

Command History	Release	Modification
	6.0(2)N1(1)	This command was introduced.

**Examples** This example shows how to commit the distribution of the syslog server configuration:

```
switch(config)# logging distribute
switch(config)# commit
switch(config)#
```

Related Commands	Command	Description
	<b>logging distribute</b>	Enables the distribution of the syslog server configuration to network switches using the CFS infrastructure.
	<b>show logging status</b>	Displays the logging status.

# logging console

To enable logging messages to the console session, use the **logging console** command. To disable logging messages to the console session, use the **no** form of this command.

**logging console** [*severity-level*]

**no logging console**

<b>Syntax Description</b>	<p><i>severity-level</i></p> <p>(Optional) Number of the desired severity level at which messages should be logged. Messages at or numerically lower than the specified level are logged. Severity levels are as follows:</p> <ul style="list-style-type: none"> <li>• <b>0</b>—emergency: System unusable</li> <li>• <b>1</b>—alert: Immediate action needed</li> <li>• <b>2</b>—critical: Critical condition—default level</li> <li>• <b>3</b>—error: Error condition</li> <li>• <b>4</b>—warning: Warning condition</li> <li>• <b>5</b>—notification: Normal but significant condition</li> <li>• <b>6</b>—informational: Informational message only</li> <li>• <b>7</b>—debugging: Appears during debugging only</li> </ul>
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	6.0(2)N1(1)	This command was introduced.

**Examples** This example shows how to enable logging messages with a severity level of 4 (warning) or higher to the console session:

```
switch# configure terminal
switch(config)# logging console 4
```

Related Commands	Command	Description
	<b>show logging console</b>	Displays the console logging configuration.

# logging distribute

To enable the distribution of the syslog server configuration to network switches using the Cisco Fabric Services (CFS) infrastructure, use the **logging distribute** command. To disable the distribution, use the **no** form of this command.

**logging distribute**

**no logging distribute**

**Syntax Description** This command has no arguments or keywords.

**Command Default** Distribution is disabled.

**Command Modes** Global configuration mode

Command History	Release	Modification
	6.0(2)N1(1)	This command was introduced.

**Examples** This example shows how to enable the distribution of the syslog server configuration:

```
switch(config)# logging distribute
switch(config)#
```

This example shows how to disable the distribution of the syslog server configuration:

```
switch(config)# no logging distribute
switch(config)#
```

Related Commands	Command	Description
	<b>logging abort</b>	Cancels the pending changes to the syslog server configuration.
	<b>logging commit</b>	Commits the changes to the syslog server configuration for distribution to the switches in the fabric.
	<b>show logging status</b>	Displays the logging status.

# logging event

To log interface events, use the **logging event** command. To disable logging of interface events, use the **no** form of this command.

**logging event port {link-status | trunk-status} {default | enable}**

**no logging event port {link-status | trunk-status} {default | enable}**

Syntax Description	link-status	Specifies to log all UP/DOWN and CHANGE messages.
	trunk-status	Specifies to log all TRUNK status messages.
	default	Specifies to the default logging configuration is used by interfaces not explicitly configured.
	enable	Enables the logging to override the port level configuration.

**Command Default** None

**Command Modes** Global configuration mode

Command History	Release	Modification
	6.0(2)N1(1)	This command was introduced.

**Examples** This example shows how to log interface events:

```
switch# configure terminal
switch(config)# logging event link-status default
```

Related Commands	Command	Description
	<b>show logging</b>	Displays the logging status.

# logging event port

To log events on an interface, use the **logging event port** command. To disable logging of interface events, use the **no** form of this command.

**logging event port** {link-status | trunk-status} [default]

**no logging event port** {link-status | trunk-status}

## Syntax Description

<b>link-status</b>	Specifies to log all UP/DOWN and CHANGE messages.
<b>trunk-status</b>	Specifies to log all TRUNK status messages.
<b>default</b>	(Optional) Specifies the default logging configuration that is used by interfaces not explicitly configured.

## Command Default

None

## Command Modes

Interface configuration mode

## Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

## Examples

This example shows how to log interface events:

```
switch# configure terminal
switch(config)# interface ethernet 1/1
switch(config-if)# logging event port link-status default
```

## Related Commands

Command	Description
<b>show interface</b>	Displays the interface configuration information.
<b>show logging</b>	Displays the logging status.

# logging ip access-list cache

To configure the Optimized ACL Logging (OAL) parameters, use the **logging ip access-list cache** command. To reset to the default settings, use the **no** form of this command.

```
logging ip access-list cache {{entries num_entries} | {interval seconds} | {threshold
num_packets}}
```

```
no logging ip access-list cache {{entries num_entries} | {interval seconds} | {threshold
num_packets}}
```

Syntax Description		
<b>entries</b> <i>num_entries</i>	Specifies the maximum number of log entries that are cached in the software. The range is from 0 to 1048576. The default value is 8000 entries.	
<b>interval</b> <i>seconds</i>	Specifies the maximum time interval before an entry is sent to a syslog. The range is from 5 to 86400. The default value is 300 seconds.	
<b>threshold</b> <i>num_packets</i>	Specifies the number of packet matches (hits) before an entry is sent to a syslog. The range is from 0 to 1000000. The default value is 0 packets—rate limiting is off; the system log is not triggered by the number of packet matches.	

**Defaults** None

**Command Modes** Global configuration

**Supported User Roles** network-admin

Command History	Release	Modification
	6.0(2)N1(1)	This command was introduced.

**Usage Guidelines** This command does not require a license.

**Examples** This example shows how to specify the maximum number of log entries that are cached in the software:

```
switch# configure terminal
switch(config)# logging ip access-list cache entries 200
switch(config)#
```

This example shows how to specify the maximum time interval before an entry is sent to the system log:

```
switch# configure terminal
switch(config)# logging ip access-list cache interval 350
switch(config)#
```

This example shows how to specify the number of packet matches before an entry is sent to the system log:

```
switch# configure terminal
switch(config)# logging ip access-list cache threshold 125
switch(config)#
```

---

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>show logging ip access-list</b>	Displays the status of IP access list logging.

---

# logging level

To enable logging messages from a defined facility that have the specified severity level or higher, use the **logging level** command. To disable logging messages from a defined facility, use the **no** form of this command.

**logging level** *facility severity-level*

**no logging level** *facility severity-level*

<b>Syntax Description</b>	<i>facility</i>	Facility. The facilities are listed in <a href="#">Table 1-1 of Appendix 1, “System Message Logging Facilities.”</a>  To apply the same severity level to all facilities, use the <b>all</b> facility.
	<i>severity-level</i>	Number of the desired severity level at which messages should be logged. Messages at or numerically lower than the specified level are logged. Severity levels are as follows: <ul style="list-style-type: none"> <li>• <b>0</b>—emergency: System unusable</li> <li>• <b>1</b>—alert: Immediate action needed</li> <li>• <b>2</b>—critical: Critical condition—default level</li> <li>• <b>3</b>—error: Error condition</li> <li>• <b>4</b>—warning: Warning condition</li> <li>• <b>5</b>—notification: Normal but significant condition</li> <li>• <b>6</b>—informational: Informational message only</li> <li>• <b>7</b>—debugging: Appears during debugging only</li> </ul>

**Command Default** None

**Command Modes** Global configuration mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
		6.0(2)N1(1)

**Examples** This example shows how to enable logging messages from the AAA facility that have a severity level of 2 or higher:

```
switch(config)# logging level aaa 2
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>show logging level</b>	Displays the facility logging level configuration.

# logging logfile

To configure the name of the log file used to store system messages and the minimum severity level to log, use the **logging logfile** command. To disable logging to the log file, use the **no** form of this command.

**logging logfile** *logfile-name severity-level [size bytes]*

**no logging logfile** [*logfile-name severity-level [size bytes]*]

## Syntax Description

<i>logfile-name</i>	Name of the log file to be used to store system messages.
<i>severity-level</i>	Number of the desired severity level at which messages should be logged. Messages at or numerically lower than the specified level are logged. Severity levels are as follows: <ul style="list-style-type: none"> <li>• <b>0</b>—emergency: System unusable</li> <li>• <b>1</b>—alert: Immediate action needed</li> <li>• <b>2</b>—critical: Critical condition—default level</li> <li>• <b>3</b>—error: Error condition</li> <li>• <b>4</b>—warning: Warning condition</li> <li>• <b>5</b>—notification: Normal but significant condition</li> <li>• <b>6</b>—informational: Informational message only</li> <li>• <b>7</b>—debugging: Appears during debugging only</li> </ul>
<i>size bytes</i>	(Optional) Specifies a maximum file size. The default file size is 4194304 bytes and can be configured from 4096 to 4194304 bytes.

## Command Default

None

## Command Modes

Global configuration mode

## Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

## Examples

This example shows how to configure a log file called logfile to store system messages and set its severity level to 4:

```
switch(config)# logging logfile logfile 4
```

## Related Commands

Command	Description
<b>show logging logfile</b>	Displays the log file.

# logging module

To enable module log messages, use the **logging module** command. To disable module log messages, use the **no** form of this command.

**logging module** [*severity-level*]

**no logging module**

## Syntax Description

*severity-level*

(Optional) Number of the desired severity level at which messages should be logged. Messages at or numerically lower than the specified level are logged. Severity levels are as follows:

- **0**—emergency: System unusable
- **1**—alert: Immediate action needed
- **2**—critical: Critical condition
- **3**—error: Error condition
- **4**—warning: Warning condition
- **5**—notification: Normal but significant condition—default level
- **6**—informational: Informational message only
- **7**—debugging: Appears during debugging only

## Command Default

None

## Command Modes

Global configuration mode

## Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

## Usage Guidelines

Set a specified severity level or use the default.

## Examples

This example shows how to enable module log messages:

```
switch(config)# logging module
```

## Related Commands

Command	Description
<b>show logging module</b>	Displays the module logging status.

# logging monitor

To enable the device to log messages to the monitor (terminal line), use the **logging monitor** command. To disable monitor log messages, use the **no** form of this command.

**logging monitor** [*severity-level*]

**no logging monitor**

<b>Syntax Description</b>	<p><i>severity-level</i></p> <p>(Optional) Number of the desired severity level at which messages should be logged. Messages at or numerically lower than the specified level are logged. Severity levels are as follows:</p> <ul style="list-style-type: none"> <li>• <b>0</b>—emergency: System unusable</li> <li>• <b>1</b>—alert: Immediate action needed</li> <li>• <b>2</b>—critical: Critical condition—default level</li> <li>• <b>3</b>—error: Error condition</li> <li>• <b>4</b>—warning: Warning condition</li> <li>• <b>5</b>—notification: Normal but significant condition</li> <li>• <b>6</b>—informational: Informational message only</li> <li>• <b>7</b>—debugging: Appears during debugging only</li> </ul>
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	6.0(2)N1(1)	This command was introduced.

<b>Usage Guidelines</b>	This configuration applies to Telnet and Secure Shell (SSH) sessions.
-------------------------	---

<b>Examples</b>	<p>This example shows how to enable monitor log messages:</p> <pre>switch(config)# logging monitor</pre>
-----------------	--

Related Commands	Command	Description
	<b>show logging monitor</b>	Displays the status of monitor logging.

# logging server

To configure a remote syslog server at the specified hostname or IPv4/IPv6 address, use the **logging server** command. To disable the remote syslog server, use the **no** form of this command.

```
logging server host [severity-level] [facility {auth | authpriv | cron | daemon | ftp | kernel | local0 | local1 | local2 | local3 | local4 | local5 | local6 | local7 | lpr | mail | news | syslog | user | uucp} | use-vrf {vrf_name | management}]
```

```
no logging server host [severity-level] [facility {auth | authpriv | cron | daemon | ftp | kernel | local0 | local1 | local2 | local3 | local4 | local5 | local6 | local7 | lpr | mail | news | syslog | user | uucp} | use-vrf {vrf_name | management}]
```

Syntax Description	
<i>host</i>	Hostname or IPv4/IPv6 address of the remote syslog server.
<i>severity-level</i>	(Optional) Number of the desired severity level at which messages should be logged. Messages at or numerically lower than the specified level are logged. Severity levels are as follows: <ul style="list-style-type: none"> <li>• <b>0</b>—emergency: System unusable</li> <li>• <b>1</b>—alert: Immediate action needed</li> <li>• <b>2</b>—critical: Critical condition—default level</li> <li>• <b>3</b>—error: Error condition</li> <li>• <b>4</b>—warning: Warning condition</li> <li>• <b>5</b>—notification: Normal but significant condition</li> <li>• <b>6</b>—informational: Informational message only</li> <li>• <b>7</b>—debugging: Appears during debugging only</li> </ul>
<b>facility</b> <i>facility</i>	(Optional) Specifies the outgoing <i>facility</i> . The facilities are listed in <a href="#">Table 1-1 of Appendix 1, “System Message Logging Facilities.”</a> The default outgoing facility is <b>local7</b> .
<b>vrf</b> <i>vrf_name</i>	(Optional) Specifies the virtual routing and forwarding (VRF) to be used in the remote server. The name can be a maximum of 32 alphanumeric characters.
<b>management</b>	Specifies the management VRF. This is the default VRF.

**Command Default** The default outgoing facility is **local7**.  
The default VRF is **management**.

**Command Modes** Global configuration mode

Command History	Release	Modification
	6.0(2)N1(1)	This command was introduced.

---

**Examples**

This example shows how to configure a remote syslog server at a specified IPv4 address, using the default outgoing facility:

```
switch(config)# logging server 192.168.2.253
```

This example shows how to configure a remote syslog server at a specified hostname with severity level 5 or higher:

```
switch(config)# logging server syslogA 5
```

---

**Related Commands**

Command	Description
<code>show logging server</code>	Displays the configured syslog servers.

# logging timestamp

To set the logging time-stamp units, use the **logging timestamp** command. To reset the logging time-stamp units to the default, use the **no** form of this command.

**logging timestamp** { **microseconds** | **milliseconds** | **seconds** }

**no logging timestamp** { **microseconds** | **milliseconds** | **seconds** }

## Syntax Description

<b>microseconds</b>	Specifies the units to use for logging timestamps in microseconds. The default units are <b>seconds</b> .
<b>milliseconds</b>	Specifies the units to use for logging timestamps in milliseconds.
<b>seconds</b>	Specifies the units to use for logging timestamps in seconds. The default units are <b>seconds</b> .

## Command Default

None

## Command Modes

Global configuration mode

## Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

## Usage Guidelines

By default, the units are seconds.

## Examples

This example shows how to set the logging time-stamp units to microseconds:

```
switch(config)# logging timestamp microseconds
```

## Related Commands

Command	Description
<b>show logging timestamp</b>	Displays the logging time-stamp configuration.