



G Commands

This chapter describes the Cisco NX-OS unicast routing commands that begin with the letter G.

glbp

To enter GLBP configuration mode and create a Gateway Load Balancing Protocol (GLBP) group, use the **glbp** command. To delete a GLBP group, use the **no** form of this command.

glbp *group*

no glbp *group*

Syntax Description	<i>group</i> GLBP group number. The range is from 0 to 1023.				
Defaults	None				
Command Modes	Interface configuration				
Supported User Roles	Network Administrator VDC Administrator				
Command History	<table><thead><tr><th>Release</th><th>Modification</th></tr></thead><tbody><tr><td>4.0(1)</td><td>This command was introduced.</td></tr></tbody></table>	Release	Modification	4.0(1)	This command was introduced.
Release	Modification				
4.0(1)	This command was introduced.				
Usage Guidelines	Use the glbp command to enter GLBP configuration mode and create a GLBP group if the group does not exist.				

Send document comments to nexus7k-docfeedback@cisco.com

**Note**

You must configure all GLBP options before you use the **ip** command to assign a virtual IP address and activate the GLBP group.

This command does not require a license.

Examples

The following example shows how to create GLBP group 10 on Ethernet interface 1/1:

```
switch(config)# interface ethernet 1/1  
switch(config-if)# glbp 10
```

Related Commands

Command	Description
ip (GLBP)	Configures a virtual IP address and activates the GLBP group.
show glbp	Displays GLBP information.

[Send document comments to nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com)

graceful-restart (BGP)

To enable the graceful restart and the graceful restart helper capability, use the graceful-restart or the graceful-restart-helper router BGP configuration mode command. To disable graceful restart and the graceful restart helper capability, use the no form of this command.

graceful-restart [**restart-time** *restart-time* | **stalepath-time** *stalepath-time*]

graceful-restart-helper

no graceful-restart {**restart-time** *restart-time* | **stalepath-time** *stalepath-time*} |
graceful-restart-helper

Syntax Description	
restart-time <i>restart-time</i>	(Optional) Sets the maximum time period that the local router will wait for a graceful-restart-capable neighbor to return to normal operation after a restart event occurs. Range: 1 to 3600. Default: 120.
stalepath-time <i>stalepath-time</i>	(Optional) Sets the maximum time period that the local router will hold stale paths for a restarting peer. All stale paths are deleted after this timer expires. Range: 1 to 3600. Default: 300.
graceful-restart-helper	Enables the graceful restart helper capability.

Command Default Graceful restart and graceful restart helper are enabled by default. The following default values are used when the **graceful-restart** command is entered without any keywords or arguments:

- *restart-time*: 120 seconds
- *stalepath-time*: 360 seconds



Note

Changing the restart and stalepath timer values is not required to enable the BGP graceful restart capability. The default values are optimal for most network deployments, and these values should be adjusted only by an experienced network operator.

Command Modes Neighbor address-family configuration
Router bgp configuration
VRF configuration

SupportedUserRoles network-admin
vdc-admin

Command History	Release	Modification
	4.0(1)	This command was introduced.

Send document comments to nexus7k-docfeedback@cisco.com

Usage Guidelines

The **graceful-restart** command is used to configure or disable the graceful restart capability on a router in a BGP network. If the graceful restart capability is enabled after a BGP session has been established, you will need to restart the session with a soft or hard reset.

The default timer values for this feature are optimal for most network deployments. We recommend that they are adjusted only by experienced network operators. When adjusting the timer values, the restart timer should not be set to a value greater than the hold time that is carried in the OPEN message. If consecutive restart operations occur, routes (from a restarting router) that were previously marked as stale will be deleted.

The **graceful-restart-helper** command is used to configure the local BGP router to support the graceful restart of a remote BGP peer.

Examples

The following example shows how to enable the BGP graceful restart capability:

```
switch(config-router)# graceful-restart
switch(config-router)#
```

The following example shows how to set the restart timer is set to 240 seconds:

```
switch(config-router)# graceful-restart restart-timer 240
switch(config-router)#
```

graceful-restart (EIGRP)

To enable graceful restart for the Enhanced Interior Gateway Routing Protocol (EIGRP), use the **graceful-restart** command. To reset to default, use the **no** form of this command.

graceful-restart

no graceful restart

Syntax Description

This command has no arguments or keywords.

Defaults

Enabled

Command Modes

Address-family configuration
Router configuration
Router VRF configuration

Supported User Roles

network-admin
vdc-admin

Command History

Release	Modification
4.0(3)	This command was introduced.

Send document comments to nexus7k-docfeedback@cisco.com**Usage Guidelines**

Use the **graceful-restart** command to allow EIGRP to remain in the data forwarding path through a process restart.

This command requires the Enterprise Services license.

Examples

The following example shows how to enable graceful restart:

```
switch(config)# router eigrp 1  
switch(config-router)# graceful-restart
```

Related Commands

Command	Description
timers nsf	Configures timers for nonstop forwarding and graceful restart.

Send document comments to nexus7k-docfeedback@cisco.com

graceful-restart (IS-IS)

To enable the graceful restart for an IS-IS process, use the graceful-restart configuration mode command. To disable graceful restart, use the no form of this command.

graceful-restart

no graceful-restart

Syntax Description This command has no arguments or keywords.

Command Default Graceful restart is enabled by default.

Command Modes Address-family configuration
Router configuration
VRF configuration

SupportedUserRoles network-admin
vdc-admin

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines The **graceful-restart** command is used to configure or disable the graceful restart capability on a router in an IS-IS network. If the graceful restart capability is enabled after an IS-IS session has been established, you will need to restart the session with a soft or hard reset.

This command requires the Enterprise Services license.

Examples The following example shows how to enable the graceful restart capability:

```
switch(config-router)# graceful-restart
switch(config-router)#
```

Related Commands	Command	Description
	feature isis	Enables IS-IS on the router.
	router isis	Creates an IS-IS instance.

[Send document comments to nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com)

graceful-restart (OSPF)

To configure nonstop forwarding for Open Shortest Path First (OSPF), use the **graceful-restart** command. To disable this feature, use the **no** form of this command.

graceful-restart [**grace-period** *seconds* | **helper-disable** | **planned-only**]

no graceful-restart [**grace-period** *seconds* | **helper-disable** | **planned-only**]

Syntax Description		
grace-period <i>seconds</i>	(Optional) Configures the maximum interval (in seconds) that another router should wait for this router to gracefully restart. The range is from 5 to 1800.	
helper-disable	(Optional) Disables helper mode. The router will not participate in the graceful restart of a neighbor router.	
planned-only	(Optional) Enables graceful restart for controlled restarts only.	

Defaults Enabled by default. Grace period: 60 seconds

Command Modes Router configuration

Supported User Roles network-admin
vdc-admin

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines Use the **graceful-restart** command to allow OSPF to remain in the data forwarding path through a process restart. Set the grace period long enough to allow a typical reboot cycle for Cisco NX-OS. Do not set the grace period too long or your network will be relying on old route information.

This command requires the Enterprise Services license.

Examples The following example shows how to configure a graceful restart to occur only for a planned restart:

```
switch(config)# router ospf 202
switch(config-router)# graceful-restart grace-period 300 planned-only
```

Related Commands	Command	Description
	flush-routes	Flushes routes on a nongraceful controlled restart.

[Send document comments to nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com)

graceful-restart (OSPFv3)

To configure nonstop forwarding for Open Shortest Path First version 3 (OSPFv3), use the **graceful-restart** command. To disable this feature, use the **no** form of this command.

graceful-restart [**grace-period** *seconds* | **helper-disable** | **planned-only**]

no graceful-restart [**grace-period** *seconds* | **helper-disable** | **planned-only**]

Syntax Description		
grace-period <i>seconds</i>	(Optional) Configures the maximum interval (in seconds) that another router should wait for this router to gracefully restart. The range is from 5 to 1800.	
helper-disable	(Optional) Disables helper mode. The router will not participate in the graceful restart of a neighbor router.	
planned-only	(Optional) Enables graceful restart for controlled restarts only.	

Defaults Enabled by default. Grace period: 60 seconds

Command Modes Router configuration

Supported User Roles network-admin
vdc-admin

Command History	Release	Modification
	4.0(1)	This command was introduced.

Usage Guidelines Use the **graceful-restart** command to allow OSPFv3 to remain in the data forwarding path through a process restart. Set the grace period long enough to allow a typical reboot cycle for Cisco NX-OS. Do not set the grace period too long or your network will be relying on old route information.

This command requires the Enterprise Services license.

Examples This example shows how to configure a graceful restart to occur only for a planned restart:

```
switch(config)# router ospfv3 202
switch(config-router)# graceful-restart grace-period 300 planned-only
```

Related Commands	Command	Description
	flush-routes	Flushes routes on a nongraceful controlled restart.

Send document comments to nexus7k-docfeedback@cisco.com

Send document comments to nexus7k-docfeedback@cisco.com