



Cisco Nexus 7000 Series NX-OS Virtual Device Context Commands

This chapter describes the Cisco Nexus 7000 Series NX-OS virtual device context (VDC) commands.

allocate interface ethernet

To allocate Ethernet interfaces to a virtual device context (VDC), use the **allocate interface ethernet** command.

allocate interface ethernet *slot/port*

allocate interface ethernet *slot/port* [- *port*]

allocate interface ethernet *slot/port* , **ethernet** *slot1/port ...* [, **ethernet** *slot1/port*]

| | |
|---------------------------|--|
| Syntax Description | <i>slot/port</i> Slot number and port number for the Ethernet interface. |
|---------------------------|--|

| | |
|-----------------|------|
| Defaults | None |
|-----------------|------|

| | |
|----------------------|-------------------|
| Command Modes | VDC configuration |
|----------------------|-------------------|

| | |
|---------------------------|---------------|
| SupportedUserRoles | network-admin |
|---------------------------|---------------|

| Command History | Release | Modification |
|------------------------|----------------|------------------------------|
| | 4.0(1) | This command was introduced. |

| | |
|-------------------------|---|
| Usage Guidelines | You can use this command only in the default VDC (VDC 1). |
|-------------------------|---|

Send document comments to nexus7k-docfeedback@cisco.com

Initially, all interfaces belong to the default VDC. You can allocate individual interfaces, ranges of interface, or lists of interfaces.

Use the **show vdc membership** command to display the current allocation of interfaces among the VDCs on the physical device.

**Note**

All configuration for the interface is lost when you allocate them to another VDC.

To remove the interface from the VDC and return them to the default VDC, you must enter VDC configuration mode for the default VDC and allocate the interface to the default VDC.

This command requires the Advanced Services license.

Examples

This example shows how to allocate one Ethernet interface to a VDC:

```
switch# config t
switch(config)# vdc MyDevice
switch(config-vdc)# allocate interface ethernet 2/1
Moving ports will cause all config associated to them in source vdc to be removed. Are you
sure you want to move the ports? [yes] yes
```

This example shows how to allocate a range of Ethernet interfaces on the same module to a VDC:

```
switch# config t
switch(config)# vdc MyDevice
switch(config-vdc)# allocate interface ethernet 2/1 - 4
Moving ports will cause all config associated to them in source vdc to be removed. Are you
sure you want to move the ports? [yes] yes
```

This example shows how to allocate a list of Ethernet interfaces on the same module to a VDC:

```
switch# config t
switch(config)# vdc MyDevice
switch(config-vdc)# allocate interface ethernet 2/1, ethernet 2/3, ethernet 2/5
Moving ports will cause all config associated to them in source vdc to be removed. Are you
sure you want to move the ports? [yes] yes
```

This example shows how to move an Ethernet interface back to the default VDC:

```
switch# config t
switch(config)# vdc switch
switch(config-vdc)# allocate interface ethernet 2/1
Moving ports will cause all config associated to them in source vdc to be removed. Are you
sure you want to move the ports? [yes] yes
```

Related Commands

| Command | Description |
|----------------------------|---|
| show vdc membership | Displays VDC interface membership information. |
| vdc | Creates or specifies a VDC and enters VDC configuration mode. |

Send document comments to nexus7k-docfeedback@cisco.com

copy running-config startup-config vdc-all

To copy the running configuration for all VDCs to the startup configuration, use the **show copy running-config startup-config vdc-all** command.

copy running-config startup-config vdc-all

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any command mode

SupportedUserRoles network-admin

| Command History | Release | Modification |
|-----------------|---------|------------------------------|
| | 4.0(1) | This command was introduced. |

Usage Guidelines You can use this command only in the default VDC (VDC 1).
This command does not require a license.

Examples This example shows how to copy the running configuration for all VDCs on the physical device to the startup configuration:

```
switch# copy running-config startup-config vdc-all
[#####] 100%
```

Send document comments to nexus7k-docfeedback@cisco.com

ha-policy

To configure the high availability (HA) policy for a virtual device context (VDC), use the **ha-policy** command.

```
ha-policy {dual-sup {bringdown | restart | switchover} | single-sup {bringdown | reload |
restart}}
```

| Syntax Description | | |
|--------------------|--|--|
| dual-sup | | Specifies the HA policy for devices with dual supervisor modules. |
| bringdown | | Puts the VDC in failed state. To recover from the failed state, you must reload the physical device. |
| restart | | Deletes the VDC and recreates it using the startup configuration. |
| switchover | | Initiates a supervisor module switchover. |
| dual-sup | | Specifies the HA policy for devices with dual supervisor modules. |
| reload | | Reloads the physical device and recreates the VDC using the startup configuration. |

| Defaults | |
|-----------------|---|
| Default VDC: | dual-sup default is switchover single-sup default is reload |
| Nondefault VDC: | dual-sup default is switchover single-sup default is restart |

| Command Modes | |
|---------------|-------------------|
| | VDC configuration |

| SupportedUserRoles | |
|--------------------|---------------|
| | network-admin |

| Command History | Release | Modification |
|-----------------|---------|------------------------------|
| | 4.0(1) | This command was introduced. |

| Usage Guidelines | |
|------------------|---|
| | You can use this command only in the default VDC (VDC 1). |
| | You cannot change the HA policy for the default VDC. |
| | This command requires the Advanced Services license. |

| Examples | |
|----------|--|
| | This example shows how to specify the HA policy for a VDC: |
| | <pre>switch# config t switch(config)# vdc MyDevice switch(config-vdc)# ha-policy reset</pre> |

Send document comments to nexus7k-docfeedback@cisco.com

| Related Commands | Command | Description |
|------------------|----------|---|
| | show vdc | Displays VDC interface membership information. |
| | vdc | Creates or specifies a VDC and enters VDC configuration mode. |

[Send document comments to nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com)

limit-resource monitor-session

To configure Switched Port Analyzer (SPAN) monitor session resource limits for a virtual device context (VDC) or a VDC resource template, use the **limit-resource monitor-session** command. To revert to the defaults, use the **no** form of the command.

limit-resource monitor-session *minimum* *min-value* **maximum** {*max-value* | **equal-to-min**}

no limit-resource monitor-session

Syntax Description

| | |
|---------------------|--|
| minimum | Specifies the minimum value reserved for the VDC. |
| <i>min-value</i> | Minimum number of SPAN monitor sessions. The range is from 0 to 2. |
| maximum | Specifies the maximum limit value as resources are available. |
| <i>max-value</i> | Maximum number of SPAN monitor sessions. The range is from 0 to 2. |
| equal-to-min | Maximum limit is always equal to the minimum limit. |

Defaults

The default minimum is 0.
The default maximum is 2.

Command Modes

VDC configuration
VDC resource template configuration

Supported User Roles

network-admin

Command History

| Release | Modification |
|---------|------------------------------|
| 4.0(1) | This command was introduced. |

Usage Guidelines

You can use this command only in the default VDC (VDC 1).

The Cisco NX-OS software reserves the minimum limit for the resource. Changing the minimum limit for SPAN monitor sessions takes affect immediately.

This command does not require a license.

Examples

This example shows how to configure the SPAN monitor session limits for a VDC:

```
switch# config t
switch(config)# vdc MyDevice
switch(config-vdc)# limit-resource session-monitor minimum 1 maximum 2
```

Send document comments to nexus7k-docfeedback@cisco.com

This example shows how to revert to the default SPAN monitor session limits for a VDC:

```
switch# config t
switch(config)# vdc MyDevice
switch(config-vdc)# no limit-resource session-monitor
```

This example shows how to configure the SPAN monitor session limits for a VDC resource template:

```
switch# config t
switch(config)# vdc resource template MyTemplate
switch(config-vdc-template)# limit-resource session-monitor minimum 0 maximum 1
```

This example shows how to revert to the default SPAN monitor session limits for a VDC resource template:

```
switch# config t
switch(config)# vdc resource template MyTemplate
switch(config-vdc-template)# no limit-resource session-monitor
```

Related Commands

| Command | Description |
|-----------------------------------|---|
| show vdc resource [detail] | Displays VDC resource limits information. |
| show vdc resource template | Displays VDC resource limits information. |
| vdc | Creates or specifies a VDC and enters VDC configuration mode. |

[Send document comments to nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com)

limit-resource port-channel

To configure port channel resource limits for a virtual device context (VDC) or a VDC resource template, use the **limit-resource port-channel** command. To revert to the defaults, use the **no** form of the command.

limit-resource port-channel minimum *min-value* **maximum** { *max-value* | **equal-to-min** }

no limit-resource monitor-session

Syntax Description

| | |
|---------------------|---|
| minimum | Specifies the minimum value reserved for the VDC. |
| <i>min-value</i> | Minimum number of port channels. The range is from 0 to 192. |
| maximum | Specifies the maximum limit value as resources are available. |
| <i>max-value</i> | Maximum number of port channels. The range is from 0 to 192. |
| equal-to-min | Maximum limit is always equal to the minimum limit. |

Defaults

The default minimum is 0.
The default maximum is 192.

Command Modes

VDC configuration
VDC resource template configuration

Supported User Roles

network-admin

Command History

| Release | Modification |
|---------|------------------------------|
| 4.0(1) | This command was introduced. |

Usage Guidelines

You can use this command only in the default VDC (VDC 1).

The Cisco NX-OS software reserves the minimum limit for the resource. Changing the minimum limit for port channels takes affect immediately.

This command does not require a license.

Examples

This example shows how to configure the port channel limits for a VDC:

```
switch# config t
switch(config)# vdc MyDevice
switch(config-vdc)# limit-resource port-channel minimum 8 maximum 64
```

Send document comments to nexus7k-docfeedback@cisco.com

This example shows how to revert to the default port channel limits for a VDC:

```
switch# config t
switch(config)# vdc MyDevice
switch(config-vdc)# no limit-resource port-channel
```

This example shows how to configure the port channel limits for a VDC resource template:

```
switch# config t
switch(config)# vdc resource template MyTemplate
switch(config-vdc-template)# limit-resource port-channel minimum 4 maximum 128
```

This example shows how to revert to the default port channel limits for a VDC resource template:

```
switch# config t
switch(config)# vdc resource template MyTemplate
switch(config-vdc-template)# no limit-resource port-channel
```

Related Commands

| Command | Description |
|------------------------------|---|
| show vdc resource | Displays VDC resource limits information. |
| vdc | Creates or specifies a VDC and enters VDC configuration mode. |
| vdc resource template | Creates or specifies a VDC resource template and enters VDC resource template configuration mode. |

[Send document comments to nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com)

limit-resource u4route-mem

To configure IPv4 route memory resource limits for a virtual device context (VDC) or a VDC resource template, use the **limit-resource u4route-mem** command. To revert to the defaults, use the **no** form of the command.

limit-resource u4route-mem **minimum** *min-value* **maximum** *max-value*

no limit-resource u4route-mem

Syntax Description

| | |
|------------------|---|
| minimum | Specifies the minimum value reserved for the VDC. |
| <i>min-value</i> | Minimum amount of IPv4 route memory in megabytes. The range is from 1 to 80 MB. |
| maximum | Specifies the maximum limit value as resources are available. |
| <i>max-value</i> | Maximum amount of IPv4 route memory in megabytes. The maximum value is 80 MB. |

Defaults

For the default VDC, the default minimum is 32 MB.
 For the default VDC, the default maximum is 80 MB.
 For a non-default VDC, the default minimum is 8 MB
 For a non-default VDC, the default maximum is 80 MB.

Command Modes

VDC configuration
 VDC resource template configuration

Supported User Roles

network-admin

Command History

| Release | Modification |
|---------|------------------------------|
| 4.0(1) | This command was introduced. |

Usage Guidelines

You can use this command only in the default VDC (VDC 1).

The routing information base (RIB) for IPv4 is in shared memory. The total available shared memory for the RIB for all VDCs on a physical device with 4 GB of memory is 256 MB. You can have approximately 11,000 routes, each with 16 next-hops, in 4 MB of IPv4 route memory.



Note

Take care when reserving IPv4 routing map memory for a VDC not to reserve more of the shared memory than is available.

The Cisco NX-OS software reserves the minimum limit for the resource. Changing the minimum limit for IPv4 routing map memory takes affect after a device reload or a stateful supervisor module switchover.

Send document comments to nexus7k-docfeedback@cisco.com

This command does not require a license.

Examples

This example shows how to configure the IPv4 route memory limits for a VDC:

```
switch# config t
switch(config)# vdc MyDevice
switch(config-vdc)# limit-resource u4route-mem minimum 8 maximum 64
```

This example shows how to revert to the default IPv4 route memory limits for a VDC:

```
switch# config t
switch(config)# vdc MyDevice
switch(config-vdc)# no limit-resource u4route-mem
```

This example shows how to configure the IPv4 route memory limits for a VDC resource template:

```
switch# config t
switch(config)# vdc resource template MyTemplate
switch(config-vdc-template)# limit-resource u4route-mem minimum 4 maximum 40
```

This example shows how to revert to the default IPv4 route memory limits for a VDC resource template:

```
switch# config t
switch(config)# vdc resource template MyTemplate
switch(config-vdc-template)# no limit-resource u4route-mem
```

Related Commands

| Command | Description |
|------------------------------|---|
| show vdc resource | Displays VDC resource limits information. |
| vdc | Creates or specifies a VDC and enters VDC configuration mode. |
| vdc resource template | Creates or specifies a VDC resource template and enters VDC resource template configuration mode. |

[Send document comments to nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com)

limit-resource u6route-mem

To configure IPv6 route memory resource limits for a virtual device context (VDC) or a VDC resource template, use the **limit-resource u6route-mem** command. To revert to the defaults, use the **no** form of the command.

limit-resource u6route-mem minimum *min-value* **maximum** *max-value*

no limit-resource u6route-mem

Syntax Description

| | |
|------------------|---|
| minimum | Specifies the minimum value reserved for the VDC. |
| <i>min-value</i> | Minimum amount of IPv6 route memory in megabytes. The range is from 1 to 48 MB. |
| maximum | Specifies the maximum limit value as resources are available. |
| <i>max-value</i> | Maximum amount of IPv6 route memory in megabytes. The maximum value is 48 MB. |

Defaults

For the default VDC, the default minimum is 16 MB.
 For the default VDC, the default maximum is 48 MB.
 For a non-default VDC, the default minimum is 4 MB
 For a non-default VDC, the default maximum is 48 MB.

Command Modes

VDC configuration
 VDC resource template configuration

Supported User Roles

network-admin

Command History

| Release | Modification |
|---------|------------------------------|
| 4.0(1) | This command was introduced. |

Usage Guidelines

You can use this command only in the default VDC (VDC 1).

The routing information base (RIB) for IPv6 is in shared memory. The total available shared memory for RIB in a physical device with 4 GB of memory is 256 MB for both IPv4 and IPv6 route memory. You can have approximately 11,000 routes, each with 16 next-hops, in 4 MB of IPv6 route memory.



Note

Take care when reserving IPv6 route memory for a VDC not to reserve more of the shared memory than is available.

The Cisco NX-OS software reserves the minimum limit for the resource. Changing the minimum limit for IPv6 routing map memory takes affect after a device reload or a stateful supervisor module switchover.

Send document comments to nexus7k-docfeedback@cisco.com

This command does not require a license.

Examples

This example shows how to configure the IPv6 route memory limits for a VDC:

```
switch# config t
switch(config)# vdc MyDevice
switch(config-vdc)# limit-resource u6route-mem minimum 8 maximum 24
```

This example shows how to revert to the default IPv6 route memory limits for a VDC:

```
switch# config t
switch(config)# vdc MyDevice
switch(config-vdc)# no limit-resource u6route-mem
```

This example shows how to configure the IPv6 route memory limits for a VDC resource template:

```
switch# config t
switch(config)# vdc resource template MyTemplate
switch(config-vdc-template)# limit-resource u6route-mem minimum 4 maximum 32
```

This example shows how to revert to the default IPv6 route memory limits for a VDC resource template:

```
switch# config t
switch(config)# vdc resource template MyTemplate
switch(config-vdc-template)# no limit-resource u6route-mem
```

Related Commands

| Command | Description |
|------------------------------|---|
| show vdc resource | Displays VDC resource limits information. |
| vdc | Creates or specifies a VDC and enters VDC configuration mode. |
| vdc resource template | Creates or specifies a VDC resource template and enters VDC resource template configuration mode. |

[Send document comments to nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com)

limit-resource vlan

To configure VLAN resource limits for a virtual device context (VDC) or a VDC resource template, use the **limit-resource vlan** command. To revert to the defaults, use the **no** form of the command.

limit-resource vlan minimum *min-value* **maximum** { *max-value* | **equal-to-min** }

no limit-resource vlan

Syntax Description

| | |
|---------------------|---|
| minimum | Specifies the minimum value reserved for the VDC. |
| <i>min-value</i> | Minimum number of VLANs. The range is from 16 to 4094. |
| maximum | Specifies the maximum limit value as resources are available. |
| <i>max-value</i> | Maximum number of VLANs. The range is from 16 to 4094. |
| equal-to-min | Maximum limit is always equal to the minimum limit. |

Defaults

The default minimum is 16.
The default maximum is 4094.

Command Modes

VDC configuration
VDC resource template configuration

Supported User Roles

network-admin

Command History

| Release | Modification |
|---------|------------------------------|
| 4.0(1) | This command was introduced. |

Usage Guidelines

You can use this command only in the default VDC (VDC 1).

The Cisco NX-OS software reserves the minimum limit for the resource. Changing the minimum limit for VLANs takes affect immediately.

This command does not require a license.

Examples

This example shows how to configure the VLAN limits for a VDC:

```
switch# config t
switch(config)# vdc MyDevice
switch(config-vdc)# limit-resource vlan minimum 32 maximum 2056
```

Send document comments to nexus7k-docfeedback@cisco.com

This example shows how to revert to the default VLAN limits for a VDC:

```
switch# config t
switch(config)# vdc MyDevice
switch(config-vdc)# no limit-resource vlan
```

This example shows how to configure the VLAN limits for a VDC resource template:

```
switch# config t
switch(config)# vdc resource template MyTemplate
switch(config-vdc-template)# limit-resource vlan minimum 24 maximum 3000
```

This example shows how to revert to the default VLAN limits for a VDC resource template:

```
switch# config t
switch(config)# vdc resource template MyTemplate
switch(config-vdc-template)# no limit-resource vlan
```

Related Commands

| Command | Description |
|------------------------------|---|
| show vdc resource | Displays VDC resource limits information. |
| vdc | Creates or specifies a VDC and enters VDC configuration mode. |
| vdc resource template | Creates or specifies a VDC resource template and enters VDC resource template configuration mode. |

[Send document comments to nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com)

limit-resource vrf

To configure Virtual Routing and Forwarding instance (VRF) resource limits for a virtual device context (VDC) or a VDC resource template, use the **limit-resource vrf** command. To revert to the defaults, use the **no** form of the command.

limit-resource vrf minimum *min-value* **maximum** {*max-value* | **equal-to-min**}

no limit-resource vrf

Syntax Description

| | |
|---------------------|---|
| minimum | Specifies the minimum value reserved for the VDC. |
| <i>min-value</i> | Minimum number of VRFs. The range is from 16 to 8192. |
| maximum | Specifies the maximum limit value as resources are available. |
| <i>max-value</i> | Maximum number of VRFs. The range is from 16 to 8192. |
| equal-to-min | Maximum limit is always equal to the minimum limit. |

Defaults

The default minimum is 16.
The default maximum is 8192.

Command Modes

VDC configuration
VDC resource template configuration

Supported User Roles

network-admin

Command History

| Release | Modification |
|---------|------------------------------|
| 4.0(1) | This command was introduced. |

Usage Guidelines

You can use this command only in the default VDC (VDC 1).

The Cisco NX-OS software reserves the minimum limit for the resource. Changing the minimum limit for VRFs takes affect immediately.

This command does not require a license.

Examples

This example shows how to configure the VRF limits for a VDC:

```
switch# config t
switch(config)# vdc MyDevice
switch(config-vdc)# limit-resource vrf minimum 32 maximum 4000
```

Send document comments to nexus7k-docfeedback@cisco.com

This example shows how to revert to the default VRF limits for a VDC:

```
switch# config t
switch(config)# vdc MyDevice
switch(config-vdc)# no limit-resource vrf
```

This example shows how to configure the VRF limits for a VDC resource template:

```
switch# config t
switch(config)# vdc resource template MyTemplate
switch(config-vdc-template)# limit-resource vrf minimum 64 maximum 6000
```

This example shows how to revert to the default VRF limits for a VDC resource template:

```
switch# config t
switch(config)# vdc resource template MyTemplate
switch(config-vdc-template)# no limit-resource vrf
```

Related Commands

| Command | Description |
|------------------------------|---|
| show vdc resource | Displays VDC resource limits information. |
| vdc | Creates or specifies a VDC and enters VDC configuration mode. |
| vdc resource template | Creates or specifies a VDC resource template and enters VDC resource template configuration mode. |

Send document comments to nexus7k-docfeedback@cisco.com

show resource

To display the resource usage for a virtual device context (VDC), use the **show resource** command.

```
show resource [monitor-sessions | port-channel | u4route-mem | u6route-mem | vlan | vrf]
```

| Syntax Description | monitor-sessions | (Optional) Displays the monitor session resource usage. |
|--------------------|------------------|---|
| | port-channel | (Optional) Displays the port channel resource usage. |
| | u4route-mem | (Optional) Displays the IPv4 route memory resource usage. |
| | u6route-mem | (Optional) Displays the IPv6 route memory resource usage. |
| | monitor-sessions | (Optional) Displays the monitor session resource usage. |

Defaults None

Command Modes Any command mode

Supported User Roles network-admin
network-operator
vdc-admin
vdc-operator

| Command History | Release | Modification |
|-----------------|---------|------------------------------|
| | 4.0(1) | This command was introduced. |

Usage Guidelines This command does not require a license.

Examples This example shows how to display resource usage for a VDC:

```
switch# show resource
```

| Resource | Min | Max | Used | Unused | Avail |
|-----------------|-----|------|------|--------|-------|
| port-channel | 0 | 192 | 4 | 0 | 188 |
| monitor-session | 0 | 2 | 2 | 0 | 0 |
| vlan | 16 | 4094 | 12 | 4 | 4082 |
| u6route-mem | 16 | 256 | 16 | 0 | 232 |
| u4route-mem | 32 | 256 | 32 | 0 | 208 |
| vrf | 16 | 8192 | 2 | 14 | 8158 |

Send document comments to nexus7k-docfeedback@cisco.com

show running-config vdc

To display the VDC information in the default VDC running configuration, use the **show running-config vdc** command.

show running-config vdc

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any command mode

SupportedUserRoles network-admin
network-operator
vdc-admin
vdc-operator

| Command History | Release | Modification |
|------------------------|----------------|------------------------------|
| | 4.0(1) | This command was introduced. |

Usage Guidelines You can use this command only in the default VDC (VDC 1).
This command does not require a license.

Send document comments to nexus7k-docfeedback@cisco.com

Examples

This example shows how to display VDC information in the running configuration:

```
switch# show running-config vdc
version 4.0(1)
vdc switch id 1
  limit-resource vlan minimum 16 maximum 4094
  limit-resource monitor-session minimum 0 maximum 2
  limit-resource vrf minimum 16 maximum 8192
  limit-resource port-channel minimum 0 maximum 192
  limit-resource u4route-mem minimum 32 maximum 256
  limit-resource u6route-mem minimum 16 maximum 256
vdc Payroll id 2
  allocate interface Ethernet2/47
  limit-resource vlan minimum 16 maximum 4094
  limit-resource monitor-session minimum 0 maximum 2
  limit-resource vrf minimum 16 maximum 8192
  limit-resource port-channel minimum 0 maximum 192
  limit-resource u4route-mem minimum 8 maximum 256
  limit-resource u6route-mem minimum 4 maximum 256
vdc Engineering id 3
  allocate interface Ethernet2/46
  limit-resource vlan minimum 16 maximum 4094
  limit-resource monitor-session minimum 0 maximum 2
  limit-resource vrf minimum 16 maximum 8192
  limit-resource port-channel minimum 0 maximum 192
  limit-resource u4route-mem minimum 8 maximum 256
  limit-resource u6route-mem minimum 4 maximum 256
vdc resource template MyTemplate
```

Send document comments to nexus7k-docfeedback@cisco.com

show running-config vdc-all

To display the running configurations for all VDCs, use the **show running-config vdc-all** command.

```
show running-config vdc-all [all]
```

| | | |
|---------------------------|------------|---|
| Syntax Description | all | (Optional) Displays VDC default setting information from the running configuration. |
|---------------------------|------------|---|

| | |
|-----------------|------|
| Defaults | None |
|-----------------|------|

| | |
|----------------------|------------------|
| Command Modes | Any command mode |
|----------------------|------------------|

| | |
|---------------------------|--|
| SupportedUserRoles | network-admin network-operator vdc-admin vdc-operator |
|---------------------------|--|

| Command History | Release | Modification |
|------------------------|----------------|------------------------------|
| | 4.0(1) | This command was introduced. |

| | |
|-------------------------|---|
| Usage Guidelines | You can use this command only in the default VDC (VDC 1). This command does not require a license. |
|-------------------------|---|

show running-config vdc-all***Send document comments to nexus7k-docfeedback@cisco.com*****Examples**

This example shows how to display the running configurations for all VDCs:

```

switch# show running-config vdc-all
!Running config for vdc: switch

switchto vdc switch
version 4.0(1)
snmp-server enable traps entity
power redundancy-mode combined force
feature tacacs+
feature pbr
feature private-vlan
feature interface-vlan
feature dot1x
feature lacp
feature glbp
feature dhcp
feature eou
feature tunnel
feature cts
logging level glbp 6
role name MyRole
username adminbackup password 5 $1$0ip/C5Ci$oOdx7oJS1BCFpNRmQK4na. role network
-operator
username admin password 5 $1$x.9srJIq$jvKISFQ1sXR4oi44YanxJ0 role network-admin
username User1 password 5 $1$Dm4XUUyR$V1/3B25/84g3YRkOt3Rj50 role network-opera
tor
telnet server enable
ssh key rsa 768 force
kernel core target 0.0.0.0
kernel core limit 1
aaa group server radius aaa-private-sg
    use-vrf management
vlan dot1Q tag native
system default switchport
no system default switchport shutdown
snmp-server user User1 auth md5 0xbc9d5254b8aedec4747ad156d8726ae0 priv 0xbc9d52
54b8aedec4747ad156d8726ae0 localizedkey engineID 128:0:0:9:3:0:24:186:216:63:188
snmp-server user admin auth md5 0xbc9d5254b8aedec4747ad156d8726ae0 priv 0xbc9d52
54b8aedec4747ad156d8726ae0 localizedkey engineID 128:0:0:9:3:0:24:186:216:63:188
snmp-server enable traps license
vrf context management
    ip route 0.0.0.0/0 172.28.230.1
logging level sysmgr 1
logging server 172.28.254.254
vdc switch id 1
    limit-resource vlan minimum 16 maximum 4094
    limit-resource monitor-session minimum 0 maximum 2
    limit-resource vrf minimum 16 maximum 8192
    limit-resource port-channel minimum 0 maximum 192
    limit-resource u4route-mem minimum 32 maximum 256
    limit-resource u6route-mem minimum 16 maximum 256
vdc Payroll id 2
    allocate interface Ethernet2/47
    limit-resource vlan minimum 16 maximum 4094
    limit-resource monitor-session minimum 0 maximum 2
    limit-resource vrf minimum 16 maximum 8192
    limit-resource port-channel minimum 0 maximum 192
    limit-resource u4route-mem minimum 8 maximum 256
    limit-resource u6route-mem minimum 4 maximum 256
vdc Engineering id 3
    allocate interface Ethernet2/46
    limit-resource vlan minimum 16 maximum 4094

```

Send document comments to nexus7k-docfeedback@cisco.com

```
limit-resource monitor-session minimum 0 maximum 2
limit-resource vrf minimum 16 maximum 8192
limit-resource port-channel minimum 0 maximum 192
limit-resource u4route-mem minimum 8 maximum 256
limit-resource u6route-mem minimum 4 maximum 256
vdc resource template MyTemplate

interface Vlan1

interface Ethernet2/1
  shutdown
  switchport
  switchport monitor
  ip access-group markin in
  ip dhcp snooping limit rate 80
  ip arp inspection limit rate 300 burst interval 5

interface Ethernet2/2
  shutdown
  no switchport

interface Ethernet2/2.1
  shutdown

interface Ethernet2/3
  no cdp enable
  shutdown
  storm-control broadcast level 20
  storm-control unicast level 20
  switchport
  dot1x mac-auth-bypass

....

interface mgmt0
  ip address 172.28.231.193/23

line console
  speed 115200
logging level cdp 6
event manager applet x
monitor session 1
  no shut
monitor session 2
  no shut
  source interface Ethernet2/2 both
  source interface Ethernet2/5 both
  destination interface Ethernet2/1
  destination interface Ethernet2/3
  filter vlan 50
monitor session 3
  no shut
logging level dhcp_snoop 6
logging level eth_port_channel 6
logging ip access-list cache entries 8000
logging ip access-list cache interval 300
logging ip access-list cache threshold 0
acllog match-log-level 6

!Running config for vdc: Payroll

switchto vdc Payroll
im_verify_ifindex failed for 0x5000000
```

```
show running-config vdc-all
```

Send document comments to nexus7k-docfeedback@cisco.com

```
status: 0x411a0000 - shared pss not opened
if_info_status: 0x0
version 4.0(1)
username admin password 5 $1$f89fb1AG$TK6vd.TAq0rp9Gwzc7j6y0 role network-admi
telnet server enable
ssh key rsa 768 force
aaa group server radius aaa-private-sg
    use-vrf management
snmp-server user admin network-admin auth md5 0xddf68fa88ad2a5ea0818856db35fa9f
    priv 0xddf68fa88ad2a5ea0818856db35fa9fb localizedkey
vrf context management
    ip route 0.0.0.0/0 172.28.230.1
logging server 172.28.254.254
```

```
interface Ethernet2/47
logging ip access-list cache entries 8000
logging ip access-list cache interval 300
logging ip access-list cache threshold 0
acllog match-log-level 6
```

```
!Running config for vdc: Engineering
```

```
switchto vdc Engineering
im_verify_ifindex failed for 0x5000000
status: 0x411a0000 - shared pss not opened
if_info_status: 0x0
version 4.0(1)
username admin password 5 $1$pPfrW5.g$rciQSDOB/A/c0N8eXf1081 role network-admi
telnet server enable
ssh key rsa 768 force
aaa group server radius aaa-private-sg
    use-vrf management
snmp-server user admin network-admin auth md5 0x67568a735d6alf7e4833fd0de8c196f
    priv 0x67568a735d6alf7e4833fd0de8c196fb localizedkey
vrf context management
    ip route 0.0.0.0/0 172.28.230.1
logging server 172.28.254.254
```

```
interface Ethernet2/46
logging ip access-list cache entries 8000
logging ip access-list cache interval 300
logging ip access-list cache threshold 0
acllog match-log-level 6
```

Send document comments to nexus7k-docfeedback@cisco.com

show startup-config vdc-all

To display the configuration information for all VDCs in the startup configuration, use the **show startup-config vdc-all** command.

```
show startup-config vdc-all
```

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any command mode

SupportedUserRoles network-admin
network-operator
vdc-admin
vdc-operator

| Command History | Release | Modification |
|-----------------|---------|------------------------------|
| | 4.0(1) | This command was introduced. |

Usage Guidelines You can use this command only in the default VDC (VDC 1).
This command does not require a license.

Examples This example shows how to display information for all VDCs in the startup configuration:

```
switch# show startup-config vdc-all
```

Send document comments to nexus7k-docfeedback@cisco.com

show vdc

To display VDC information, use the **show vdc** command.

```
show vdc [vdc-name] [detail]
```

| Syntax Description | |
|--------------------|--|
| <i>vdc-name</i> | (Optional) VDC name. |
| detail | (Optional) Displays detailed information about the VDCs. |

Defaults None

Command Modes Any command mode

SupportedUserRoles network-admin
network-operator
vdc-admin
vdc-operator

| Command History | Release | Modification |
|-----------------|---------|------------------------------|
| | 4.0(1) | This command was introduced. |

Usage Guidelines In the default VDC, this commands displays information about all VDCs on the physical device. In non-default VDCs, this command display information only about the current VDC.

This command does not require a license.

Examples This example shows how to display summary information about VDCs in the default VDC:

```
switch# show vdc
```

```
vdc_id  vdc_name                state                mac
-----  -----                -
1        switch                    active              00:18:ba:d8:3f:fd
2        Payroll                    active              00:18:ba:d8:3f:fe
3        MyVDC                      active              00:18:ba:d8:3f:ff
```

Send document comments to nexus7k-docfeedback@cisco.com

This example shows how to display detailed information about VDCs in the default VDC:

```
switch# show vdc detail
vdc id: 1
vdc name: switch
vdc state: active
vdc mac address: 00:18:ba:d8:3f:fd
vdc ha policy: RESET
vdc swover policy: RESET

vdc id: 2
vdc name: Payroll
vdc state: active
vdc mac address: 00:18:ba:d8:3f:fe
vdc ha policy: RESTART
vdc swover policy: BRINGDOWN

vdc id: 3
vdc name: MyVDC
vdc state: active
vdc mac address: 00:18:ba:d8:3f:ff
vdc ha policy: RESTART
vdc swover policy: BRINGDOWN
```

This example shows how to display summary VDC information in a non-default VDC:

```
switch-Payroll# show vdc

vdc_id  vdc_name                state      mac
-----  -
2       Payroll                    active     00:18:ba:d8:3f:fe
```

This example shows how to display detailed VDC information in a non-default VDC:

```
switch-Payroll# show vdc detail
vdc id: 2
vdc name: Payroll
vdc state: active
vdc mac address: 00:18:ba:d8:3f:fe
vdc ha policy: RESTART
vdc swover policy: BRINGDOWN
```

■ `show vdc current-vdc`

Send document comments to nexus7k-docfeedback@cisco.com

show vdc current-vdc

To display the current VDC identifier information, use the **show vdc current-vdc** command.

show vdc current-vdc

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any command mode

SupportedUserRoles network-admin
network-operator
vdc-admin
vdc-operator

| Command History | Release | Modification |
|-----------------|---------|------------------------------|
| | 4.0(1) | This command was introduced. |

Usage Guidelines You can use this command in any VDC.
This command does not require a license.

Examples This example shows how to display the current VDC identifier information:

```
switch-Payroll# show vdc current-vdc
Current vdc is 2 - Payroll
```

Send document comments to nexus7k-docfeedback@cisco.com

show vdc membership

To display the interface membership information for the VDCs, use the **show vdc membership** command.

show vdc membership [status]

| Syntax Description | status (Optional) Displays status information about the interfaces. | | | | |
|---------------------------|--|---------|--------------|--------|------------------------------|
| Defaults | None | | | | |
| Command Modes | Any command mode | | | | |
| SupportedUserRoles | network-admin network-operator vdc-admin vdc-operator | | | | |
| Command History | <table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>4.0(1)</td> <td>This command was introduced.</td> </tr> </tbody> </table> | Release | Modification | 4.0(1) | This command was introduced. |
| Release | Modification | | | | |
| 4.0(1) | This command was introduced. | | | | |
| Usage Guidelines | You can use this command only in the default VDC. This command does not require a license. | | | | |

Send document comments to nexus7k-docfeedback@cisco.com

Examples

This example shows how to display the interface membership information in the default VDC:

```
switch# show vdc membership

vdc_id: 1 vdc_name: switch interfaces:
Ethernet2/1      Ethernet2/2      Ethernet2/3
Ethernet2/4      Ethernet2/5      Ethernet2/6
Ethernet2/7      Ethernet2/8      Ethernet2/9
Ethernet2/10     Ethernet2/11     Ethernet2/12
Ethernet2/13     Ethernet2/14     Ethernet2/15
Ethernet2/16     Ethernet2/17     Ethernet2/18
Ethernet2/19     Ethernet2/20     Ethernet2/21
Ethernet2/22     Ethernet2/23     Ethernet2/24
Ethernet2/25     Ethernet2/26     Ethernet2/27
Ethernet2/28     Ethernet2/29     Ethernet2/30
Ethernet2/31     Ethernet2/32     Ethernet2/33
Ethernet2/34     Ethernet2/35     Ethernet2/36
Ethernet2/37     Ethernet2/38     Ethernet2/39
Ethernet2/40     Ethernet2/41     Ethernet2/42
Ethernet2/43     Ethernet2/44     Ethernet2/45
Ethernet2/48

vdc_id: 2 vdc_name: Payroll interfaces:
Ethernet2/47

vdc_id: 3 vdc_name: MyVDC interfaces:
Ethernet2/46
```

This example shows how to display the interface membership information in a non-default VDC:

```
switch-Payroll# show vdc membership

vdc_id: 2 vdc_name: Payroll interfaces:
Ethernet2/47
```

This example shows how to display the interface status information in a default VDC:

```
switch# show vdc membership status

vdc_id: 1 vdc_name: switch interfaces:
Port      Status
----      -
Eth2/1    OK
Eth2/2    OK
Eth2/3    OK
Eth2/4    OK
Eth2/5    OK
Eth2/6    OK
Eth2/7    OK
Eth2/8    OK
Eth2/9    OK
Eth2/10   OK
...
```

Send document comments to nexus7k-docfeedback@cisco.com

show vdc resource

To display the VDC resource information, use the **show vdc resource** command.

show vdc resource [**monitor-session** | **port-channel** | **u4route-mem** | **vlan** | **vrf**] [**detail**]

| Syntax Description | | |
|------------------------|------------|---|
| monitor-session | (Optional) | Displays only the Switched Port Analyzer (SPAN) monitor session resources. |
| port-channel | (Optional) | Displays only the port channel resource information. |
| u4route-mem | (Optional) | Displays only the IPv4 route resource information. |
| vlan | (Optional) | Displays only the VLAN resource information. |
| vrf | (Optional) | Displays only the Virtual Forwarding and Routing instance (VRF) resource information. |
| detail | (Optional) | Displays detailed information. |

Defaults None

Command Modes Any command mode

SupportedUserRoles network-admin
network-operator
vdc-admin
vdc-operator

| Command History | Release | Modification |
|-----------------|---------|------------------------------|
| | 4.0(1) | This command was introduced. |

Usage Guidelines You can use this command only in the default VDC (VDC 1).
This command does not require a license.

Send document comments to nexus7k-docfeedback@cisco.com

Examples

This example shows how to display summary VDC resource information:

```
switch# show vdc resource

port-channel          0 used          0 unused          192 free          192 total

monitor-session      0 used          0 unused           2 free           2 total

vlan                  14 used         34 unused        16370 free        16384 total

u4route-mem          48 used          0 unused          208 free          256 total

vrf                   6 used          42 unused         8186 free         8192 total
```

This example shows how to display detailed VDC resource information:

```
switch# show vdc resource detail

port-channel          0 used          0 unused          192 free          192 total
-----
  Vdc      Min      Max      Used      Unused      Avail
  ----      -
switch      0      192      0         0         192
Payroll     0      192      0         0         192
MyVDC       0      192      0         0         192

monitor-session      0 used          0 unused           2 free           2 total
-----
  Vdc      Min      Max      Used      Unused      Avail
  ----      -
switch      0         2         0         0         2
Payroll     0         2         0         0         2
MyVDC       0         2         0         0         2

vlan                  14 used         34 unused        16370 free        16384 total
-----
  Vdc      Min      Max      Used      Unused      Avail
  ----      -
switch     16     4094         10         6        4084
Payroll    16     4094         2         14       4092
MyVDC     16     4094         2         14       4092

u4route-mem          48 used          0 unused          208 free          256 total
-----
  Vdc      Min      Max      Used      Unused      Avail
  ----      -
switch     32     256         32         0         208
Payroll    8      256         8         0         208
MyVDC      8      256         8         0         208

vrf                   6 used          42 unused         8186 free         8192 total
-----
  Vdc      Min      Max      Used      Unused      Avail
  ----      -
switch     16     8192         2         14       8158
Payroll    16     8192         2         14       8158
MyVDC     16     8192         2         14       8158
```

This example shows how to display summary VDC resource information for port channels:

```
switch# show vdc resource port-channel

port-channel          0 used          0 unused          192 free          192 total
```

Send document comments to nexus7k-docfeedback@cisco.com

This example shows how to display detailed VDC resource information for port channels:

```
switch# show vdc resource port-channel detail
```

```
port-channel          0 used          0 unused        192 free        192 total
-----
   Vdc                Min           Max           Used           Unused          Avail
-----
switch                0             192            0              0              192
Payroll                0             192            0              0              192
MyVDC                  0             192            0              0              192
```

[Send document comments to nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com)

show vdc resource template

To display the VDC resource template information, use the **show vdc resource template** command.

```
show vdc resource template [vdc-template-name]
```

| Syntax Description | <i>vdc-template-name</i> (Optional) VDC resource template name. | | | | |
|---------------------------|--|---------|--------------|--------|------------------------------|
| Defaults | None | | | | |
| Command Modes | Any command mode | | | | |
| SupportedUserRoles | network-admin network-operator vdc-admin vdc-operator | | | | |
| Command History | <table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>4.0(1)</td> <td>This command was introduced.</td> </tr> </tbody> </table> | Release | Modification | 4.0(1) | This command was introduced. |
| Release | Modification | | | | |
| 4.0(1) | This command was introduced. | | | | |
| Usage Guidelines | <p>You can use this command only in the default VDC (VDC 1).</p> <p>This command does not require a license.</p> | | | | |

Send document comments to nexus7k-docfeedback@cisco.com

Examples

This example shows how to display summary information for all VDC resource templates:

```
switch# show vdc resource template
```

```
MyTemplate
-----
Resource           Min           Max
-----
port-channel       8             64

global-default
-----
Resource           Min           Max
-----
u4route-mem       32            256

vdc-default
-----
Resource           Min           Max
-----
port-channel       0             192
monitor-session    0              2
vlan               16            4094
u4route-mem       8             256
vrf                16            8192
```

This example shows how to display summary information for a specific VDC resource template:

```
switch# show vdc resource template MyTemplate
```

```
MyTemplate
-----
Resource           Min           Max
-----
port-channel       8             64
```

Send document comments to nexus7k-docfeedback@cisco.com

This example shows how to display detailed VDC resource information:

```
switch# show vdc resource detail
```

```

port-channel          0 used          0 unused          192 free          192 total
-----
   Vdc      Min      Max      Used      Unused      Avail
   ----      -
switch          0      192         0         0         192
Payroll         0      192         0         0         192
MyVDC           0      192         0         0         192

monitor-session      0 used          0 unused           2 free           2 total
-----
   Vdc      Min      Max      Used      Unused      Avail
   ----      -
switch          0         2         0         0         2
Payroll         0         2         0         0         2
MyVDC           0         2         0         0         2

vlan                 14 used          34 unused        16370 free        16384 total
-----
   Vdc      Min      Max      Used      Unused      Avail
   ----      -
switch         16      4094         10         6         4084
Payroll        16      4094          2        14         4092
MyVDC          16      4094          2        14         4092

u4route-mem         48 used          0 unused          208 free          256 total
-----
   Vdc      Min      Max      Used      Unused      Avail
   ----      -
switch         32      256         32         0         208
Payroll         8      256          8         0         208
MyVDC           8      256          8         0         208

vrf                  6 used          42 unused         8186 free         8192 total
-----
   Vdc      Min      Max      Used      Unused      Avail
   ----      -
switch         16      8192          2        14         8158
Payroll        16      8192          2        14         8158
MyVDC          16      8192          2        14         8158

```

Send document comments to nexus7k-docfeedback@cisco.com

switchback

To switch back to the default virtual device context (VDC) from another VDC, use the **switchback** command.

switchback

Syntax Description This command has no arguments or keywords.

Defaults None

Command Modes Any command mode

SupportedUserRoles network-admin
network-operator

| Command History | Release | Modification |
|-----------------|---------|------------------------------|
| | 4.0(1) | This command was introduced. |

Usage Guidelines This command requires the Advanced Services license.

Examples This example shows how to switchback to the default VDC:

```
switch-MyVDC# switchback
switch(config)#
```

| Related Commands | Command | Description |
|------------------|-------------------------|---|
| | show current vdc | Displays information about the current VDC. |
| | switchto vdc | Switches to a nondefault VDC. |

Send document comments to nexus7k-docfeedback@cisco.com

switchto vdc

To switch to another virtual device context (VDC) from the default VDC, use the **switchto vdc** command.

switchto vdc *vdc-name*

| Syntax Description | <i>vdc-name</i> | VDC name. |
|--------------------|-----------------|-----------|
|--------------------|-----------------|-----------|

| Defaults | None |
|----------|------|
|----------|------|

| Command Modes | Any command mode |
|---------------|------------------|
|---------------|------------------|

| SupportedUserRoles | network-admin network-operator |
|--------------------|-----------------------------------|
|--------------------|-----------------------------------|

| Command History | Release | Modification |
|-----------------|---------|------------------------------|
| | 4.0(1) | This command was introduced. |

| Usage Guidelines | <p>You can use this command only from the default VDC (VDC 1).</p> <p>To return to the default VDC, use the exit from EXEC mode or the switchback command.</p> <p>This command requires the Advanced Services license.</p> |
|------------------|--|
|------------------|--|

| Examples | <p>This example shows how to switch to a VDC:</p> |
|----------|---|
|----------|---|

```
switch# switchto vdc MyDevice
TAC support: http://www.cisco.com/tac
Copyright (c) 2002-2008, Cisco Systems, Inc. All rights reserved.
The copyrights to certain works contained in this software are
owned by other third parties and used and distributed under
license. Certain components of this software are licensed under
the GNU General Public License (GPL) version 2.0 or the GNU
Lesser General Public License (LGPL) Version 2.1. A copy of each
such license is available at
http://www.opensource.org/licenses/gpl-2.0.php and
http://www.opensource.org/licenses/lgpl-2.1.php
switch-MyDevice#
```

Send document comments to nexus7k-docfeedback@cisco.com

| Related Commands | Command | Description |
|------------------|------------------|---|
| | show current vdc | Displays information about the current VDC. |
| | switchback | Returns to the default VDC. |

Send document comments to nexus7k-docfeedback@cisco.com

template

To apply a virtual device context (VDC) resource template to a VDC, use the **template** command.

template *vdc-template-name*

| | | |
|---------------------------|--------------------------|-----------------------------|
| Syntax Description | <i>vdc-template-name</i> | VDC resource template name. |
|---------------------------|--------------------------|-----------------------------|

| | | |
|-----------------|------|--|
| Defaults | None | |
|-----------------|------|--|

| | | |
|----------------------|-------------------|--|
| Command Modes | VDC configuration | |
|----------------------|-------------------|--|

| | | |
|---------------------------|---------------|--|
| SupportedUserRoles | network-admin | |
|---------------------------|---------------|--|

| Command History | Release | Modification |
|------------------------|----------------|------------------------------|
| | 4.0(1) | This command was introduced. |

| | | |
|-------------------------|--|--|
| Usage Guidelines | <p>You can use this command only in the default VDC (VDC 1).</p> <p>This command does not require a license.</p> | |
|-------------------------|--|--|

| | | |
|-----------------|--|--|
| Examples | <p>This example shows how to apply a resource template to a VDC:</p> <pre>switch# config t switch(config)# vdc MyDevice switch(config-vdc)# template MyTemplate</pre> | |
|-----------------|--|--|

| Related Commands | Command | Description |
|-------------------------|---|--|
| | show vdc | Displays VDC interface membership information. |
| vdc | Creates or specifies a VDC and enters VDC configuration mode. | |

Send document comments to nexus7k-docfeedback@cisco.com

vdc

To create or specify a virtual device context (VDC) and enter VDC configuration mode, use the **vdc** command. To delete a VDC, use the **no** form of the command.

```
vdc vdc-name [ha-policy { dual-sup { bringdown | restart | switchover } [single-sup { bringdown
| reload | restart}] | single-sup { bringdown | reload | restart } [dual-sup { bringdown | restart
| switchover}]]] [id vdc-id] [template vdc-template-name]
```

```
no vdc vdc-name
```

| Syntax Description | | |
|-----------------------------------|--|--|
| ha-policy | (Optional) Specifies the high availability (HA) policy for the VDC when an unrecoverable error occurs. The default is restart. | |
| dual-sup | Specifies the HA policy for devices with dual supervisor modules. | |
| bringdown | Puts the VDC in failed state. To recover from the failed state, you must reload the physical device. | |
| restart | Deletes the VDC and recreates it using the startup configuration. | |
| switchover | Initiates a supervisor module switchover. | |
| dual-sup | Specifies the HA policy for devices with dual supervisor modules. | |
| reload | Reloads the physical device and recreates the VDC using the startup configuration. | |
| id vdc-id | (Optional) Specifies the VDC ID. The default is the first available number. The range is from 1 to 4. | |
| template vdc-template-name | (Optional) Specifies the VDC resource template. | |

Defaults

The default HA policy for the default VDC: **dual-sup** default is **switchover**
single-sup default is **reload**

The default HA policy for nondefault VDCs: **dual-sup** default is **switchover**
single-sup default is **restart**

The default VDC ID is first available.

The default VDC resource template is the default template.

Command Modes

Global configuration

Supported User Roles

network-admin

Command History

| Release | Modification |
|---------|------------------------------|
| 4.0(1) | This command was introduced. |

Send document comments to nexus7k-docfeedback@cisco.com

Usage Guidelines

You can use this command only in the default VDC (VDC 1).

When you create a VDC, the Cisco NX-OS software allocates the internal resources for the VDC. This process can take a few minutes to complete depending on the amount of internal resource you have requested for the VDC.

When you delete a VDC, the Cisco NX-OS software removes the interface configuration and moves the interfaces to the default VDC.

This command requires the Advanced Services license for creating and managing nondefault VDCs. It does not require a license for managing the default VDC.

Examples

This example shows how to create a VDC and enter VDC configuration mode:

```
switch# config t
switch(config)# vdc MyDevice
Note: VDC creation is a time consuming process, please wait until the command completes
switch(config-vdc)#
```

This example shows how to create a VDC with a different single supervisor module HA policy than the default and enter VDC configuration mode:

```
switch# config t
switch(config)# vdc MyDevice ha-policy single-sup reload
Note: VDC creation is a time consuming process, please wait until the command completes
switch(config-vdc)#
```

This example shows how to delete a VDC:

```
switch# config t
switch(config)# no vdc MyDevice
Deleting this vdc will remove its config. Continue deleting this vdc? [no] yes
Note: VDC deletion is a time consuming process, please wait until the command completes
```

Related Commands

| Command | Description |
|-----------------|----------------------------------|
| show vdc | Displays VDC status information. |

[Send document comments to nexus7k-docfeedback@cisco.com](mailto:nexus7k-docfeedback@cisco.com)

vdc resource template

To create or specify a virtual device context (VDC) resource template and enter VDC resource template configuration mode, use the **vdc** command. To delete a VDC resource template, use the **no** form of the command.

vdc resource template *vdc-template-name*

no vdc resource template *vdc-template-name*

Syntax Description

| | |
|--------------------------|---|
| <i>vdc-template-name</i> | Specifies the VDC resource template name. The name has a maximum length of 32 characters and is not case-sensitive. |
|--------------------------|---|

Defaults

| Resource | Minimum | Maximum |
|--------------------------------|---------|---------|
| IPv4 route memory ¹ | 8 | 256 |
| IPv6 route memory ¹ | 4 | 256 |
| Port channels | 0 | 256 |
| SPAN sessions | 0 | 2 |
| VLANs | 16 | 4094 |
| VRFs | 16 | 8192 |

1. Route memory limits are in megabytes.

Command Modes

Global configuration

Supported User Roles

network-admin

Command History

| Release | Modification |
|---------|------------------------------|
| 4.0(1) | This command was introduced. |

Usage Guidelines

You can use this command only in the default VDC (VDC 1).

You cannot change the default VDC resource template provided by the Cisco NX-OS software.

You can create up to 64 VDC resource templates.

This command does not require a license.

Send document comments to nexus7k-docfeedback@cisco.com

Examples

This example shows how to create or specify a VDC resource template and enter VDC resource template configuration mode:

```
switch# config t  
switch(config)# vdc resource template MyTemplate  
switch(config-vdc-template)#
```

This example shows how to delete a VDC resource template:

```
switch# config t  
switch(config)# no vdc resource template MyTemplate
```

Related Commands

| Command | Description |
|-----------------------------------|----------------------------------|
| show vdc resource template | Displays VDC status information. |
