



CHAPTER 7

EPLD Software Upgrade or Downgrade

This chapter contains the recommended procedure for upgrading or downgrading an electronic programmable logic device (EPLD). EPLDs are hardware components such as ASICs on I/O modules that can be upgraded without having to replace the hardware. EPLD upgrades are typically not required, but in some cases, such as new chassis installs or chassis redeployments, we recommend that you upgrade to the latest EPLD version to ensure that all upgradable hardware components have the latest feature enhancements and caveat fixes.

This chapter includes the following sections:

- [EPLD Upgrade/Downgrade Verification](#)
- [EPLD Upgrade Procedure](#)

EPLD Upgrade/Downgrade Verification

Introduced: Cisco NX-OS Release 4.2(6)

Before starting an EPLD upgrade, an upgrade verification check should be performed on the chassis to understand what EPLD upgrades are required and the impact that each upgrade will have. This will assist in planning when determining if any of the upgrades will impact production traffic that could create an unnecessary network outage.

```
n7000# show install all impact epld bootflash:n7000-s1-epld.5.1.1.img
```

Compatibility check:

Module	Type	Upgradable	Impact	Reason
-----	----	-----	-----	-----
1	LC	Yes	disruptive	Module Upgradable
2	LC	Yes	disruptive	Module Upgradable
4	LC	No	none	Module is not Online
5	SUP	Yes	disruptive	Module Upgradable
7	LC	Yes	disruptive	Module Upgradable
8	LC	Yes	disruptive	Module Upgradable
9	LC	Yes	disruptive	Module Upgradable
10	LC	Yes	disruptive	Module Upgradable
1	Xbar	Yes	disruptive	Module Upgradable
2	Xbar	Yes	disruptive	Module Upgradable
3	Xbar	Yes	disruptive	Module Upgradable
1	FAN	Yes	disruptive	Module Upgradable
2	FAN	Yes	disruptive	Module Upgradable
3	FAN	Yes	disruptive	Module Upgradable
4	FAN	Yes	disruptive	Module Upgradable

Retrieving EPLD versions... Please wait.

Images will be upgraded according to following table:

Module	Type	EPLD	Running-Version	New-Version	Upg-Required
1	LC	Power Manager	4.008	4.008	No
1	LC	IO	1.015	1.016	Yes
1	LC	Forwarding Engine	1.006	1.006	No
1	LC	FE Bridge(1)	186.005	186.006	Yes
1	LC	FE Bridge(2)	186.005	186.006	Yes
1	LC	Linksec Engine(1)	2.006	2.006	No
1	LC	Linksec Engine(2)	2.006	2.006	No
1	LC	Linksec Engine(3)	2.006	2.006	No
1	LC	Linksec Engine(4)	2.006	2.006	No
1	LC	Linksec Engine(5)	2.006	2.006	No
1	LC	Linksec Engine(6)	2.006	2.006	No
1	LC	Linksec Engine(7)	2.006	2.006	No

EPLD Upgrade Procedure

Introduced: Cisco NX-OS Release 4.0(1)

This section was included for reference and is typically not required, but we recommend that you read it. Cisco NX-OS software can be upgraded without upgrading to the latest EPLD image. Customers should review the EPLD release notes on cisco.com and determine if they need to upgrade their EPLDs based on new features or caveat fixes. Customers performing a new install may want to upgrade EPLDs to the latest version to reduce the likelihood for having to upgrade EPLDs in the future.

EPLDs are upgraded per component when using the **install** command. Only one component can be upgraded at a time. Upgrading a single component provides granular control to avoid any unnecessary network impact. The EPLD upgrades can take up to 30 minutes per I/O module. The same procedure can be used to downgrade a component, although downgrades are typically not required.

For best results, follow these recommendations:

- Only upgrade the EPLDs on an I/O module that is not passing production traffic. (Redirect traffic before starting the upgrade.)
- To save time, make sure the I/O module being upgraded is not powered off. If the module is powered off, the module will be powered on, and all upgradable components on the module will be updated regardless if they require it. This will take more time to upgrade the I/O module.
- Use the **install all epld** command to start a rolling EPLD upgrade for the entire chassis. This procedure should only be used for non-production chassis, or if the production chassis is not passing any “production” traffic.
- Do not disrupt the upgrade process for a component.

```
n7000# install module 1 epld bootflash:n7000-s1-epld.5.1.1.img
```

Retrieving EPLD versions... Please wait.

Images will be upgraded according to following table:

Module	Type	EPLD	Running-Version	New-Version	Upg-Required
1	LC	Power Manager	4.008	4.008	No
1	LC	IO	1.015	1.016	Yes
1	LC	Forwarding Engine	1.006	1.006	No
1	LC	FE Bridge(1)	186.005	186.006	Yes

1	LC	FE Bridge(2)	186.005	186.006	Yes
1	LC	Linksec Engine(1)	2.006	2.006	No
1	LC	Linksec Engine(2)	2.006	2.006	No
1	LC	Linksec Engine(3)	2.006	2.006	No
1	LC	Linksec Engine(4)	2.006	2.006	No
1	LC	Linksec Engine(5)	2.006	2.006	No
1	LC	Linksec Engine(6)	2.006	2.006	No
1	LC	Linksec Engine(7)	2.006	2.006	No
1	LC	Linksec Engine(8)	2.006	2.006	No

Module 1 will be powered down.

Do you want to continue? (yes/no) [n]:

