



Numerics

10/100/1000 ports

- cable lengths [2-11, 3-4](#)
- connecting to [3-27 to 3-28](#)
- connectors and cables [B-2 to B-3](#)
- described [2-8](#)
- illustrated [2-6 to 2-7](#)

10/100 ports

- cable lengths [3-4](#)
- connecting to [3-27 to 3-28](#)
- connectors and cables [B-1 to B-2](#)
- described [2-7 to 2-8](#)
- illustrated [2-3](#)

1000BASE-SX ports

- cable lengths [3-4](#)
- connecting to [3-29 to 3-30](#)
- connectors and cables [B-4](#)
- described [2-9](#)
- illustrated [2-6](#)
- power levels, fiber-optic [A-5](#)

1000BASE-T GBIC modules

- cable lengths [3-4](#)
- connecting to [3-36 to 3-37](#)
- connectors [B-4](#)
- described [2-10](#)
- illustrated [3-22](#)
- installing [3-22](#)

1000BASE-X GBIC modules

- cable lengths [3-4](#)
- connecting to [3-35 to 3-36](#)
- connectors [B-4](#)
- described [2-10](#)

illustrated [3-22](#)

installing [3-22](#)

100BASE-FX ports

- cable lengths [3-4](#)
- connecting to [3-29 to 3-30](#)
- connectors and cables [B-4](#)
- described [2-9](#)
- illustrated [2-4](#)
- power levels, fiber-optic [A-5](#)

A

AC power

- connector [2-22](#)
- specifications [A-1 to A-2](#)

adapter pinouts, terminal

- RJ-45-to-DB-25 [B-11](#)
- RJ-45-to-DB-9 [B-10](#)

addresses, assigning IP [3-40](#)

agency approvals [A-5 to A-6, A-7](#)

altitude [A-1 to A-2](#)

autonegotiation

- 10/100/1000 ports [2-8](#)
- 10/100 ports [2-8](#)

B

bandwidth utilization [2-17 to 2-21](#)

brackets

See mounting brackets, attaching

C

- cable guide, attaching [3-16](#)
- cables
 - 10/100/1000 ports [2-8](#)
 - 10/100 ports [2-7 to 2-8](#)
- crossover
 - connecting to [B-1, B-2 to B-3](#)
 - four twisted-pair pinout, 10/100 ports [B-7](#)
 - four twisted-pair pinout, 1000BASE-T ports [B-8](#)
 - identifying [B-5](#)
 - two twisted-pair pinout [B-6](#)
- GBIC
 - 1000BASE-T module [3-36](#)
 - 1000BASE-X module [3-35](#)
 - CWDM module [3-35](#)
 - GigaStack module [3-37](#)
- problems, solving [4-2 to 4-3](#)
- RJ-21 pinouts [B-8 to B-10](#)
- SFP module
 - 1000BASE-T module [3-39](#)
- straight-through
 - connecting to [B-1, B-2 to B-3](#)
 - four twisted-pair pinout, 10/100 ports [B-7](#)
 - four twisted-pair pinout, 1000BASE-T ports [B-8](#)
 - two twisted-pair pinout [B-6](#)
- twisted-pair
 - 10/100/1000 ports [2-8](#)
 - 10/100 ports [2-7 to 2-8](#)
- See also connectors and cables
- Catalyst 2950G-24-EI-DC service warning [C-1](#)
- Catalyst 2950ST-24 LRE 997 service warning [C-1](#)
- cautions, defined [x](#)
- chassis warnings
 - rack-mounting, servicing [3-7](#)
- Cisco IE2100 [2-25](#)
- Cisco IE2100 Series Configuration Registrar
 - See Cisco IE2100
- Cisco Intelligent Engine 2100
 - See Cisco IE2100
- CiscoView [2-24](#)
- clearance [3-5](#)
- CLI [2-24](#)
 - accessing by using Express Setup [D-1](#)
 - accessing through console port [D-2](#)
- Coarse Wave Division Multiplexing GBIC modules
 - See CWDM GBIC modules
- command-line interface
 - See CLI
- configuration examples, network [2-1](#)
- configuring ports [3-40](#)
- connecting
 - to 10/100/1000 ports [3-27 to 3-28](#)
 - to 10/100 ports [3-27 to 3-28](#)
 - to 1000BASE-SX ports [3-29 to 3-30](#)
 - to 1000BASE-T GBIC module ports [3-36](#)
 - to 1000BASE-X GBIC module ports [3-35 to 3-36](#)
 - to 100BASE-FX ports [3-29 to 3-30](#)
 - to CWDM GBIC module ports [3-35](#)
 - to DC power [C-1 to C-7](#)
 - to GBIC module ports [3-35 to 3-38](#)
 - to GigaStack GBIC module ports [3-37](#)
 - to LRE ports [3-30 to 3-34](#)
 - to SFP modules [3-38 to 3-40](#)
- connecting to the console port [D-3](#)
- connection procedures [3-27 to 3-40](#)
- connectivity problems, solving [4-3](#)
- connectors and cables
 - 10/100/1000 ports [B-2 to B-3](#)
 - 10/100 ports [B-1 to B-2](#)
 - 1000BASE-SX ports [B-4](#)
 - 1000BASE-T GBIC module ports [B-4](#)
 - 1000BASE-X GBIC module ports [B-4](#)
 - 100BASE-FX ports [B-4](#)
 - console port [B-5](#)

GigaStack GBIC module ports [B-4](#)

power

- AC [2-22](#)
- DC [2-23](#)
- RPS [2-23](#)

RJ-21 [2-9, B-3](#)

See also cables

console port

- connecting to [D-3](#)
- RJ-45-to-DB-25 terminal adapter pinouts [B-11](#)
- RJ-45-to-DB-9 adapter cable pinouts [B-10](#)

conventions

- command [ix](#)
- document [ix](#)

crossover cable

- connecting to
 - 10/100/1000 ports [3-28](#)
 - 10/100 ports [3-28](#)
 - 1000BASE-T GBIC module ports [3-36](#)
 - 1000BASE-T SFP module ports [3-39](#)
- connectivity problems [4-3](#)
- pinout
 - four twisted-pair, 10/100 ports [B-7](#)
 - four twisted-pair, 1000BASE-T ports [B-8](#)
 - two twisted-pair [B-6](#)

CWDM GBIC modules

- cable lengths [3-4](#)
- connecting to [3-35](#)
- described [2-10](#)
- installing [3-22](#)

D

DC power

- connecting to [C-1 to C-7](#)
- connector [2-23](#)
- specifications [A-2, A-4](#)
- warnings [C-1 to C-4](#)

desk-mounting [3-17](#)

Device Manager [xvi](#)

- description [2-24](#)
- to configure switch [3-40](#)
- viewing LEDs [2-13](#)

dimensions [A-1 to A-4](#)

documentation

- ordering [xvii](#)
- related publications [xv to xvi](#)
- URLs, Cisco [xvii](#)

document conventions [ix](#)

duplex LED [2-17 to 2-18](#)

E

electrical noise, avoiding [3-5](#)

electromagnetic interface (EMI) [A-5 to A-6](#)

EMC

- agency approvals [A-5 to A-6](#)
- environmental ranges [A-1 to A-4](#)

Ethernet cable warning [C-1](#)

examples, network configuration [2-1](#)

exposed DC power wire warning [C-6](#)

Express Setup

- accessing CLI by using [D-1](#)

F

fan problems, solving [4-3](#)

features [2-1 to 2-3](#)

feedback to Cisco Systems, web [xviii](#)

fiber-optic port specifications [A-5](#)

front panel

- 10/100/1000 ports [2-8](#)
- 10/100 ports [2-7 to 2-8](#)
- 1000BASE-SX ports [2-9](#)
- 100BASE-FX ports [2-9](#)
- clearance [3-5](#)
- described [2-3](#)

GBIC module ports [2-10](#)
 illustrated [2-3 to 2-7](#)
 LEDs [2-13 to 2-15](#)
 LRE ports [2-9](#)
 SFP module ports [2-11](#)

G

GBIC modules

cable lengths [3-4](#)
 cables
 1000BASE-T [B-3](#)
 1000BASE-X [3-35](#)
 CWDM [3-35](#)
 GigaStack [B-4](#)
 connecting to [3-35 to 3-38](#)
 connectors
 1000BASE-T [B-3](#)
 1000BASE-X [B-4](#)
 CWDM [3-35](#)
 GigaStack [B-4](#)
 described [2-10](#)
 illustrated
 1000BASE-T [3-22](#)
 1000BASE-X [3-22](#)
 GigaStack [3-23](#)
 module slots [2-4 to 2-5](#)
 installing [3-22](#)

Gigabit Interface Converters

See GBIC modules

GigaStack GBIC modules

cable lengths [3-5](#)
 connecting to [3-37](#)
 connectors and cables [B-4](#)
 described [2-10](#)
 illustrated [3-23](#)
 installing [3-22](#)

ground connection warning [C-2](#)

grounded equipment warning [3-3, C-2](#)

H

HP OpenView [2-24](#)

humidity [A-1 to A-4](#)

I

installation

 assigning the IP Address [D-5](#)
 cable guide [3-16](#)
 connecting to a power source [D-5](#)
 connecting to LRE ports [3-30 to 3-34](#)
 desk-mount [3-17](#)
 guidelines [3-4](#)
 mounting on a wall [3-18 to 3-19](#)
 package contents [3-5 to 3-6](#)
 pre-installation information and guidelines [3-1 to 3-3](#)
 rack-mount [3-7 to 3-16](#)
 shelf-mount [3-17](#)
 site requirements [2-11](#)
 starting the terminal-emulation software [D-4](#)
 table-mount [3-17](#)
 wall-mount [3-17 to 3-19](#)

installing GBIC modules [3-22 to 3-23](#)

installing SFP modules [3-23 to 3-25](#)

IOS command-line interface

 See CLI

IP address procedures [3-40](#)

L

LEDs

 color meanings [2-17 to 2-18](#)
 duplex (DUPLX) [2-17 to 2-18](#)
 front panel [2-13 to 2-15](#)
 full-duplex [2-17 to 2-18](#)
 half-duplex [2-17 to 2-18](#)
 interpreting [2-17 to 2-18](#)
 LRE [2-17, 2-18](#)

port [2-16](#)
 port mode [2-16 to 2-19](#)
 port status [2-16](#)
 RPS [2-16](#)
 speed (SPEED) [2-17 to 2-19](#)
 status (STAT) [2-17, 2-18](#)
 system [2-16](#)
 utilization (UTIL) [2-17](#)

Long-Reach Ethernet ports
 See LRE ports

LRE ports
 and POTS splitters [3-31](#)
 cables, RJ-21 [3-32](#)
 connecting to [3-30 to 3-34](#)
 connection guidelines [3-30](#)
 described [2-9](#)
 illustrated [2-5](#)
 LEDs [2-17, 2-18](#)
 problems, solving [4-4](#)
 See also RJ-21 connector

LRE uplink ports [2-9](#)

M

management options [2-24](#)

Mode button [2-16](#)

mounting
 desk [3-17](#)
 rack [3-7 to 3-16](#)
 shelf [3-17](#)
 table [3-17](#)

mounting brackets, attaching [3-8 to 3-15, 3-17](#)

MT-RJ connector [B-4](#)

N

Network Assistant
 getting started guide [xvi](#)
 to configure switch [3-40](#)
 viewing LEDs [2-13](#)

network configuration examples [2-1](#)

Network Manager
 described [2-24](#)

noise, electrical [3-5](#)

notes, defined [ix](#)

O

obtaining documentation [xvii to xviii](#)

P

package contents [3-5 to 3-6](#)

patch cables, MT-RJ [2-9](#)

performance problems, solving [4-2](#)

physical dimensions [A-1 to A-4](#)

pinouts
 10/100/1000 ports [B-3](#)
 10/100 ports [B-2](#)
 1000BASE-T GBIC port [B-4](#)

console port
 DB-25 adapter [B-11](#)
 RJ-45-to-DB-9 adapter cable [B-10](#)

crossover cables
 four twisted-pair, 10/100 ports [B-7](#)
 four twisted-pair, 1000BASE-T ports [B-8](#)
 two twisted-pair [B-6](#)

DB-25 adapters [B-11](#)

RJ-21 connector [B-8 to B-10](#)

RJ-45-to-DB-25 terminal adapter [B-11](#)

RJ-45-to-DB-9 adapter cable [B-10](#)

RJ-45-to-DB-9 PC adapter cable [B-10](#)

straight-through cables

- four twisted-pair, 10/100 ports [B-7](#)
- four twisted-pair, 1000BASE-T ports [B-8](#)
- two twisted-pair [B-6](#)

port

- LEDs [2-13 to 2-15, 2-16](#)
- mode
 - LEDs [2-13 to 2-15, 2-16 to 2-18](#)
 - selecting [2-16](#)

ports

See 10/100 ports, 10/100/1000 ports, 100BASE-FX ports, 1000BASE-SX, GBIC module ports, LRE, and console ports

POST

- problems, solving [4-3](#)

POTS splitters, limitations and restrictions [3-31](#)

power

- agency approvals [A-7](#)
- connecting to
 - DC [C-1 to C-7](#)
- requirements [A-1 to A-4](#)
- supply
 - AC connector [2-22](#)
 - DC connector [2-23](#)
 - RPS connector [2-23](#)

power connectors [2-22 to 2-23](#)

procedures

- connecting to
 - DC power [C-1 to C-7](#)
- connection [3-27 to 3-40](#)
- installation [3-7 to 3-18](#)
- IP address [3-40](#)

publications, related [xv to xvi](#)

R

rack-mounting

- bracket mounting points [3-8 to 3-15](#)
- procedures [3-7 to 3-16](#)
- warning [3-7](#)

rear panel

- clearance [3-5](#)
- console port connector [2-24](#)
- described [2-21 to 2-22](#)
- illustrated [2-21 to 2-22](#)
- power connectors [2-22 to 2-23](#)

Redundant Power System

See RPS

related publications [xv to xvi](#)

restricted access area warning [C-1](#)

RJ-21 connector pinouts [B-8 to B-10](#)

RPS

- attaching the connector cover [3-18](#)
- connector [2-23](#)
- connector cover [3-18](#)
- described [2-23](#)
- LED [2-16](#)

S

safety agency approvals [A-5 to A-6](#)

safety warnings [3-1 to 3-4](#)

SFP module

- bale-clasp latch
 - illustrated [3-24](#)

SFP modules

- actuator button latch
 - illustrated [3-24](#)
- actuator button latch, removing [3-26](#)
- bale-clasp latch, removing [3-26](#)
- connecting to [3-38 to 3-40](#)
- described [2-11](#)
- installation [3-23 to 3-25](#)

Mylar tab latch
 illustrated [3-24](#)
 removing [3-25](#)
 removing [3-25 to 3-26](#)
 SFP ports, illustrated [2-5](#)
 shelf-mounting [3-17](#)
 SNMP network management platforms [2-24](#)
 software switch management [2-24](#)
 specifications [A-1 to A-7](#)
 speed LED [2-17 to 2-19](#)
 status LED [2-17, 2-18](#)
 straight-through cable
 connecting to
 10/100/1000 ports [3-28](#)
 10/100 ports [3-28](#)
 1000BASE-T GBIC module ports [3-36](#)
 connectivity problems [4-3](#)
 pinout
 four twisted-pair, 10/100 ports [B-7](#)
 four twisted-pair, 1000BASE-T ports [B-8](#)
 two twisted-pair [B-6](#)
 SunNet Manager [2-24](#)
 system LED [2-16](#)

T

table-mounting [3-17](#)
 technical assistance [xviii to xix](#)
 technical specifications [A-1 to A-7](#)
 Telnet, and accessing the CLI [2-24](#)
 temperature
 operating [A-1 to A-4](#)
 terminal-emulation software [D-4](#)
 troubleshooting
 diagnosing problems [4-1 to 4-3](#)
 understanding POST results [4-1](#)

U

uplink ports, LRE [2-9](#)
 URLs, Cisco [xvii](#)
 utilization
 bandwidth [2-17 to 2-21](#)
 LED [2-17](#)

V

verifying package contents [3-5 to 3-6](#)

W

warnings
 DC power [C-1 to C-4](#)
 installation [3-1 to 3-4](#)

