



## INDEX

---

### Numerics

#### 10/100/1000 ports

- auto-MDIX feature [1-9](#)
- cable lengths [2-5, 3-6](#)
- connectors and cables [B-1](#)
- described [1-8](#)
- dual-purpose ports [1-10](#)
- illustrated [1-7](#)
- pinouts [B-2](#)
- PoE [1-9](#)

#### 10/100 ports

- auto-MDIX feature [1-9](#)
- cable lengths [2-5, 3-6](#)
- connecting to [2-19](#)
- connectors and cables [B-1](#)
- described [1-8](#)
- illustrated [1-3](#)
- PoE [1-9](#)

#### 1000BASE-T SFP module

- ports cable lengths [2-5, 3-6](#)

#### 5 A-branch circuit protection caution [C-5](#)

---

### A

#### AC power

- connecting to [2-6, 3-7](#)
- connector [1-19](#)
- specifications [A-2](#)

#### adapter pinouts, terminal

- RJ-45-to-DB-25 [B-7](#)
- RJ-45-to-DB-9 [B-7](#)

#### auto-MDIX [2-19, B-3](#)

#### autonegotiation [1-8](#)

- troubleshooting [4-4](#)

---

### C

#### cable guard [1-15](#)

#### cable guide, attaching [2-11](#)

#### cable lengths [2-5, 3-5](#)

#### cables

##### crossover

- four twisted-pair pinout, 1000BASE-T ports [B-6](#)
- identifying [B-6](#)
- two twisted-pair pinout, 10/100 ports [B-5](#)
- for connecting 1000BASE-T modules [2-22](#)
- for SFP modules [B-4](#)

##### straight-through

- four twisted-pair pinout, 1000BASE-T ports [B-6](#)
- two twisted-pair pinout [B-5](#)

See also connectors and cables

#### cabling

- 10/100/1000 ports [2-19](#)
- 10/100 ports [1-8, 2-19, B-2](#)
- auto-MDIX [B-3](#)
- pinouts [B-5](#)

See also connectors and cables

#### cautions [i-vii](#)

- 5 A-branch-circuit protection [C-5](#)
- DC power [C-5](#)
- electromagnetic safety [2-5, 3-5](#)
- grounding procedure [C-2](#)
- lightning surge requirements [C-1](#)
- nonexposed wiring connections [C-2](#)
- secure terminal block wires [C-7](#)

- torquing recommendation [C-6](#)
- Cisco IOS command-line interface [1-21](#)
- Cisco IP Phones, connecting to [1-9, 2-20](#)
- Cisco Network Assistant [1-20](#)
- Cisco RPS
  - See RPS
- CiscoView [1-21](#)
- CLI
  - to manage switch [1-21](#)
  - to set up switch [D-1](#)
- code compliance warning [2-4, 3-4](#)
- command-line interface
  - See CLI
- configuration examples, network [1-1](#)
- connecting
  - to 10/100/1000 ports [2-19](#)
  - to 10/100 ports [2-19](#)
  - to console port [B-3](#)
  - to DC power [C-1 to C-2](#)
  - to SFP modules [2-21 to 2-23](#)
- connection procedures [2-19 to 2-23](#)
- connectors and cables
  - 10/100 ports [B-2](#)
  - console port [B-3 to B-8](#)
  - dual-purpose ports [B-3](#)
  - power (AC and RPS) [1-19](#)
  - power (DC) [1-1](#)
  - SFP module ports [B-2](#)
  - See also cables
- console port
  - connecting to [D-2](#)
  - connectors and cables [B-3 to B-8](#)
  - described [1-19](#)
- conventions, document [i-vii](#)
- crossover cable [B-6](#)
  - connecting to
    - 1000BASE-T SFP module ports [2-22](#)
  - pinout for four twisted-pair, 1000BASE-T ports [B-6](#)

---

## D

- DC circuit warning [C-5](#)
- DC-I grounding note [2-5, 3-5](#)
- DC power
  - connecting to [C-1 to C-2](#)
  - specifications [A-7](#)
  - warnings [C-6](#)
- DC power caution [C-5](#)
- DC power through RPS [1-1](#)
- desk-mounting
  - 24- and 48-port switches [2-15](#)
  - 8- and 12-port switches [3-8](#)
- device manager
  - to configure switch [2-24, 3-20](#)
  - to manage switch [1-20](#)
- diagnosing problems [4-1](#)
- document conventions [i-vii](#)
- dual-purpose ports
  - connectors and cables [B-3](#)
  - described [1-10](#)
  - LEDs [1-15](#)
- duplex, troubleshooting [4-4](#)
- duplex LED [1-13](#)

---

## E

- electrical noise, avoiding [2-5, 3-6](#)
- electromagnetic safety [2-5, 3-5](#)
- Ethernet and fiber-optic cable troubleshooting [4-3](#)
- examples, network configuration [1-1](#)

---

## F

- features [1-1](#)
- front panel
  - 10/100/1000 ports [1-8](#)
  - 10/100 ports [1-8](#)
  - clearance [2-5, 3-5](#)

description [1-3 to 1-14](#)  
 dual-purpose ports [1-10](#)  
 LEDs [1-11 to 1-14](#)  
 SFP module ports [1-10](#)

---

## G

ground connection warning [C-2](#)  
 grounding procedure caution [C-2](#)  
 grounding procedure for DC power [C-2 to C-4](#)

---

## H

HP OpenView [1-21](#)  
 humidity, relative [A-1](#)

---

## I

installation  
   assigning the IP address [D-3](#)  
   connecting to a power source [D-2](#)  
   mounting  
     on a desk with mounting screws (8- and 12-port switches) [3-9](#)  
     on a wall (24- and 48-port switches) [2-12](#)  
     on a wall (8- and 12-port switches) [3-12 to 3-14](#)  
     under a desk (8- and 12-port switches) [3-9 to 3-11](#)  
     with a magnet (8- and 12-port switches) [3-15](#)  
   mounting in a rack  
     24- and 48-port switches [2-7 to 2-11](#)  
     8- and 12-port switches [3-16 to 3-17](#)  
   mounting on a desk  
     24- and 48-port switches [2-15](#)  
     8- and 12-port switches [3-8, 3-12](#)  
   mounting on a shelf  
     24- and 48-port switches [2-15](#)  
     8- and 12-port switches [3-8, 3-12](#)  
   mounting on a wall  
     8- and 12-port switches [3-17](#)

site requirements [2-5, 3-5](#)  
 starting the terminal emulation software [D-2](#)  
 See also procedures

installing SFP modules [2-16 to 2-17](#)  
 internal power supply [1-18](#)

---

## L

LEDs  
   color meanings [1-13](#)  
   dual-purpose port [1-15](#)  
   duplex [1-13](#)  
   front panel [1-11](#)  
   interpreting [1-13](#)  
   PoE [1-13](#)  
   port [1-13](#)  
   port mode [1-13 to 1-14](#)  
   POST results [2-7, 4-2, D-3](#)  
   RPS [1-12](#)  
   speed [1-13](#)  
   STATUS [1-13](#)  
   system [1-11](#)  
     troubleshooting with [4-1 to 4-2](#)  
 lightning surge caution [C-1](#)  
 link status troubleshooting [4-3](#)  
 local and national electrical codes compliance [2-4, 3-4](#)

---

## M

message URL http  
   [//www.cisco.com/web/learning/index.html](http://www.cisco.com/web/learning/index.html) [i-vii](#)  
 Mode button [1-11](#)  
 mounting  
   desk- or shelf-mounting  
     8- and 12-port switches [3-8](#)  
   wall-mounting  
     24- and 48-port switches [2-12](#)  
     8- and 12-port switches [3-17](#)

## mounting brackets

- attaching (24- and 48-port switches) [2-8 to 2-10](#)
- rack-mount (24- and 48-port switches) [2-10](#)
- rack-mount (8- and 12-port switches) [3-17](#)

## mounting desk- or shelf-mounting

- 24- and 48-port switches [2-15](#)

**N**

NEBS standard for electromagnetic safety [2-5, 3-5](#)

## Network Assistant

- using to configure switch [2-24, 3-20](#)

network configuration examples [1-1](#)

## Network Equipment Building Systems

See NEBS

noise, electrical [2-5, 3-6](#)

nonexposed wiring connections caution [C-2](#)

**P**

## pinouts

- 10/100/1000 ports [B-2](#)
- 10/100 ports [B-2](#)
- adapters [B-6](#)
- console port [B-8, B-8](#)
- crossover cable [B-6](#)
- crossover cables
  - four twisted-pair, 1000BASE-T ports [B-6](#)
  - two twisted-pair 10/100 ports [B-5](#)
- RJ-45-to-DB-25 terminal adapter [B-8](#)
- RJ-45-to-DB-9 terminal adapter [B-7](#)
- SFP module ports [B-2](#)
- straight-through cables
  - four twisted-pair 1000BASE-T ports [B-6](#)
  - two twisted-pair [B-5](#)

## PoE

- LED [1-13](#)
- shock hazard warning [2-4, 3-4](#)

port and interface troubleshooting [4-4](#)

port LEDs [1-13](#)

## port modes

- changing [1-11](#)
- LEDs [1-13](#)
- See also Mode button

## ports

- 10/100 [1-3, 1-8](#)
- 10/100/1000 [1-8, 1-10, B-2](#)
- 10/100/1000 pinouts [B-2](#)
- 10/100 pinouts [B-2](#)
- dual-purpose [1-10](#)
- numbering of 10/100 [1-8](#)
- numbering of 10/100/1000 [1-8](#)
- numbering of SFP module ports [1-3, 1-4](#)

## POST

- LEDs [2-7, 3-7, 4-2, D-3](#)
- results [2-7, 4-1, D-3](#)
- running at power on [4-2](#)

## power

- connecting to [2-6, 3-7](#)
- connectors [1-19](#)

power on [2-6, 3-7](#)

## Power over Ethernet

See PoE

## power supply

- AC power outlet [1-18](#)
- internal [1-18](#)
- RPS connector [1-19](#)

## procedures

- connection [2-19 to 2-23](#)
- DC grounding [C-2 to C-4](#)
- installation (24- and 48-port switches) [2-7 to 2-15](#)
- installation (8- and 12-port switches) [3-7 to 3-18](#)

publications, related [i-viii](#)

**R**

## rack-mounting

- 24- and 48-port switches [2-7, 2-11](#)
- 8- and 12-port switches [3-16, 3-17](#)
- rear panel
  - clearance [2-5, 3-5](#)
  - description [1-15 to 1-19](#)
- removing SFP modules [2-17 to 2-18](#)
- restricted access area warning [C-1](#)
- RJ-45 connector, console port [B-3](#)
- RPS
  - connecting to [2-6, 3-7](#)
  - connector [1-19](#)
  - LED [1-12](#)

---

## S

- safety warnings (24- and 48-port switches) [2-2, 3-2](#)
- security slot [1-20](#)
- serial number location [4-6](#)
- servicing equipment warning [C-5](#)
- SFP module patch cable
  - description [1-10](#)
  - installing and removing [2-18](#)
- SFP modules
  - 1000BASE-T supported speeds [1-14](#)
  - bale-clasp latch removal [2-17](#)
  - cable specifications [B-4](#)
  - connecting to [2-21 to 2-23](#)
  - connectors [B-2](#)
  - described [1-10](#)
  - installation [2-16 to 2-17](#)
- shelf-mounting
  - 24- and 48-port switches [2-15](#)
  - 8- and 12-port switches [3-8](#)
- Simple Network Management Protocol
  - See SNMP
- SNMP network management platforms [1-21](#)
- software switch management [1-20](#)
- speed, troubleshooting [4-4](#)
- straight-through cable pinout

- four twisted-pair 1000BASE-T ports [B-6](#)
- two twisted-pair 10/100 ports [B-5](#)
- SunNet Manager [1-21](#)
- Switch models illustrated [1-3](#)
- switch powering on [2-6, 3-7](#)

---

## T

- Telnet, and accessing the CLI [1-21](#)
- terminal block wires caution [C-7](#)
- terminal emulation software [D-2](#)
- torquing the terminal block caution [C-6](#)
- troubleshooting [4-1 to 4-6](#)
  - bad or damaged cable [4-2](#)
  - connection problems [4-2](#)
  - diagnosing problems [4-1](#)
  - Ethernet and fiber-optic cables [4-3](#)
  - link status [4-3](#)
  - ping end device [4-4](#)
  - port and interface settings [4-4](#)
  - POST [4-1](#)
  - spanning tree loops [4-4](#)
  - speed, duplex, and autonegotiation [4-4](#)
  - switch performance [4-4](#)
- troubleshooting spanning tree loops [4-4](#)

---

## W

- wall-mounting
  - 24- and 48-port switches [2-12](#)
  - 8- and 12-port switches [3-17](#)
- warnings
  - code compliance [2-4, 3-4](#)
  - DC power [C-6](#)
  - defined [i-vii](#)
  - ground connection [C-2](#)
  - installation (24- and 48-port switches) [2-2](#)
  - installation (8- and 12-port switches) [3-2](#)

PoE shock hazard [2-4, 3-4](#)

removing power from DC circuit [C-5](#)

restricted access area [C-1](#)

servicing equipment [C-5](#)