



Numerics

802.1X

and switchport modes [2-360](#)

See also port-based authentication

A

aaa authentication dot1x command [2-1](#)

AAA methods [2-1](#)

abort command [2-401](#)

access control entries

See ACEs

access control lists

See ACLs

access groups, IP [2-80](#)

access map configuration mode [2-99](#)

access mode [2-359](#)

access ports [2-359](#)

ACEs [2-54](#), [2-151](#)

ACLs

deny [2-52](#)

displaying [2-180](#)

for non-IP protocols [2-93](#)

matching [2-99](#)

permit [2-149](#)

action command [2-3](#)

address aliasing [2-140](#)

aggregate-port learner [2-145](#)

allowed VLANs [2-372](#)

apply command [2-401](#)

archive copy-sw command [2-5](#)

archive download-sw command [2-7](#)

archive tar command [2-10](#)

archive upload-sw command [2-13](#)

audience [xv](#)

authorization state of controlled port [2-58](#)

autonegotiation of duplex mode [2-65](#)

B

BackboneFast, for STP [2-317](#)

boot (boot loader) command [A-2](#)

boot auto-copy-sw command [2-15](#)

boot boothlpr command [2-16](#)

boot config-file command [2-17](#)

boot enable-break command [2-18](#)

boot helper command [2-19](#)

boot helper-config file command [2-20](#)

booting

displaying environment variables [2-183](#)

interrupting [2-18](#)

IOS image [2-23](#)

manually [2-21](#)

boot loader

accessing [A-1](#)

booting

helper image [2-19](#)

IOS image [A-2](#)

directories

creating [A-16](#)

displaying a list of [A-7](#)

removing [A-20](#)

- boot loader (continued)
 - displaying
 - available commands [A-12](#)
 - memory heap utilization [A-14](#)
 - version [A-27](#)
 - environment variables
 - described [A-21](#)
 - displaying settings [A-21](#)
 - location of [A-23](#)
 - setting [A-21](#)
 - unsetting [A-25](#)
 - files
 - copying [A-5](#)
 - deleting [A-6](#)
 - displaying a list of [A-7](#)
 - displaying the contents of [A-4, A-17, A-24](#)
 - renaming [A-18](#)
 - file system
 - formatting [A-10](#)
 - initializing Flash [A-9](#)
 - running a consistency check [A-11](#)
 - loading helper images [A-13](#)
 - prompt [A-1](#)
 - resetting the system [A-19](#)
 - boot manual command [2-21](#)
 - boot private-config-file command [2-22](#)
 - boot system command [2-23](#)
 - BPDU filtering, for spanning tree [2-318, 2-331](#)
 - BPDU guard, for spanning tree [2-320, 2-331](#)
 - broadcast storm control [2-348](#)
 - broadcast traffic counters [2-221](#)
-
- C**
- candidate switches
 - See clusters
 - cat (boot loader) command [A-4](#)
 - caution, description [xvi](#)
 - channel-group command [2-24](#)
 - Cisco Technical Assistance Center [xix](#)
 - class command [2-27](#)
 - class-map command [2-29](#)
 - class maps
 - creating [2-29](#)
 - defining the match criteria [2-101](#)
 - displaying [2-185](#)
 - class of service
 - See CoS
 - clear mac-address-table command [2-31](#)
 - clear pagp command [2-32](#)
 - clear vmps statistics command [2-33](#)
 - clear vtp counters command [2-34](#)
 - cluster commander-address command [2-35](#)
 - cluster discovery hop-count command [2-37](#)
 - cluster enable command [2-38](#)
 - cluster holdtime command [2-40](#)
 - cluster member command [2-41](#)
 - cluster outside-interface command [2-43](#)
 - cluster run command [2-44](#)
 - clusters
 - adding candidates [2-41](#)
 - binding to HSRP group [2-45](#)
 - building manually [2-41](#)
 - communicating with
 - devices outside the cluster [2-43](#)
 - members by using Telnet [2-161](#)
 - debug messages, display [B-2](#)
 - displaying
 - candidate switches [2-188](#)
 - debug messages [B-2](#)
 - member switches [2-190](#)
 - status [2-186](#)
 - hop-count limit for extended discovery [2-37](#)
 - HSRP standby groups [2-45](#)
 - redundancy [2-45](#)
 - SNMP trap [2-310](#)
 - cluster standby-group command [2-45](#)
 - cluster timer command [2-47](#)

- command modes defined [1-2](#)
 - command switch
 - See clusters
 - configuration files
 - password recovery disable considerations [A-1](#)
 - specifying the name [2-17, 2-22](#)
 - configuring multiple interfaces [2-75](#)
 - config-vlan mode
 - commands [2-387](#)
 - description [1-4](#)
 - entering [2-386](#)
 - summary [1-2](#)
 - conventions
 - command [xvi](#)
 - for examples [xvi](#)
 - publication [xvi](#)
 - text [xvi](#)
 - copy (boot loader) command [A-5](#)
 - CoS
 - assigning default value to incoming packets [2-107](#)
 - overriding the incoming value [2-107](#)
 - CoS-to-DSCP map [2-111](#)
 - CPU ASIC statistics, displaying [2-192](#)
 - CPU statistics, displaying [2-192](#)
-
- D**
- debug cluster command [B-2](#)
 - debug dot1x command [B-4](#)
 - debug dtp command [B-6](#)
 - debug etherchannel command [B-7](#)
 - debug interface command [B-8](#)
 - debug ip igmp filter command [B-9](#)
 - debug ip igmp max-groups command [B-10](#)
 - debug ip igmp snooping command [B-11](#)
 - debug mac-notification command [B-12](#)
 - debug matm command [B-13](#)
 - debug monitor command [B-14](#)
 - debug mvrdbg command [B-15](#)
 - debug nvramp command [B-16](#)
 - debug pagp command [B-17](#)
 - debug platform acl command [B-18](#)
 - debug platform cli-redirect main command [B-19](#)
 - debug platform configuration command [B-20](#)
 - debug platform cpu-queues command [B-21](#)
 - debug platform device-manager command [B-23](#)
 - debug platform dot1x command [B-24](#)
 - debug platform etherchannel command [B-25](#)
 - debug platform fallback-bridging command [B-26](#)
 - debug platform forw-tcam command [B-27](#)
 - debug platform ipc command [B-34](#)
 - debug platform ip igmp snooping command [B-28](#)
 - debug platform ip multicast command [B-30](#)
 - debug platform ip unicast command [B-32](#)
 - debug platform led command [B-35](#)
 - debug platform matm command [B-36](#)
 - debug platform messaging command [B-37](#)
 - debug platform phy command [B-38](#)
 - debug platform pm command [B-39](#)
 - debug platform port-asic command [B-41](#)
 - debug platform port-security command [B-42](#)
 - debug platform qos-acl-tcam command [B-43](#)
 - debug platform remote-commands command [B-44](#)
 - debug platform resource-manager command [B-45](#)
 - debug platform snmp command [B-46](#)
 - debug platform span command [B-47](#)
 - debug platform stack-manager command [B-48](#)
 - debug platform supervisor-asic command [B-49](#)
 - debug platform sw-bridge command [B-50](#)
 - debug platform tcam command [B-51](#)
 - debug platform udd command [B-54](#)
 - debug platform vlan command [B-55](#)
 - debug pm command [B-56](#)
 - debug port-security command [B-58](#)
 - debug qos-manager command [B-59](#)
 - debug spanning-tree backbonefast command [B-62](#)
 - debug spanning-tree bpdu command [B-63](#)
 - debug spanning-tree bpdu-opt command [B-64](#)

debug spanning-tree command [B-60](#)
 debug spanning-tree switch command [B-65](#)
 debug spanning-tree uplinkfast command [B-67](#)
 debug sw-vlan command [B-68](#)
 debug sw-vlan ifs command [B-70](#)
 debug sw-vlan notification command [B-71](#)
 debug sw-vlan vtp command [B-73](#)
 debug udld command [B-75](#)
 debug vqpc command [B-77](#)
 define interface-range command [2-48](#)
 delete (boot loader) command [A-6](#)
 delete command [2-50](#)
 deny command [2-52](#)
 detect mechanism, causes [2-67](#)
 dir (boot loader) command [A-7](#)
 directories, deleting [2-50](#)
 documentation

- feedback [xviii](#)
- obtaining
 - CD-ROM [xvii](#)
 - world wide web [xvii](#)
- ordering [xviii](#)
- related [xvii](#)

document conventions [xvi](#)
 domain name, VTP [2-410, 2-414](#)
 dot1x default command [2-55](#)
 dot1x max-req command [2-56](#)
 dot1x multiple-hosts command [2-57](#)
 dot1x port-control command [2-58](#)
 dot1x re-authenticate command [2-60](#)
 dot1x re-authentication command [2-61](#)
 dot1x timeout quiet-period command [2-62](#)
 dot1x timeout re-authperiod command [2-63](#)
 dot1x timeout tx-period command [2-64](#)
 dropping packets, with ACL matches [2-3](#)
 DSCP-to-CoS map [2-111](#)
 DSCP-to-DSCP-mutation map [2-111](#)
 DTP [2-360](#)

DTP flap

- error detection for [2-67](#)
- error recovery timer [2-69](#)

duplex command [2-65](#)
 dynamic-access ports

- configuring [2-355](#)
- restrictions [2-356](#)

dynamic auto VLAN membership mode [2-359](#)
 dynamic desirable VLAN membership mode [2-359](#)
 Dynamic Trunking Protocol

- See DTP

E

EAP-request/identity frame

- maximum number to send [2-56](#)
- response time before retransmitting [2-64](#)

encapsulation methods [2-372](#)
 environment variables, displaying [2-183](#)
 errdisable detect cause command [2-67](#)
 errdisable recovery command [2-69](#)
 error conditions, displaying [2-209](#)
 error disable detection [2-67](#)
 error-disabled interfaces, displaying [2-216](#)
 EtherChannel

- assigning Ethernet interface to channel group [2-24](#)
- creating port-channel logical interface [2-73](#)
- debug EtherChannel/PAGP, display [B-7](#)
- debug platform-specific events, display [B-25](#)
- displaying [2-213](#)
- interface information, displaying [2-216](#)
- load-distribution methods [2-158](#)

PAGP

- aggregate-port learner [2-145](#)
- clearing channel-group information [2-32](#)
- debug messages, display [B-17](#)
- displaying [2-270](#)
- error detection for [2-67](#)
- error recovery timer [2-69](#)

EtherChannel (continued)

- learn method [2-145](#)
- modes [2-24](#)
- physical-port learner [2-145](#)
- priority of interface for transmitted traffic [2-147](#)

Ethernet controller, internal register display [2-194](#)

Ethernet statistics, collecting [2-167](#)

examples, conventions for [xvi](#)

exit command [2-401](#)

extended discovery of candidate switches [2-37](#)

extended-range VLANs

- and allowed VLAN list [2-372](#)
- and pruning-eligible list [2-372](#)
- configuring [2-386](#)

extended system ID for STP [2-324](#)

F

fan information, displaying [2-206](#)

feedback to Cisco Systems, web [xviii](#)

file name, VTP [2-410](#)

files, deleting [2-50](#)

flash_init (boot loader) command [A-9](#)

flowcontrol command [2-71](#)

format (boot loader) command [A-10](#)

forwarding packets, with ACL matches [2-3](#)

forwarding results, display [C-5](#)

frame forwarding information, displaying [C-5](#)

fsck (boot loader) command [A-11](#)

G

global configuration mode [1-2, 1-4](#)

H

hardware ACL statistics [2-180](#)

help (boot loader) command [A-12](#)

hop-count limit for clusters [2-37](#)

host connection, port configuration [2-358](#)

HSRP

- binding HSRP group to cluster [2-45](#)
- standby group [2-45](#)

I

IGMP filters

- applying [2-84](#)
- debug messages, display [B-9](#)

IGMP groups, setting maximum [2-85](#)

IGMP maximum groups, debugging [B-10](#)

IGMP profiles

- creating [2-86](#)
- displaying [2-224](#)

IGMP snooping

- displaying [2-225, 2-227, 2-228](#)
- enabling [2-88](#)

images

- See software images

Immediate-Leave feature, MVR [2-142](#)

Immediate-Leave processing [2-88](#)

interface command [2-78](#)

interface configuration mode [1-2, 1-4](#)

interface port-channel command [2-73](#)

interface range command [2-75](#)

interface-range macros [2-48](#)

interfaces

- assigning Ethernet interface to channel group [2-24](#)
- configuring [2-65](#)
- configuring multiple [2-75](#)
- creating port-channel logical [2-73](#)
- debug messages, display [B-8](#)
- disabling [2-308](#)
- displaying the MAC address table [2-240](#)
- restarting [2-308](#)

interface speed, configuring [2-340](#)

internal registers, displaying [2-194, 2-198](#)

invalid GBIC

- error detection for [2-67](#)
- error recovery timer [2-69](#)

ip address command [2-82](#)

IP addresses, setting [2-82](#)

IP address matching [2-99](#)

ip igmp filter command [2-84](#)

ip igmp max-groups command [2-85](#)

ip igmp profile command [2-86](#)

ip igmp snooping command [2-88](#)

IP multicast addresses [2-139](#)

IP-precedence-to-DSCP map [2-111](#)

J

jumbo frames. See MTU

L

Layer 2 mode, enabling [2-353](#)

Layer 3 mode, enabling [2-353](#)

line configuration mode [1-3, 1-5](#)

link flap

- error detection for [2-67](#)
- error recovery timer [2-69](#)

load_helper (boot loader) command [A-13](#)

load-distribution methods for EtherChannel [2-158](#)

logging file command [2-91](#)

logical interface [2-73](#)

loopback, error recovery timer [2-69](#)

loop guard, for spanning tree [2-325, 2-327](#)

M

MAC access list configuration mode [2-93](#)

mac access-list extended command [2-93](#)

MAC access lists [2-52](#)

MAC addresses

displaying

- aging time [2-234](#)
- all [2-232](#)
- dynamic [2-238](#)
- Layer 2 multicast entries [2-242](#)
- notification settings [2-244](#)
- number of addresses in a VLAN [2-236](#)
- per interface [2-240](#)
- per VLAN [2-248](#)
- static [2-246](#)
- static and dynamic entries [2-230](#)

dynamic

- aging time [2-95](#)
- deleting [2-31](#)
- displaying [2-238](#)

enabling MAC address notification [2-96](#)

matching [2-99](#)

static

- adding and removing [2-98](#)
- displaying [2-246](#)

tables [2-232](#)

MAC address notification, debugging [B-12](#)

mac address-table aging-time [2-99](#)

mac-address-table aging-time command [2-95](#)

mac-address-table notification command [2-98](#)

mac-address-table static command [2-98](#)

macros, interface range [2-48, 2-75](#)

manual

- audience [xv](#)
- purpose of [xv](#)

maps

QoS

- defining [2-111](#)
- displaying [2-257](#)

VLAN

- creating [2-398](#)
- defining [2-99](#)
- displaying [2-300](#)

match (access-map configuration) command [2-99](#)
 match (class-map configuration) command [2-101](#)
 maximum transmission unit
 See MTU
 member switches
 See clusters
 memory (boot loader) command [A-14](#)
 mkdir (boot loader) command [A-16](#)
 mls qos aggregate-policer command [2-105](#)
 mls qos command [2-103](#)
 mls qos cos command [2-107](#)
 mls qos dscp-mutation command [2-109](#)
 mls qos map command [2-111](#)
 mls qos queue-set output buffers command [2-114](#)
 mls qos queue-set output threshold command [2-116](#)
 mls qos srr-queue input bandwidth command [2-118](#)
 mls qos srr-queue input buffers command [2-120](#)
 mls qos srr-queue input cos-map command [2-122](#)
 mls qos srr-queue input dscp-map command [2-124](#)
 mls qos srr-queue input priority-queue command [2-126](#)
 mls qos srr-queue input threshold command [2-128](#)
 mls qos srr-queue output cos-map command [2-130](#)
 mls qos srr-queue output dscp-map command [2-132](#)
 mls qos trust command [2-134](#)
 mode, MVR [2-139](#)
 Mode button, and password recovery [2-170](#)
 modes, commands [1-2](#)
 monitor session command [2-136](#)
 more (boot loader) command [A-17](#)
 MTU
 configuring size [2-377](#)
 displaying global setting [2-290](#)
 multicast group address, MVR [2-142](#)
 multicast groups, MVR [2-140](#)
 multicast router learning method [2-88](#)
 multicast router ports, configuring [2-88](#)
 multicast storm control [2-348](#)
 multicast traffic counters [2-221](#)
 multicast VLAN, MVR [2-139](#)

multicast VLAN registration
 See MVR
 multiple hosts on authorized port [2-57](#)
 MVR
 and address aliasing [2-140](#)
 configuring [2-139](#)
 configuring interfaces [2-142](#)
 debug messages, display [B-15](#)
 displaying [2-264](#)
 displaying interface information [2-266](#)
 members, displaying [2-268](#)
 mvr (global configuration) command [2-139](#)
 mvr (interface configuration) command [2-142](#)
 mvr vlan group command [2-143](#)

N

native VLANs [2-372](#)
 negotiate
 DTP messaging [2-361](#)
 speed [2-340](#)
 non-IP protocols
 denying [2-52](#)
 forwarding [2-149](#)
 non-IP traffic access lists [2-93](#)
 non-IP traffic forwarding
 denying [2-52](#)
 permitting [2-149](#)
 normal-range VLANs [2-386, 2-392](#)
 note, description [xvi](#)
 no vlan command [2-386, 2-396](#)

P

PAgP
 See EtherChannel
 pagp learn-method command [2-145](#)
 pagp port-priority command [2-147](#)

- password, VTP [2-410, 2-414](#)
 - password-recovery mechanism, enabling and disabling [2-170](#)
 - permit command [2-149](#)
 - physical-port learner [2-145](#)
 - PIM-DVMRP, as multicast router learning method [2-88](#)
 - police aggregate command [2-154](#)
 - police command [2-152](#)
 - policed-DSCP map [2-111](#)
 - policy-map command [2-156](#)
 - policy maps
 - applying to an interface [2-172, 2-177](#)
 - creating [2-156](#)
 - displaying [2-272](#)
 - policers
 - displaying [2-251](#)
 - for a single class [2-152](#)
 - for multiple classes [2-105, 2-154](#)
 - policed-DSCP map [2-111](#)
 - traffic classification
 - defining the class [2-27](#)
 - defining trust states [2-379](#)
 - setting DSCP or IP precedence values [2-175](#)
 - Port Aggregation Protocol
 - See EtherChannel
 - port-based authentication
 - AAA method list [2-1](#)
 - debug messages, display [B-4](#)
 - enabling 802.1X [2-58](#)
 - manual control of authorization state [2-58](#)
 - multiple hosts on authorized port [2-57](#)
 - periodic re-authentication
 - enabling [2-61](#)
 - time between attempts [2-63](#)
 - quiet period between failed authentication exchanges [2-62](#)
 - re-authenticating 802.1X-enabled ports [2-60](#)
 - resetting global 802.1X parameters [2-55](#)
 - statistics and status display [2-200](#)
 - switch-to-client frame-retransmission number [2-56](#)
 - switch-to-client retransmission time [2-64](#)
 - port-channel load-balance command [2-158](#)
 - Port Fast, for spanning tree [2-333](#)
 - port ranges, defining [2-48](#)
 - ports, debugging [B-56](#)
 - ports, protected [2-370](#)
 - port security
 - aging [2-366](#)
 - debug messages, display [B-58](#)
 - enabling [2-363](#)
 - violation error recovery [2-69](#)
 - port trust states for QoS [2-134](#)
 - port types, MVR [2-142](#)
 - power information, displaying [2-206](#)
 - priority value, stack member [2-287, 2-350](#)
 - privileged EXEC mode [1-2, 1-3](#)
 - protected ports, displaying [2-220](#)
 - pruning
 - VLANs [2-372](#)
 - VTP
 - displaying interface information [2-216](#)
 - enabling [2-410, 2-414](#)
 - pruning-eligible VLAN list [2-374](#)
 - publications for products, technologies, and network solutions [xx](#)
-
- ## Q
- QoS
 - class maps
 - creating [2-29](#)
 - defining the match criteria [2-101](#)
 - displaying [2-185](#)
 - defining the CoS value for an incoming packet [2-107](#)
 - displaying configuration information [2-250](#)
 - DSCP trusted ports
 - applying DSCP-to-DSCP-mutation map to [2-109](#)
 - defining DSCP-to-DSCP-mutation map [2-111](#)

QoS (continued)

egress queues

- allocating buffers [2-114](#)
- defining the CoS output queue threshold map [2-130](#)
- defining the DSCP output queue threshold map [2-132](#)
- displaying buffer allocations [2-254](#)
- displaying CoS output queue threshold map [2-257](#)
- displaying DSCP output queue threshold map [2-257](#)
- displaying queueing strategy [2-254](#)
- displaying queue-set settings [2-260](#)
- enabling bandwidth shaping and scheduling [2-344](#)
- enabling bandwidth sharing and scheduling [2-346](#)
- limiting the maximum output on a port [2-342](#)
- mapping a port to a queue-set [2-160](#)
- mapping CoS values to a queue and threshold [2-130](#)
- mapping DSCP values to a queue and threshold [2-132](#)
- setting maximum and reserved memory allocations [2-116](#)
- setting WTD thresholds [2-116](#)

enabling [2-103](#)

ingress queues

- allocating buffers [2-120](#)
- assigning SRR scheduling weights [2-118](#)
- defining the CoS input queue threshold map [2-122](#)
- defining the DSCP input queue threshold map [2-124](#)
- displaying buffer allocations [2-254](#)
- displaying CoS input queue threshold map [2-257](#)
- displaying DSCP input queue threshold map [2-257](#)
- displaying queueing strategy [2-254](#)
- displaying settings for [2-252](#)
- enabling the priority queue [2-126](#)
- mapping CoS values to a queue and threshold [2-122](#)
- mapping DSCP values to a queue and threshold [2-124](#)
- setting WTD thresholds [2-128](#)

maps

- defining [2-111, 2-122, 2-124, 2-130, 2-132](#)
- displaying [2-257](#)

policy maps

- applying an aggregate policer [2-154](#)
- applying to an interface [2-172, 2-177](#)
- creating [2-156](#)
- defining policers [2-105, 2-152](#)
- displaying policers [2-251](#)
- displaying policy maps [2-272](#)
- policed-DSCP map [2-111](#)
- setting DSCP or IP precedence values [2-175](#)
- traffic classifications [2-27](#)
- trust states [2-379](#)

port trust states [2-134](#)

statistics

- in-profile and out-of-profile packets [2-254](#)
- packets enqueued or dropped [2-254](#)
- sent and received CoS values [2-254](#)
- sent and received DSCP values [2-254](#)

quality of service

See QoS

querytime, MVR [2-139](#)queue-set command [2-160](#)

Rrcommand command [2-161](#)re-authenticating 802.1X-enabled ports [2-60](#)

re-authentication

- periodic [2-61](#)
- time between attempts [2-63](#)

receiver ports, MVR [2-142](#)receiving flow-control packets [2-71](#)

recovery mechanism

- causes [2-69](#)
- display [2-208, 2-211](#)
- timer interval [2-69](#)

redundancy for cluster switches [2-45](#)reload command [2-163](#)remote command command [2-164](#)remote-span command [2-165](#)

Remote Switched Port Analyzer

See RSPAN

rename (boot loader) command [A-18](#)

reset (boot loader) command [A-19](#)

reset command [2-401](#)

resource templates, displaying [2-278](#)

rmdir (boot loader) command [A-20](#)

rmon collection stats command [2-167](#)

root guard, for spanning tree [2-325](#)

routed ports

IP addresses on [2-83](#)

number supported [2-83, 2-169](#)

RSPAN

configuring [2-136](#)

displaying [2-262](#)

filter RSPAN traffic [2-136](#)

remote-span command [2-165](#)

sessions

add interfaces to [2-136](#)

displaying [2-262](#)

start new [2-136](#)

show cluster members command [2-190](#)

show controllers cpu-interface command [2-192, 2-194](#)

show controllers team command [2-198](#)

show current command [2-401](#)

show dot1x command [2-200](#)

show dtp [2-204](#)

show env command [2-206](#)

show errdisable detect command [2-208](#)

show errdisable flap-values command [2-209](#)

show errdisable recovery command [2-211](#)

show etherchannel command [2-213](#)

show interfaces command [2-216](#)

show interfaces counters command [2-221](#)

show ip igmp profile command [2-224](#)

show ip igmp snooping command [2-225, 2-227, 2-228](#)

show mac-address-table address command [2-232](#)

show mac-address-table aging time command [2-234](#)

show mac-address-table command [2-230](#)

show mac-address-table count command [2-236](#)

show mac-address-table dynamic command [2-238](#)

show mac-address-table interface command [2-240](#)

show mac address-table multicast command [2-242](#)

show mac-address-table notification command [2-244](#)

show mac-address-table static command [2-246](#)

show mac-address-table vlan command [2-248](#)

show mls qos aggregate-policer command [2-251](#)

show mls qos command [2-250](#)

show mls qos input-queue command [2-252](#)

show mls qos interface command [2-254](#)

show mls qos maps command [2-257](#)

show mls qos queue-set command [2-260](#)

show monitor command [2-262](#)

show mvr command [2-264](#)

show mvr interface command [2-266](#)

show mvr members command [2-268](#)

show pagp command [2-270](#)

show platform acl command [C-2](#)

show platform configuration command [C-3](#)

show platform etherchannel command [C-4](#)

S

sdm prefer command [2-168](#)

secure ports, limitations [2-364](#)

sending flow-control packets [2-71](#)

service password-recovery command [2-170](#)

service-policy command [2-172](#)

session command [2-174](#)

set (boot loader) command [A-21](#)

set command [2-175](#)

setup command [2-177](#)

show access-lists command [2-180](#)

show boot command [2-183](#)

show changes command [2-401](#)

show class-map command [2-185](#)

show cluster candidates command [2-188](#)

show cluster command [2-186](#)

- show platform forward command [C-5](#)
- show platform igmp snooping command [C-7](#)
- show platform ipc trace command [C-12](#)
- show platform ip multicast command [C-9](#)
- show platform ip unicast command [C-10](#)
- show platform layer4op command [C-13](#)
- show platform mac-address-table command [C-14](#)
- show platform messaging command [C-15](#)
- show platform monitor command [C-16](#)
- show platform mvr table command [C-17](#)
- show platform pm command [C-23](#)
- show platform port-asic command [C-18](#)
- show platform port-security command [C-24](#)
- show platform qos command [C-25](#)
- show platform resource-manager command [C-26](#)
- show platform snmp counters command [C-28](#)
- show platform spanning-tree command [C-29](#)
- show platform stack-manager command [C-30](#)
- show platform team command [C-32](#)
- show platform vlan command [C-35](#)
- show policy-map command [2-272](#)
- show port security command [2-274](#)
- show proposed command [2-401](#)
- show running-config vlan command [2-276](#)
- show sdm prefer command [2-278](#)
- show spanning-tree command [2-280](#)
- show storm-control command [2-285](#)
- show switch command [2-287](#)
- show system mtu command [2-290](#)
- show trust command [2-379](#)
- show udd command [2-291](#)
- show version command [2-294](#)
- show vlan access-map command [2-300](#)
- show vlan command [2-296](#)
- show vlan command fields [2-297](#)
- show vlan filter command [2-301](#)
- show vmps command [2-302](#)
- show vtp command [2-304](#)
- shutdown command [2-308](#)
- shutdown vlan command [2-309](#)
- SNMP host, specifying [2-312](#)
- SNMP informs, enabling the sending of [2-310](#)
- snmp-server enable traps command [2-310](#)
- snmp-server host command [2-312](#)
- snmp trap mac-notification command [2-315](#)
- SNMP traps
 - enabling MAC address notification trap [2-315](#)
 - enabling the MAC address notification feature [2-96](#)
 - enabling the sending of [2-310](#)
- software images
 - copying [2-5](#)
 - deleting [2-50](#)
 - downloading [2-7](#)
 - upgrading [2-5, 2-7](#)
 - uploading [2-13](#)
- software version, displaying [2-294](#)
- source ports, MVR [2-142](#)
- SPAN
 - configuring [2-136](#)
 - debug messages, display [B-14](#)
 - displaying [2-262](#)
 - filter SPAN traffic [2-136](#)
 - sessions
 - add interfaces to [2-136](#)
 - displaying [2-262](#)
 - start new [2-136](#)
- spanning-tree backbonefast command [2-317](#)
- spanning-tree bpdudfilter command [2-318](#)
- spanning-tree bpduguard command [2-320](#)
- spanning-tree cost command [2-322](#)
- spanning-tree extend system-id command [2-324](#)
- spanning-tree guard command [2-325](#)
- spanning-tree loopguard default command [2-327](#)
- spanning-tree mode command [2-328](#)
- spanning-tree portfast (global configuration)
 - command [2-331](#)
- spanning-tree portfast (interface configuration)
 - command [2-333](#)

- spanning-tree port-priority command [2-329](#)
- Spanning Tree Protocol
 - See STP
- spanning-tree uplinkfast command [2-335](#)
- spanning-tree vlan command [2-337](#)
- speed command [2-340](#)
- srr-queue bandwidth limit command [2-342](#)
- srr-queue bandwidth shape command [2-344](#)
- srr-queue bandwidth share command [2-346](#)
- stack member
 - access [2-174](#)
 - number [2-351](#)
 - priority value [2-350](#)
 - reloading [2-163](#)
- stack member number [2-287](#)
- stacks, switch
 - reloading [2-163](#)
 - stack member access [2-174](#)
 - stack member number [2-287](#), [2-351](#)
 - stack member priority value [2-287](#), [2-350](#)
- static-access ports, configuring [2-355](#)
- statistics, Ethernet group [2-167](#)
- storm-control command [2-348](#)
- STP
 - BackboneFast [2-317](#)
 - debug messages, display
 - BackboneFast events [B-62](#)
 - optimized BPDUs handling [B-64](#)
 - spanning-tree activity [B-60](#)
 - switch shim [B-65](#)
 - transmitted and received BPDUs [B-63](#)
 - UplinkFast [B-67](#)
 - detection of indirect link failures [2-317](#)
 - extended system ID [2-324](#)
 - path cost [2-322](#)
 - root port
 - accelerating choice of new [2-335](#)
 - loop guard [2-325](#)
 - preventing from becoming designated [2-325](#)
 - restricting which can be root [2-325](#)
 - root guard [2-325](#)
 - UplinkFast [2-335](#)
- root switch
 - affects of extended system ID [2-324](#), [2-338](#)
 - hello-time [2-337](#)
 - interval between BPDU messages [2-337](#)
 - interval between hello BPDU messages [2-337](#)
 - max-age [2-337](#)
 - port priority for selection of [2-329](#)
 - primary or secondary [2-337](#)
 - switch priority [2-337](#)
- state changes
 - blocking to forwarding state [2-333](#)
 - enabling BPDU filtering [2-318](#), [2-331](#)
 - enabling BPDU guard [2-320](#), [2-331](#)
 - enabling Port Fast [2-331](#), [2-333](#)
 - enabling timer to recover from error state [2-69](#)
 - forward-delay time [2-337](#)
 - length of listening and learning states [2-337](#)
 - shutting down Port Fast-enabled ports [2-331](#)
- state information display [2-280](#)
- VLAN options [2-337](#)
- SVIs
 - creating [2-78](#)
 - number supported [2-169](#)
- Switched Port Analyzer
 - See SPAN
- switching characteristics
 - modifying [2-353](#), [2-361](#)
 - returning to interfaces [2-353](#), [2-361](#)
- switchport access command [2-355](#)
- switchport block command [2-357](#)
- switchport command [2-353](#)
- switchport host command [2-358](#)
- switchport mode command [2-359](#)
- switchport nonegotiate command [2-361](#)
- switchport port-security aging command [2-366](#)
- switchport port-security command [2-363](#)

switchport priority extend command [2-368](#)
 switchport protected command [2-370](#)
 switchports, displaying [2-216](#)
 switchport trunk command [2-372](#)
 switchport voice vlan command [2-375](#)
 switch priority command [2-350](#)
 switch renumber command [2-351](#)
 system message logging, save message to Flash [2-91](#)
 system mtu command [2-377](#)
 system resource templates [2-168](#)

T

TAC

inquiries [xix](#)
 toll-free telephone numbers [xx](#)
 website [xix](#)

tar files, creating, listing, and extracting [2-10](#)

technical assistance

- Cisco.com [xviii](#)
- TAC [xix](#)
- TAC website [xix](#)
- toll-free telephone numbers [xx](#)

Telnetting to cluster switches [2-161](#)

temperature information, displaying [2-206](#)

templates, system resources [2-168](#)

trunking, VLAN mode [2-359](#)

trunk mode [2-359](#)

trunk ports [2-359](#)

trunks, to non-DTP device [2-360](#)

trusted port states for QoS [2-134](#)

type (boot loader) command [A-24](#)

U

UDLD

aggressive mode [2-381, 2-383](#)
 debug messages, display [B-75](#)

enable globally [2-381](#)
 enable per interface [2-383](#)
 error recovery timer [2-69](#)
 message timer [2-381](#)
 normal mode [2-381, 2-383](#)
 reset a shutdown interface [2-385](#)
 status [2-291](#)

udld (global configuration) command [2-381](#)
 udld (interface configuration) command [2-383](#)
 udld reset command [2-385](#)
 unicast storm control [2-348](#)
 unicast traffic counters [2-221](#)

UniDirectional Link Detection

- See UDLD

unknown multicast traffic, preventing [2-357](#)
 unknown unicast traffic, preventing [2-357](#)
 unset (boot loader) command [A-25](#)
 upgrading, software images [2-5, 2-7](#)
 UplinkFast, for STP [2-335](#)
 user EXEC mode [1-2, 1-3](#)

V

version (boot loader) command [A-27](#)

vlan (global configuration) command [2-386](#)
 vlan (VLAN configuration) command [2-392](#)
 vlan access-map command [2-398](#)
 VLAN access map configuration mode [2-398](#)
 VLAN access maps

- actions [2-3](#)
- displaying [2-300](#)

VLAN configuration

- rules [2-390, 2-394](#)
- saving [2-386, 2-396](#)

VLAN configuration mode

- commands

 - VLAN [2-392](#)
 - VTP [2-414](#)

- description [1-5](#)

VLAN configuration mode (continued)

- entering [2-400](#)

- summary [1-3](#)

- vlan database command [2-400](#)

- vlan filter command [2-403](#)

- VLAN filters, displaying [2-301](#)

- VLAN ID range [2-386, 2-392](#)

VLAN maps

- applying [2-403](#)

- creating [2-398](#)

- defining [2-99](#)

- displaying [2-300](#)

VLAN Query Protocol

- See VQP

VLANs

- adding [2-386](#)

- configuring [2-386, 2-392](#)

- debug messages, display

- ISL [B-71](#)

- VLAN IOS file system error tests [B-70](#)

- VLAN manager activity [B-68](#)

- VTP [B-73](#)

- displaying configurations [2-276, 2-296](#)

- extended-range [2-386](#)

MAC addresses

- displaying [2-248](#)

- number of [2-236](#)

- media types [2-389, 2-394](#)

- normal-range [2-386, 2-392](#)

- restarting [2-309](#)

- saving the configuration [2-386](#)

- shutting down [2-309](#)

- SNMP traps for VTP [2-310, 2-312](#)

- suspending [2-309](#)

- variables [2-392](#)

VLAN Trunking Protocol

- See VTP

VMPS

- configuring servers [2-408](#)

- displaying [2-302](#)

- error recovery timer [2-69](#)

- reconfirming dynamic VLAN assignments [2-405](#)

- vmmps reconfirm (global configuration) command [2-406](#)

- vmmps reconfirm (privileged EXEC) command [2-405](#)

- vmmps retry command [2-407](#)

- vmmps server command [2-408](#)

voice VLAN

- configuring [2-375](#)

- setting port priority [2-368](#)

VQP

- and dynamic-access ports [2-356](#)

- clearing client statistics [2-33](#)

- displaying information [2-302](#)

- per-server retry count [2-407](#)

- reconfirmation interval [2-406](#)

- reconfirming dynamic VLAN assignments [2-405](#)

VTP

- changing characteristics [2-410](#)

- clearing pruning counters [2-34](#)

configuring

- domain name [2-410, 2-414](#)

- file name [2-410](#)

- mode [2-410, 2-414](#)

- password [2-410, 2-414](#)

- counters display fields [2-305](#)

- displaying information [2-304](#)

enabling

- pruning [2-410, 2-414](#)

- version 2 [2-410, 2-414](#)

- mode [2-410, 2-414](#)

- pruning [2-410, 2-414](#)

- saving the configuration [2-386, 2-396](#)

- statistics [2-304](#)

- status [2-304](#)

- status display fields [2-306](#)

- vtp (global configuration) command [2-410](#)

- vtp (VLAN configuration) command [2-414](#)