



## INDEX

### A

- aaa accounting dot1x command [2-1](#)
- aaa authentication dot1x command [2-3, 2-846](#)
- aaa authorization network command [2-5, 2-24, 2-30, 2-32, 2-34, 2-36, 2-38, 2-148, 2-316, 2-485, B-7, B-34](#)
- AAA methods [2-3, 2-846](#)
- access control entries
  - See ACEs
- access control lists
  - See ACLs
- access groups
  - IP [2-203](#)
  - MAC, displaying [2-613](#)
- access list, IPv6 [2-273](#)
- access map configuration mode [2-332](#)
- access mode [2-803](#)
- access ports [2-803](#)
- ACEs [2-133, 2-409](#)
- ACLs
  - deny [2-131](#)
  - displaying [2-466](#)
  - for non-IP protocols [2-320](#)
  - IP [2-203](#)
  - matching [2-332](#)
  - on Layer 2 interfaces [2-203](#)
  - permit [2-407](#)
- action command [2-6](#)
- address aliasing [2-380](#)
- aggregate-port learner [2-395](#)
- allowed VLANs [2-823](#)
- archive copy-sw command [2-8](#)
- archive download-sw command [2-11](#)
- archive tar command [2-15](#)
- archive upload-sw command [2-18](#)
- arp access-list command [2-20](#)
- authentication command bounce-port ignore [2-22](#)
- authentication command disable-port ignore [2-23](#)
- authentication control-direction command [2-24](#)
- authentication event command [2-26](#)
- authentication failed VLAN
  - See dot1x auth-fail vlan
- authentication fallback command [2-30](#)
- authentication host-mode command [2-32](#)
- authentication mac-move permit command [2-34](#)
- authentication open command [2-36](#)
- authentication order command [2-38](#)
- authentication periodic command [2-40](#)
- authentication port-control command [2-42](#)
- authentication priority command [2-44](#)
- authentication timer command [2-46](#)
- authentication violation command [2-48](#)
- auth-fail max-attempts
  - See dot1x auth-fail max-attempts
- auth-fail vlan
  - See dot1x auth-fail vlan
- auth open command [2-36](#)
- auth order command [2-38](#)
- authorization state of controlled port [2-168](#)
- auth timer command [2-46](#)
- autonegotiation of duplex mode [2-181](#)
- auto qos classify command [2-50](#)
- auto qos trust command [2-53](#)
- auto qos voip command [2-56](#)

**B**

BackboneFast, for STP [2-724](#)

backup interfaces

- configuring [2-796](#)
- displaying [2-543](#)

boot (boot loader) command [A-2](#)

boot auto-copy-sw command [2-62](#)

boot auto-download-sw command [2-63](#)

boot config-file command [2-66](#)

boot enable-break command [2-67](#)

boot helper command [2-68](#)

boot helper-config file command [2-69](#)

booting

- Cisco IOS image [2-72](#)
- displaying environment variables [2-479](#)
- interrupting [2-63, 2-67](#)
- manually [2-70](#)

boot loader

- accessing [A-1](#)
- booting
  - Cisco IOS image [A-2](#)
  - helper image [2-68](#)
- directories
  - creating [A-15](#)
  - displaying a list of [A-7](#)
  - removing [A-19](#)
- displaying
  - available commands [A-12](#)
  - memory heap utilization [A-13](#)
  - version [A-26](#)
- environment variables
  - described [A-20](#)
  - displaying settings [A-20](#)
  - location of [A-21](#)
  - setting [A-20](#)
  - unsetting [A-24](#)

boot loader (continued)

- files
  - copying [A-5](#)
  - deleting [A-6](#)
  - displaying a list of [A-7](#)
  - displaying the contents of [A-4, A-16, A-23](#)
  - renaming [A-17](#)
- file system
  - formatting [A-10](#)
  - initializing flash [A-9](#)
  - running a consistency check [A-11](#)
- prompt [A-1](#)
- resetting the system [A-18](#)

boot manual command [2-70](#)

boot private-config-file command [2-71](#)

boot system command [2-72](#)

BPDU filtering, for spanning tree [2-725, 2-759](#)

BPDU guard, for spanning tree [2-727, 2-759](#)

broadcast storm control [2-780](#)

**C**

candidate switches

- See clusters

cat (boot loader) command [A-4](#)

Catalyst 3750G Integrated Wireless LAN Controller Switch [2-457](#)

CDP, enabling protocol tunneling for [2-297](#)

channel-group command [2-75](#)

channel-protocol command [2-79](#)

Cisco SoftPhone

- auto-QoS configuration [2-56](#)
- trusting packets sent from [2-371](#)

CISP

- See Client Information Signalling Protocol

cisp

- debug platform cisp command [B-34](#)

cisp enable command [2-80](#)

class command [2-81](#)

- class-map command [2-84](#)
- class maps
  - creating [2-84](#)
  - defining the match criteria [2-334](#)
  - displaying [2-486](#)
- class of service
  - See CoS
- clear dot1x command [2-86](#)
- clear eap sessions command [2-87](#)
- clear errdisable interface [2-88](#)
- clear ip arp inspection log command [2-89](#)
- clear ip arp inspection statistics command [2-90](#)
- clear ipc command [2-93](#)
- clear ip dhcp snooping database command [2-91](#)
- clear ipv6 dhcp conflict command [2-94](#)
- clear l2protocol-tunnel counters command [2-95](#)
- clear lacp command [2-96](#)
- clear mac address-table command [2-97, 2-99](#)
- clear nmsp statistics command [2-100](#)
- clear pagp command [2-101](#)
- clear port-security command [2-102](#)
- clear spanning-tree counters command [2-104](#)
- clear spanning-tree detected-protocols command [2-105](#)
- clear vmps statistics command [2-106](#)
- clear vtp counters command [2-107](#)
- Client Information Signalling Protocol [2-80, 2-148, 2-485, B-7, B-34](#)
- cluster commander-address command [2-108](#)
- cluster discovery hop-count command [2-110](#)
- cluster enable command [2-111](#)
- cluster holdtime command [2-112](#)
- cluster member command [2-113](#)
- cluster outside-interface command [2-115](#)
- cluster run command [2-116](#)
- clusters
  - adding candidates [2-113](#)
  - binding to HSRP group [2-117](#)
  - building manually [2-113](#)
  - communicating with
    - devices outside the cluster [2-115](#)
    - members by using Telnet [2-437](#)
  - debug messages, display [B-8](#)
  - displaying
    - candidate switches [2-489](#)
    - debug messages [B-8](#)
    - member switches [2-491](#)
    - status [2-487](#)
  - hop-count limit for extended discovery [2-110](#)
  - HSRP standby groups [2-117](#)
  - redundancy [2-117](#)
  - SNMP trap [2-713](#)
- cluster standby-group command [2-117](#)
- cluster timer command [2-119](#)
- command modes defined [1-2](#)
- command switch
  - See clusters
- configuration files
  - password recovery disable considerations [A-1](#)
  - specifying the name [2-66, 2-71](#)
- configuring multiple interfaces [2-199](#)
- controller, wireless [2-457](#)
- copy (boot loader) command [A-5](#)
- CoS
  - assigning default value to incoming packets [2-341](#)
  - assigning to Layer 2 protocol packets [2-300](#)
  - overriding the incoming value [2-341](#)
- CoS-to-DSCP map [2-345](#)
- CPU ASIC statistics, displaying [2-493](#)
- crashinfo files [2-192](#)
- critical VLAN [2-27](#)

**D**

- debug authentication [B-2](#)
- debug auto qos command [B-4](#)
- debug backup command [B-6](#)
- debug cisp command [B-7](#)
- debug cluster command [B-8](#)
- debug dot1x command [B-10](#)
- debug dtp command [B-12](#)
- debug eap command [B-13](#)
- debug etherchannel command [B-14](#)
- debug ilpower command [B-15](#)
- debug interface command [B-16](#)
- debug ip dhcp snooping command [B-17](#)
- debug ip igmp filter command [B-19](#)
- debug ip igmp max-groups command [B-20](#)
- debug ip igmp snooping command [B-21](#)
- debug ip verify source packet command [B-18](#)
- debug lacp command [B-22](#)
- debug lldp packets command [B-23](#)
- debug mac-notification command [B-24](#)
- debug matm command [B-25](#)
- debug matm move update command [B-26](#)
- debug monitor command [B-27](#)
- debug mvrdbg command [B-28](#)
- debug nmsp command [B-29](#)
- debug nvram command [B-30](#)
- debug pagp command [B-31](#)
- debug platform acl command [B-32](#)
- debug platform backup interface command [B-33](#)
- debug platform cisp command [B-34](#)
- debug platform cli-redirect main command [B-35](#)
- debug platform configuration command [B-36, B-44](#)
- debug platform cpu-queues command [B-37](#)
- debug platform device-manager command [B-39](#)
- debug platform dot1x command [B-40](#)
- debug platform etherchannel command [B-41](#)
- debug platform fallback-bridging command [B-42](#)
- debug platform forw-tcam command [B-43](#)
- debug platform ip arp inspection command [B-45](#)
- debug platform ipc command [B-56](#)
- debug platform ip dhcp command [B-46](#)
- debug platform ip igmp snooping command [B-47](#)
- debug platform ip multicast command [B-49](#)
- debug platform ip source-guard command [B-52](#)
- debug platform ip unicast command [B-53](#)
- debug platform ip wccp command [B-55](#)
- debug platform led command [B-57](#)
- debug platform matm command [B-58](#)
- debug platform messaging application command [B-59](#)
- debug platform phy command [B-60](#)
- debug platform pm command [B-62](#)
- debug platform port-asic command [B-64](#)
- debug platform port-security command [B-65](#)
- debug platform qos-acl-tcam command [B-66](#)
- debug platform remote-commands command [B-67](#)
- debug platform resource-manager command [B-68](#)
- debug platform snmp command [B-69](#)
- debug platform span command [B-70](#)
- debug platform stack-manager command [B-71](#)
- debug platform supervisor-asic command [B-72](#)
- debug platform sw-bridge command [B-73](#)
- debug platform tcam command [B-74](#)
- debug platform udd command [B-77](#)
- debug platform vlan command [B-78](#)
- debug platform wireless-controller [B-103](#)
- debug pm command [B-79](#)
- debug port-security command [B-81](#)
- debug qos-manager command [B-82](#)
- debug spanning-tree backbonefast command [B-85](#)
- debug spanning-tree bpdu command [B-86](#)
- debug spanning-tree bpdu-opt command [B-87](#)
- debug spanning-tree command [B-83](#)
- debug spanning-tree mstp command [B-88](#)
- debug spanning-tree switch command [B-90](#)
- debug spanning-tree uplinkfast command [B-92](#)
- debug sw-vlan command [B-93](#)
- debug sw-vlan ifs command [B-95](#)

- debug sw-vlan notification command [B-96](#)
- debug sw-vlan vtp command [B-98](#)
- debug uddl command [B-100](#)
- debug vqpc command [B-102](#)
- define interface-range command [2-120](#)
- delete (boot loader) command [A-6](#)
- delete command [2-122](#)
- deny (ARP access-list configuration) command [2-124](#)
- deny (IPv6) command [2-126](#)
- deny command [2-131](#)
- detect mechanism, causes [2-183](#)
- DHCP snooping
  - accepting untrusted packets from edge switch [2-234](#)
  - enabling
    - on a VLAN [2-240](#)
    - option 82 [2-232, 2-234](#)
    - trust on an interface [2-238](#)
  - error recovery timer [2-189](#)
  - rate limiting [2-237](#)
- DHCP snooping binding database
  - binding file, configuring [2-230](#)
  - bindings
    - adding [2-228](#)
    - deleting [2-228](#)
    - displaying [2-563](#)
  - clearing database agent statistics [2-91](#)
  - database agent, configuring [2-230](#)
  - displaying
    - binding entries [2-563](#)
    - database agent status [2-565, 2-567](#)
  - renewing [2-444](#)
- dir (boot loader) command [A-7](#)
- directories, deleting [2-122](#)
- domain name, VTP [2-860](#)
- dot1x auth-fail max-attempts [2-142](#)
- dot1x auth-fail vlan [2-144](#)
- dot1x command [2-140](#)
- dot1x control-direction command [2-146](#)
- dot1x credentials (global configuration) command [2-148](#)
- dot1x critical global configuration command [2-149](#)
- dot1x critical interface configuration command [2-151](#)
- dot1x default command [2-153](#)
- dot1x fallback command [2-154](#)
- dot1x guest-vlan command [2-155](#)
- dot1x host-mode command [2-158](#)
- dot1x initialize command [2-160](#)
- dot1x mac-auth-bypass command [2-161](#)
- dot1x max-reauth-req command [2-163](#)
- dot1x max-req command [2-165](#)
- dot1x multiple-hosts command [2-166](#)
- dot1x pae command [2-167](#)
- dot1x port-control command [2-168](#)
- dot1x re-authenticate command [2-170](#)
- dot1x re-authentication command [2-171](#)
- dot1x reauthentication command [2-172](#)
- dot1x supplicant force-multicast command [2-173](#)
- dot1x test eapol-capable command [2-174](#)
- dot1x test timeout command [2-175](#)
- dot1x timeout command [2-176](#)
- dot1x violation-mode command [2-179](#)
- dropping packets, with ACL matches [2-6](#)
- drop threshold, Layer 2 protocol tunneling [2-297](#)
- DSCP-to-CoS map [2-345](#)
- DSCP-to-DSCP-mutation map [2-345](#)
- DTP [2-804](#)
- DTP flap
  - error detection for [2-183](#)
  - error recovery timer [2-189](#)
- DTP negotiation [2-808](#)
- dual-purpose uplink ports
  - displaying configurable options [2-546](#)
- duplex command [2-180](#)
- dynamic-access ports
  - configuring [2-792](#)
  - restrictions [2-793](#)

## dynamic ARP inspection

## ARP ACLs

- apply to a VLAN [2-211](#)
- define [2-20](#)
- deny packets [2-124](#)
- display [2-470](#)
- permit packets [2-399](#)

## clear

- log buffer [2-89](#)
- statistics [2-90](#)

## display

- ARP ACLs [2-470](#)
- configuration and operating state [2-558](#)
- log buffer [2-558](#)
- statistics [2-558](#)
- trust state and rate limit [2-558](#)

enable per VLAN [2-221](#)error detection for [2-183](#)error recovery timer [2-189](#)

## log buffer

- clear [2-89](#)
- configure [2-215](#)
- display [2-558](#)

rate-limit incoming ARP packets [2-213](#)

## statistics

- clear [2-90](#)
- display [2-558](#)

trusted interface state [2-217](#)type of packet logged [2-222](#)validation checks [2-219](#)dynamic auto VLAN membership mode [2-803](#)dynamic desirable VLAN membership mode [2-803](#)

## Dynamic Host Configuration Protocol (DHCP)

See DHCP snooping

## Dynamic Trunking Protocol

See DTP

**E**

## EAP-request/identity frame

- maximum number to send [2-165](#)
- response time before retransmitting [2-176](#)

encapsulation methods [2-823](#)environment variables, displaying [2-479](#)epm access-control open [2-182](#)errdisable detect cause command [2-183](#)errdisable detect cause small-frame comand [2-186](#)errdisable recovery cause small-frame [2-188](#)errdisable recovery command [2-189](#)error conditions, displaying [2-529](#)error disable detection [2-183](#)error-disabled interfaces, displaying [2-543](#)

## EtherChannel

- assigning Ethernet interface to channel group [2-75](#)
- creating port-channel logical interface [2-197](#)
- debug EtherChannel/PAGP, display [B-14](#)
- debug platform-specific events, display [B-41](#)
- displaying [2-533](#)
- enabling Layer 2 protocol tunneling for
  - LACP [2-298](#)
  - PAGP [2-298](#)
  - UDLD [2-298](#)

interface information, displaying [2-543](#)

## LACP

- clearing channel-group information [2-96](#)
- debug messages, display [B-22](#)
- displaying [2-603](#)
- modes [2-75](#)
- port priority for hot-standby ports [2-301](#)
- restricting a protocol [2-79](#)
- system priority [2-303](#)

load-distribution methods [2-417](#)

## EtherChannel (continued)

## PAgP

- aggregate-port learner [2-395](#)
- clearing channel-group information [2-101](#)
- debug messages, display [B-31](#)
- displaying [2-662](#)
- error detection for [2-183](#)
- error recovery timer [2-189](#)
- learn method [2-395](#)
- modes [2-75](#)
- physical-port learner [2-395](#)
- priority of interface for transmitted traffic [2-397](#)

Ethernet controller, internal register display [2-495](#)

Ethernet statistics, collecting [2-447](#)

exception crashinfo command [2-192](#)

extended discovery of candidate switches [2-110](#)

extended-range VLANs

- and allowed VLAN list [2-823](#)
- and pruning-eligible list [2-823](#)

extended system ID for STP [2-733](#)

---

**F**

fallback profile command [2-193](#)

fallback profiles, displaying [2-536](#)

fan information, displaying [2-523](#)

file name, VTP [2-860](#)

files, deleting [2-122](#)

flash\_init (boot loader) command [A-9](#)

flexible authentication ordering [2-38](#)

Flex Links

- configuring [2-796](#)
- configuring preferred VLAN [2-799](#)
- displaying [2-543](#)

flowcontrol command [2-195](#)

format (boot loader) command [A-10](#)

forwarding packets, with ACL matches [2-6](#)

forwarding results, display [C-6](#)

frame forwarding information, displaying [C-6](#)

front-end controller, counter and status information [C-8](#)

fsck (boot loader) command [A-11](#)

---

**G**

global configuration mode [1-2, 1-4](#)

---

**H**

hardware ACL statistics [2-466](#)

help (boot loader) command [A-12](#)

hierarchical policy maps [2-415](#)

hop-count limit for clusters [2-110](#)

host connection, port configuration [2-802](#)

host ports, private VLANs [2-806](#)

Hot Standby Router Protocol

See HSRP

HSRP

binding HSRP group to cluster [2-117](#)

standby group [2-117](#)

---

**I**

IEEE 802.1Q trunk ports and native VLANs [2-852](#)

IEEE 802.1Q tunnel ports

- configuring [2-803](#)
- displaying [2-512](#)
- limitations [2-804](#)

IEEE 802.1x

- and switchport modes [2-804](#)
- violation error recovery [2-189](#)

See also port-based authentication

IEEE 802.1X Port Based Authentication

enabling guest VLAN supplicant [2-143, 2-154, 2-194](#)

IGMP filters

- applying [2-243](#)
- debug messages, display [B-19](#)

IGMP groups, setting maximum [2-244](#)

- IGMP maximum groups, debugging [B-20](#)
- IGMP profiles
  - creating [2-246](#)
  - displaying [2-570](#)
- IGMP snooping
  - adding ports as a static member of a group [2-262](#)
  - displaying [2-571, 2-576, 2-578](#)
  - enabling [2-248](#)
  - enabling the configurable-leave timer [2-250](#)
  - enabling the Immediate-Leave feature [2-259](#)
  - flooding query count [2-256](#)
  - interface topology change notification behavior [2-258](#)
  - multicast table [2-574](#)
  - querier [2-252](#)
  - query solicitation [2-256](#)
  - report suppression [2-254](#)
  - switch topology change notification behavior [2-256](#)
- images
  - See software images
- Immediate-Leave feature, MVR [2-382](#)
- immediate-leave processing [2-259](#)
- Immediate-Leave processing, IPv6 [2-293](#)
- interface configuration mode [1-2, 1-4](#)
- interface port-channel command [2-197](#)
- interface range command [2-199](#)
- interface-range macros [2-120](#)
- interfaces
  - assigning Ethernet interface to channel group [2-75](#)
  - configuring [2-180](#)
  - configuring multiple [2-199](#)
  - creating port-channel logical [2-197](#)
  - debug messages, display [B-16](#)
  - disabling [2-709](#)
  - displaying the MAC address table [2-625](#)
  - restarting [2-709](#)
- interface speed, configuring [2-769](#)
- interface vlan command [2-201](#)
- internal registers, displaying [2-495, 2-505](#)
- Internet Group Management Protocol
  - See IGMP
- invalid GBIC
  - error detection for [2-183](#)
  - error recovery timer [2-189](#)
- ip access-group command [2-203](#)
- ip address command [2-206](#)
- IP addresses, setting [2-206](#)
- IP address matching [2-332](#)
- ip admission command [2-208](#)
- ip admission name proxy http command [2-209](#)
- ip arp inspection filter vlan command [2-211](#)
- ip arp inspection limit command [2-213](#)
- ip arp inspection log-buffer command [2-215](#)
- ip arp inspection trust command [2-217](#)
- ip arp inspection validate command [2-219](#)
- ip arp inspection vlan command [2-221](#)
- ip arp inspection vlan logging command [2-222](#)
- ip device tracking command [2-226](#)
- ip device tracking probe command [2-224](#)
- IP DHCP snooping
  - See DHCP snooping
- ip dhcp snooping binding command [2-228](#)
- ip dhcp snooping command [2-227](#)
- ip dhcp snooping database command [2-230](#)
- ip dhcp snooping information option allow-untrusted command [2-234](#)
- ip dhcp snooping information option command [2-232](#)
- ip dhcp snooping information option format remote-id command [2-236](#)
- ip dhcp snooping limit rate command [2-237](#)
- ip dhcp snooping trust command [2-238](#)
- ip dhcp snooping verify command [2-239](#)
- ip dhcp snooping vlan command [2-240](#)
- ip dhcp snooping vlan information option format-type circuit-id string command [2-241](#)
- ip igmp filter command [2-243](#)
- ip igmp max-groups command [2-244, 2-268, 2-270](#)
- ip igmp profile command [2-246](#)
- ip igmp snooping command [2-248](#)

ip igmp snooping last-member-query-interval command [2-250](#)  
 ip igmp snooping querier command [2-252](#)  
 ip igmp snooping report-suppression command [2-254](#)  
 ip igmp snooping tcn command [2-256](#)  
 ip igmp snooping tcn flood command [2-258](#)  
 ip igmp snooping vlan immediate-leave command [2-259](#)  
 ip igmp snooping vlan mrouter command [2-260](#)  
 ip igmp snooping vlan static command [2-262](#)  
 IP multicast addresses [2-379](#)  
 IP phones  
     auto-QoS configuration [2-56](#)  
     trusting packets sent from [2-371](#)  
 IP-precedence-to-DSCP map [2-345](#)  
 ip snap forwarding command [2-264](#)  
 ip source binding command [2-265](#)  
 IP source guard  
     disabling [2-272](#)  
     displaying  
         binding entries [2-580](#)  
         configuration [2-581](#)  
         dynamic binding entries only [2-563](#)  
     enabling [2-272](#)  
     static IP source bindings [2-265](#)  
 ip ssh command [2-267](#)  
 IPv6 access list, deny conditions [2-126](#)  
 ipv6 access-list command [2-273](#)  
 ipv6 address dhcp command [2-275](#)  
 ipv6 dhcp client request vendor command [2-276](#)  
 ipv6 dhcp ping packets command [2-277](#)  
 ipv6 dhcp pool command [2-278](#)  
 ipv6 dhcp server command [2-280](#)  
 ipv6 mld snooping command [2-282](#)  
 ipv6 mld snooping last-listener-query count command [2-284](#)  
 ipv6 mld snooping last-listener-query-interval command [2-286](#)  
 ipv6 mld snooping listener-message-suppression command [2-288](#)  
 ipv6 mld snooping robustness-variable command [2-289](#)

ipv6 mld snooping tcn command [2-291](#)  
 ipv6 mld snooping vlan command [2-293](#)  
 IPv6 SDM template [2-448](#)  
 ipv6 traffic-filter command [2-295](#)  
 ip verify source command [2-272](#)

---

## J

jumbo frames  
     See MTU

---

## L

l2protocol-tunnel command [2-297](#)  
 l2protocol-tunnel cos command [2-300](#)  
 LACP  
     See EtherChannel  
 lacp port-priority command [2-301](#)  
 lacp system-priority command [2-303](#)  
 Layer 2 mode, enabling [2-790](#)  
 Layer 2 protocol ports, displaying [2-600](#)  
 Layer 2 protocol-tunnel  
     error detection for [2-183](#)  
     error recovery timer [2-189](#)  
 Layer 2 protocol tunnel counters [2-95](#)  
 Layer 2 protocol tunneling error recovery [2-298](#)  
 Layer 2 traceroute  
     IP addresses [2-837](#)  
     MAC addresses [2-834](#)  
 Layer 3 mode, enabling [2-790](#)  
 line configuration mode [1-3, 1-5](#)  
 Link Aggregation Control Protocol  
     See EtherChannel  
 link flap  
     error detection for [2-183](#)  
     error recovery timer [2-189](#)  
 link state group command [2-305](#)  
 link state track command [2-307](#)

load-distribution methods for EtherChannel [2-417](#)  
 location (global configuration) command [2-308](#)  
 location (interface configuration) command [2-310](#)  
 logging event command [2-312](#)  
 logging event power-inline-status command [2-313](#)  
 logging file command [2-314](#)  
 logical interface [2-197](#)  
 loopback error  
   detection for [2-183](#)  
   recovery timer [2-189](#)  
 loop guard, for spanning tree [2-735, 2-739](#)

## M

mab request format attribute 32 command [2-316](#)  
 mac access-group command [2-318](#)  
 MAC access-groups, displaying [2-613](#)  
 MAC access list configuration mode [2-320](#)  
 mac access-list extended command [2-320](#)  
 MAC access lists [2-131](#)  
 MAC addresses  
   disabling MAC address learning per VLAN [2-323](#)  
   displaying  
     aging time [2-619](#)  
     all [2-617](#)  
     dynamic [2-623](#)  
     MAC address-table move updates [2-628](#)  
     notification settings [2-627, 2-630](#)  
     number of addresses in a VLAN [2-621](#)  
     per interface [2-625](#)  
     per VLAN [2-634](#)  
     static [2-632](#)  
     static and dynamic entries [2-615](#)  
   dynamic  
     aging time [2-322](#)  
     deleting [2-97](#)  
     displaying [2-623](#)  
   enabling MAC address notification [2-327](#)  
   enabling MAC address-table move update [2-325](#)

MAC addresses (continued)  
   matching [2-332](#)  
   persistent stack [2-777](#)  
   static  
     adding and removing [2-329](#)  
     displaying [2-632](#)  
     dropping on an interface [2-330](#)  
   tables [2-617](#)  
 MAC address notification, debugging [B-24](#)  
 mac address-table aging-time [2-318, 2-332](#)  
 mac address-table aging-time command [2-322](#)  
 mac address-table learning command [2-323](#)  
 mac address-table move update command [2-325](#)  
 mac address-table notification command [2-327](#)  
 mac address-table static command [2-329](#)  
 mac address-table static drop command [2-330](#)  
 macros  
   interface range [2-120, 2-199](#)  
 maps  
   QoS  
     defining [2-345](#)  
     displaying [2-644](#)  
   VLAN  
     creating [2-849](#)  
     defining [2-332](#)  
     displaying [2-700](#)  
 match (access-map configuration) command [2-332](#)  
 match (class-map configuration) command [2-334](#)  
 maximum transmission unit  
   See MTU  
 mdix auto command [2-336](#)  
 member switches  
   See clusters  
 memory (boot loader) command [A-13](#)  
 mkdir (boot loader) command [A-15](#)

- MLD snooping
  - configuring [2-288, 2-289](#)
  - configuring queries [2-284, 2-286](#)
  - configuring topology change notification [2-291](#)
  - displaying [2-590, 2-592, 2-594, 2-596](#)
  - enabling [2-282](#)
- MLD snooping on a VLAN, enabling [2-293](#)
- mls qos aggregate-policer command [2-339](#)
- mls qos command [2-337](#)
- mls qos cos command [2-341](#)
- mls qos dscp-mutation command [2-343](#)
- mls qos map command [2-345](#)
- mls qos queue-set output buffers command [2-349](#)
- mls qos queue-set output threshold command [2-351](#)
- mls qos rewrite ip dscp command [2-353](#)
- mls qos srr-queue input bandwidth command [2-355](#)
- mls qos srr-queue input buffers command [2-357](#)
- mls qos-srr-queue input cos-map command [2-359](#)
- mls qos-srr-queue input dscp-map command [2-361](#)
- mls qos-srr-queue input priority-queue command [2-363](#)
- mls qos-srr-queue input threshold command [2-365](#)
- mls qos-srr-queue output cos-map command [2-367](#)
- mls qos-srr-queue output dscp-map command [2-369](#)
- mls qos trust command [2-371](#)
- mls qos vlan-based command [2-373](#)
- mode, MVR [2-379](#)
- Mode button, and password recovery [2-452](#)
- modes, commands [1-2](#)
- monitor session command [2-374](#)
- more (boot loader) command [A-16](#)
- MSTP
  - displaying [2-677](#)
  - interoperability [2-105](#)
  - link type [2-737](#)
- MSTP (continued)
  - MST region
    - aborting changes [2-742](#)
    - applying changes [2-742](#)
    - configuration name [2-742](#)
    - configuration revision number [2-742](#)
    - current or pending display [2-742](#)
    - displaying [2-677](#)
    - MST configuration mode [2-742](#)
    - VLANs-to-instance mapping [2-742](#)
  - path cost [2-744](#)
  - protocol mode [2-740](#)
  - restart protocol migration process [2-105](#)
  - root port
    - loop guard [2-735](#)
    - preventing from becoming designated [2-735](#)
    - restricting which can be root [2-735](#)
    - root guard [2-735](#)
  - root switch
    - affects of extended system ID [2-733](#)
    - hello-time [2-747, 2-755](#)
    - interval between BPDU messages [2-748](#)
    - interval between hello BPDU messages [2-747, 2-755](#)
    - max-age [2-748](#)
    - maximum hop count before discarding BPDU [2-749](#)
    - port priority for selection of [2-751](#)
    - primary or secondary [2-755](#)
    - switch priority [2-754](#)
  - state changes
    - blocking to forwarding state [2-761](#)
    - enabling BPDU filtering [2-725, 2-759](#)
    - enabling BPDU guard [2-727, 2-759](#)
    - enabling Port Fast [2-759, 2-761](#)
    - forward-delay time [2-746](#)
    - length of listening and learning states [2-746](#)
    - rapid transition to forwarding [2-737](#)
    - shutting down Port Fast-enabled ports [2-759](#)

## MSTP (continued)

state information display [2-676](#)

## MTU

configuring size [2-831](#)

displaying global setting [2-689](#)

## Multicast Listener Discovery

See MLD

multicast group address, MVR [2-382](#)

multicast groups, MVR [2-380](#)

## Multicast Listener Discovery

See MLD

multicast router learning method [2-260](#)

multicast router ports, configuring [2-260](#)

multicast router ports, IPv6 [2-293](#)

multicast storm control [2-780](#)

multicast VLAN, MVR [2-379](#)

multicast VLAN registration

See MVR

## Multiple Spanning Tree Protocol

See MSTP

## MVR

and address aliasing [2-380](#)

configuring [2-379](#)

configuring interfaces [2-382](#)

debug messages, display [B-28](#)

displaying [2-652](#)

displaying interface information [2-654](#)

members, displaying [2-656](#)

mvr (global configuration) command [2-379](#)

mvr (interface configuration) command [2-382](#)

mvr vlan group command [2-383](#)

**N**

native VLANs [2-823](#)

native VLAN tagging [2-852](#)

network-policy (global configuration) command [2-386](#)

network-policy command [2-385](#)

network-policy profile (network-policy configuration) command [2-387](#)

nmsp attachment suppress command [2-390](#)

nmsp command [2-389](#)

no authentication logging verbose [2-391](#)

no dot1x logging verbose [2-392](#)

no mab logging verbose [2-393](#)

nonegotiate, speed [2-769](#)

nonegotiating DTP messaging [2-808](#)

non-IP protocols

denying [2-131](#)

forwarding [2-407](#)

non-IP traffic access lists [2-320](#)

non-IP traffic forwarding

denying [2-131](#)

permitting [2-407](#)

non-stop forwarding [2-394](#)

normal-range VLANs [2-848](#)

nsf command [2-394](#)

**O**

online diagnostics

displaying

configured boot-up coverage level [2-509](#)

current scheduled tasks [2-509](#)

event logs [2-509](#)

supported test suites [2-509](#)

test ID [2-509](#)

test results [2-509](#)

test statistics [2-509](#)

global configuration mode

clearing health monitoring diagnostic test schedule [2-89](#)

clearing test-based testing schedule [2-136](#)

setting health monitoring diagnostic testing [2-89](#)

setting test-based testing [2-136](#)

setting up health monitoring diagnostic test schedule [2-89](#)

- online diagnostics (continued)
  - global configuration mode
    - setting up test-based testing [2-136](#)
  - health monitoring diagnostic tests, configuring [2-134](#)
  - scheduled switchover
    - disabling [2-136](#)
    - enabling [2-136](#)
  - scheduling
    - enabling [2-136](#)
    - removing [2-136](#)
  - testing, starting [2-138](#)
  - test interval, setting [2-136](#)

## P

### PAgP

See EtherChannel

- pagp learn-method command [2-395](#)
- pagp port-priority command [2-397](#)
- password, VTP [2-861](#)
- password-recovery mechanism, enabling and disabling [2-452](#)
- permit (ARP access-list configuration) command [2-399](#)
- permit (IPv6) command [2-401](#)
- permit (MAC access-list configuration) command [2-407](#)
- per-VLAN spanning-tree plus
  - See STP
- physical-port learner [2-395](#)
- PID, displaying [2-557](#)
- PIM-DVMRP, as multicast router learning method [2-260](#)

### PoE

- configuring the power budget [2-421](#)
- configuring the power management mode [2-418](#)
- displaying controller register values [2-503](#)
- displaying power management information [2-669](#)
- logging of status [2-313](#)
- police aggregate command [2-412](#)
- police command [2-410](#)
- policed-DSCP map [2-345](#)

- policy-map command [2-414](#)
- policy maps
  - applying to an interface [2-454, 2-461](#)
  - creating [2-414](#)
  - displaying [2-664](#)
  - hierarchical [2-415](#)
- policers
  - displaying [2-637](#)
  - for a single class [2-410](#)
  - for multiple classes [2-339, 2-412](#)
  - policed-DSCP map [2-345](#)
- traffic classification
  - defining the class [2-81](#)
  - defining trust states [2-839](#)
  - setting DSCP or IP precedence values [2-459](#)
- Port Aggregation Protocol
  - See EtherChannel
- port-based authentication
  - AAA method list [2-3, 2-846](#)
  - configuring violation modes [2-179](#)
  - debug messages, display [B-10](#)
  - enabling IEEE 802.1x
    - globally [2-140](#)
    - per interface [2-168](#)
  - guest VLAN [2-155](#)
  - host modes [2-158](#)
  - IEEE 802.1x AAA accounting methods [2-1](#)
  - initialize an interface [2-160, 2-175](#)
  - MAC authentication bypass [2-161](#)
  - manual control of authorization state [2-168](#)
  - PAE as authenticator [2-167](#)
  - periodic re-authentication
    - enabling [2-172](#)
    - time between attempts [2-176](#)
  - quiet period between failed authentication exchanges [2-176](#)
  - re-authenticating IEEE 802.1x-enabled ports [2-170](#)
  - resetting configurable IEEE 802.1x parameters [2-153](#)

port-based authentication (continued)

- switch-to-authentication server retransmission time [2-176](#)
- switch-to-client frame-retransmission number [2-163 to 2-165](#)
- switch-to-client retransmission time [2-176](#)
- test for IEEE 802.1x readiness [2-174](#)

port-channel load-balance command [2-417](#)

Port Fast, for spanning tree [2-761](#)

port ranges, defining [2-120](#)

ports, debugging [B-79](#)

ports, protected [2-821](#)

port security

- aging [2-815](#)
- debug messages, display [B-81](#)
- enabling [2-810](#)
- violation error recovery [2-189](#)

port trust states for QoS [2-371](#)

port types, MVR [2-382](#)

power information, displaying [2-523](#)

power inline command [2-418](#)

power inline consumption command [2-421](#)

Power over Ethernet

- See PoE

power rps command (user EXEC) [2-423](#)

priority-queue command [2-425](#)

priority value, stack member [2-684, 2-785](#)

private-vlan command [2-427](#)

private-vlan mapping command [2-430](#)

private VLANs

- association [2-819](#)
- configuring [2-427](#)
- configuring ports [2-806](#)
- displaying [2-695](#)
- host ports [2-806](#)
- mapping
  - configuring [2-819](#)
  - displaying [2-543](#)
- promiscuous ports [2-806](#)

privileged EXEC mode [1-2, 1-3](#)

product identification information, displaying [2-557](#)

promiscuous ports, private VLANs [2-806](#)

protected ports, displaying [2-549](#)

pruning

- VLANs [2-823](#)
- VTP
  - displaying interface information [2-543](#)
  - enabling [2-861](#)

pruning-eligible VLAN list [2-825](#)

PVST+

- See STP

---

## Q

### QoS

auto-QoS

- configuring [2-56](#)
- debug messages, display [B-4](#)
- displaying [2-475](#)

auto-QoS trust

- configuring [2-53](#)

class maps

- creating [2-84](#)
- defining the match criteria [2-334](#)
- displaying [2-486](#)

defining the CoS value for an incoming packet [2-341](#)

displaying configuration information [2-475, 2-636](#)

DSCP transparency [2-353](#)

DSCP trusted ports

- applying DSCP-to-DSCP-mutation map to [2-343](#)
- defining DSCP-to-DSCP-mutation map [2-345](#)

## QoS (continued)

## egress queues

- allocating buffers [2-349](#)
- defining the CoS output queue threshold map [2-367](#)
- defining the DSCP output queue threshold map [2-369](#)
- displaying buffer allocations [2-640](#)
- displaying CoS output queue threshold map [2-644](#)
- displaying DSCP output queue threshold map [2-644](#)
- displaying queueing strategy [2-640](#)
- displaying queue-set settings [2-647](#)
- enabling bandwidth shaping and scheduling [2-773](#)
- enabling bandwidth sharing and scheduling [2-775](#)
- limiting the maximum output on a port [2-771](#)
- mapping a port to a queue-set [2-432](#)
- mapping CoS values to a queue and threshold [2-367](#)
- mapping DSCP values to a queue and threshold [2-369](#)
- setting maximum and reserved memory allocations [2-351](#)
- setting WTD thresholds [2-351](#)

enabling [2-337](#)

## ingress queues

- allocating buffers [2-357](#)
- assigning SRR scheduling weights [2-355](#)
- defining the CoS input queue threshold map [2-359](#)
- defining the DSCP input queue threshold map [2-361](#)
- displaying buffer allocations [2-640](#)
- displaying CoS input queue threshold map [2-644](#)
- displaying DSCP input queue threshold map [2-644](#)
- displaying queueing strategy [2-640](#)
- displaying settings for [2-638](#)
- enabling the priority queue [2-363](#)

## QoS (continued)

## ingress queues

- mapping CoS values to a queue and threshold [2-359](#)
- mapping DSCP values to a queue and threshold [2-361](#)
- setting WTD thresholds [2-365](#)

## maps

- defining [2-345](#), [2-359](#), [2-361](#), [2-367](#), [2-369](#)
- displaying [2-644](#)

## policy maps

- applying an aggregate policer [2-412](#)
- applying to an interface [2-454](#), [2-461](#)
- creating [2-414](#)
- defining policers [2-339](#), [2-410](#)
- displaying policers [2-637](#)
- displaying policy maps [2-664](#)
- hierarchical [2-415](#)
- policed-DSCP map [2-345](#)
- setting DSCP or IP precedence values [2-459](#)
- traffic classifications [2-81](#)
- trust states [2-839](#)

port trust states [2-371](#)queues, enabling the expedite [2-425](#)

## statistics

- in-profile and out-of-profile packets [2-640](#)
- packets enqueued or dropped [2-640](#)
- sent and received CoS values [2-640](#)
- sent and received DSCP values [2-640](#)

trusted boundary for IP phones [2-371](#)VLAN-based [2-373](#)

## quality of service

## See QoS

querytime, MVR [2-379](#)queue-set command [2-432](#)

**R**

radius-server dead-criteria command [2-433](#)  
radius-server host command [2-435](#)  
rapid per-VLAN spanning-tree plus  
    See STP  
rapid PVST+  
    See STP  
rcommand command [2-437](#)  
re-authenticating IEEE 802.1x-enabled ports [2-170](#)  
re-authentication  
    periodic [2-172](#)  
    time between attempts [2-176](#)  
receiver ports, MVR [2-382](#)  
receiving flow-control packets [2-195](#)  
recovery mechanism  
    causes [2-189](#)  
    display [2-88, 2-481, 2-527, 2-531](#)  
    timer interval [2-190](#)  
redundancy for cluster switches [2-117](#)  
redundant power supply  
    See RPS  
reload command [2-439](#)  
remote command [2-441](#)  
remote-span command [2-442](#)  
Remote Switched Port Analyzer  
    See RSPAN  
rename (boot loader) command [A-17](#)  
renew ip dhcp snooping database command [2-444](#)  
reset (boot loader) command [A-18](#)  
resource templates, displaying [2-672](#)  
restricted VLAN  
    See dot1x auth-fail vlan  
rmdir (boot loader) command [A-19](#)  
rmon collection stats command [2-447](#)  
root guard, for spanning tree [2-735](#)  
routed ports  
    IP addresses on [2-207](#)  
    number supported [2-207](#)

RPS 2300  
    configuring [2-423](#)  
    managing [2-423](#)  
RSPAN  
    configuring [2-374](#)  
    displaying [2-650](#)  
    filter RSPAN traffic [2-374](#)  
    remote-span command [2-442](#)  
    sessions  
        displaying [2-650](#)

**S**

scheduled switchover  
    disabling [2-136](#)  
    enabling [2-136](#)  
SDM mismatch mode [2-449, 2-685](#)  
sdm prefer command [2-448](#)  
SDM templates  
    allowed resources [2-450](#)  
    and stacking [2-449](#)  
    displaying [2-672](#)  
    dual IPv4 and IPv6 [2-448](#)  
secure ports, limitations [2-812](#)  
sending flow-control packets [2-195](#)  
service password-recovery command [2-452](#)  
service-policy command [2-454](#)  
session command [2-457](#)  
set (boot loader) command [A-20](#)  
set command [2-459](#)  
setup command [2-461](#)  
setup express command [2-464](#)  
show access-lists command [2-466](#)  
show archive status command [2-469](#)  
show arp access-list command [2-470](#)  
show authentication command [2-471](#)  
show auto qos command [2-475](#)  
show boot command [2-479](#)  
show cable-diagnostics tdr command [2-481](#)

- show cisp command [2-485](#)
- show class-map command [2-486](#)
- show cluster candidates command [2-489](#)
- show cluster command [2-487](#)
- show cluster members command [2-491](#)
- show controllers cpu-interface command [2-493](#)
- show controllers ethernet-controller command [2-495](#)
- show controllers power inline command [2-503](#)
- show controllers tcam command [2-505](#)
- show controller utilization command [2-507](#)
- show dot1q-tunnel command [2-512](#)
- show dot1x command [2-513](#)
- show dtp [2-518](#)
- show eap command [2-520](#)
- show env command [2-523](#)
- show errdisable detect command [2-527](#)
- show errdisable flap-values command [2-529](#)
- show errdisable recovery command [2-531](#)
- show etherchannel command [2-533](#)
- show fallback profile command [2-536](#)
- show flowcontrol command [2-538](#)
- show idprom command [2-540](#)
- show interfaces command [2-543](#)
- show interfaces counters command [2-554](#)
- show inventory command [2-557](#)
- show ip arp inspection command [2-558](#)
- show ipc command [2-583](#)
- show ip dhcp snooping binding command [2-563](#)
- show ip dhcp snooping command [2-562](#)
- show ip dhcp snooping database command [2-565, 2-567](#)
- show ip igmp profile command [2-570](#)
- show ip igmp snooping address command [2-592](#)
- show ip igmp snooping command [2-571, 2-590](#)
- show ip igmp snooping groups command [2-574](#)
- show ip igmp snooping mrouter command [2-576, 2-594](#)
- show ip igmp snooping querier command [2-578, 2-596](#)
- show ip source binding command [2-580](#)
- show ipv6 access-list command [2-587](#)
- show ipv6 dhcp conflict command [2-589](#)
- show ipv6 route updated [2-598](#)
- show ip verify source command [2-581](#)
- show l2protocol-tunnel command [2-600](#)
- show lacp command [2-603](#)
- show link state group command [2-611](#)
- show lldp command [2-607](#)
- show location [2-608](#)
- show mac access-group command [2-613](#)
- show mac address-table address command [2-617](#)
- show mac address-table aging time command [2-619](#)
- show mac address-table command [2-615](#)
- show mac address-table count command [2-621](#)
- show mac address-table dynamic command [2-623](#)
- show mac address-table interface command [2-625](#)
- show mac address-table learning command [2-627](#)
- show mac address-table move update command [2-628](#)
- show mac address-table notification command [2-99, 2-630, B-26](#)
- show mac address-table static command [2-632](#)
- show mac address-table vlan command [2-634](#)
- show mls qos aggregate-policer command [2-637](#)
- show mls qos command [2-636](#)
- show mls qos input-queue command [2-638](#)
- show mls qos interface command [2-640](#)
- show mls qos maps command [2-644](#)
- show mls qos queue-set command [2-647](#)
- show mls qos vlan command [2-649](#)
- show monitor command [2-650](#)
- show mvr command [2-652](#)
- show mvr interface command [2-654](#)
- show mvr members command [2-656](#)
- show network-policy profile command [2-658](#)
- show nmsp command [2-659](#)
- show pagp command [2-662](#)
- show platform acl command [C-2](#)
- show platform backup interface command [C-3](#)
- show platform configuration command [C-4](#)
- show platform etherchannel command [C-5](#)
- show platform forward command [C-6](#)

- show platform frontend-controller command [C-8](#)
- show platform igmp snooping command [C-9](#)
- show platform ipc trace command [C-17](#)
- show platform ip multicast command [C-11](#)
- show platform ip unicast command [C-12](#)
- show platform ipv6 unicast command [C-18](#)
- show platform ip wccp command [C-16](#)
- show platform layer4op command [C-20](#)
- show platform mac-address-table command [C-21](#)
- show platform messaging command [C-22](#)
- show platform monitor command [C-23](#)
- show platform mvr table command [C-24](#)
- show platform pm command [C-25](#)
- show platform port-asic command [C-26](#)
- show platform port-security command [C-31](#)
- show platform qos command [C-32](#)
- show platform resource-manager command [C-33](#)
- show platform snmp counters command [C-35](#)
- show platform spanning-tree command [C-36](#)
- show platform stack manager command [C-38](#)
- show platform stp-instance command [C-37](#)
- show platform tb command [C-42](#)
- show platform team command [C-44](#)
- show platform vlan command [C-47](#)
- show policy-map command [2-664](#)
- show port security command [2-666](#)
- show power inline command [2-669](#)
- show sdm prefer command [2-672](#)
- show setup express command [2-675](#)
- show spanning-tree command [2-676](#)
- show storm-control command [2-682](#)
- show switch command [2-684](#)
- show system mtu command [2-689](#)
- show trust command [2-839](#)
- show udd command [2-690](#)
- show version command [2-693](#)
- show vlan access-map command [2-700](#)
- show vlan command [2-695](#)
- show vlan command, fields [2-697](#)
- show vlan filter command [2-701](#)
- show vmps command [2-702](#)
- show vtp command [2-704](#)
- shutdown command [2-709](#)
- shutdown threshold, Layer 2 protocol tunneling [2-297](#)
- shutdown vlan command [2-710](#)
- small violation-rate command [2-711](#)
- SNMP host, specifying [2-718](#)
- SNMP informs, enabling the sending of [2-713](#)
- snmp-server enable traps command [2-713](#)
- snmp-server host command [2-718](#)
- snmp trap mac-notification change command [2-722](#)
- SNMP traps
  - enabling MAC address notification trap [2-722](#)
  - enabling the MAC address notification feature [2-327](#)
  - enabling the sending of [2-713](#)
- SoftPhone
  - See Cisco SoftPhone
- software images
  - copying [2-8](#)
  - deleting [2-122](#)
  - downloading [2-11](#)
  - upgrading [2-8, 2-11](#)
  - uploading [2-18](#)
- software version, displaying [2-693](#)
- source ports, MVR [2-382](#)
- SPAN
  - configuring [2-374](#)
  - debug messages, display [B-27](#)
  - displaying [2-650](#)
  - filter SPAN traffic [2-374](#)
  - sessions
    - add interfaces to [2-374](#)
    - displaying [2-650](#)
    - start new [2-374](#)
- spanning-tree backbonefast command [2-724](#)
- spanning-tree bpdupfilter command [2-725](#)
- spanning-tree bpduguard command [2-727](#)
- spanning-tree cost command [2-729](#)

- spanning-tree etherchannel command [2-731](#)
- spanning-tree extend system-id command [2-733](#)
- spanning-tree guard command [2-735](#)
- spanning-tree link-type command [2-737](#)
- spanning-tree loopguard default command [2-739](#)
- spanning-tree mode command [2-740](#)
- spanning-tree mst configuration command [2-742](#)
- spanning-tree mst cost command [2-744](#)
- spanning-tree mst forward-time command [2-746](#)
- spanning-tree mst hello-time command [2-747](#)
- spanning-tree mst max-age command [2-748](#)
- spanning-tree mst max-hops command [2-749](#)
- spanning-tree mst port-priority command [2-751](#)
- spanning-tree mst pre-standard command [2-753](#)
- spanning-tree mst priority command [2-754](#)
- spanning-tree mst root command [2-755](#)
- spanning-tree portfast (global configuration) command [2-759](#)
- spanning-tree portfast (interface configuration) command [2-761](#)
- spanning-tree port-priority command [2-757](#)
- Spanning Tree Protocol
  - See STP
- spanning-tree transmit hold-count command [2-763](#)
- spanning-tree uplinkfast command [2-764](#)
- spanning-tree vlan command [2-766](#)
- speed command [2-769](#)
- srr-queue bandwidth limit command [2-771](#)
- srr-queue bandwidth share command [2-775](#)
- SSH, configuring version [2-267](#)
- stack-mac persistent timer command [2-777](#)
- stack member
  - access [2-457](#)
  - number [2-684, 2-788](#)
  - priority value [2-785](#)
  - provisioning [2-786](#)
  - reloading [2-439](#)
- stacks, switch
  - disabling a member [2-783](#)
  - enabling a member [2-783](#)
  - MAC address [2-777](#)
  - provisioning a new member [2-786](#)
  - reloading [2-439](#)
  - stack member access [2-457](#)
  - stack member number [2-684, 2-788](#)
  - stack member priority value [2-684, 2-785](#)
- static-access ports, configuring [2-792](#)
- statistics, Ethernet group [2-447](#)
- sticky learning, enabling [2-810](#)
- storm-control command [2-780](#)
- STP
  - BackboneFast [2-724](#)
  - counters, clearing [2-104](#)
  - debug messages, display
    - BackboneFast events [B-85](#)
    - MSTP [B-88](#)
    - optimized BPDUs handling [B-87](#)
    - spanning-tree activity [B-83](#)
    - switch shim [B-90](#)
    - transmitted and received BPDUs [B-86](#)
    - UplinkFast [B-92](#)
  - detection of indirect link failures [2-724](#)
  - enabling protocol tunneling for [2-297](#)
  - EtherChannel misconfiguration [2-731](#)
  - extended system ID [2-733](#)
  - path cost [2-729](#)
  - protocol modes [2-740](#)
  - root port
    - accelerating choice of new [2-764](#)
    - loop guard [2-735](#)
    - preventing from becoming designated [2-735](#)
    - restricting which can be root [2-735](#)
    - root guard [2-735](#)
    - UplinkFast [2-764](#)

## STP (continued)

## root switch

- affects of extended system ID [2-733, 2-767](#)
- hello-time [2-766](#)
- interval between BPDU messages [2-766](#)
- interval between hello BPDU messages [2-766](#)
- max-age [2-766](#)
- port priority for selection of [2-757](#)
- primary or secondary [2-766](#)
- switch priority [2-766](#)

## state changes

- blocking to forwarding state [2-761](#)
- enabling BPDU filtering [2-725, 2-759](#)
- enabling BPDU guard [2-727, 2-759](#)
- enabling Port Fast [2-759, 2-761](#)
- enabling timer to recover from error state [2-189](#)
- forward-delay time [2-766](#)
- length of listening and learning states [2-766](#)
- shutting down Port Fast-enabled ports [2-759](#)

state information display [2-676](#)VLAN options [2-754, 2-766](#)SVIs, creating [2-201](#)SVI status calculation [2-794](#)

## Switched Port Analyzer

See SPAN

## switching characteristics

- modifying [2-790](#)
- returning to interfaces [2-790](#)

switchport access command [2-792](#)switchport autostate exclude command [2-794](#)switchport backup interface command [2-796](#)switchport block command [2-800](#)switchport command [2-790](#)switchport host command [2-802](#)switchport mode command [2-803](#)switchport mode private-vlan command [2-806](#)switchport nonegotiate command [2-808](#)switchport port-security aging command [2-815](#)switchport port-security command [2-810](#)switchport priority extend command [2-817](#)switchport private-vlan command [2-819](#)switchport protected command [2-821](#)switchports, displaying [2-543](#)switchport trunk command [2-823](#)switchport voice vlan command [2-826, 2-827](#)switch priority command [2-783, 2-785](#)switch provision command [2-786](#)switch renumber command [2-788](#)system env temperature threshold yellow command [2-829](#)system message logging [2-313](#)system message logging, save message to flash [2-314](#)system mtu command [2-831](#)system resource templates [2-448](#)


---

**T**
tar files, creating, listing, and extracting [2-15](#)TDR, running [2-833](#)Telnet, using to communicate to cluster switches [2-437](#)temperature information, displaying [2-523](#)templates, system resources [2-448](#)test cable-diagnostics tdr command [2-833](#)traceroute mac command [2-834](#)traceroute mac ip command [2-837](#)trunking, VLAN mode [2-803](#)trunk mode [2-803](#)trunk ports [2-803](#)trunks, to non-DTP device [2-804](#)trusted boundary for QoS [2-371](#)trusted port states for QoS [2-371](#)tunnel ports, Layer 2 protocol, displaying [2-600](#)type (boot loader) command [A-23](#)

---

**U**

## UDLD

- aggressive mode [2-841, 2-843](#)
- debug messages, display [B-100](#)
- enable globally [2-841](#)
- enable per interface [2-843](#)
- error recovery timer [2-189](#)
- message timer [2-841](#)
- normal mode [2-841, 2-843](#)
- reset a shutdown interface [2-845](#)
- status [2-690](#)

udld command [2-841](#)

udld port command [2-843](#)

udld reset command [2-845](#)

unicast storm control [2-780](#)

UniDirectional Link Detection

See UDLD

unknown multicast traffic, preventing [2-800](#)

unknown unicast traffic, preventing [2-800](#)

unset (boot loader) command [A-24](#)

upgrading

- software images
  - copying [2-8](#)
  - downloading [2-11](#)
  - monitoring status of [2-469](#)

UplinkFast, for STP [2-764](#)

user EXEC mode [1-2, 1-3](#)

---

**V**

version (boot loader) command [A-26](#)

version mismatch mode [2-685, C-39](#)

vlan access-map command [2-849](#)

VLAN access map configuration mode [2-849](#)

VLAN access maps

- actions [2-6](#)
- displaying [2-700](#)

VLAN-based QoS [2-373](#)

VLAN configuration mode

commands

VLAN [2-848](#)

VTP [2-866](#)

description [1-4](#)

entering [2-851](#)

summary [1-3](#)

vlan dot1q tag native command [2-852](#)

vlan filter command [2-853](#)

VLAN filters, displaying [2-701](#)

VLAN maps

applying [2-853](#)

creating [2-849](#)

defining [2-332](#)

displaying [2-700](#)

VLAN Query Protocol

See VQP

VLANs

configuring [2-848](#)

debug messages, display

ISL [B-96](#)

VLAN IOS file system error tests [B-95](#)

VLAN manager activity [B-93](#)

VTP [B-98](#)

displaying configurations [2-695](#)

enabling guest VLAN supplicant [2-143, 2-154, 2-194](#)

MAC addresses

displaying [2-634](#)

number of [2-621](#)

normal-range [2-848](#)

private [2-806](#)

configuring [2-427](#)

displaying [2-695](#)

See also private VLANs

restarting [2-710](#)

shutting down [2-710](#)

SNMP traps for VTP [2-716, 2-719](#)

suspending [2-710](#)

## VLAN Trunking Protocol

See VTP

VM mode [2-685, C-39](#)

## VMPS

configuring servers [2-858](#)

displaying [2-702](#)

error recovery timer [2-190](#)

reconfirming dynamic VLAN assignments [2-855](#)

vmps reconfirm (global configuration) command [2-856](#)

vmps reconfirm (privileged EXEC) command [2-855](#)

vmps retry command [2-857](#)

vmps server command [2-858](#)

## voice VLAN

configuring [2-826, 2-827](#)

setting port priority [2-817](#)

## VQP

and dynamic-access ports [2-793](#)

clearing client statistics [2-106](#)

displaying information [2-702](#)

per-server retry count [2-857](#)

reconfirmation interval [2-856](#)

reconfirming dynamic VLAN assignments [2-855](#)

## VTP

changing characteristics [2-860](#)

clearing pruning counters [2-107](#)

## configuring

domain name [2-860](#)

file name [2-860](#)

mode [2-860](#)

password [2-861](#)

counters display fields [2-705](#)

displaying information [2-704](#)

## enabling

pruning [2-861](#)

tunneling for [2-297](#)

Version 2 [2-861](#)

enabling per port [2-865](#)

mode [2-860](#)

pruning [2-861](#)

## VTP (continued)

statistics [2-704](#)

status [2-704](#)

status display fields [2-707](#)

vtp (global configuration) command [2-860](#)

vtp interface configuration) command [2-865](#)

vtp primary command [2-867](#)

---

**W**

wireless controller, accessing [2-457](#)

wireless controller switch. [B-103](#)

---

**X**

XENPAK module serial EEPROM information [2-499, 2-540](#)