



Preface

This preface describes who should read the *Software Configuration Guide for the Catalyst 4006 Switch with Supervisor Engine III*, how it is organized, and its document conventions.

Audience

This guide is for experienced network administrators who are responsible for configuring and maintaining Catalyst 4000 family switches.

Organization

This guide is organized into the following chapters:

Chapter	Title	Description
Chapter 1	Product Overview	Presents an overview of the Catalyst 4000 family switches
Chapter 2	Command-Line Interfaces	Describes how to use the command-line interface (CLI)
Chapter 3	Configuring the Switch for the First Time	Describes how to perform a baseline configuration of the switch
Chapter 4	Configuring Interfaces	Describes how to configure non-layer-specific features on Fast Ethernet and Gigabit Ethernet interfaces
Chapter 5	Checking Port Status and Connectivity	Describes how to check module and interface status
Chapter 6	Configuring Layer 2 Ethernet Interfaces	Describes how to configure interfaces to support Layer 2 features, including VLAN trunks
Chapter 7	Understanding and Configuring VLANs	Describes how to set up and modify VLANs
Chapter 8	Understanding and Configuring Private VLANs	Describes how to set up and modify private VLANs

Chapter	Title	Description
Chapter 9	Understanding and Configuring VTP	Describes how to configure the VLAN Trunking Protocol
Chapter 10	Configuring Layer 3 Interfaces	Describes how to configure interfaces to support Layer 3 features
Chapter 11	Understanding and Configuring EtherChannel	Describes how to configure Layer 2 and Layer 3 EtherChannel port bundles
Chapter 12	Understanding and Configuring STP	Describes how to configure the Spanning Tree Protocol (STP) and explains how spanning tree works
Chapter 13	Configuring STP Features	Describes how to configure the spanning-tree PortFast, UplinkFast, and BackboneFast features
Chapter 14	Configuring Cisco Express Forwarding	Describes how to configure Cisco Express Forwarding (CEF) for IP unicast traffic
Chapter 15	Understanding and Configuring IP Multicast	Describes how to configure IP Multicast Multilayer Switching (MMLS)
Chapter 16	Configuring Network Security	Describes how to configure access control lists
Chapter 17	Understanding and Configuring IGMP Snooping	Describes how to configure Internet Group Management Protocol (IGMP) snooping
Chapter 18	Understanding and Configuring CDP	Describes how to configure Cisco Discovery Protocol (CDP)
Chapter 19	Understanding and Configuring UDLD	Describes how to configure the UniDirectional Link Detection (UDLD) protocol
Chapter 20	Understanding and Configuring QoS	Describes how to configure quality of service (QoS)
Chapter 21	Configuring SPAN	Describes how to configure the Switch Port Analyzer (SPAN)
Chapter 22	Environmental Monitoring	Describes how to configure the environmental monitoring features

Related Documentation

The following publications are available for the Catalyst 4006 switch with Supervisor Engine III:

- *Catalyst 4000 Family Installation Guide*
- *Catalyst 4000 Family Module Installation Guide*
- *Command Reference for the Catalyst 4006 Switch with Supervisor Engine III*
- *System Message Guide for the Catalyst 4006 Switch with Supervisor Engine III*
- *Release Notes for the Catalyst 4006 Switch with Supervisor Engine III, Cisco IOS Release 12.1(8a)EW*

- Cisco IOS Configuration Guides and Command References—Use these publications to help you configure Cisco IOS software features not described in the Catalyst 4006 switch with Supervisor Engine III publications:
 - *Configuration Fundamentals Configuration Guide*
 - *Configuration Fundamentals Command Reference*
 - *Interface Configuration Guide*
 - *Interface Command Reference*
 - *Network Protocols Configuration Guide*, Part 1, 2, and 3
 - *Network Protocols Command Reference*, Part 1, 2, and 3
 - *Security Configuration Guide*
 - *Security Command Reference*
 - *Switching Services Configuration Guide*
 - *Switching Services Command Reference*
 - *Voice, Video, and Home Applications Configuration Guide*
 - *Voice, Video, and Home Applications Command Reference*
 - *Software Command Summary*
 - *Software System Error Messages*
 - *Debug Command Reference*
 - *Internetwork Design Guide*
 - *Internetwork Troubleshooting Guide*
 - *Configuration Builder Getting Started Guide*
- The Cisco IOS Configuration Guides and Command References are at <http://www.cisco.com/univercd/cc/td/doc/product/software/ios121/121cgcr/index.htm>
- For information about MIBs, refer to <http://www.cisco.com/public/sw-center/netmgmt/cmtk/mibs.shtml>

Conventions

This document uses the following conventions:

Convention	Description
boldface font	Commands and keywords are in boldface .
<i>italic font</i>	Arguments for which you supply values are in <i>italics</i> .
[]	Elements in square brackets are optional.
{ x y z }	Alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.

Convention	Description
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
screen font	Terminal sessions and information the system displays are in screen font.
boldface screen font	Information you must enter is in boldface screen font .
<i>italic screen font</i>	Arguments for which you supply values are in <i>italic screen font</i> .
→	This pointer highlights an important line of text in an example.
^	The symbol ^ represents the key labeled Control—for example, the key combination ^D in a screen display means hold down the Control key while you press the D key.
< >	Nonprinting characters, such as passwords are in angle brackets.

Commands listed in task tables show only the relevant information for completing the task and not all available options for the command. For a complete description of a command, please refer to the command in the Command Reference for the Catalyst 4006 Switch with Supervisor Engine III.

Notes use the following conventions:


Note

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the publication.

Cautions use the following conventions:


Caution

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

Obtaining Documentation

The following sections explain how to obtain documentation from Cisco Systems.

World Wide Web

You can access the most current Cisco documentation on the World Wide Web at the following URL:

<http://www.cisco.com>

Translated documentation is available at the following URL:

http://www.cisco.com/public/countries_languages.shtml

Documentation CD-ROM

Cisco documentation and additional literature are available in a Cisco Documentation CD-ROM package, which is shipped with your product. The Documentation CD-ROM is updated monthly and may be more current than printed documentation. The CD-ROM package is available as a single unit or through an annual subscription.

Ordering Documentation

Cisco documentation is available in the following ways:

- Registered Cisco Direct Customers can order Cisco product documentation from the Networking Products MarketPlace:
http://www.cisco.com/cgi-bin/order/order_root.pl
- Registered Cisco.com users can order the Documentation CD-ROM through the online Subscription Store:
<http://www.cisco.com/go/subscription>
- Nonregistered Cisco.com users can order documentation through a local account representative by calling Cisco corporate headquarters (California, USA) at 408 526-7208 or, elsewhere in North America, by calling 800 553-NETS (6387).

Documentation Feedback

If you are reading Cisco product documentation on Cisco.com, you can submit technical comments electronically. Click **Leave Feedback** at the bottom of the Cisco Documentation home page. After you complete the form, print it out and fax it to Cisco at 408 527-0730.

You can e-mail your comments to bug-doc@cisco.com.

To submit your comments by mail, use the response card behind the front cover of your document, or write to the following address:

Cisco Systems
Attn: Document Resource Connection
170 West Tasman Drive
San Jose, CA 95134-9883

We appreciate your comments.

Obtaining Technical Assistance

Cisco provides Cisco.com as a starting point for all technical assistance. Customers and partners can obtain documentation, troubleshooting tips, and sample configurations from online tools by using the Cisco Technical Assistance Center (TAC) Web Site. Cisco.com registered users have complete access to the technical support resources on the Cisco TAC Web Site.

Cisco.com

Cisco.com is the foundation of a suite of interactive, networked services that provides immediate, open access to Cisco information, networking solutions, services, programs, and resources at any time, from anywhere in the world.

Cisco.com is a highly integrated Internet application and a powerful, easy-to-use tool that provides a broad range of features and services to help you to

- Streamline business processes and improve productivity
- Resolve technical issues with online support
- Download and test software packages
- Order Cisco learning materials and merchandise
- Register for online skill assessment, training, and certification programs

You can self-register on Cisco.com to obtain customized information and service. To access Cisco.com, go to the following URL:

<http://www.cisco.com>

Technical Assistance Center

The Cisco TAC is available to all customers who need technical assistance with a Cisco product, technology, or solution. Two types of support are available through the Cisco TAC: the Cisco TAC Web Site and the Cisco TAC Escalation Center.

Inquiries to Cisco TAC are categorized according to the urgency of the issue:

- Priority level 4 (P4)—You need information or assistance concerning Cisco product capabilities, product installation, or basic product configuration.
- Priority level 3 (P3)—Your network performance is degraded. Network functionality is noticeably impaired, but most business operations continue.
- Priority level 2 (P2)—Your production network is severely degraded, affecting significant aspects of business operations. No workaround is available.
- Priority level 1 (P1)—Your production network is down, and a critical impact to business operations will occur if service is not restored quickly. No workaround is available.

Which Cisco TAC resource you choose is based on the priority of the problem and the conditions of service contracts, when applicable.

Cisco TAC Web Site

The Cisco TAC Web Site allows you to resolve P3 and P4 issues yourself, saving both cost and time. The site provides around-the-clock access to online tools, knowledge bases, and software. To access the Cisco TAC Web Site, go to the following URL:

<http://www.cisco.com/tac>

All customers, partners, and resellers who have a valid Cisco services contract have complete access to the technical support resources on the Cisco TAC Web Site. The Cisco TAC Web Site requires a Cisco.com login ID and password. If you have a valid service contract but do not have a login ID or password, go to the following URL to register:

<http://www.cisco.com/register/>

If you cannot resolve your technical issues by using the Cisco TAC Web Site, and you are a Cisco.com registered user, you can open a case online by using the TAC Case Open tool at the following URL:

<http://www.cisco.com/tac/caseopen>

If you have Internet access, it is recommended that you open P3 and P4 cases through the Cisco TAC Web Site.

Cisco TAC Escalation Center

The Cisco TAC Escalation Center addresses issues that are classified as priority level 1 or priority level 2; these classifications are assigned when severe network degradation significantly impacts business operations. When you contact the TAC Escalation Center with a P1 or P2 problem, a Cisco TAC engineer will automatically open a case.

To obtain a directory of toll-free Cisco TAC telephone numbers for your country, go to the following URL:

<http://www.cisco.com/warp/public/687/Directory/DirTAC.shtml>

Before calling, please check with your network operations center to determine the level of Cisco support services to which your company is entitled; for example, SMARTnet, SMARTnet Onsite, or Network Supported Accounts (NSA). In addition, please have available your service agreement number and your product serial number.

