



## Device Configuration

---

Cisco CallManager allows you to configure the following devices in your telephony network:

- Cisco voice-mail ports
- CTI route points
- Device profiles
- Gatekeepers
- Gateways
- Phones

This section covers the following topics:

- [Adding Devices to Cisco CallManager, page 43-2](#)
- [Restarting or Resetting a Device, page 43-2](#)

# Adding Devices to Cisco CallManager

Before you can use devices, such as gateways and Cisco IP phones in your IP telephony network, you must add them to the Cisco CallManager configuration database.

Refer to these sections for assistance in adding telephony devices to the Cisco CallManager configuration database:

- [Adding a CTI Route Point, page 44-2](#)
- [Adding a Gatekeeper, page 46-2](#)
- [Adding Gateways to Cisco CallManager, page 47-2](#)
- [Adding a Phone, page 48-4](#)
- [Adding Phone Button Templates, page 49-2](#)
- [Cisco Unity Configuration Checklist, \*Cisco CallManager System Guide\*](#)

## Restarting or Resetting a Device

At any time, you can restart or reset a device by clicking the Reset button in the device window or by clicking the Reset icon in the Find and List window associated with the device, if available. You can restart a device without shutting it down by clicking the **Restart** button. You can shut down a device and bring it back up again by clicking the **Reset** button. If you want to return to the previous window without resetting or restarting the device, click **Close**.

**Note**

---

Restarting or resetting a gateway drops any calls in progress using that gateway. Other devices wait until calls are complete before restarting or resetting.

---