



# Survivable Remote Site Telephony Configuration

---

A survivable remote site telephony (SRST) reference comprises the gateway that can provide limited Cisco CallManager functionality when all other Cisco CallManager servers for a device are unreachable. Typically assigned to device pools, SRST references determine the gateways where calling devices search when they attempt to complete a call if Cisco CallManager is unavailable. For more detailed information on SRST references, refer to the [“Survivable Remote Site Telephony References”](#) section in the *Cisco CallManager System Guide*.

Use the following topics to add, update, copy, or delete a SRST reference:

- [Finding an SRST Reference, page 13-2](#)
- [Adding an SRST Reference, page 13-3](#)
- [Updating an SRST Reference, page 13-4](#)
- [Copying an SRST Reference, page 13-5](#)
- [Deleting an SRST Reference, page 13-6](#)
- [SRST Reference Configuration Settings, page 13-7](#)

# Finding an SRST Reference

Because you might have several SRST references in your network, Cisco CallManager lets you locate specific SRST references based on specific criteria. Use the following procedure to locate SRST references that are defined by a particular user.

## Procedure

---

- Step 1** Choose **System > SRST**.  
The Find and List SRST References window displays.
- Step 2** From the drop-down list box, choose one of the following criteria:
- begins with
  - contains
  - ends with
  - is exactly
- Step 3** Specify the appropriate search text, if applicable, and click **Find**. You can also specify how many items per page to display.



---

**Note** To find all user-defined SRST references that are registered in the database, click **Find** without entering any search text.

---

A list of discovered SRST references displays by

- SRST Reference Name
- IP Address
- Port



---

**Note** You can delete multiple SRST references from the Find and List SRST References window by checking the check boxes next to the appropriate SRST references and clicking **Delete Selected**. You can choose all the SRST references in the window by checking the check box in the matching records title bar and clicking **Delete Selected**.

---

**Step 4** From the list of records, click the SRST reference that matches your search criteria.

The window displays the SRST reference that you chose.

---

#### Related Topics

- [Adding an SRST Reference, page 13-3](#)
- [Updating an SRST Reference, page 13-4](#)
- [Copying an SRST Reference, page 13-5](#)
- [Deleting an SRST Reference, page 13-6](#)
- [SRST Reference Configuration Settings, page 13-7](#)

## Adding an SRST Reference

The following procedure describes how to add an SRST reference.

#### Procedure

---

**Step 1** In the menu bar, choose **System > SRST**.

**Step 2** Click **Add a New SRST Reference**.

**Step 3** Enter the appropriate settings as described in [Table 13-1](#).

**Step 4** To add the new SRST reference, click **Insert**.

The message “Status: Insert completed” displays.

**Step 5** To add more SRST references, click **Add a New SRST Reference** and repeat this procedure.

---

#### Related Topics

- [Finding an SRST Reference, page 13-2](#)
- [Updating an SRST Reference, page 13-4](#)
- [Copying an SRST Reference, page 13-5](#)

- [Deleting an SRST Reference](#), page 13-6
- [SRST Reference Configuration Settings](#), page 13-7

## Updating an SRST Reference

The following procedure describes how to update an SRST reference.

### Procedure

---

- Step 1** In the menu bar, choose **System > SRST**.
- Step 2** Locate the SRST reference that you want to update. See the [“Finding an SRST Reference” section on page 13-2](#).
- Step 3** Update the appropriate settings as described in [Table 13-1](#).
- Step 4** Click **Update**.

The message “Status: Update completed” displays.



**Note** If devices are associated with this SRST reference, a message displays to tell you that devices need to be reset for the update to take effect. Cisco CallManager may drop calls in progress on an affected gateway may be dropped when the gateway is reset.

To reset the affected devices, click the **Reset Devices** button when the update is complete. If you do not want to reset the devices at this time, you can return to this item at any time and click the **Reset Devices** button to initiate the required device resets.

---

### Related Topics

- [Finding an SRST Reference](#), page 13-2
- [Adding an SRST Reference](#), page 13-3
- [Copying an SRST Reference](#), page 13-5

- [Deleting an SRST Reference](#), page 13-6
- [SRST Reference Configuration Settings](#), page 13-7

## Copying an SRST Reference

The following procedure describes how to copy an SRST reference.

### Procedure

---

- Step 1** In the menu bar, choose **System > SRST**.
- Step 2** Locate the SRST reference that you want to copy. See the [“Finding an SRST Reference” section on page 13-2](#).
- Step 3** Click the name of the SRST reference that you want to copy.  
The window displays the SRST reference.
- Step 4** Click **Copy** to copy the SRST reference.  
The window displays a copy of the SRST reference.
- Step 5** Update the desired settings as described in [Table 13-1](#).
- Step 6** Click **Insert** to add the new SRST reference.
- 

### Related Topics

- [Finding an SRST Reference](#), page 13-2
- [Adding an SRST Reference](#), page 13-3
- [Updating an SRST Reference](#), page 13-4
- [Deleting an SRST Reference](#), page 13-6
- [SRST Reference Configuration Settings](#), page 13-7

# Deleting an SRST Reference

The following procedure describes how to delete an SRST reference.

**Note**

You cannot delete SRST references that device pools are using.

**Procedure**

- Step 1** In the menu bar, choose **System > SRST**.
- Step 2** Locate the SRST reference that you want to delete. See the “[Finding an SRST Reference](#)” section on page 13-2.
- Step 3** Check the check box of the SRST reference that you want to delete and click **Delete Selected**.  
A message displays, that tells you that you cannot undo this action.
- Step 4** To delete the SRST reference, click **OK** or to cancel the deletion, click **Cancel**.

**Caution**

Before initiating this action, check carefully to ensure that you are deleting the correct SRST reference. You cannot retrieve deleted SRST references. If an SRST reference is accidentally deleted, you must rebuild it.

**Tip**

You can also delete an SRST reference by locating and displaying the SRST reference that you want to delete and clicking **Delete**.

**Related Topics**

- [Finding an SRST Reference](#), page 13-2
- [Adding an SRST Reference](#), page 13-3
- [Updating an SRST Reference](#), page 13-4
- [Copying an SRST Reference](#), page 13-5
- [SRST Reference Configuration Settings](#), page 13-7

# SRST Reference Configuration Settings

Table 13-1 describes the SRST reference configuration settings.

**Table 13-1 SRST Reference Configuration Settings**

Field	Description
SRST Reference Name	Enter a name in the SRST Reference Name field. The name can comprise up to 50 alphanumeric characters and can contain any combination of spaces, periods (.), hyphens (-), and underscore characters (_). Ensure that each SRST reference name is unique.  <b>Note</b> Use concise and descriptive names for your SRST references.
IP Address	Enter the IP address of the gateway for devices in a device pool to use as an SRST reference.
Port	Enter the port number for this SRST reference. Default value specifies 2000.  <b>Note</b> Change this value only if it does not match the gateway port setting. This value and the gateway port setting must match.

## Related Topics

- [Finding an SRST Reference, page 13-2](#)
- [Adding an SRST Reference, page 13-3](#)
- [Updating an SRST Reference, page 13-4](#)
- [Copying an SRST Reference, page 13-5](#)
- [Deleting an SRST Reference, page 13-6](#)

