



Server Configuration

Use server configuration to specify the address of the server where Cisco CallManager is installed. If your network uses Domain Name System (DNS) services, you can specify the host name of the server. If your network does not use DNS services, you must specify the Internet Protocol (IP) address of the server.



Note

You must update the DNS server with the appropriate Cisco CallManager name and address information before using that information to configure the Cisco CallManager server.

Use the following topics to add, update, or delete a server address in the Cisco CallManager database:

- [Finding a Server, page 2-2](#)
- [Adding a Server, page 2-4](#)
- [Updating a Server, page 2-4](#)
- [Deleting a Server, page 2-5](#)
- [Server Configuration Settings, page 2-7](#)

Finding a Server

Because you might have several servers in your network, Cisco CallManager lets you locate specific servers on the basis of specific criteria. Use the following procedure to locate servers.



Note During your work in a browser session, Cisco CallManager Administration retains your server search preferences. If you navigate to other menu items and return to this menu item, Cisco CallManager Administration retains your server search preferences until you modify your search or close the browser.

Procedure

Step 1 Choose **System > Server**.

The Find and List Servers window displays. Use the two drop-down list boxes to search for a server.

Step 2 From the first Find Servers where drop-down list box, choose one of the following criteria:

- Name
- Description



Note The criterion that you choose in this drop-down list box specifies how the list of servers that your search generates will be sorted. For example, if you choose Description, the Description column will display as the left column of the results list.

From the second Find Servers where drop-down list box, choose one of the following criteria:

- begins with
- contains
- ends with
- is exactly

- is not empty
- is empty

Step 3 Specify the appropriate search text, if applicable, and click **Find**. You can also specify how many items per page to display.

**Tip**

To find all servers that are registered in the database, click **Find** without entering any search text.

A list of discovered servers displays by

- Server icon
- Server name
- Description

**Note**

You can delete multiple servers from the Find and List Servers window by checking the check boxes next to the appropriate servers and clicking **Delete Selected**. You can delete all servers in the window by checking the check box in the Matching records title bar and clicking **Delete Selected**.

Step 4 From the list of records, click the Server icon or name or the Description that matches your search criteria.

The window displays the server that you choose.

Related Topics

- [Adding a Server, page 2-4](#)
- [Updating a Server, page 2-4](#)
- [Deleting a Server, page 2-5](#)
- [Server Configuration Settings, page 2-7](#)

Adding a Server

This section describes how to add a server address to the Cisco CallManager database.

Before You Begin

Activate the Cisco CallManager service as described in the *Cisco CallManager Serviceability Administration Guide*.

Procedure

- Step 1** Choose **System > Server**.
- Step 2** In the upper, right corner of the window, click the **Add a New Server** link. The Server Configuration window displays.
- Step 3** Enter the appropriate settings as described in [Table 2-1](#).
- Step 4** Click **Insert**. The server is added to the database.
-

Related Topics

- [Adding a Cisco CallManager, page 3-4](#)
- [Finding a Server, page 2-2](#)
- [Updating a Server, page 2-4](#)
- [Deleting a Server, page 2-5](#)
- [Server Configuration Settings, page 2-7](#)

Updating a Server

This section describes how to update server information in the Cisco CallManager database.

Procedure

- Step 1** Find the server by using the procedure in the [“Finding a Server”](#) section on [page 2-2](#).
- Step 2** Click the server that you want to update.
- Step 3** Update the appropriate settings as described in [Table 2-1](#).
- Step 4** Click **Update** to save the changes in the database.

Changes to the server configuration do not take effect until you restart Cisco CallManager. For information on restarting the Cisco CallManager service, refer to the *Cisco CallManager Serviceability Administration Guide*.

Related Topics

- [Finding a Server, page 2-2](#)
- [Adding a Server, page 2-4](#)
- [Deleting a Server, page 2-5](#)
- [Server Configuration Settings, page 2-7](#)

Deleting a Server

This section describes how to delete a server from the Cisco CallManager database.

Before You Begin

You cannot delete a server that has a specific Cisco CallManager running on it. To find out which Cisco CallManagers are using the server, click the **Dependency Records** link from the Server Configuration window. For more information about dependency records, see the [“Accessing Dependency Records”](#) section on

[page A-1](#). If you try to delete a server that is in use, Cisco CallManager displays an error message. Before deleting a server that is currently in use, you must perform the following tasks:

- Update the Cisco CallManager in question and assign it to a different server, or delete the Cisco CallManager that is assigned to that server. See the [“Updating a Cisco CallManager” section on page 3-5](#) and [“Deleting a Cisco CallManager” section on page 3-6](#).
- Delete the conference bridges, MTPs, and MOH servers that use the server that you want to delete. See the [“Deleting a Conference Device” section on page 25-13](#), [“Deleting a Media Termination Point” section on page 26-7](#), and the [“Deleting a Music On Hold Server” section of the *Cisco CallManager Features and Services Guide*](#).
- Deactivate the services that are running on that server. Refer to the [Cisco CallManager Serviceability Administration Guide](#).

Procedure

- Step 1** Find the server by using the procedure in the [“Finding a Server” section on page 2-2](#).
- Step 2** From list of matching records, choose the server that you want to delete.
- Step 3** Click **Delete**.

If the server is not in use, Cisco CallManager deletes it. If it is in use, an error message displays.

Changes to the server configuration do not take effect until you restart Cisco CallManager. For information on restarting the Cisco CallManager service, refer to the [Cisco CallManager Serviceability Administration Guide](#).

Related Topics

- [Finding a Server, page 2-2](#)
- [Adding a Server, page 2-4](#)
- [Updating a Server, page 2-4](#)
- [Server Configuration Settings, page 2-7](#)

Server Configuration Settings

Table 2-1 describes the server configuration settings.

Table 2-1 *Server Configuration Settings*

Field	Description
Host Name/IP Address	<p>If your network uses DNS services, you can enter the host name of the Cisco CallManager server. Otherwise, you must enter the full IP address of the server.</p> <p>Note You must update the DNS server with the appropriate Cisco CallManager name and address information before using that information here.</p>
MAC Address	<p>Enter the media access control (MAC) address of the network interface card (NIC) in the Cisco CallManager server. The MAC address specifies the permanent hardware address of the NIC. If you plan to move the server periodically to different locations on the network, you must enter the MAC address, so other devices on the network can always identify the server. If you do not plan to relocate the server, entry of the MAC address is optional.</p>
Description	<p>Enter a description of the server.</p>

Related Topics

- [Finding a Server, page 2-2](#)
- [Adding a Server, page 2-4](#)
- [Updating a Server, page 2-4](#)
- [Deleting a Server, page 2-5](#)

