



## CTI Route Point Configuration

---

A computer telephony integration (CTI) route point designates a virtual device that can receive multiple, simultaneous calls for application-controlled redirection.

For first-party call control, you can optionally add a CTI port for each active voice line (the CTI application determines this). Applications that use CTI route points and CTI ports include Cisco SoftPhone, Cisco IP AutoAttendant, and Cisco IP Interactive Voice Response System. After you add a CTI route point to Cisco Unified CallManager Administration, information from the RIS Data Collector service displays in the CTI Route Point Configuration window. When available, the IP address of the device and the name of the Cisco Unified CallManager with which the device registered display.

For detailed instructions on how to configure CTI route points and CTI ports that are associated with these applications, refer to the documentation and online help that is included with these applications.

This section describes the following basic procedures:

- [Adding a CTI Route Point, page 56-2](#)
- [Modifying a CTI Route Point, page 56-2](#)
- [Deleting a CTI Route Point, page 56-3](#)
- [Finding CTI Route Points, page 56-5](#)
- [Resetting a CTI Route Point, page 56-6](#)
- [CTI Route Point Configuration Settings, page 56-7](#)
- [Computer Telephony Integration, \*Cisco Unified CallManager System Guide\*](#)

# Adding a CTI Route Point

To add a CTI route point, perform the following procedure.

## Procedure

---

- Step 1 Choose **Device** > **CTI Route Point**.
- Step 2 Click the **Add a New CTI Route Point** link.
- Step 3 Enter the appropriate settings, as defined in [Table 56-1](#).
- Step 4 To add the new CTI route point, click **Insert**.

When prompted to add a directory number for line 1, click either **OK** to add the directory number or **Cancel** to continue without adding a directory number. For instructions on how to add and configure directory numbers, see the “[Adding a Directory Number](#)” section on page 59-49.

After you add a CTI route point to Cisco Unified CallManager Administration, information from the RIS Data Collector service displays in the CTI Route Point Configuration window. When available, the IP address of the device and the name of the Cisco Unified CallManager with which the device registered display.

## Related Topics

- [CTI Route Point Configuration, page 56-1](#)
- [Modifying a CTI Route Point, page 56-2](#)
- [Deleting a CTI Route Point, page 56-3](#)
- [Finding CTI Route Points, page 56-5](#)
- [Resetting a CTI Route Point, page 56-6](#)
- [CTI Route Point Configuration Settings, page 56-7](#)
- [Computer Telephony Integration, Cisco Unified CallManager System Guide](#)

# Modifying a CTI Route Point

To modify a CTI route point, perform the following steps.

### Procedure

---

- Step 1** Choose **Device > CTI Route Point**.
- The Find/List CTI Route Points window displays.
- Step 2** Enter the search criteria that are needed to locate the CTI route point that you want to modify.
- Step 3** Click **Find**.
- The window updates to display a list of CTI route points that match the specified search criteria.
- Step 4** Choose the name of the CTI route point whose settings you want to modify.
- The window refreshes to show the current settings for the chosen CTI route point.
- Step 5** Update the appropriate settings as described in [Table 56-1](#).
- Step 6** To apply the changes, click **Update**.
- The window refreshes to display the new settings.
- 

### Related Topics

- [CTI Route Point Configuration, page 56-1](#)
- [Adding a CTI Route Point, page 56-2](#)
- [Deleting a CTI Route Point, page 56-3](#)
- [Finding CTI Route Points, page 56-5](#)
- [Resetting a CTI Route Point, page 56-6](#)
- [CTI Route Point Configuration Settings, page 56-7](#)
- [Computer Telephony Integration, Cisco Unified CallManager System Guide](#)

## Deleting a CTI Route Point

To delete a CTI route point, perform the following procedure.

### Before You Begin

Because you can delete a CTI route point that is assigned to one or more directory numbers, you should determine which directory numbers are using the CTI route point by clicking the **Dependency Records** link from the CTI Route Point Configuration window. If the dependency records are not enabled for the system, the dependency records summary window displays a message. For more information about dependency records, see the [“Accessing Dependency Records” section on page A-3](#). If you try to delete a CTI route point that is in use, Cisco Unified CallManager displays a message.

If you delete a CTI Route Point that has a directory number assigned to it, you can find the directory number by using the Route Plan Report. You can also delete the directory number by using the Route Plan Report.

### Procedure

---

- Step 1** Choose **Device > CTI Route Point**.
- The Find/List CTI Route Points window displays.
- Step 2** Specify the search criteria that are needed to locate the CTI route point that you want to delete.
- Step 3** Click **Find**.
- The window refreshes to display a list of the CTI route points that match the specified search criteria.
- Step 4** Perform one of the following actions:
- Check the check boxes next to the CTI route points that you want to delete and click **Delete Selected**.
  - Delete all the CTI route points in the window by checking the check box in the matching records title bar and clicking **Delete Selected**.
  - Choose the name of the CTI route point that you want to delete from the list to display its current settings and click **Delete**.
- Step 5** To permanently delete the CTI route point, click **OK**.
-

### Related Topics

- [CTI Route Point Configuration, page 56-1](#)
- [Adding a CTI Route Point, page 56-2](#)
- [Modifying a CTI Route Point, page 56-2](#)
- [Finding CTI Route Points, page 56-5](#)
- [Resetting a CTI Route Point, page 56-6](#)
- [CTI Route Point Configuration Settings, page 56-7](#)
- [Computer Telephony Integration, Cisco Unified CallManager System Guide](#)

## Finding CTI Route Points

To find and list CTI route points, perform the following procedure.

### Procedure

- 
- Step 1** Choose **Device > CTI Route Point**.
- The Find and List Route Points window displays.
- Step 2** Choose the search criteria to use. To list all items, do not enter any search text or use “Device Name is not empty” as the search criterion.
- Step 3** Click **Find**.
- The window refreshes to display a list of the CTI route points that match the specified search criteria.
- Step 4** To view the next set of CTI route points, click **Next**.



### Note

You can delete or reset multiple CTI route points from the Find and List Route Points window by checking the check boxes next to the appropriate CTI route points and clicking **Delete Selected** to delete the CTI route points or clicking **Reset Selected** to reset the CTI route points. You can choose all CTI route points in the window by checking the check box in the matching records title bar.

---

**Related Topics**

- [CTI Route Point Configuration, page 56-1](#)
- [Adding a CTI Route Point, page 56-2](#)
- [Modifying a CTI Route Point, page 56-2](#)
- [Deleting a CTI Route Point, page 56-3](#)
- [Resetting a CTI Route Point, page 56-6](#)
- [CTI Route Point Configuration Settings, page 56-7](#)
- [Computer Telephony Integration, Cisco Unified CallManager System Guide](#)

## Resetting a CTI Route Point

To reset a CTI route point, perform the following procedure.

**Procedure**

**Step 1** Choose **Device > CTI Route Point**.

The Find and List CTI Route Points window displays.





**Step 2** Choose the search criteria to use.

**Step 3** Click **Find**.

The window displays a list of CTI route points that match the search criteria as illustrated in [Figure 56-1](#).

*Figure 56-1 Find and List CTI Route Points Configuration Window*

Matching record(s) 1 to 2 of 2  
Real-time Information Service returned information for 2 of 2 devices listed below.

<input type="checkbox"/>	Device Name	Description	Device Pool	Status	IP Address	Copy
<input type="checkbox"/>	 AutoAttendant	AutoAttendant Route Point	cm231	DLS2-CM166-CM3	172.28.235.133	
<input type="checkbox"/>	 TAPSRoutePoint	TAPSRoutePoint	Default	DLS2-CM166-CM1	172.28.235.131	

Delete Selected    Reset Selected    First Previous Next Last    Page 1 of 1

56947

- Step 4** Check the check boxes next to the CTI route points that you want to reset. To choose all CTI route points in the window, check the check box in the matching records title bar.
- Step 5** Click **Reset Selected**.  
The Reset Device dialog displays.
- Step 6** Click one of the following buttons:
- **Restart**—Restarts a device without shutting it down.
  - **Reset**—Shuts down a device and brings it back up.
  - **Close**—Closes the Reset Device dialog without performing any action.
- 

#### Related Topics

- [CTI Route Point Configuration, page 56-1](#)
- [Adding a CTI Route Point, page 56-2](#)
- [Modifying a CTI Route Point, page 56-2](#)
- [Deleting a CTI Route Point, page 56-3](#)
- [Finding CTI Route Points, page 56-5](#)
- [CTI Route Point Configuration Settings, page 56-7](#)
- [Computer Telephony Integration, Cisco Unified CallManager System Guide](#)

## CTI Route Point Configuration Settings

[Table 56-1](#) describes the CTI route point configuration settings.

*Table 56-1 CTI Route Point Configuration Settings*

Field	Description
Device Name	Enter unique identifier for this device, from 1 to 15 characters, including alphanumeric, dot, dash, or underscores.
Description	Enter a descriptive name for the CTI route point.

Table 56-1 CTI Route Point Configuration Settings (continued)

Field	Description
Device Pool	Choose the name of a Device Pool. The device pool specifies the collection of properties for this device including CallManager Group, Date/Time Group, Region, and Calling Search Space for auto-registration.
Common Profile	Choose the common profile to assign to this device. The common profile includes the attributes (services or features) that are associated with a particular user.  To see the common profile settings, click the <b>View Details</b> link.
Calling Search Space	From the drop-down list box, choose a calling search space. The calling search space specifies the collection of partitions that are searched to determine how a collected (originating) number should be routed.  You can configure the number of calling search spaces that display in this drop-down list box by using the Max List Box Items enterprise parameter. If more calling search spaces exist than the Max List Box Items enterprise parameter specifies, the ellipsis button (...) displays next to the drop-down list box. Click the ... button to display the Select Calling Search Space window. Enter a partial calling search space name in the <b>List items where Name contains</b> field. Click the desired calling search space name in the list of calling search spaces that displays in the <b>Select item to use</b> box and click <b>OK</b> .  <b>Note</b> To set the maximum list box items, choose <b>System &gt; Enterprise Parameters</b> and choose <b>CCMAdmin Parameters</b> .
Location	Choose the appropriate location for this route point. The location specifies the total bandwidth that is available for calls to and from this location. A location setting of <i>None</i> means that the locations feature does not keep track of the bandwidth that this route point consumes.

**Table 56-1 CTI Route Point Configuration Settings (continued)**

Field	Description
Media Resource Group List	<p>Choose the appropriate Media Resource Group List. A Media Resource Group List comprises a prioritized grouping of media resource groups. An application chooses the required media resource, such as a Music On Hold server, from the available media resources according to the priority order that is defined in a Media Resource Group List.</p> <p>If you choose &lt;none&gt;, Cisco Unified CallManager uses the Media Resource Group that is defined in the device pool.</p> <p>For more information, see the “<a href="#">Media Resource Management</a>” section in the <i>Cisco Unified CallManager System Guide</i>.</p>
User Hold Audio Source	<p>To specify the audio source that plays when an application initiates a hold action, click the drop-down arrow and choose an audio source from the list that displays.</p> <p>If you do not choose an audio source, Cisco Unified CallManager uses the audio source that is defined in the device pool or the system default if the device pool does not specify an audio source ID.</p> <p>You define audio sources in the Music On Hold Audio Source Configuration window. For access, choose <b>Service &gt; Music On Hold</b>.</p>

**Table 56-1 CTI Route Point Configuration Settings (continued)**

Field	Description
Network Hold Audio Source	<p>To specify the audio source that is played when the network initiates a hold action, click the drop-down arrow and choose an audio source from the list that displays.</p> <p>If you do not choose an audio source, Cisco Unified CallManager uses the audio source that is defined in the device pool or the system default if the device pool does not specify an audio source ID.</p> <p>You define audio sources in the Music On Hold Audio Source Configuration window. For access, choose <b>Service &gt; Music On Hold</b>.</p>

**Related Topics**

- [CTI Route Point Configuration, page 56-1](#)
- [Adding a CTI Route Point, page 56-2](#)
- [Modifying a CTI Route Point, page 56-2](#)
- [Deleting a CTI Route Point, page 56-3](#)
- [Finding CTI Route Points, page 56-5](#)
- [Resetting a CTI Route Point, page 56-6](#)
- [Computer Telephony Integration, Cisco Unified CallManager System Guide](#)