



Command Line Interface Reference Guide for Cisco Unified Communications Solutions Release 7.0(1)

This document describes the Command Line Interface (CLI) commands that are available for the Cisco Unified Operating System.

Contents

This document comprises the following sections:

- [Starting a CLI Session, page 2](#)
- [CLI Basics, page 2](#)
- [Delete Commands, page 5](#)
- [File Commands, page 9](#)
- [Run Commands, page 18](#)
- [Set Commands, page 20](#)
- [Show Commands, page 35](#)
- [Unset Commands, page 82](#)
- [Utils Commands, page 83](#)
- [Related Documentation, page 110](#)
- [Obtaining Documentation, Obtaining Support, and Security Guidelines, page 110](#)



Starting a CLI Session

You can access the Cisco Unified Operating System CLI remotely or locally:

- From a web client workstation, such as the workstation that you use for Cisco Unified Operating System Administration, you can use SSH to connect securely to the Cisco Unified Operating System.
- You can access the Cisco Unified Operating System CLI directly by using the monitor and keyboard that you used during installation or by using a terminal server that is connected to the serial port. Use this method if a problem exists with the IP address.

Before You Begin

Ensure you have the following information that gets defined during installation:

- A primary IP address and hostname
- An administrator ID
- A password

You will need this information to log in to the Cisco IPT Platform.

Perform the following steps to start a CLI session:

Step 1

Do one of the following actions depending on your method of access:

- From a remote system, use SSH to connect securely to the Cisco IPT Platform. In your SSH client, enter

```
ssh adminname@hostname
```

where *adminname* specifies the Administrator ID and *hostname* specifies the hostname that was defined during installation.

For example, **ssh admin@ipt-1**.

- From a direct connection, you receive this prompt automatically:

```
ipt-1 login:
```

where **ipt-1** represents the host name of the system.

Enter your administrator ID.

In either case, the system prompts you for a password.

Step 2

Enter your password.

The CLI prompt displays. The prompt represents the Administrator ID; for example:

```
admin:
```

CLI Basics

The following section contains basic tips for using the command line interface.

- [Completing Commands, page 3](#)
- [Getting Help on Commands, page 3](#)

- [Ending a CLI Session, page 4](#)

Completing Commands

To complete commands, use **Tab**:

- Enter the start of a command and press **Tab** to complete the command. For example, if you enter **se** and press **Tab**, **set** gets completed.
- Enter a full command name and press **Tab** to display all the commands or subcommands that are available. For example, if you enter **set** and press **Tab**, you see all the **set** subcommands. An ***** identifies the commands that have subcommands.
- If you reach a command, keep pressing **Tab**, and the current command line repeats; this indicates that no additional expansion is available.

Getting Help on Commands

You can get two kinds of help on any command:

- Detailed help that includes a definition of the command and an example of its use
- Short query help that includes only command syntax

Procedure

To get detailed help, at the CLI prompt, enter

help *command*

Where *command* specifies the command name or the command and parameter. See [Example 1-1](#).



Note

If you enter the **help** command without specifying the name of a particular command as the optional parameter, the system provides information about the CLI system.

To query only command syntax, at the CLI prompt, enter

command?

Where *command* represents the command name or the command and parameter. See [Example 1-2](#).



Note

If you enter a **?** after a menu command, such as **set**, it acts like the **Tab** key and lists the commands that are available.

Example 1-1 Detailed Help Example:

```
admin:help file list activelog
activelog help:
This will list active logging files
```

```

options are:
page      - pause output
detail    - show detailed listing
reverse   - reverse sort order
date      - sort by date
size      - sort by size

file-spec can contain '*' as wildcards

Example:
admin:file list activelog platform detail
02 Dec,2004 12:00:59      <dir>   drf
02 Dec,2004 12:00:59      <dir>   log
16 Nov,2004 21:45:43      8,557  enGui.log
27 Oct,2004 11:54:33      47,916 startup.log
dir count = 2, file count = 2

```

Example 1-2 Query Example:

```

admin:file list activelog?
Syntax:
file list activelog file-spec [options]
file-spec  mandatory   file to view
options    optional     page|detail|reverse|[date|size]

```

Ending a CLI Session

At the CLI prompt, enter **quit**. If you are logged in remotely, you get logged off, and the ssh session gets dropped. If you are logged in locally, you get logged off, and the login prompt returns.

The following sections list and describe the CLI commands that are available for the Cisco Unified Operating System.

Conventions

This document uses the following conventions:

Convention	Description
boldface font	Commands and keywords are in boldface .
<i>italic font</i>	Arguments for which you supply values are in <i>italics</i> .
[]	Elements in square brackets are optional.
{ x y z }	Alternative keywords are grouped in braces and separated by vertical bars.
[x y z]	Optional alternative keywords are grouped in brackets and separated by vertical bars.
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.
screen font	Terminal sessions and information the system displays are in <code>screen font</code> .
boldface screen font	Information you must enter is in boldface screen font .
<i>italic screen font</i>	Arguments for which you supply values are in <i>italic screen font</i> .

Convention	Description
	This pointer highlights an important line of text in an example.
^	The symbol ^ represents the key labeled Control—for example, the key combination ^D in a screen display means hold down the Control key while you press the D key.
< >	Nonprinting characters, such as passwords, are in angle brackets.

Notes use the following conventions:



Note

Means *reader take note*. Notes contain helpful suggestions or references to material not covered in the publication.

Timesavers use the following conventions:



Timesaver

Means *the described action saves time*. You can save time by performing the action described in the paragraph.

Tips use the following conventions:



Tip

Means *the information contains useful tips*.

Cautions use the following conventions:



Caution

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

Warnings use the following conventions:



Warning

This warning symbol means danger. You are in a situation that could cause bodily injury. Before you work on any equipment, you must be aware of the hazards involved with electrical circuitry and familiar with standard practices for preventing accidents.

Delete Commands

This section contains descriptions of the following commands:

- [delete account 6](#)
- [delete cuc futuredelivery \(Cisco Unity Connection Only\) 6](#)
- [delete cuc locale \(Cisco Unity Connection Only\) 6](#)
- [delete dns 7](#)
- [delete ipsec 7](#)
- [delete process 8](#)

- [delete smtp 8](#)

delete account

This command allows you to delete an administrator account.

Command Syntax

delete account *account-name*

Parameters

- *account-name* represents the name of an administrator account.

Requirements

Command privilege level: 4

Allowed during upgrade: No

delete cuc futuredelivery (Cisco Unity Connection Only)

This command deletes all messages that have been marked for future delivery.

Command Syntax

delete cuc futuredelivery

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
delete cuc futuredelivery
```

```
Deleting File : UmssMtaFutureDelivery/UnityMbxDb1/5C56C086-E64B-11DC-9BAF-41FC55D89593.eml
Deleting File : UmssMtaFutureDelivery/UnityMbxDb1/6D7DD796-E64B-11DC-A0E6-D1FD55D89593.eml
Files : Found = 2, Deleted = 2
```

Note: Files that are in use cannot be deleted

delete cuc locale (Cisco Unity Connection Only)

This command deletes the specified locale and all of the associated files and settings from Connection.

Command Syntax

delete cuc locale *locale-id*

Parameters

- *locale-id* represents the ID of the locale that you want to delete.

For a list of installed locales and their IDs, run the [show cuc locales \(Cisco Unity Connection Only\)](#) command. Be aware that locale IDs are case sensitive.

Usage Guidelines

Before you run this command, you must stop the Connection Conversation Manager and Connection Mixer services. After you run this command, you must restart the Connection Conversation Manager and Connection Mixer services.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

The following example deletes the en-GB locale and all of the associated files and settings.

```
delete cuc locale en-GB

en-GB uninstalled
```

delete dns

This command allows you to delete the IP address for a DNS server.

Command Syntax

```
delete dns ip-address
```

Parameters

- ip-address* represents the IP address of the DNS server that you want to delete.

Usage Guidelines

The system asks whether you want to continue to execute this command.



Caution

If you continue, this command causes a temporary loss of network connectivity.

Requirements

Command privilege level: 1

Allowed during upgrade: No

delete ipsec

This command allows you to delete IPSec policies and associations.

Command Syntax

```
delete ipsec
```

```
policy { ALL | policy-name }
```

```
association policy name { ALL | association-name }
```

Parameters

- *policy-name* represents an IPSec policy.
- *association-name* represents an IPSec association.

Requirements

Command privilege level: 1

Allowed during upgrade: No

delete process

This command allows you to delete a particular process.

Command Syntax

delete process *process-id* [**force** | **terminate** | **crash**]

Parameters

- *process-id* represents the process ID number.

Options

- **force**—Tells the process to stop.
- **terminate**—Tells the operating system to terminate the process.
- **crash**—Crashes the process and produces a crash dump.

Usage Guidelines**Note**

Use the **force** option only if the command alone does not delete the process and use the **terminate** option only if **force** does not delete the process.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

delete smtp

This command allows you to delete the SMTP host.

Command Syntax

delete smtp

Requirements

Command privilege level: 1

Allowed during upgrade: No

File Commands

This section contains descriptions of the following commands:

- [file check 9](#)
- [file delete 10](#)
- [file dump 11](#)
- [file fragmentation sdi 12](#)
- [file fragmentation sdl 12](#)
- [file get 13](#)
- [file list 14](#)
- [file search 15](#)
- [file tail 16](#)
- [file view 17](#)

file check

This command checks the /usr directory tree to see whether any files or directories have been added, removed, or changed in size since the last fresh installation or upgrade and displays the results.

Command Syntax

file check [*detection-size-kb*]

Options

detection-size-kb specifies the minimum file size change that is required for the command to display the file as changed.

Usage Guidelines

The command notifies you about a possible impact to system performance and asks you whether you want to continue.



Caution

Because running this command can affect system performance, Cisco recommends that you run the command during off-peak hours.

The display includes both deleted and new files.

Defaults

The default value of *detection-size-kb* specifies 100 KB.

Requirements

Command privilege level: 0

Allowed during upgrade: No

file delete

This command deletes one or more files.

Command Syntax

file delete

activelog *directory/filename* [**detail**] [**noconfirm**]

dir tftp *directory* [**detail**]

inactivelog *directory/filename* [**detail**] [**noconfirm**]

install *directory/filename* [**detail**] [**noconfirm**]

license *filename* [**detail**]

tftp *directory/filename* [**detail**]

Parameters

- **activelog** specifies a log on the active side.
- **dir tftp** *directory* deletes the TFTP directory that is specified by *directory*. You cannot enter the wildcard character (*) in *directory*.
- **inactivelog** specifies a log on the inactive side.
- **install** specifies an installation log.
- **license** *filename* deletes the license file that is specified by *license*. You can enter the wildcard character (*) as *filename* to delete all the license files.
- **tftp** specifies a TFTP file.
- *directory/filename* specifies the path and filename of the file(s) to delete. You can use the wildcard character, *, for *filename*.

Options

- **detail**—Displays a listing of deleted files with the date and time.
- **noconfirm**—Deletes files without asking you to confirm each deletion.

Usage Guidelines



Caution

You cannot recover a deleted file except, possibly, by using the Disaster Recovery System.

You get prompted for confirmation after entering the command. You cannot delete directories or files that are in use.

If you delete a TFTP data file on the inactive side, you may need to manually restore that file if you switch versions to the inactive side.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

The following example deletes the install log.

```
file delete install install.log
```

file dump

This command dumps the contents of a file to the screen, a page at a time.

Command Syntax

file dump

```
activelog directory/filename [detail] [hex]
inactivelog directory/filename [detail] [hex]
install directory/filename [detail] [hex]
sftpdetails filename [hex] [regexp expression] [recent]
tftp directory/filename [detail] [hex]
```

Parameters

- **activelog** specifies a log on the active side.
- **inactivelog** specifies a log on the inactive side.
- **install** specifies an installation log.
- **sftpdetails** specifies SFTP-related files.
- **tftp** specifies a TFTP file.
- *directory/filename* specifies the path and filename of the file to dump. You can use the wildcard character, *, for *filename* as long as it resolves to one file.
- *filename* specifies the filename of the file to dump.

Options

- **detail**—Displays listing with the date and time
- **hex**—Displays output in hexadecimal
- **regexp** *expression*—Displays only the lines in the file that match the regular expression *expression*.
- **recent**—Displays the most recently modified file in the directory.

Usage Guidelines

To determine which files you can dump with the **sftpdetails** parameter, first enter the following command:

```
file list sftpdetails *
```

The output lists the filenames that you can dump.

Requirements

Command privilege level: 1 for logs, 0 for TFTP files

Allowed during upgrade: Yes

Example

This command dumps contents of file `_cdrIndex.idx`.

```
file dump activelog cm/cdr/_cdrIndex.idx
```

file fragmentation sdi

This command displays file fragmentation information about SDI log files.

Command Syntax

file fragmentation sdi

all *outfile*
file *filename* {**verbose**}
most fragmented *number*
most recent *number*

Parameters

- **all** records information about all files in the directory in the file that is specified by *outfile*.
- **file** displays information about the file that is specified by *filename*.
- **most fragmented** displays information about the most fragmented files.
- **most recent** displays information about the most recently logged fragmented file.
- *number* specifies the number of files to list.

Options

- **verbose**—Displays more detailed information.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

file fragmentation sdl

This command displays file fragmentation information about SDL log files.

Command Syntax

file fragmentation sdl

all *outfile*
file *filename* {**verbose**}
most fragmented *number*
most recent *number*

Parameters

- **all** records information about all files in the directory in the file that is specified by *outfile*.
- **file** displays information about the file that is specified by *filename*.
- **most fragmented** displays information about the most fragmented files.

- **most recent** displays information about the most recently logged fragmented file.
- *number* specifies the number of files to list.

Options

- **verbose**—Displays more detailed information

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

file get

This command sends the file to another system by using SFTP.

Command Syntax

file get

```

activelog directory/filename [reltime] [abstime] [match] [recurs]
inactivelog directory/filename [reltime] [abstime] [match] [recurs]
install directory/filename [reltime] [abstime] [match] [recurs]
partBsalog directory/filename [reltime] [abstime] [match] [recurs]
salog directory/filename [reltime] [abstime] [match] [recurs]
tftp directory/filename [reltime] [abstime] [match] [recurs]

```

Parameters

- **activelog** specifies a log on the active side.
- **inactivelog** specifies a log on the inactive side.
- **install** specifies an installation log.
- **partBsalog** specifies the partBsalog log directory.
- **salog** specifies the salog log directory.
- **tftp** specifies a TFTP file.
- *directory/filename* specifies the path to the file(s) to delete. You can use the wildcard character, *, for *filename* as long as it resolves to one file.

Options

- **abstime**—Absolute time period, specified as *hh:mm:MM/DD/YY hh:mm:MM/DD/YY*
- **reltime**—Relative time period, specified as **minutes** | **hours** | **days** | **weeks** | **months** *value*
- **match**—Match a particular string in the filename, specified as *string value*
- **recurs**—Get all files, including subdirectories

Usage Guidelines

After the command identifies the specified files, you get prompted to enter an SFTP host, username, and password.

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Examples

This command gets all files in the activelog operating system directory that match the string “plat”.

```
file get activelog platform match plat
```

This command gets all operating system log files for a particular time period.

```
file get activelog platform/log abstime 18:00:9/27/2005 18:00:9/28/2005
```

file list

This command lists the log files in an available log directory.

Command Syntax**file list**

```
activelog directory [page] [detail] [reverse] [date | size]
inactivelog directory [page] [detail] [reverse] [date | size]
install directory [page] [detail] [reverse] [date | size]
partBsalog directory [page] [detail] [reverse] [date | size]
salog directory [page] [detail] [reverse] [date | size]
tftp directory [page] [detail] [reverse] [date | size]
```

Parameters

- **activelog** specifies a log on the active side.
- **inactivelog** specifies a log on the inactive side.
- **install** specifies an installation log.
- **partBsalog** specifies the partBsalog log directory.
- **salog** specifies the salog log directory.
- **tftp** specifies a TFTP file.
- *directory* specifies the path to the directory to list. You can use a wildcard character, *, for *directory* as long as it resolves to one directory.

Options

- **detail**—Long listing with date and time
- **date**—Sort by date
- **size**—Sort by file size
- **reverse**—Reverse sort direction
- **page**—Displays the output one screen at a time.

Requirements

Command privilege level: 1 for logs, 0 for TFTP files

Allowed during upgrade: Yes

Examples

This example lists operating system log files with details.

```
file list activelog platform/log page detail
```

This example lists directories in CDR repository.

```
file list activelog cm/cdr_repository
```

This example lists CDR files in a specified directory by size.

```
file list activelog cm/cdr_repository/processed/20050812 size
```

file search

This command searches the content of a log and displays the matching lines a page at a time.

Command Syntax**file search**

```
activelog directory/filename reg-exp [abstime hh:mm:ss mm/dd/yyyy hh:mm:ss mm/dd/yyyy]  
[ignorecase] [retime {days | hours | minutes} timevalue]
```

```
inactivelog directory/filename reg-exp [abstime hh:mm:ss mm/dd/yyyy hh:mm:ss mm/dd/yyyy]  
[ignorecase] [retime {days | hours | minutes} timevalue]
```

```
install directory/filename reg-exp [abstime hh:mm:ss mm/dd/yyyy hh:mm:ss mm/dd/yyyy]  
[ignorecase] [retime {days | hours | minutes} timevalue]
```

```
tftp directory/filename reg-exp [abstime hh:mm:ss mm/dd/yyyy hh:mm:ss mm/dd/yyyy]  
[ignorecase] [retime {days | hours | minutes} timevalue]
```

Parameters

- **activelog** specifies a log on the active side.
- **inactivelog** specifies a log on the inactive side.
- **install** specifies an installation log.
- **tftp** specifies a TFTP file.
- *reg-exp* represents a regular expression.
- *directory/filename* represents the path to the file(s) to search. You can use the wildcard character, *, to represent all or part of the filename.

Options

- **abstime**—Specifies which files to search based on file creation time. Enter a start time and an end time.
- **days|hours|minutes**—Specifies whether the file age is in days, hours, or minutes.
- **ignorecase**—Ignores case when searching.
- **retime**—Specifies which files to search based on file creation time. Enter the age of files to search.

- *hh:mm:ss mm/dd/yyyy*—An absolute time, in the format hours:minutes:seconds month/day/year.
- *timevalue*—The age of files to search. Specify the unit of this value with the {**days** | **hours** | **minutes**} option.

Usage Guidelines

Write the search term in the form of a regular expression, which is a special text string for describing a search pattern.

If the search term is found in only one file, the filename appears at the top of the output. If the search term is found in multiple files, each line of the output begins with the filename in which the matching line was found.

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Example

```
file search activelog platform/log/platform.log Err[a-z] ignorecase
```

file tail

This command tails (prints the last few lines) of a log file.

Command Syntax

file tail

```
activelog directory/filename [detail] [hex] [lines]
```

```
inactivelog directory/filename [detail] [hex] [lines]
```

```
install directory/filename [detail] [hex] [lines]
```

```
tftp directory/filename [detail] [hex] [lines]
```

Parameters

- **activelog** specifies a log on the active side.
- **inactivelog** specifies a log on the inactive side.
- **install** specifies an installation log.
- **tftp** specifies a TFTP file.
- *directory/filename* specifies the path to the file to tail. You can use the wildcard character, *, for filename as long as it resolves to one file.

Options

- **detail**—Long listing with date and time
- **hex**—Hexadecimal listing
- **lines**—Number of lines to display

Requirements

Command privilege level: 1 for logs, 0 for TFTP files

Allowed during upgrade: Yes

Example

This example tails the operating system CLI log file.

```
file tail activelog platform/log/cli00001.log
```

file view

This command displays the contents of a file.

Command Syntax

file view

```
activelog directory/filename
inactivelog directory/filename
install directory/filename
system-management-log
tftp directory/filename
```

Parameters

- **activelog** specifies a log on the active side.
- **inactivelog** specifies a log on the inactive side.
- **install** specifies an installation log.
- **system-management-log** displays the contents of the Integrated Management Logs (IML).
- **tftp** specifies a TFTP file.
- *directory/filename* specifies the path to the file to view. You can use the wildcard character, *, for *filename* as long as it resolves to one file.

Usage Guidelines



Caution

Do not use this command to view binary files because this can corrupt the terminal session.

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Examples

This example displays the install log.

```
file view install install.log
```

This example displays a particular CDR file.

```
file view activelog /cm/cdr_repository/processed/20058012/{filename}
```

Run Commands

This section contains descriptions of the following commands:

- [run cuc dbquery \(Cisco Unity Connection Only\) 18](#)
- [run cuc sysagent task \(Cisco Unity Connection Only\) 19](#)
- [run cuc vui rebuild \(Cisco Unity Connection Only\) 19](#)
- [run loadxml 19](#)
- [run sql 20](#)

run cuc dbquery (Cisco Unity Connection Only)

This command runs an SQL query and displays the results.

Command Syntax

```
run cuc dbquery database_name sql_statement [page]
```

Parameters

- *database_name* specifies the database that *sql_statement* operates on. Be aware that database names are case sensitive. Connection databases include
 - **unitydirdb**—contains the directory and configuration data.
 - **unitydyndb**—contains dynamic data that Connection uses internally.
 - **unitymbxdb1**—contains the data about the current voice messages, including pointers to the audio files that are stored in the file system.
 - **unityrptdb**—contains audit log data.
- *sql_statement* specifies the SQL query that you want to run.

Option

- **page**—Causes the output to display one page at a time. Be aware that **page** is case sensitive.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

The following example runs the SQL query **select alias from vw_usertemplate** on the **unitydirdb** database.

```
run cuc dbquery unitydirdb select alias from vw_usertemplate
```

```
AdministratorTemplate
VoiceMailUserTemplate
```

run cuc sysagent task (Cisco Unity Connection Only)

This command runs a Sysagent task.

Command Syntax

```
run cuc sysagent task task_name
```

Parameters

- task_name* specifies the name of the sysagent task that you want to run.

For a list of Sysagent tasks, run the command [show cuc sysagent task list \(Cisco Unity Connection Only\)](#). Be aware that sysagent task names are case sensitive.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

The following example runs the Sysagent task **CleanDeletedMessagesTask**.

```
run cuc sysagent task CleanDeletedMessagesTask  
  
CleanDeletedMessagesTask started
```

run cuc vui rebuild (Cisco Unity Connection Only)

This command instructs the voice recognition transport utility to immediately rebuild the voice recognition name grammars with any pending changes.

Command Syntax

```
run cuc vui rebuild
```

Usage Guidelines

Running this command will only rebuild grammars that have changes flagged in the database. This command ignores any name grammar update blackout schedules and will execute immediately. Due to the overhead of retrieving potentially large amounts of name-related data from the database, you should use this command sparingly and only when absolutely necessary.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

run loadxml

Run this command as a workaround when service parameters or product-specific information does not appear in the administration window as expected.

You may need to restart of some services after this command.

Command Syntax

```
run loadxml
```

Requirements

Command privilege level: 1

Allowed during upgrade: No

run sql

This command allows you to run an SQL command.

Command Syntax

```
run sql sql_statement
```

Parameters

- *sql_statement* represents the SQL command to run.

Requirements

Command privilege level: 1

Allowed during upgrade: No

Example

This example runs an SQL command.

```
run sql select name from device
```

Set Commands

This section contains descriptions of the following commands:

- [set account 21](#)
- [set commandcount 21](#)
- [set cli pagination 22](#)
- [set cuc trace \(Cisco Unity Connection Only\) 22](#)
- [set ipsec 23](#)
- [set logging 23](#)
- [set network dhcp 23](#)
- [set network dns 24](#)
- [set network dns options 25](#)
- [set network domain 25](#)
- [set network failover 26](#)
- [set network gateway 26](#)
- [set network hostname 26](#)

- [set network ip 27](#)
- [set network mtu 28](#)
- [set network max_ip_contrack 28](#)
- [set network nic 29](#)
- [set network pmtud 29](#)
- [set network restore 30](#)
- [set network status 30](#)
- [set password 31](#)
- [set smtp 32](#)
- [set timezone 32](#)
- [set trace 33](#)
- [set web-security 33](#)
- [set workingdir 34](#)

set account

This command sets up a new account on the operating system.

Command Syntax

set account *name*

Parameters

- *name* represents the username for the new account.

Usage Guidelines

After you enter the username, the system prompts you to enter the privilege level and password for the new account.

Requirements

Command privilege level: 0

Allowed during upgrade: No

set commandcount

This command changes the CLI command prompt, so it displays how many CLI commands have executed.

Command Syntax

set commandcount {enable | disable}

Parameters

- *unit-name* represents the name of the certificate that you want to regenerate.

Requirements

Command privilege level: 1

Allowed during upgrade: No

set cli pagination

For the current CLI session, this command turns automatic pagination **On** or **Off**.

Command Syntax

```
set cli pagination {on | off}
```

Parameters

- **on** turns pagination On.
- **off** turns pagination Off.

Requirements

Level privilege: 1

Command privilege: 1

Allowed during upgrade: No

Example

```
admin:set cli pagination off
Automatic pagination is turned off
```

set cuc trace (Cisco Unity Connection Only)

This command enables or disables the specified traces and trace levels.

Command Syntax

```
set cuc trace {enable | disable} trace_name level
```

Parameters

- **enable** enables Connection traces. Be aware that **enable** is case sensitive.
- **disable** disables Connection traces. Be aware that **disable** is case sensitive.
- *trace_name* specifies the name of the trace to enable or disable. Be aware that trace names are case sensitive.
- *level* specifies the level(s) of *trace_name* that you want to enable or disable. Each trace comprises up to 31 levels, numbered 0 to 30; each level provides a different type of information for the specified trace. When you are enabling or disabling multiple levels, use a comma to separate levels and a hyphen to indicate a range of levels. Do not include spaces.

Usage Guidelines

To display a list of the traces and trace levels that are currently enabled, use the [show cuc trace levels \(Cisco Unity Connection Only\)](#) command.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

The following example enables VUI traces 1, 13, and 17 through 20.

```
set cuc trace enable VUI 1,13,17-20
```

VUI trace levels are now set to: 1,13,17-20

The following example disables vui traces 17 through 20. VUI trace levels 1 and 13 are still set.

```
set cuc trace disable VUI 17-20
```

VUI trace levels are now set to: 1,13

set ipsec

This command allows you to set IPSec policies and associations.

Command Syntax**set ipsec**

policy {**ALL** | *policy-name*}

association *policy-name* {**ALL** | *association-name*}

Parameters

- *policy-name* represents an IPSec policy.
- *association-name* represents an IPSec association.

Requirements

Command privilege level: 1

Allowed during upgrade: No

set logging

This command allows you to enable or disable CLI Admin logs.

Command Syntax

set logging {**enable** | **disable**}

Requirements

Command privilege level: 0

Allowed during upgrade: No

set network dhcp

This command enables or disables DHCP for Ethernet interface 0. You cannot configure Ethernet interface 1.

Command Syntax

set network dhcp eth0

enable

disable *node_ip net_mask gateway_ip*

Parameters

- **eth0** specifies Ethernet interface 0.
- **enable** enables DHCP.
- **disable** disables DHCP.
- *node_ip* represents the new static IP address for the server.
- *net_mask* represents the subnet mask for the server.
- *gateway_ip* represents the IP address of the default gateway.

Usage Guidelines

The system asks whether you want to continue to execute this command.



Caution

If you continue, this command causes the system to restart. Cisco also recommends that you restart all nodes whenever any IP address gets changed.

Requirements

Command privilege level: 1

Allowed during upgrade: No

set network dns

This command sets the IP address for the primary or secondary DNS server.

Command Syntax

set network dns {primary | secondary} ip-address

Parameters

- *ip-address* represents the IP address of the primary or secondary DNS server.

Usage Guidelines

The system asks whether you want to continue to execute this command.



Note

If you change the IP address for the primary DNS server, you must also restart the Cisco Tomcat service. For more information, see the [utils service](#) command.

**Caution**

If you continue, this command causes a temporary loss of network connectivity. If you change the IP address of the DNS server, you must restart Cisco Tomcat and Cluster Manager. For more information, see [utils service, page 107](#).

Requirements

Command privilege level: 1

Allowed during upgrade: No

set network dns options

This command sets DNS options.

Command Syntax

set network dns options [*timeout seconds*] [*attempts number*] [**rotate**]

Parameters

- **timeout** sets the DNS request timeout.
- **attempts** sets the number of times to attempt a DNS request before quitting.
- **rotate** causes the system to rotate among the configured DNS servers, distributing the load.
- *seconds* specifies the DNS timeout period, in seconds.
- *number* specifies the number of attempts.

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

set network domain

This command sets the domain name for the system.

Command Syntax

set network domain *domain-name*

Parameters

- *domain-name* represents the system domain that you want to assign.

Usage Guidelines

The system asks whether you want to continue to execute this command.

**Caution**

If you continue, this command causes a temporary loss of network connectivity.

Requirements

Command privilege level: 1

Allowed during upgrade: No

set network failover

This command enables and disables Network Fault Tolerance on the Media Convergence Server network interface card.

Command Syntax

failover {enable | disable}

Parameters

- **enable** enables Network Fault Tolerance.
- **disable** disables Network Fault Tolerance.

Requirements

Command privilege level: 1

Allowed during upgrade: No

set network gateway

This command enables you to configure the IP address of the network gateway.

Command Syntax

set network gateway *ip-address*

Parameters

- *ip-address* represents the IP address of the network gateway that you want to assign.

Usage Guidelines

The system asks whether you want to continue to execute this command.



Caution

If you continue, this command causes the system to restart.

Requirements

Command privilege level: 1

Allowed during upgrade: No

set network hostname (Cisco Unified Communications Manager Only)



Note

For information on changing the host name of a Cisco Unity Connection server, see the “Renaming Cisco Unity Connection Servers” chapter in the applicable *Reconfiguration and Upgrade Guide for Cisco Unity Connection* at http://www.cisco.com/en/US/products/ps6509/prod_installation_guides_list.html.

This command sets the network host name and then causes a restart of the system.

Command Syntax

set network hostname *hostname*

Parameters

- *hostname* represents the new network hostname of the system.



Note

The host name must follow the rules for ARPANET host names. It must start with an alphabetic character, end with an alphanumeric character, and consist of alphanumeric characters and hyphens. The host name can have a maximum length of 63 characters.

Usage Guidelines

The system asks whether you want to continue to execute this command.



Caution

If you continue, this command causes the system to restart.

Requirements

Level privilege: 1

Command privilege: 1

Allowed during upgrade: No

Example

```
admin:set network hostname myname
```

```
*** WARNING ***
```

```
This will cause the system to restart - Do you want to continue ?
Enter "yes" to continue and restart or any other key to abort
yes
executing...
Broadcast message from root (Thu Jun 24 13:00:21 2008):
```

```
The system is going down for restart NOW!
```

set network ip

This command sets the IP address for Ethernet interface 0. You cannot configure Ethernet interface 1.

Command Syntax

set network ip eth0 *ip-address ip-mask*

Parameters

- **eth0** specifies Ethernet interface 0.
- *ip-address* represents the IP address that you want to assign.
- *ip-mask* represents the IP mask that you want to assign.

Usage Guidelines

The system asks whether you want to continue to execute this command.

**Caution**

If you continue, this command causes the system to restart.

Requirements

Command privilege level: 1

Allowed during upgrade: No

set network mtu

This command sets the maximum MTU value.

Command Syntax

set network mtu *mtu_max*

Parameters

- *mtu_max* specifies the maximum MTU value.

**Note**

The system default MTU value equals 1500.

Usage Guidelines

The system asks whether you want to continue to execute this command.

**Caution**

If you continue, the system will temporarily lose network connectivity.

Requirements

Level privilege: 1

Command privilege: 1

Allowed during upgrade: No

Example

```
admin:set network mtu 576
***  W A R N I N G  ***
This will cause the system to temporarily lose network connectivity

Do you want to continue ?

Enter "yes" to continue or any other key to abort

yes
executing...
```

set network max_ip_contrack

This command sets the `ip_contrack_max` value.

Command Syntax

```
set network max_ip_contrack ip_contrack_max
```

Parameters

- `ip_contrack_max` specifies the value for `ip_contrack_max`.

set network nic

This command sets the properties of the Ethernet Interface 0. You cannot configure Ethernet interface 1.

Command Syntax

```
set network nic eth0 [auto en | dis] [speed 10 | 100] [duplex half | full]
```

Parameters

- `eth0` specifies Ethernet interface 0.
- `auto` specifies whether auto negotiation gets enabled or disabled.
- `speed` specifies whether the speed of the Ethernet connection: 10 or 100 Mb/s.
- `duplex` specifies half-duplex or full-duplex.

Usage Guidelines

The system asks whether you want to continue to execute this command.



Note

You can enable only one active NIC at a time.



Caution

If you continue, this command causes a temporary loss of network connections while the NIC gets reset.

Requirements

Command privilege level: 1

Allowed during upgrade: No

set network pmtud

This command enables and disables Path MTU Discovery.

Command Syntax

```
set network pmtud [enable | disable]
```

Parameters

- `enable` enables Path MTU Discovery.

- **disable** disables Path MTU Discovery.

Usage Guidelines

The system asks whether you want to continue to execute this command.



Caution

If you continue, the system will temporarily lose network connectivity.

Requirements

Level privilege: 1

Command privilege: 1

Allowed during upgrade: No

Example

```
admin:set network pmtud enable
***  W A R N I N G  ***
This will cause the system to temporarily lose network connectivity

Do you want to continue ?

Enter "yes" to continue or any other key to abort
yes
executing...
admin:
```

set network restore

This command configures the specified Ethernet port to use a specified static IP address.



Caution

Only use this command option if you cannot restore network connectivity by using any other **set network** commands. This command deletes all previous network settings for the specified network interface, including Network Fault Tolerance. After running this command, you must restore your previous network configuration manually.



Caution

The server temporarily loses network connectivity when you run this command.

Command Syntax

```
set network restore eth0 ip-address network-mask gateway
```

Parameters

- **eth0** specifies Ethernet interface 0.
- *ip-address* specifies the IP address.
- *network-mask* specifies the subnet mask.
- *gateway* specifies the IP address of the default gateway.

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

set network status

This command sets the status of Ethernet 0 to up or down. You cannot configure Ethernet interface 1.

Command Syntax

```
set network status eth0 {up | down}
```

Parameters

- **eth0** specifies Ethernet interface 0.

Usage Guidelines

The system asks whether you want to continue to execute this command.

**Caution**

If you continue, the system will temporarily lose network connectivity.

Requirements

Command privilege level: 1

Allowed during upgrade: No

set password

This command allows you to change the administrator and security passwords.

Command Syntax

```
set password {admin | security}
```

Parameters

- **eth0** specifies Ethernet interface 0.

Usage Guidelines

The systems prompts you for the old and new passwords.

**Note**

The password must contain at least six characters, and the system checks it for strength.

Servers in a cluster use the security password to authenticate communication between servers. You must reset the cluster after you change the security password.

Procedure

-
- Step 1** Change the security password on the publisher server (first node) and then reboot the server (node).

Step 2 Change the security password on all the subsequent servers/nodes to the same password that you created on the first node and restart subsequent nodes, including application servers, to propagate the password change.

**Note**

Cisco recommends that you restart each server after the password is changed on that server.

**Caution**

Failure to reboot the servers (nodes) causes system service problems and problems with the Cisco Unified Communications Manager Administration windows on the subscriber servers.

Requirements

Command privilege level: 1

Allowed during upgrade: No

set smtp

This command sets the SMTP server hostname.

Command Syntax

set smtp *hostname*

Parameters

- *hostname* represents the SMTP server name.

Requirements

Command privilege level: 0

Allowed during upgrade: No

set timezone

This command lets you change the system time zone.

Command Syntax

set timezone *timezone*

Parameters

- *timezone* specifies the new time zone.

Usage Guidelines

Enter enough characters to uniquely identify the new time zone. Be aware that the time-zone name is case-sensitive.

**Caution**

You must restart the system after you change the time zone.

Requirements

Command privilege level: 0

Allowed during upgrade: No

Example

This example sets the time zone to Pacific time.

```
set timezone Pac
```

set trace

This command sets trace activity for the specified task.

Command Syntax**set trace**

```

enable Error tname
enable Special tname
enable State_Transition tname
enable Significant tname
enable Entry_exit tname
enable Arbitrary tname
enable Detailed tname
disable tname

```

Parameters

- *tname* represents the task for which you want to enable or disable traces.
- **enable Error** sets task trace settings to the error level.
- **enable Special** sets task trace settings to the special level.
- **enable State_Transition** sets task trace settings to the state transition level.
- **enable Significant** sets task trace settings to the significant level.
- **enable Entry_exit** sets task trace settings to the entry_exit level.
- **enable Arbitrary** sets task trace settings to the arbitrary level.
- **enable Detailed** sets task trace settings to the detailed level.
- **disable** unsets the task trace settings.

Requirements

Command privilege level: 1

Allowed during upgrade: No

set web-security

This command sets the web security certificate information for the operating system.

Command Syntax

set web-security *orgunit orgname locality state country alternate-host-name*

Parameters

- *orgunit* represents the organizational unit.
- *orgname* represents the organizational name.
- *locality* represents the organization location.
- *state* represents the organization state.
- *country* represents the organization country.
- *alternate-host-name* (optional) specifies an alternate name for the host when you generate a web-server (Tomcat) certificate.



Note When you set an alternate-host-name parameter with the **set web-security** command, self-signed certificates for tomcat will contain the Subject Alternate Name extension with the alternate-host-name specified. CSR for Cisco Unified Communications Manager will contain Subject Alternate Name Extension with the alternate host name included in the CSR.

Requirements

Command privilege level: 0

Allowed during upgrade: No

set workingdir

This command sets the working directory for active, inactive, and installation logs.

Command Syntax

set workingdir

activelog *directory*

inactivelog *directory*

install *directory*

tftp *directory*

Parameters

- **activelog** sets the working directory for active logs.
- **inactivelog** set the working directory for inactive logs.
- **install** sets the working directory for installation logs.
- **tftp** sets the working directory for TFTP files.
- *directory* represents the current working directory.

Requirements

Command privilege level: 0 for logs, 1 for TFTP

Allowed during upgrade: Yes

Show Commands

This section contains descriptions of the following commands:

- [show account 37](#)
- [show cert 37](#)
- [show cli pagination 38](#)
- [show ctl 38](#)
- [show cuc cluster status \(Cisco Unity Connection Only\) 38](#)
- [show cuc config groups \(Cisco Unity Connection Only\) 39](#)
- [show cuc config settings \(Cisco Unity Connection Only\) 39](#)
- [show cuc dbconsistency \(Cisco Unity Connection Only\) 40](#)
- [show cuc dbcontents \(Cisco Unity Connection Only\) 41](#)
- [show cuc dbschema \(Cisco Unity Connection Only\) 42](#)
- [show cuc dbserver disk \(Cisco Unity Connection Only\) 43](#)
- [show cuc dbserver session \(Cisco Unity Connection Only\) 43](#)
- [show cuc dbserver sessions all \(Cisco Unity Connection Only\) 44](#)
- [show cuc dbserver sessions list \(Cisco Unity Connection Only\) 45](#)
- [show cuc dbserver user list \(Cisco Unity Connection Only\) 46](#)
- [show cuc dbserver user waiting \(Cisco Unity Connection Only\) 46](#)
- [show cuc dbtable contents \(Cisco Unity Connection Only\) 47](#)
- [show cuc dbtable list \(Cisco Unity Connection Only\) 48](#)
- [show cuc dbtable schema \(Cisco Unity Connection Only\) 48](#)
- [show cuc dbview contents \(Cisco Unity Connection Only\) 49](#)
- [show cuc dbview list \(Cisco Unity Connection Only\) 50](#)
- [show cuc dbview schema \(Cisco Unity Connection Only\) 51](#)
- [show cuc locales \(Cisco Unity Connection Only\) 52](#)
- [show cuc sysagent task list \(Cisco Unity Connection Only\) 52](#)
- [show cuc sysagent task results \(Cisco Unity Connection Only\) 53](#)
- [show cuc tech dbschemaversion \(Cisco Unity Connection Only\) 53](#)
- [show cuc tech dbserver all \(Cisco Unity Connection Only\) 54](#)
- [show cuc tech dbserver integrity \(Cisco Unity Connection Only\) 54](#)
- [show cuc tech dbserver log diagnostic \(Cisco Unity Connection Only\) 55](#)
- [show cuc tech dbserver log message \(Cisco Unity Connection Only\) 55](#)
- [show cuc tech dbserver status \(Cisco Unity Connection Only\) 56](#)

- [show cuc trace levels \(Cisco Unity Connection Only\) 56](#)
- [show cuc version \(Cisco Unity Connection Only\) 57](#)
- [show diskusage 57](#)
- [show environment 58](#)
- [show firewall list 59](#)
- [show hardware 59](#)
- [show ipsec 59](#)
- [show logins 60](#)
- [show memory 60](#)
- [show myself 61](#)
- [show network 61](#)
- [show network ipprefs 62](#)
- [show open 63](#)
- [show packages 63](#)
- [show perf counterhelp 64](#)
- [show perf list categories 64](#)
- [show perf list classes 65](#)
- [show perf list counter 65](#)
- [show perf list instances 65](#)
- [show perf query class 66](#)
- [show perf query counter 66](#)
- [show perf query instance 67](#)
- [show perf query path 67](#)
- [show process 68](#)
- [show registry 69](#)
- [show risdb 69](#)
- [show smtp 70](#)
- [show stats io 70](#)
- [show status 71](#)
- [show tech all 71](#)
- [show tech ccm_service 72](#)
- [show tech database 72](#)
- [show tech dbintegrity 72](#)
- [show tech dbinuse 72](#)
- [show tech dbschema 73](#)
- [show tech dbstateinfo 73](#)
- [show tech devdefaults 73](#)
- [show tech gateway 73](#)

- [show tech locales 74](#)
- [show tech network 74](#)
- [show tech notify 75](#)
- [show tech params all 75](#)
- [show tech params enterprise 75](#)
- [show tech params service 75](#)
- [show tech prefs 76](#)
- [show tech procedures 76](#)
- [show tech routepatterns 76](#)
- [show tech routeplan 76](#)
- [show tech runtime 77](#)
- [show tech systables 77](#)
- [show tech system 78](#)
- [show tech table 78](#)
- [show tech triggers 79](#)
- [show tech version 79](#)
- [show timezone 79](#)
- [show trace 80](#)
- [show ups status 80](#)
- [show version 80](#)
- [show web-security 81](#)
- [show workingdir 81](#)

show account

This command lists current administrator accounts, except the master administrator account.

Command Syntax

show account

Requirements

Command privilege level: 4

Allowed during upgrade: Yes

show cert

This command displays certificate contents and certificate trust lists.

Command Syntax

show cert

```

own filename
trust filename
list { own | trust }

```

Parameters

- *filename* represents the name of the certificate file.
- **own** specifies owned certificates.
- **trust** specifies trusted certificates.
- **list** specifies a certificate trust list.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

This command displays owned certificate trust lists.

```
show cert list own
```

show cli pagination

This command displays the status of automatic CLI pagination.

Command Syntax

```
show cli pagination
```

Parameters

None

Requirements

Level privilege: 0

Command privilege: 0

Allowed during upgrade: Yes

Example

```
admin: show cli pagination
Automatic Pagination : Off.
```

show ctl

This command displays the contents of the Certificate Trust List (CTL) file on the server. It notifies you if the CTL is not valid.

Command Syntax

```
show ctl
```

show cuc cluster status (Cisco Unity Connection Only)

This command shows the status of the servers in the cluster..

Command Syntax

```
show cuc cluster status
```

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
show cuc cluster status
```

Server Name	Member ID	Server State	Internal State	Reason
cuc-server-1	0	Primary	Pri Active	Normal
cuc-server-2	1	Secondary	Sec Active	Normal

show cuc config groups (Cisco Unity Connection Only)

This command displays a list of the valid configuration group names.

Command Syntax

```
show cuc config groups [page]
```

Option

- **page**—Causes the output to display one page at a time. Be aware that **page** is case sensitive.

Usage Guidelines

To see a list of the settings for a specified group, run the command [show cuc config settings \(Cisco Unity Connection Only\)](#).

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
show cuc config groups
```

```
CiscoLicensing
ConfigurationAssistant
Conversations
Directory
Groupware
LogMgr
Messaging
:
:
Telephony
```

show cuc config settings (Cisco Unity Connection Only)

This command displays the settings and values for a specified group of Connection configuration settings.

Command Syntax

```
show cuc config settings group_name [page]
```

Parameter

- *group_name* specifies the name of the configuration group whose settings you want to display. To see a list of valid group names, run the command [show cuc config groups \(Cisco Unity Connection Only\)](#). Be aware that group names are case sensitive.

Option

- **page**—Causes the output to display one page at a time. Be aware that **page** is case sensitive.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

The following example shows the configuration settings for the group SA.

```
show cuc config settings SA

SA Setting          Value
-----
SessionTimeout      20
Use24HrClockFormat  0
```

show cuc dbconsistency (Cisco Unity Connection Only)

This command checks the tables and indexes of a specified database for inconsistencies.

Command Syntax

```
show cuc dbconsistency database_name
```

Parameters

- *database_name* specifies the name of the database that you want to check. Be aware that database names are case sensitive. Connection databases include
 - **unitydirdb**—contains the directory and configuration data.
 - **unitydyndb**—contains dynamic data that Connection uses internally.
 - **unitymbxdb1**—contains the data about the current voice messages, including pointers to the audio files that are stored in the file system.
 - **unityrptdb**—contains audit log data.

Usage Guidelines

When the command completes, the system saves detailed information in a log file and displays a summary of the results, including the location of the log file. Use the **file** commands to display the contents of the file.

**Caution**

Checking database consistency makes a significant impact on system performance. Run this command only when little or no system activity is occurring. After the operation begins, you cannot cancel it. Do not restart the server during the operation; the operation must complete successfully before Connection will function properly.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

The following example checks the consistency of the unityrptdb database.

```
show cuc dbconsistency unityrptdb
```

```
Checking consistency of unityrptdb tables. Please wait.
```

```
Consistency check of unityrptdb tables successful.
```

```
Validation of unityrptdb indexes successful.
```

```
Output is in file: cuc/cli/consistency_unityrptdb_070404-123636.txt
```

show cuc dbcontents (Cisco Unity Connection Only)

This command exports the data from a specified database to a CSV file.

Command Syntax

```
show cuc dbcontents database_name
```

Parameters

- *database_name* specifies the name of the database whose data you want to export to a CSV file. Be aware that database names are case sensitive. Connection databases include
 - **unitydirdb**—contains the directory and configuration data.
 - **unitydyndb**—contains dynamic data that Connection uses internally.
 - **unitymbxdb1**—contains the data about the current voice messages, including pointers to the audio files that are stored in the file system.
 - **unityrptdb**—contains audit log data.

Usage Guidelines

When the command completes, the location of the CSV file displays. Use the **file** commands to display the contents of the file.

**Caution**

Saving the contents of a database to a CSV file affects system performance. Run this command only when little or no system activity is occurring.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

The following example exports the data from the `unitydirdb` database to a CSV file and displays the location of the file.

```
show cuc dbcontents unitydirdb
```

This operation may take a few minutes to complete. Please wait.

Output is in file: `cuc/cli/contents_unitydirdb_070404-124027.csv`

show cuc dbschema (Cisco Unity Connection Only)

This command exports the SQL statements that are necessary to replicate the schema for a specified database to a file.

Command Syntax

```
show cuc dbschema database_name
```

Parameters

- *database_name* specifies the name of the database whose schema you want to export. Be aware that database names are case sensitive. Connection databases include
 - **unitydirdb**—contains the directory and configuration data.
 - **unitydyndb**—contains dynamic data that Connection uses internally.
 - **unitymbxdb1**—contains the data about the current voice messages, including pointers to the audio files that are stored in the file system.
 - **unityrptdb**—contains audit log data.

Usage Guidelines

When the command completes, the location of the file displays. Use the **file** commands to display the file.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

The following example exports the schema of the `unitydirdb` database to a file and displays the location of the file.

```
show cuc dbschema unitydirdb
```

Output is in file: cuc/cli/schema_unitydirdb_061013-115815.sql

show cuc dbserver disk (Cisco Unity Connection Only)

This command displays summary information about Informix storage space for all Connection databases on the current server.

Command Syntax

show cuc dbserver disk [**page** | **file**]

Options

- **page**—Causes the output to display one page at a time. Be aware that **page** is case sensitive.
- **file**—Saves the output to a file. If you include this option, the summary includes the location of the file. Be aware that **file** is case sensitive.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
show cuc dbserver disk
```

```
Dbspaces
=====
DbSPACE  DbSPACE          Size   Used   Free   Percent
Number  Name              MB     MB     MB     Free
-----  -
1        rootdbs           300.0  107.3  192.7   64
2        ciscommunity_sbspace 20.0   19.0   1.0     5

Chunks
=====
Chunk  Offset  Size   Free   Path
-----  -
1      0       300.0  192.7  /var/opt/cisco/connection/db/root_dbSPACE
2      250     20.0   1.0    /usr/local/cm/db/informix/databases/ciscommunity_sbspace
```

show cuc dbserver session (Cisco Unity Connection Only)

This command displays summary information about a specified Informix database user session.

Command Syntax

show cuc dbserver session *session_id* [**page** | **file**]

Parameter

- *session_id* specifies the database user session for which you want to display summary information. To get a list of current sessions, use either the **show cuc dbserver sessions list (Cisco Unity Connection Only)** command or the **show cuc dbserver user list (Cisco Unity Connection Only)** command.

Options

- **page**—Causes the output to display one page at a time. Be aware that **page** is case sensitive.
- **file**—Saves the output to a file. If you include this option, the summary includes the location of the file. Be aware that **file** is case sensitive.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

The following example displays summary information about database user session 63.

```
show cuc dbserver session 63
```

```
IBM Informix Dynamic Server Version 10.00.UC4W3 -- On-Line -- Up 5 days 20:38:40 --
255716 Kbytes
```

session id	user	tty	pid	hostname	#RSAM threads	total memory	used memory	dynamic explain
63	dbuser	-	11488	smilliga	1	184320	143808	off

tid	name	rstcb	flags	curstk	status
108	sqlexec	4bedd2b0	Y--P---	4064	cond wait(netnorm)

Memory pools name	count	class	addr	totalsize	freesize	#allocfrag	#freefrag
63	1	V	4e774020	180224	38064	134	30

name	free	used	name	free	used
sql	0	40	rdahead	0	448

Sess Id	SQL Stmt type	Current Database	Iso Lvl	Lock Mode	SQL ERR	ISAM ERR	F.E. Vers	Explain
63	-	ccm0500v0000	CR	Wait 30	0	0	9.03	Off

```
Last parsed SQL statement :
select paramvalue from processconfig where
paramName='RisCleanupTimeOfDay'
```

show cuc dbserver sessions all (Cisco Unity Connection Only)

This command displays summary information about all the current Informix database user sessions.

Command Syntax

show cuc dbserver sessions all [page | file]

Options

- **page**—Causes the output to display one page at a time. Be aware that **page** is case sensitive.
- **file**—Saves the output to a file. If you include this option, the summary includes the location of the file. Be aware that **file** is case sensitive.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
show cuc dbserver sessions all
```

```
IBM Informix Dynamic Server Version 10.00.UC4W3 -- On-Line -- Up 5 days 20:38:40 --
255716 Kbytes
```

session id	user	tty	pid	hostname	#RSAM threads	total memory	used memory	dynamic explain
63	dbuser	-	11488	smilliga	1	184320	143808	off

tid	name	rstcb	flags	curstk	status
108	sqlxec	4bedd2b0	Y--P---	4064	cond wait(netnorm)

Memory pools	count	1				
name	class	addr	totalsize	freesize	#allocfrag	#freefrag
63	V	4e774020	180224	38064	134	30

name	free	used	name	free	used
opentable	0	3256	filetable	0	704

Sess Id	SQL Stmt type	Current Database	Iso Lvl	Lock Mode	SQL ERR	ISAM ERR	F.E. Vers	Explain
63	-	ccm0500v0000	CR	Wait 30	0	0	9.03	Off

```
Last parsed SQL statement :
select paramvalue from processconfig where
paramName='RisCleanupTimeOfDay'
```

show cuc dbserver sessions list (Cisco Unity Connection Only)

This command displays a list of the current Informix database user sessions.

Command Syntax

```
show cuc dbserver sessions list [page]
```

Option

- **page**—Causes the output to display one page at a time. Be aware that **page** is case sensitive.

Usage Guidelines

The names of internal database users generally correspond with the names of Connection components. Run this command before you run the [show cuc dbserver session \(Cisco Unity Connection Only\)](#) command to obtain the required session id.

Results are sorted by session id.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
show cuc dbserver sessions list
```

Session	Database	User	PID
14	unitydirdb	tomcat	4707
4986	unitydirdb	cudbeventpublisher	5818

show cuc dbserver user list (Cisco Unity Connection Only)

This command displays a list of the active Connection internal database users.

Command Syntax

```
show cuc dbserver user list [page]
```

Option

- **page**—Causes the output to display one page at a time. Be aware that **page** is case sensitive.

Usage Guidelines

The names of internal database users generally correspond with the names of Connection components.

Results get sorted first by database and then by user.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
show cuc dbserver user list
```

Database	User	Session	PID
unitydirdb	tomcat	18	4707
unitydirdb	cunotifier	5064	8690
unitydirdb	cumta	5028	8504
unitydirdb	cumixer	5018	8190
unitydirdb	cuscavenger	5114	8943

show cuc dbserver user waiting (Cisco Unity Connection Only)

This command displays a list of the Connection internal users, if any, that are waiting for a resource.

Command Syntax

```
show cuc dbserver user waiting [page]
```

Option

- **page**—Causes the output to display one page at a time. Be aware that **page** is case sensitive.

Usage Guidelines

The names of internal database users generally correspond with the names of Connection components.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
show cuc dbserver user waiting
```

User Name	Session ID	Latch	Lock	Waiting On		Trans	In Crit
				Buffer	Chkpt		
cucsmgr	5403	N	N	N	N	N	N
cudbeventpublisher	4989	N	N	N	N	N	N
cugalsvc	5097	N	N	N	N	N	N

show cuc dbtable contents (Cisco Unity Connection Only)

This command exports the contents of a specified Connection table to a CSV file.

Command Syntax

```
show cuc dbtable contents database_name table_name
```

Parameters

- *database_name* specifies the database that contains the table whose contents you want to export to a CSV file. Be aware that database names are case sensitive. Connection databases include
 - **unitydirdb**—contains the directory and configuration data.
 - **unitydyndb**—contains dynamic data that Connection uses internally.
 - **unitymbxdb1**—contains the data about the current voice messages, including pointers to the audio files that are stored in the file system.
 - **unityrptdb**—contains audit log data.
- *table_name* specifies the table whose contents you want to export to a CSV file. For a list of the tables in a specified database, use the [show cuc dbtable list \(Cisco Unity Connection Only\)](#) command. Be aware that table names are case sensitive.

Usage Guidelines

When the command completes, the location of the CSV file displays. Use the **file** commands to display the contents of the file.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
show cuc dbtable contents unitydirdb tbl_cos
```

Output is in file: cuc/cli/contents_tbl_cos_1013-113910.csv

show cuc dbtable list (Cisco Unity Connection Only)

This command displays a list of the tables in a specified database.

Command Syntax

```
show cuc dbtable list database_name [page]
```

Parameter

- *database_name* specifies the database for which you want a list of tables. Be aware that database names are case sensitive. Connection databases include
 - **unitydirdb**—contains the directory and configuration data.
 - **unitydyndb**—contains dynamic data that Connection uses internally.
 - **unitymbxdb1**—contains the data about the current voice messages, including pointers to the audio files that are stored in the file system.
 - **unityrptdb**—contains audit log data.

Option

- **page**—Causes the output to display one page at a time. Be aware that **page** is case sensitive.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
show cuc dbtable list unitydirdb
```

```
tbl_accountlogonpolicy
tbl_agency
tbl_agencyextensionrange
tbl_alias
tbl_alternatename
tbl_broadcastmessage
tbl_broadcastmessagerecipient
...
tbl_waveformat
```

show cuc dbtable schema (Cisco Unity Connection Only)

This command displays a description for a specified table and a list of the columns in the table.

Command Syntax

```
show cuc dbtable schema database_name table_name [page]
```

Parameters

- *database_name* specifies the database that contains the table whose schema you want to display. Be aware that database names are case sensitive. Connection databases include
 - **unitydirdb**—contains the directory and configuration data.
 - **unitydyndb**—contains dynamic data that Connection uses internally.
 - **unitymbxdb1**—contains the data about the current voice messages, including pointers to the audio files that are stored in the file system.
 - **unityrptdb**—contains audit log data.
- *table_name* specifies the table whose schema you want to display.

For a list of the tables in a specified database, use the **show cuc dbtable list (Cisco Unity Connection Only)** command. Be aware that table names are case sensitive.

Option

- **page**—Causes the output to display one page at a time. Be aware that **page** is case sensitive.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

The following example displays the schema for the table `tbl_user` in the database `unitydirdb`.

```
show cuc dbtable schema unitydirdb tbl_cos
```

```
A collection of service privileges for subscribers that control access to
features and use of the system into classes. Class Of Service objects
determine which features a subscriber is licensed to use, the maximum length
of their greetings and messages, what numbers they are allowed to dial, and
what options are available to the subscriber among other things.
```

```
Columns:
displayname
movetodeletefolder
accessunifiedclient
...
accesslivereply
```

show cuc dbview contents (Cisco Unity Connection Only)

This command saves the results from a specified SQL view in a CSV file.

Command Syntax

```
show cuc dbview contents database_name view_name
```

Parameters

- *database_name* specifies the database that contains the view whose results you want to save to a file. Be aware that database names are case sensitive. Connection databases include
 - **unitydirdb**—contains the directory and configuration data.

- **unitydyndb**—contains dynamic data that Connection uses internally.
- **unitymbxdb1**—contains the data about the current voice messages, including pointers to the audio files that are stored in the file system.
- **unityrptdb**—contains audit log data.
- *view_name* specifies the view whose results you want to save to a file.

For a list of the views in a specified database, use the **show cuc dbview list (Cisco Unity Connection Only)** command. Be aware that view names are case sensitive.

Usage Guidelines

When the command completes, the location of the CSV file displays. Use the **file** commands to display the contents of the file.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

The following example saves the results from the view `vw_cos`, in the database `unitydirdb`, to a CSV file.

```
show cuc dbview contents unitydirdb vw_cos
```

```
Output is in file: cuc/cli/contents_vw_cos_061013-113910.csv
```

show cuc dbview list (Cisco Unity Connection Only)

This command displays a list of the views in a specified database.

Command Syntax

```
show cuc dbview list database_name [page]
```

Parameter

- *database_name* specifies the database for which you want a list of views. Be aware that database names are case sensitive. Connection databases include
 - **unitydirdb**—contains the directory and configuration data.
 - **unitydyndb**—contains dynamic data that Connection uses internally.
 - **unitymbxdb1**—contains the data about the current voice messages, including pointers to the audio files that are stored in the file system.
 - **unityrptdb**—contains audit log data.

Option

- **page**—Causes the output to display one page at a time. Be aware that **page** is case sensitive.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

The following example displays a list of the views in the unitydirdb database.

```
show cuc dbview list unitydirdb

vw_agency
vw_agencyextensionrange
vw_alias
vw_alternatename
vw_broadcastmessage
vw_broadcastmessagerecipient
vw_callaction
...
vw_waveformat
```

show cuc dbview schema (Cisco Unity Connection Only)

This command displays the schema for a specified view.

Command Syntax

```
show cuc dbview schema database_name view_name [page]
```

Parameters

- *database_name* specifies the database that contains the view for which you want to display the schema. Be aware that database names are case sensitive. Connection databases include
 - **unitydirdb**—contains the directory and configuration data.
 - **unitydyndb**—contains dynamic data that Connection uses internally.
 - **unitymbxdb1**—contains the data about the current voice messages, including pointers to the audio files that are stored in the file system.
 - **unityrptdb**—contains audit log data.
- *view_name* specifies the view for which you want to display the schema.

For a list of the views in a specified database, use the [show cuc dbview list \(Cisco Unity Connection Only\)](#) command. Be aware that view names are case sensitive.

Option

- **page**—Causes the output to display one page at a time. Be aware that **page** is case sensitive.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

The following example displays the schema for the view vw_user in the database unitydirdb.

```
show cuc dbview schema unitydirdb vw_cos

A simple view for tbl_Cos.

Columns:
```

```

objectid
accessfaxmail
accessstts
callholdavailable
callscreenavailable
canrecordname
...
requiresecuremessages

```

show cuc locales (Cisco Unity Connection Only)

This command displays a list of the locales currently installed.

Command Syntax

```
show cuc locales
```

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
show cuc locales
```

```

Installed Locale Package  Locale
-----
uc-locale-en_GB-6.0.0.0-0  en-GB
uc-locale-fr_CA-6.0.0.0-0  fr-CA

```

show cuc sysagent task list (Cisco Unity Connection Only)

This command displays a list of the Sysagent tasks.

Command Syntax

```
show cuc sysagent task list [page]
```

Option

- **page**—Causes the output to display one page at a time. Be aware that **page** is case sensitive.

Usage Guidelines

To run a sysagent task, use the [run cuc sysagent task \(Cisco Unity Connection Only\)](#) command. If the value of the Is Singleton column is Y for a specified task, the task can only be run on the primary server in a multi-server cluster. If this server is standalone, then all tasks will run on this server.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
show cuc sysagent task list
```

Task Name	Is Singleton
BroadcastMessagePurge	N
CallManagerSubscriberTemplateSynchTask	Y
CallManagerUserSynchTask	Y
CleanDeletedMessagesTask	Y
CleanDirectoryStreamFilesTask	N
CleanOrphanAttachmentFilesTask	Y
...	
UpdateDatabaseStats	N

show cuc sysagent task results (Cisco Unity Connection Only)

This command displays the time(s) at which the specified task started and completed, with the most recent time listed first.

Command Syntax

```
show cuc sysagent task results task_name [page]
```

Parameters

- task_name* specifies the task for which you want to display information about when the task was started and completed.

For a list of task names, run the [show cuc sysagent task list \(Cisco Unity Connection Only\)](#) command. Be aware that task names are case sensitive.

Option

- page**—Causes the output to display one page at a time. Be aware that **page** is case sensitive.

Usage Guidelines

To run a Sysagent task, use the [run cuc sysagent task \(Cisco Unity Connection Only\)](#) command.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

The following example displays the times at which the Sysagent task CleanDeletedMessages started and completed.

```
show cuc sysagent task results CleanDeletedMessagesTask
```

Time Started	Time Completed
2006-10-25 17:31:45.689	2006-10-25 17:31:45.785
2006-10-25 17:16:45.702	2006-10-25 17:16:45.742
2006-10-25 17:01:45.690	2006-10-25 17:01:45.730

show cuc tech dbschemaversion (Cisco Unity Connection Only)

This command displays the schema version information for each database.

Command Syntax

```
show cuc tech dbschemaversion [page]
```

Option

- **page**—Causes the output to display one page at a time. Be aware that **page** is case sensitive.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
show cuc tech dbschemaversion
```

```
unitydirdb
=====
Schema Version   Product Version   Date
-----
1.2.363          2.1                2007-02-13 19:10:50.0
```

show cuc tech dbserver all (Cisco Unity Connection Only)

This command runs all the show cuc tech commands in sequence and saves the results in a text file.

Command Syntax

```
show cuc tech dbserver all
```

Usage Guidelines

When the command completes, detailed information gets saved in a text file, and the location of the text file displays. Use the **file** commands to display the contents of the file.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
show cuc tech dbserver all
```

```
Output is in file: cuc/cli/dbserverall_061013-111801.txt
```

show cuc tech dbserver integrity (Cisco Unity Connection Only)

This command checks the integrity of the Informix database server storage space structure.

Command Syntax

```
show cuc tech dbserver integrity
```

Usage Guidelines

When the command completes, detailed information gets saved in a text file, and a summary of the results displays, including the location of the file. Use the **file** commands to display the contents of the file.

Be aware that the following warning is expected and should be ignored in the output file:

```
WARNING: No syssyntable records found
```

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
show cuc tech dbserver integrity
```

```
Database system catalog tables were successfully validated.
```

```
Database disk extents were successfully validated.
```

```
Database reserved pages were successfully validated.
```

```
Output is in file: cuc/cli/integrity_061013-95853.txt
```

show cuc tech dbserver log diagnostic (Cisco Unity Connection Only)

This command checks for the existence of Informix assertion-failure and shared-memory-dump logs.

Command Syntax

```
show cuc tech dbserver log diagnostic
```

Usage Guidelines

If the logs exist, their location displays. Use the **file** commands to display the contents of the files.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
show cuc tech dbserver log diagnostic
```

```
The following Informix logs are available for the UC database server:
```

```
core/af.3599c
```

```
core/af.36858
```

show cuc tech dbserver log message (Cisco Unity Connection Only)

This command displays the last *n* lines of the Informix message log.

Command Syntax

```
show cuc tech dbserver log message [lines] [page]
```

Parameter

- *lines* specifies the number of lines that display at the end of the Informix message log. If the *lines* parameter is not included, the last 20 lines of the log are displayed.

Option

- **page**—Causes the output to display one page at a time. Be aware that **page** is case sensitive.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
show cuc tech dbserver log message
```

```
Message Log File: online.ciscounity.log
```

```
18:09:01 Fuzzy Checkpoint Completed: duration was 0 seconds, 6 buffers not flushed.  
18:09:01 Checkpoint loguniq 57, logpos 0x208418, timestamp: 0x33b807
```

```
18:09:01 Maximum server connections 159  
18:14:01 Fuzzy Checkpoint Completed: duration was 0 seconds, 6 buffers not flushed.  
18:14:01 Checkpoint loguniq 57, logpos 0x20a57c, timestamp: 0x33b9fc
```

show cuc tech dbserver status (Cisco Unity Connection Only)

This command saves a detailed status report of the database server instance to a file.

Command Syntax

```
show cuc tech dbserver status
```

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
show cuc tech dbserver status
```

```
Output is in file: cuc/cli/status_061013-95031.txt
```

show cuc trace levels (Cisco Unity Connection Only)

This command displays a list of all the diagnostic traces and trace levels that are currently enabled.

Command Syntax

show cuc trace levels [page]

Option

- **page**—Causes the output to display one page at a time. Be aware that **page** is case sensitive.

Usage Guidelines

To enable or disable specified traces and trace levels, use the [set cuc trace \(Cisco Unity Connection Only\)](#) command.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
show cuc trace levels
```

Trace Name	Levels
-----	-----
Arbiter	-
AudioStore	0
AxlAccess	-
BulkAdministrationTool	0
CCL	10,11
CDE	3,14
CDL	11,13,15,17
:	
:	
VirtualQueue	-

show cuc version (Cisco Unity Connection Only)

This command displays the Cisco Unity Connection version that is currently installed on the active and inactive partitions.

Command Syntax

show cuc version

Usage Guidelines

This command always displays the version in the active partition. If the active partition contains an upgrade, the command will also show the version in the inactive partition. The current Engineering Special, if any, also displays.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
show cuc version
```

```
Active version: 2.0(1.0)
```

show diskusage

This command displays information about disk usage on the server.

Command Syntax

```
show diskusage
```

```

activelog { filename filename | directory | sort }
common { filename filename | directory | sort }
inactivelog { filename filename | directory | sort }
install { filename filename | directory | sort }
tftp { filename filename | directory | sort }
tmp { filename filename | directory | sort }

```

Parameters

- **activelog** displays disk usage information about the activelog directory.
- **common** displays disk usage information about the common directory.
- **inactivelog** displays disk usage information about the inactivelog directory.
- **install** displays disk usage information about the install directory.
- **tftp** displays disk usage information about the TFTP directory.
- **tmp** displays disk usage information about the TMP directory.

Options

- **filename** *filename*—Saves the output to a file that is specified by *filename*. These files get stored in the **platform/cli** directory. To view saved files, use the **file view activelog** command.
- **directory**—Displays just the directory sizes.
- **sort**—Sorts the output on the basis of file size. File sizes display in 1024-byte blocks.

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

show environment

This command displays information about the server hardware.

Command Syntax

```
show environment
```

fans
power-supply
temperatures

Options

- **fans**—Displays information that fan probes gather.
- **power-supply**—Displays information that power supply probes gather.
- **temperatures**—Displays information that temperature probes gather.

show firewall list

This command displays system aspects of the server.

Command Syntax

show firewall list [**detail**] [**page**] [**file** *filename*]

Options

- **detail**—Displays detailed statistics on every available device on the system
- **page**—Displays the output one page at a time
- **file** *filename*—Outputs the information to a file



Note The file option saves the information to `platform/cli/filename.txt`. Ensure the file name does not contain the “.” character.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

show hardware

This command displays the following information on the platform hardware.

Command Syntax

show hardware

Usage Guidelines

This command displays the following information on the platform hardware:

- Platform
- Serial number
- BIOS build level
- BIOS manufacturer
- Active processors

- RAID controller status

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

show ipsec

This command displays information on IPsec policies and associations.

Command Syntax

show ipsec

policy

association *policy*

information *policy association*

status

Parameters

- **policy** displays all IPsec policies on the node.
- **association** displays the association list and status for the policy.
- **information** displays the association details and status for the policy.
- **status** displays the status of all IPsec tunnels that are defined in the system.
- *policy* represents the name of a specific IPsec policy.
- *association* represents the association name.

Requirements

Command privilege level: 1

Allowed during upgrade: yes

Example

This example displays IPsec policies.

```
show ipsec policy
```

show logins

This command lists recent logins to the server.

Command Syntax

show logins *number*

Parameters

number specifies the number of most recent logins to display. The default equals 20.

show memory

This command displays information about the server memory.

Command Syntax

```
show memory
    count
    module [ALL | module_number]
    size
```

Options

- **count**—Displays the number of memory modules on the system.
- **module**—Displays detailed information about each memory module.
- **size**—Displays the total amount of memory.

Parameters

ALL displays information about all installed memory modules.

module_number specifies which memory module to display.

show myself

This command displays information about the current account.

Command Syntax

```
show myself
```

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

show network

This command displays network information.

Command Syntax

```
show network
    cluster
    eth0 [detail]
    failover [detail] [page]
    route [detail]
    status [detail] [listen] [process] [all] [nodns] [search stext]
    ip_conntrack
```

max_ip_conntrack
dhcp eth0 status
all [detail]

Parameters

- **cluster** displays a list of the nodes in the network cluster.
- **eth0** specifies Ethernet 0.
- **failover** specifies Network Fault Tolerance information.
- **route** specifies network routing information.
- **status** specifies active Internet connections.
- **ip_conntrack** specifies ip_conntrack usage information.
- **max_ip_conntrack** specifies max_ip_conntrack information.
- **dhcp eth0 status** displays DHCP status information.
- **all** specifies all basic network information.

Options

- **detail**—Displays additional information.
- **page**—Displays information 1 page at a time.
- **listen**—Displays only listening sockets
- **process**—Displays the process ID and name of the program to which each socket belongs.
- **all**—Displays both listening and nonlistening sockets.
- **nodns**—Displays numerical addresses without any DNS information.
- **search stext**—Searches for the stext in the output.

Usage Guidelines

The **eth0** parameter displays Ethernet port 0 settings, including DHCP and DNS configurations and options.

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Example

This example displays active Internet connections.

```
show network status
```

show network ipprefs

This command displays the list of ports that have been requested to be opened or translated in the firewall.

Command Syntax

ipprefs {all | enabled | public}

Parameters

all—Displays all incoming ports that may be used on the product.

enabled—Displays all incoming ports that are currently opened.

public—Displays all incoming ports that are currently opened for any remote client.

Requirements

Level privilege: 0

Command privilege: 0

Allowed during upgrade: Yes

Example

```
admin:show network ipprefs public
```

Application	IPProtocol	PortValue	Type	XlatedPort	Status	Description
sshd	tcp	22	public	-	enabled	sftp and ssh
access						
tomcat	tcp	8443	translated	443	enabled	secure web
access						
tomcat	tcp	8080	translated	80	enabled	web access
clm	udp	8500	public	-	enabled	cluster
manager						
clm	tcp	8500	public	-	enabled	cluster
manager						
ntpd	udp	123	public	-	enabled	network time
sync						
snmpdm	udp	161	public	-	enabled	SNMP
ccm	tcp	2000	public	-	enabled	SCCP-SIG
ctftp	udp	6969	translated	69	enabled	TFTP access
to CUCM TFTP Server						
ctftp	tcp	6970	public	-	enabled	HTTP access
to CUCM TFTP Server						

```
admin:
```

show open

This command displays open files and ports on the system.

Command Syntax

show open

files [all] [process *processID*] [regexp *reg_exp*]

ports [all] [regexp *reg_exp*]

Parameters

- **files** displays open files on the system.
- **ports** displays open ports on the system.

Options

- **all**—Displays all open files or ports.
- **process**—Displays open files that belong to the specified process.
- *processID*—Specifies a process.
- **regexp**—Displays open files or ports that match the specified regular expression.
- *reg_exp*—Represents a regular expression.

show packages

This command displays the name and version for installed packages.

Command Syntax

show packages

active *name* [**page**]

inactive *name* [**page**]

Parameters

name represents the package name. To display all active or inactive packages, use the wildcard character, *.

Options

- **page**—Displays the output one page at a time

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

show perf counterhelp

This command displays the explanation text for the specified perfmon counter.

Command Syntax

show perf counterhelp *class-name counter-name*

Parameters

- *class-name* represents the class name that contains the counter.
- *counter-name* represents the counter that you want to view.



Note If the class name or counter name contains white spaces, enclose the name in double quotation marks.

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

show perf list categories

This command lists all categories in the perfmon system.

Command Syntax

show perf list categories

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

show perf list classes

This commands lists the perfmon classes or objects.

Command Syntax

show perf list classes [*cat category*] [**detail**]

Options

- **detail**—Displays detailed information
- **cat category**—Displays perfmon classes for the specified category

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

show perf list counter

This command lists perfmon counters for the specified perfmon class.

Command Syntax

list counters *class-name* [**detail**]

Parameters

class-name represents a perfmon class name for which you want to list the counters.



Note If the class name or counter name contains white spaces, enclose the name in double quotation marks.

Options

detail—Displays detailed information

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

show perf list instances

The command lists the perfmon instances for the specified perfmon class.

Command Syntax

list instances *class-name* [**detail**]

Parameters

class-name represents a perfmon class name for which you want to list the counters.



Note If the class name contains white spaces, enclose the name in double quotation marks.

Options

detail—Displays detailed information

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

show perf query class

This command queries a perfmon class and displays all the instances and counter values of each instance.

Command Syntax

show perf query class *class-name* [,*class-name*...]

Parameters

class-name specifies the perfmon class that you want to query. You can specify a maximum of five classes per command.



Note If the class name contains white spaces, enclose the name in double quotation marks.

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

show perf query counter

This command queries the specified counter and displays the counter value of all instances.

Command Syntax

show perf query counter *class-name counter-name* [,*counter-name*...]

Parameters

- *class-name* specifies the perfmon class that you want to query.
- *counter-name* specifies the counter to view. You can specify a maximum of five counters per command.



Note If the class name or counter name contains white spaces, enclose the name in double quotation marks.

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

show perf query instance

This command queries the specified instance and displays all its counter values.

Command Syntax

show perf query instance *class-name instance-name* [,*instance-name*...]

Parameters

- *class-name* specifies the perfmon class that you want to query.
- *instance-name* specifies the perfmon instance to view. You can specify a maximum of five instances per command.



Note If the class name or instance name contains white spaces, enclose the name in double quotation marks.

Usage Guidelines

This command does not apply to singleton perfmon classes.

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

show perf query path

This command queries a specified perfmon path.

Command Syntax

show perf query path *path-spec* [,*path-spec*...]

Parameters

- For an instance-based perfmon class, specify *path-spec* as *class-name(instance-name)\counter-name*.

- For a noninstance-based perfmon class (a singleton), specify *path-spec* as *class-name\counter-name*.

You can specify a maximum of five paths per command.



Note If the path name contains white spaces, enclose the name in double quotation marks.

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Example

```
show perf query path "Cisco Phones(phone-0)\CallsAttempted",
"Cisco Unified Communications Manager\TlChannelsActive"
```

show process

This command displays information about process that is running on the system.

Syntax

show process

list [**file** *filename*] [**detail**]

load [**cont**] [**clear**] [**noidle**] [**num** *number*] [**thread**] [**cpu** | **memory**| **time**] [**page**]

name *process* [**file** *filename*]

open-fd *process-id* [, *process-id2*]

search *regexp* [**file** *filename*]

using-most cpu [*number*] [**file** *filename*]

using-most memory [*number*] [**file** *filename*]

Parameters

- **list** displays a list of all the processes and critical information about each process and visually indicates the child-parent relationships between the processes.
- **load** displays the current load on the system.
- **name** displays the details of processes that share the same name and indicates their parent-child relationship.
- **open-fd** lists the open file descriptors for a comma-separated list of process IDs.
- **search** searches for the pattern that the regular expression *regexp* specifies in the output of the operating system-specific process listing.
- **using-most cpu** displays a list of the most CPU-intensive processes.
- **using-most memory** displays a list of the most memory-intensive processes.

Options

- **file** *filename*—Outputs the results to the file that is specified by *filename*

- **detail**—Displays detailed output
- **cont**—Repeats the command continuously
- **clear**—Clears the screen before displaying output
- **noidle**—Ignore the idle/zombie processes
- **num number**—Displays the number of processes that are specified by *number*. The default number of processes equals 10. Set *number* to **all** to display all processes.
- **thread**—Displays threads
- [**cpu** | **memory** | **time**]—Sorts output by CPU usage, memory usage, or time usage. The default specifies to sort by CPU usage.
- **page**—Displays the output in pages
- *process*—Specifies the name of a process
- *process-id*—Specifies the process ID number of a process
- *regexp*—Represents a regular expression
- *number*—Specifies the number of processes to display. The default equals 5.

show registry

This command displays the contents of the registry.

Command Syntax

show registry *system component* [*name*] [**page**]

Parameters

- *system* represents the registry system name.
- *component* represents the registry component name.
- *name* represents the name of the parameter to show.



Note To display all items, enter the wildcard character, *.

Options

page—Displays one page at a time

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

This example shows contents of the cm system, dbl/sdi component.

```
show registry cm dbl/sdi
```

show risdb

This command displays RIS database table information.

Command Syntax

show risdb

list [**file** *filename*]

query *table1 table2 table3 ...* [**file** *filename*]

Parameters

- **list** displays the tables that are supported in the Realtime Information Service (RIS) database.
- **query** displays the contents of the RIS tables.

Options

file *filename*—Outputs the information to a file.



Note

The file option saves the information to `platform/cli/filename.txt`. Ensure that the file name does not contain the “.” character.

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Example

This example displays a list of RIS database tables.

```
show risdb list
```

show smtp

This command displays the name of the SMTP host.

Command Syntax

show snmp

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

show stats io

This command displays system IO statistics.

Command Syntax

show stats io [**kilo**] [**detail**] [**page**] [**file filename**]

Options

- **kilo**—Displays statistics in kilobytes.
- **detail**—Displays detailed statistics on every available device on the system and overrides the **kilo** option.
- **file filename**—Outputs the information to a file.



Note The file option saves the information to `platform/cli/filename.txt`. Ensure that the file name does not contain the “.” character.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

show status

This command displays basic platform status.

Command Syntax

show status

Usage Guidelines

This command displays the following basic platform status:

- Host name
- Date
- Time zone
- Locale
- Product version
- Platform version
- CPU usage
- Memory and disk usage

Requirements

Command privilege level: 0

show tech all

This command displays the combined output of all **show tech** commands.

Command Syntax

show tech all [**page**] [**file filename**]

Options

- **page**—Displays one page at a time.
- **file filename**—Outputs the information to a file.



Note The file option saves the information to `platform/cli/filename.txt`. Ensure that the file name does not contain the “.” character.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

show tech ccm_service

This command displays information on all Cisco Unified Communications Manager services that can run on the system.

Command Syntax

show tech ccm_service

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

show tech database

This command shows information about the database.

Command Syntax

show tech database

dump

sessions

Parameters

- **dump** creates a CSV file of the entire database.
- **sessions** redirects the session and SQL information of the present session IDs to a file.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

show tech dbintegrity

This command displays the database integrity.

Command Syntax
`show tech dbintegrity`

show tech dbinuse

This command displays the database in use.

Command Syntax
`show tech dbinuse`

Requirements
Command privilege level: 1
Allowed during upgrade: Yes

show tech dbschema

This command displays the database schema in a CSV file.

Command Syntax
`show tech dbschema`

Requirements
Command privilege level: 1
Allowed during upgrade: Yes

show tech dbstateinfo

This command displays the state of the database.

Command Syntax
`show tech dbstateinfo`

show tech devdefaults

This command displays the device defaults table.

Command Syntax
`show tech devdefaults`

Requirements
Command privilege level: 1
Allowed during upgrade: Yes

show tech gateway

This command displays the gateway table from the database.

Command Syntax

```
show tech gateway
```

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

show tech locales

This command displays the locale information for devices, device pools, and end users.

Command Syntax

```
show tech locales
```

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

show tech network

This command displays network aspects of the server.

Command Syntax

```
show tech network
```

```
all [page] [search text] [file filename]  
hosts [page] [search text] [file filename]  
interfaces [page] [search text] [file filename]  
resolv [page] [search text] [file filename]  
routes [page] [search text] [file filename]  
sockets {numeric}
```

Parameters

- **all** displays all network tech information.
- **hosts** displays information about hosts configuration.
- **interfaces** displays information about the network interfaces.
- **resolv** displays information about hostname resolution.
- **routes** displays information about network routes.
- **sockets** displays the list of open sockets.

Options

- **page**—Displays one page at a time.
- **search *text***—Searches the output for the string that *text* specifies. Be aware that the search is case insensitive.
- **file *filename***—Outputs the information to a file.
- **numeric**—Displays the numerical addresses of the ports instead of determining symbolic hosts. This parameter is equivalent to running the Linux shell command `netstat [-n]` command.

Usage Guidelines

The **file** option saves the information to `platform/cli/filename.txt`. Ensure that the file name does not contain the “.” character.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

show tech notify

This command displays the database change notify monitor.

Command Syntax

```
show tech notify
```

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

show tech params all

This command displays all the database parameters.

Command Syntax

```
show tech params all
```

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

show tech params enterprise

This command displays the database enterprise parameters.

Command Syntax

```
show tech params enterprise
```

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

show tech params service

This command displays the database service parameters.

Command Syntax

show tech params service

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

show tech prefs

This command displays database settings.

Command Syntax

show tech prefs

show tech procedures

This command displays the procedures that are in use for the database.

Command Syntax

show tech procedures

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

show tech routepatterns

This command displays the route patterns that are configured for the system.

Command Syntax

show tech routepatterns

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

show tech routeplan

This command displays the route plan that are configured for the system.

Command Syntax

show tech routeplan

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

show tech runtime

This command displays runtime aspects of the server.

Command Syntax

show tech runtime

all [**page**] [**file filename**]
cpu [**page**] [**file filename**]
disk [**page**] [**file filename**]
env [**page**] [**file filename**]
memory [**page**] [**file filename**]

Parameters

- **all** displays all runtime information.
- **cpu** displays CPU usage information at the time the command is run.
- **disk** displays system disk usage information.
- **env** displays environment variables.
- **memory** displays memory usage information.

Options

- **page**—Displays one page at a time.
- **file filename**—Outputs the information to a file.

Usage Guidelines

The **file** option saves the information to `platform/cli/filename.txt`. Ensure that the file name cannot contain the “.” character.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

show tech systables

This command displays the name of all tables in the sysmaster database.

Command Syntax

```
show tech systables
```

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

show tech system

The show tech system command gets updated as described in this section. This command displays system aspects of the server.

Command Syntax

```
show tech system
```

```
all [page] [file filename]
bus [page] [file filename]
hardware [page] [file filename]
host [page] [file filename]
kernel [page] [file filename]
software [page] [file filename]
tools [page] [file filename]
```

Parameters

- **all** displays all the system information.
- **bus** displays information about the data buses on the server.
- **hardware** displays information about the server hardware.
- **host** displays information about the server.
- **kernel** lists the installed kernel modules.
- **software** displays information about the installed software versions.
- **tools** displays information about the software tools on the server.

Options

- **page**—Displays one page at a time.
- **file filename**—Outputs the information to a file.

Usage Guidelines

The **file** option saves the information to platform/cli/*filename*.txt. Ensure that the file name does not contain the "." character.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

show tech table

This command displays the contents of the specified database table.

Command Syntax

```
show tech table table_name [page] [csv]
```

Parameters

table_name represents the name of the table to display.

Options

- **page**—Displays the output one page at a time.
- **csv**—Sends the output to a comma separated values file.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

show tech triggers

This command displays table names and the triggers that are associated with those tables.

Command Syntax

```
show tech triggers
```

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

show tech version

This command displays the version of the installed components.

Command Syntax

```
show tech version [page]
```

Options

Page—Displays the output one page at a time.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

show timezone

This command displays time zone information.

Command Syntax

show timezone

config

list [page]

Parameters

- **config** displays the current time zone settings.
- **list** displays the available time zones.

Options

- **page**—Displays the output one page at a time.

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

show trace

This command displays trace information for a particular task.

Command Syntax

show trace [*task_name*]

Parameters

task_name represents the name of the task for which you want to display the trace information.



Note

If you do not enter any parameters, the command returns a list of available tasks.

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Example

This example displays trace information for CDP.

```
show trace cdfs
```

show ups status

This command shows the current status of the USB-connected APC smart-UPS device and starts the monitoring service if it is not already started.

This command to give full status is only available on 7835-H2 and 7825-H2 servers.

Command Syntax

show ups status

show version

Be aware that this command displays the software version on the active or inactive partition.

Command Syntax

show version

active

inactive

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

show web-security

This command displays the contents of the current web-security certificate.

Command Syntax

show web-security

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

show workingdir

This command retrieves the current working directory for activelog, inactivelog, install, and TFTP.

Command Syntax

show workingdir

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

Unset Commnds

This section contains descriptions of the following commands:

- [unset ipsec 81](#)
- [unset network 82](#)

unset ipsec

This command allows you to disable IPSec policies and associations.

Command Syntax

unset ipsec

policy {**ALL** | *policy-name*}

association *policy-name* {**ALL** | *association-name*}

Parameters

- *policy-name* represents the name of an IPSec policy.
- *association-name* represents the name of an IPSec association.

Requirements

Command privilege level: 1

Allowed during upgrade: No

unset network

This command unsets DNS options.

Command Syntax

unset network dns options [**timeout**] [**attempts**] [**rotate**]

Parameters

- **timeout** sets the wait time before the system considers a DNS query as failed to the default.
- **attempts** sets the number of DNS attempts to make before failing to the default.
- **rotate** sets the method for selecting a nameserver to the default. This affects how loads are distributed across nameservers.

Usage Guidelines

The system asks whether you want to continue to execute this command.



Caution

If you continue, the system will temporarily lose network connectivity.

Utils Commands

This section contains descriptions of the following commands:

- [utils core list](#) 84
- [utils core analyze](#) 84
- [utils create report](#) 85
- [utils csa disable](#) 85
- [utils csa enable](#) 86
- [utils csa status](#) 86
- [utils cuc cluster activate \(Cisco Unity Connection Only\)](#) 86
- [utils cuc cluster deactivate \(Cisco Unity Connection Only\)](#) 87
- [utils cuc cluster makeprimary \(Cisco Unity Connection Only\)](#) 87
- [utils cuc cluster overwrittenb \(Cisco Unity Connection Only\)](#) 87
- [utils cuc cluster renegotiate \(Cisco Unity Connection Only\)](#) 88
- [utils cuc create report \(Cisco Unity Connection Only\)](#) 88
- [utils cuc reset password \(Cisco Unity Connection Only\)](#) 89
- [utils dbreplication clusterreset](#) 89
- [utils dbreplication dropadmindb](#) 90
- [utils dbreplication forcedatasyncsub](#) 90
- [utils dbreplication repair](#) 91
- [utils dbreplication reset](#) 91
- [utils dbreplication setreptimeout](#) 92
- [utils dbreplication status](#) 93
- [utils dbreplication stop](#) 93
- [utils diagnose](#) 93
- [utils disaster_recovery backup tape](#) 94
- [utils disaster_recovery backup network](#) 94
- [utils disaster_recovery cancel_backup](#) 94
- [utils disaster_recovery restore tape](#) 95
- [utils disaster_recovery restore network](#) 95
- [utils disaster_recovery show_backupfiles network](#) 96
- [utils disaster_recovery show_backupfiles tape](#) 96
- [utils disaster_recovery show_registration](#) 96
- [utils disaster_recovery show_tapeid](#) 97
- [utils disaster_recovery status](#) 97
- [utils fior](#) 97
- [utils firewall](#) 98
- [utils iostat](#) 99

- [utils iothrottle enable](#) 99
- [utils iothrottle disable](#) 100
- [utils iothrottle status](#) 100
- [utils netdump client](#) 100
- [utils netdump server](#) 101
- [utils network arp](#) 101
- [utils network capture eth0](#) 102
- [utils network connectivity](#) 103
- [utils network host](#) 103
- [utils network ping](#) 103
- [utils network traceroute](#) 104
- [utils ntp](#) 104
- [utils ntp restart](#) 104
- [utils ntp start](#) 105
- [utils remote_account](#) 105
- [utils reset_ui_administrator_name](#) 106
- [utils reset_ui_administrator_password](#) 106
- [utils service list](#) 106
- [utils service](#) 107
- [utils sftp handshake](#) 107
- [utils snmp](#) 107
- [utils soap_realtimeservice test](#) 108
- [utils system](#) 109
- [utils system boot](#) 109
- [utils system upgrade](#) 110

utils core list

This command lists all existing core files.

Command Syntax

utils core list

utils core analyze

This command generates a backtrace for the specified core file, a thread list, and the current value of all CPU registers.

Command Syntax

utils core analyze *core file name*

Parameters

- *core file name* specifies the name of a core file.

Usage Guidelines

The command creates a file of the same name as the core file, with a .txt extension, in the same directory as the core file. This command works only on the active partition.

utils create report

This command creates reports about the server in the platform/log directory.

Command Syntax**utils create report**

hardware

platform

csa

Parameters

- **hardware** creates a system report that contains disk array, remote console, diagnostic, and environmental data.
- **platform** collects the platform configuration files into a TAR file.
- **csa** collects all the files required for CSA diagnostics and assembles them into a single CSA diagnostics file. You can retrieve this file by using the **file get** command.

Usage Guidelines

You are prompted to continue after you enter the command.

After creating a report, use the command **file get activelog platform/log/filename**, where *filename* specifies the report filename that displays after the command completes, to get the report.

Requirements

Level privilege: 1

Command privilege: 1

Allowed during upgrade: No

utils csa disable

This command stops Cisco Security Agent (CSA).

Command Syntax**utils csa disable****Requirements**

Command privilege level: 1

Allowed during upgrade: No

utils csa enable

This command enables Cisco Security Agent (CSA).

Command Syntax

utils csa enable

Usage Guidelines

The system prompts you to confirm that you want to enable CSA.



Caution

You must restart the system after you start CSA.ca

Requirements

Command privilege level: 1

Allowed during upgrade: No

utils csa status

This command displays the current status of Cisco Security Agent (CSA).

Command Syntax

utils csa status

Usage Guidelines

The system indicates whether CSA is running.

Requirements

Command privilege level: 0

Allowed during upgrade: No

utils cuc cluster activate (Cisco Unity Connection Only)

This command activates the roles on this server.

Command Syntax

utils cuc cluster activate

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
utils cuc cluster activate
```

utils cuc cluster deactivate (Cisco Unity Connection Only)

This command deactivates the roles on this server.

Command Syntax

```
utils cuc cluster deactivate
```

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
utils cuc cluster deactivate
```

utils cuc cluster makeprimary (Cisco Unity Connection Only)

This command forces the specified server to be the primary server in a cluster.

Command Syntax

```
utils cuc cluster makeprimary [server]
```

Parameters

- *server* specifies the name of the server to make the primary. If you do not specify a server, the other server in the cluster becomes the primary server.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
utils cuc cluster makeprimary
```

utils cuc cluster overwritedb (Cisco Unity Connection Only)

This command overwrites the database on destination with the database on source.

Command Syntax

```
utils cuc cluster overwritedb master
```

Parameters

- *master* specifies the host name or the IP address of the server from which to pull the database.

Usage Guidelines

This will overwrite the database on the partner server with a copy of the database on *master* and start replication. Replication will restart after the database is overwritten. This method is used when you restore one server from a backup and must copy the restored data to the other server.

Requirements

Command privilege level: 1
 Allowed during upgrade: Yes

Example

```
utils cuc cluster overwrittenb connectionprimary
```

utils cuc cluster renegotiate (Cisco Unity Connection Only)

This command sets up a trust relationship with the specified server.

Command Syntax

utils cuc cluster renegotiate

Usage Guidelines

Run this command on the primary server in a cluster to set up a trust with the secondary server.

Requirements

Command privilege level: 1
 Allowed during upgrade: Yes

Example

```
utils cuc cluster renegotiate
```

utils cuc create report (Cisco Unity Connection Only)

This command collects data that is helpful to technical support staff for troubleshooting the system. Data collected includes version information, clustering status, service information, database information, trace files, log files, disk information, memory information, and restart information.

Command Syntax

utils cuc create report

Usage Guidelines

When the command completes, detailed information gets saved in a .zip file, and the location of the .zip file displays. Use the [file get](#) command to move the file to a computer on which you can uncompress the file and view the contents.

Requirements

Command privilege level: 1
 Allowed during upgrade: Yes

Example

```
utils cuc create report
```

```
Getting unity connection version. Please wait...Done
Getting cluster status. Please wait...Done
Getting service information. Please wait...Done
Getting installed locales. Please wait...Done
Getting database schema version. Please wait...Done
Getting database integrity. Please wait...Done
Getting database diagnostic log. Please wait...Done
Getting database message log. Please wait...Done
Getting trace files. Please wait...Done
Getting log files. Please wait...Done
Getting platform status. Please wait...Done
Compressing 75 files. Please wait...Done
```

Output is in file: cuc/cli/systeminfo_080318-140843.zip
To free disk space, delete the file after copying it to another computer

utils cuc reset password (Cisco Unity Connection Only)

This command resets the password for a specified user account.

Syntax

```
utils cuc reset password
```

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

Example

```
admin:utils cuc reset password jdoe
Enter password:
Re-enter password:
jdoe
07/29/2008 12:41:14.704 : Update SUCCEEDED
```

utils dbreplication clusterreset

You can use this command to debug database replication. However, you should only use it if you have already tried **utils dbreplication reset all**, and it failed to restart replication on the cluster. This command will tear down and rebuild replication for the entire cluster. After using this command, you must restart each subscriber server. After all subscriber servers have been restarted, you must go to the publisher server and issue the CLI command **utils dbreplication reset all**.

Command Syntax

```
utils dbreplication clusterreset
```

Usage Guidelines

Before you run this command, run the command **utils dbreplication stop** first on all subscribers servers and then on the publisher server.

Requirements

Command privilege level: 0

Allowed during upgrade: No

utils dbreplication dropadmindb

This command drops the Informix syscdr database on any server in the cluster.

Command Syntax

utils dbreplication dropadmindb

Usage Guidelines

You should run this command only if database replication reset or cluster reset fails and replication cannot be restarted.

Requirements

Command privilege level: 0

Allowed during upgrade: No

utils dbreplication forcedatasyncsub

This command forces a subscriber server to have its data restored from data on the publisher server.

Use this command only after you have run the **utils dbreplication repair** command several times, but the **utils dbreplication status** command still shows non-dynamic tables that are not in sync



Note

Do not run this command if only dynamic tables are out of sync; dynamic tables can be out of sync during normal system operation.

You can only run this command from the publisher server. Use the **all** parameter to force sync on all subscriber servers in the cluster. If only one subscriber server is out of sync, use the *hostname* parameter.

After you run this command, you must restart the restored subscriber servers.

This command can take a significant amount of time to execute and can affect the system-wide IOWAIT.

Command Syntax

utils dbreplication forcedatasyncsub {allhostname}

Parameters

- **all** causes all subscriber servers in the cluster to have their data restored from data on the publisher server.

- *hostname* specifies a particular subscriber server to have its data restored from data on the publisher server.

Usage Guidelines

The **utils dbreplication forcedatasyncsub** command takes a database backup of the publisher server and restores that data into the database on the subscriber server.



Note

This command erases all existing data on the subscriber server and replaces it with the database from the publisher server, which makes it impossible to determine the original root cause for the subscriber server tables going out of sync.

Requirements

Command privilege level: 0

Allowed during upgrade: No

utils dbreplication repair

This command repairs database replication.

Command Syntax

```
utils dbreplication repair {all|hostname}
```

Parameters

- **all** causes data repair to take place on all subscriber servers.
- *hostname* specifies a particular subscriber server for data repair.

Usage Guidelines

If the command **utils dbreplication status** show that servers are connected but one or more tables have data that is out of sync, this command will repair the data on the subscriber servers so that it is in sync with the data on the publisher server.

Use the **all** parameter to repair all nodes in the cluster, or if only one subscriber server is out of sync, specify the *hostname* parameter.

Requirements

Command privilege level: 0

Allowed during upgrde: No

utils dbreplication reset

This command resets and restarts database replication. It can be used to tear down and rebuild replication when the system has not set up properly.

Command Syntax

```
utils dbreplication reset {all|hostname}
```

- **all** causes all subscriber servers in the cluster to have replication torn down and rebuilt.

- *hostname* specifies a particular subscriber server to have replication torn down and rebuilt.

Usage Guidelines

This is the best command to use when servers show an RTMT state of 4. If only one subscriber server is showing an RTMT state of 4, you may reset that server by specifying the *hostname* parameter. To reset the entire cluster, use the **all** parameter.



Tip

Before you run this command, first run the command **utils dbreplication stop** on all subscriber servers that will be reset and then on the publisher server.

Requirements

Command privilege level: 0

Allowed during upgrde: No

utils dbreplication setreptimeout

You can use this command to set the timeout for database replication on large clusters.

Command Syntax

utils dbreplication setreptimeout *timeout*

Options

- *timeout*—The new database replication timeout, in seconds. Ensure that the value is between 300 and 3600.

Usage Guidelines

The default database replication timeout equals 5 minutes (value of 300).

When the first subscriber server requests replication with the publisher server, the system sets this timer. When the timer expires, the first subscriber server, plus all other subscriber servers that requested replication within that time period, begin data replication with the publisher server in a batch. If you have several subscriber servers, batch replication is more efficient than individual server replication. For large clusters, you can use the command to increase the default timeout value, so that more subscriber servers will be included in the batch.



Note

After you upgrade the publisher server and restart it on the upgraded partition, you should set this timer value before you switch the first subscriber server to the new release. When the first subscriber server requests replication, the publisher server will set the replication timer based on the new value.



Tip

Cisco recommends that you restore this value back to the default of 300 (5 minutes) after you finish upgrading the entire cluster, and the subscriber servers have successfully set up replication.

Requirements

Command privilege level: 0

Allowed during upgrade: No

utils dbreplication status

This command displays the status of database replication and indicates whether the servers in the cluster are connected and the data is in sync. You should run this command only on the first node (publisher server) of a cluster.

Command Syntax

utils dbreplication status

Requirements

Command privilege level: 0

Allowed during upgrde: No

utils dbreplication stop

This command stops the automatic setup of database replication. Use this command on subscriber and publisher servers prior to executing the CLI command **utils dbreplication reset** or **utils dbreplication clusterreset**. You can run this command on the subscriber servers simultaneously, before you run it on the publisher server.

Command Syntax

utils dbreplication stop

Requirements

Command privilege level: 0

Allowed during upgrde: No

utils diagnose

This command enables you to diagnose and attempt to automatically fix system problems.

Command Syntax

utils diagnose

fix

list

module *module_name*

test

version

Parameters

- **fix** runs all diagnostic commands and attempts to fix problems.
- **list** lists all available diagnostic commands.
- **module** runs a single diagnostic command or group of commands and attempts to fix problems.
- **test** runs all diagnostic commands but does not attempt to fix problems.

- **version** displays the diagnostic framework version.
- *module_name* specifies the name of a diagnostics module.

utils disaster_recovery backup tape

This command starts a backup job and stores the resulting Tar file on tape.

Command Syntax

utils disaster_recovery backup tape *featurelist tapeid*

Parameters

- *featurelist* specifies the list of features to back up, separated by commas.
- *tapeid* represents the ID of an available tape device.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

utils disaster_recovery backup network

This command starts a backup job and stores the resulting Tar file on a remote server.

Command Syntax

utils disaster_recovery backup network *featurelist path servername username*

Parameters

- *featurelist* specifies the list of features to back up, separated by commas.
- *path* represents the location of the backup files on the remote server.
- *servername* represents the IP address or host name of the server where you stored the backup files.
- *username* represents the username that is needed to log in to the remote server.

Usage Guidelines



Note

The system prompts you to enter the password for the account on the remote server.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

utils disaster_recovery cancel_backup

This command cancels the ongoing backup job.

Command Syntax

utils disaster_recovery cancel_backup

Usage Guidelines

The system prompts you to confirm that you want to cancel the backup job.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

utils disaster_recovery restore tape

This command starts a restore job and takes the backup tar file from tape.

Command Syntax

utils disaster_recovery restore tape *server tarfilename tapeid*

Parameters

- *server* specifies the hostname of the server that you want to restore.
- *tarfilename* specifies the name of the file to restore.
- *tapeid* specifies the name of the tape device from which to perform the restore job.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

utils disaster_recovery restore network

This command starts a restore job and takes the backup Tar file from a remote server.

Command Syntax

utils disaster_recovery restore network *restore_server tarfilename path servername username*

Parameters

- *restore_server* specifies the hostname of the server that you want to restore.
- *tarfilename* specifies the name of the file to restore.
- *path* represents the location of the backup files on the remote server.
- *servername* represents the IP address or host name of the server where you stored the backup files.
- *username* represents the username that is needed to log in to the remote server.

Usage Guidelines**Note**

The system prompts you to enter the password for the account on the remote server.

Requirements

Command privilege level: 1
 Allowed during upgrade: Yes

utils disaster_recovery show_backupfiles network

This command starts a restore job and takes the backup Tar file from a remote server.

Command Syntax

utils disaster_recovery show_backupfiles network *path servername username*

Parameters

- *path* represents the location of the backup files on the remote server.
- *servername* represents the IP address or host name of the server where you stored the backup files.
- *username* represents the username that is needed to log in to the remote server.

Usage Guidelines



Note

The system prompts you to enter the password for the account on the remote server.

Requirements

Command privilege level: 1
 Allowed during upgrade: No

utils disaster_recovery show_backupfiles tape

This command displays information about the backup files that are stored on a tape.

Command Syntax

utils disaster_recovery show_backupfiles tape *tapeid*

Parameters

- *tapeid* represents the ID of an available tape device.

Requirements

Command privilege level: 1
 Allowed during upgrade: No

utils disaster_recovery show_registration

This command displays the registered features and components on the specified server.

Command Syntax

utils disaster_recovery show_registration *hostname*

Parameters

- *hostname* specifies the server for which you want to display registration information.

Requirements

Command privilege level: 1

Allowed during upgrade: No

utils disaster_recovery show_tapeid

This command displays a list of tape device IDs.

Command Syntax

utils disaster_recovery show_tapeid

Requirements

Command privilege level: 1

Allowed during upgrade: No

utils disaster_recovery status

This command displays the status of the current backup or restore job.

Command Syntax

utils disaster_recovery status *operation*

Parameters

- *operation* specifies the name of the ongoing operation: **backup** or **restore**.

Requirements

Command privilege level: 1

Allowed during upgrade: No

utils fior

This command allows you to monitor the I/O on the server. The File I/O Reporting service provides a kernel-based daemon for collecting file I/O per process.

Command Syntax

utils fior

disable

enable

list [start=*date-time*] [stop=*date-time*]

start

status

stop

top *number* [**read** | **write** | **read-rate** | **write-rate**] [**start**=*date-time*] [**stop**=*date-time*]

Options

- **disable**—Prevents the file I/O reporting service from starting automatically when the machine boots. This command does not stop the service without a reboot. Use the **stop** option to stop the service immediately.
- **enable**—Enables the file I/O reporting service to start automatically when the machine boots. This command does not start the service without a reboot. Use the **start** option to start the service immediately.
- **list**—This command displays a list of file I/O events, in chronological order, from oldest to newest.
- **start**—Starts a previously stopped file I/O reporting service. The service remains in a started state until it is manually stopped or the machine is rebooted.
- **status**—Displays the status of the file I/O reporting service.
- **stop**—Stops the file I/O reporting service. The service remains in a stopped state until it is manually started or the machine is rebooted.
- **top**—Displays a list of top processes that create file I/O. You can sort this list by the total number of bytes read, the total number of bytes written, the rate of bytes read, or the rate of bytes written.
- **start**—Specifies a starting date and time.
- **stop**—Specifies a stopping date and time.
- *date-time*—specifies a date and time, in any of the following formats: *H:M*, *H:M:S a*, *H:M, a*, *H:M:S Y-m-d*, *H:M, Y-m-d*, *H:M:S*.
- *number*—Specifies how many of the top processes to list.
- [**read** | **write** | **read-rate** | **write-rate**]—Specifies the metric that is used to sort the list of top process.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

utils firewall

This command manages the firewall on the node.

Command Syntax

utils firewall

disable {*time*}

enable

list

status

Parameters

- **disable** disables the firewall.

- *time* specifies the duration for which the firewall is disabled, in one of these formats:
 - [0-1440]**m** to specify a duration in minutes.
 - [0-24]**h** to specify a duration in hours.
 - [0-23]**h**[0-60]**m** to specify a duration in hours and minutes.
 If you do not specify a time, the default equals 5 minutes.
- **list** displays the current firewall configuration.
- **status** displays the status of the firewall.

Usage Guidelines

When the firewall is disabled, you must enter the URL of the Cisco Unified Communications Manager server in the following format to log into the web interface:

```
https://server:8443/
```

where *server* specifies the servername or IP address of the server.

Cisco does not recommend that you disable the firewall.

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

utils iostat

This command displays the iostat output for the given number of iterations and interval.

Command Syntax

```
utils iostat [interval] [iterations] [filename]
```

Parameters

- *interval* represents the value in seconds between two iostat readings (mandatory if you specify the number of iterations)
- *iterations* represents the number of iostat iterations to be performed (mandatory if you specify an interval)
- *filename* redirects the output to a file

Requirements

Level privilege: 0

Command privilege: 1

Allowed during upgrade: No

utils iothrottle enable

This command enables I/O throttling enhancements. When enabled, I/O throttling enhancements lower the impact of upgrades on an active system.

Command Syntax
utils iothrottle enable

utils iothrottle disable

This command disables I/O throttling enhancements. This could adversely affect the system during upgrades.

Command Syntax
utils iothrottle disable

utils iothrottle status

This command displays the status of I/O throttling enhancements.

Command Syntax
utils iothrottle status

utils netdump client

This command configures the netdump client.

Command Syntax
utils netdump client

```
start ip-address-of-netdump-server
status
stop
```

Parameters

- **start** starts the netdump client.
- **status** displays the status of the netdump client.
- **stop** stops the netdump client.
- *ip-address-of-netdump-server* specifies the IP address of the netdump server to which the client will send diagnostic information.

Usage Guidelines

If a kernel panic crash occurs, the netdump client sends diagnostic information about the crash to a netdump server.

Requirements

Command privilege level: 0

Allowed during upgrade: No

utils netdump server

This command configures the netdump server.

Command Syntax

utils netdump server

```
add-client ip-address-of-netdump-client  
delete-client ip-address-of-netdump-client  
list-clients  
start  
status  
stop
```

Parameters

- **add-client** adds a netdump client.
- **delete-client** deletes a netdump client.
- **list-clients** lists the clients that are registered with this netdump server.
- **start** starts the netdump server.
- **status** displays the status of the netdump server.
- **stop** stops the netdump server.
- *ip-address-of-netdump-client* specifies the IP address of a netdump client.

Usage Guidelines

If a kernel panic crash occurs, a netdump-enabled client system sends diagnostic information about the crash to the netdump server.

The netdump diagnostic information gets stored in the following location on the netdump server: *crash/*. The subdirectories whose names comprise a client IP address and a date contain netdump information.

You can configure each Cisco Unified Operating System server as both a netdump client and server.

If the server is on another Cisco Unified Operating System server, only the kernel panic trace signature gets sent to the server; otherwise, an entire core dump gets sent.

Requirements

Command privilege level: 0

Allowed during upgrade: No

utils network arp

This command lists, sets, or deletes Address Resolution Protocol (ARP) table entries.

Command Syntax

utils network arp

```
list [host host] [page] [numeric]
```

```
set {host} {address}
delete host
```

Parameters

- **list** lists the contents of the address resolution protocol table.
- **set** sets an entry in the address resolution protocol table.
- **delete** deletes an entry in the address resolution table.
- *host* represents the host name or IP address of the host to add or delete to the table.
- *address* represents the MAC address of the host to be added. Enter the MAC address in the following format: XX:XX:XX:XX:XX:XX.

Options

- **page**—Displays the output one page at a time
- **numeric**—Displays hosts as dotted IP addresses

Requirements

Command privilege level: 0
 Allowed during upgrade: Yes

utils network capture eth0

This command captures IP packets on the specified Ethernet interface.

Command Syntax

```
utils network capture eth0 [page] [numeric] [file fname] [count num] [size bytes] [src addr] [dest addr] [port num]
```

Parameters

- **eth0** specifies Ethernet interface 0.

Options

- **page**—Displays the output one page at a time
 When you use the page or file options, the complete capture of all requested packets must occur before the command completes.
- **numeric**—Displays hosts as dotted IP addresses
- **file *fname***—Outputs the information to a file
 The file option saves the information to platform/cli/*fname*.cap. The filename cannot contain the “.” character.
- **count *num***—Sets a count of the number of packets to capture
 For screen output, the maximum count equals 1000, and, for file output, the maximum count equals 10,000.
- **size *bytes***—Sets the number of bytes of the packet to capture
 For screen output, the maximum number of bytes equals 128, for file output, the maximum of bytes can be any number or **ALL**

- **src addr**—Specifies the source address of the packet as a host name or IPV4 address
- **dest addr**—Specifies the destination address of the packet as a host name or IPV4 address
- **port num**—Specifies the port number of the packet, either source or destination

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

utils network connectivity

This command verifies the node network connection to the first node in the cluster. Be aware that it is only valid on a subsequent node.

Command Syntax

utils network connectivity

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

utils network host

This command resolves a host name to an address or an address to a host name.

Command Syntax

utils network host *hostname* [**server** *server-name*] [**page**] [**detail**] [**srv**]

Parameters

- *hostname* represents the host name or IP address that you want to resolve.

Options

- *server-name*—Specifies an alternate domain name server.
- **page**—Displays the output one screen at a time.
- **detail**—Displays a detailed listing.
- **srv**—Displays DNS SRV records.

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

utils network ping

This command allows you to ping another server.

Command Syntax

utils network ping *destination* [*count*]

Parameters

- *destination* represents the hostname or IP address of the server that you want to ping.

Options

- *count*—Specifies the number of times to ping the external server. The default count equals 4.

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

utils network tracert

This command traces IP packets that are sent to a remote destination.

Command Syntax

utils network tracert *destination*

Parameters

- *destination* represents the hostname or IP address of the server to which you want to send a trace.

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

utils ntp

This command displays the NTP status or configuration.

Command Syntax

utils ntp {*status* | *config*}

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

utils ntp restart

This command restarts the NTP service.

Command Syntax

utils ntp restart

Parameters

None

Requirements

Level privilege: 0

Command privilege: 0

Allowed during upgrade: Yes

utils ntp start

If it is not already running, this command starts the NTP service.

**Note**

You cannot stop the NTP service from the command line interface. Use this command when the **utils ntp status** command returns **stopped**.

Command Syntax**utils ntp start****Parameters**

None

Requirements

Level privilege: 0

Command privilege: 0

Allowed during upgrade: Yes

utils remote_account

This command allows you to enable, disable, create, and check the status of a remote account.

Command Syntax**utils remote_account****status****enable****disable****create** *username life***Parameters**

- *username* specifies the name of the remote account. The username can contain only lowercase characters and must be more than six characters long.
- *life* specifies the life of the account in days. After the specified number of day, the account expires.

Usage Guidelines

A remote account generates a pass phrase that allows Cisco Systems support personnel to get access to the system for the specified life of the account. You can have only one remote account that is enabled at a time.

Requirements

Command privilege level: 1
 Allowed during upgrade: Yes

Example

```
utils remote_account status
```

utils reset_ui_administrator_name (Cisco Unified Communications Manager Only)



Note

To change the administrator user name for Cisco Unity Connection, use Cisco Unity Connection Administration.

This command resets the administrator user name you use to log in the administration user interface for the installed product.

Command Syntax

```
utils reset_ui_administrator_name
```

utils reset_ui_administrator_password (Cisco Unified Communications Manager Only)



Note

To change the password for a Cisco Unity Connection user, use the **utils cuc reset password** command. See the “[utils cuc reset password \(Cisco Unity Connection Only\)](#)” section on page 89.

This command resets the administrator password you use to log in the administration user interface for the installed product.

Command Syntax

```
utils reset_ui_administrator_password
```

utils service list

This command retrieves a list of all services and their status.

Command Syntax

```
utils service list [page]
```

Options

- **page**—Displays the output one page at a time

Requirements

Command privilege level: 0

Allowed during upgrade: Yes

utils service

This command stops, starts, or restarts a service.

Command Syntax**utils service**

start *service-name*

stop *service-name*

restart *service-name*

auto-restart { **enable** | **disable** | **show** } *service-name*

Parameters

- *service-name* represents the name of the service that you want to stop or start:
 - System SSH
 - Cluster Manager
 - Service Manager
 - Cisco Tomcat
 - Cisco Database Layer Monitor
 - Cisco CallManager Serviceability
- **auto-restart** causes a service to automatically restart.
- **enable** enables auto-restart.
- **disable** disables auto-restart.
- **show** shows the auto-restart status.

Requirements

Command privilege level: 1

Allowed during upgrade: No

utils sftp handshake

This command exchanges SFTP SSH keys to all members of the cluster.

Command Syntax

utils sftp handshake

utils snmp

This command manages SNMP on the server.

Command Syntax

utils snmp

```

get version community ip-address object [file]
hardware-agents [status | stop | restart]
test
walk version community ip-address object [file]

```

Parameters

- **get** displays the value of the specified SNMP object.
- **hardware-agents status** displays the status of the hardware agents on the server.
- **hardware-agents stop** stops all SNMP agents provided by the hardware vendor.
- **hardware-agents restart** restarts the hardware agents on the server.
- **test** tests the SNMP host by sending sample alarms to local syslog, remote syslog, and SNMP trap.
- **walk** walks the SNMP MIB, starting with the specified SNMP object.
- *version* specifies the SNMP version. Possible values include 1 or 2c.
- *community* specifies the SNMP community string.
- *ip-address* specifies the IP address of the server. Enter 127.0.0.0 to specify the local host. You can enter the IP address of another node in the cluster to run the command on that node.
- *object* specifies the SNMP Object ID (OID) to get.
- *file* specifies a file in which to save the command output.

Requirements

Command privilege level: 1

Allowed during upgrade: Yes

utils soap realservice test

This command executes a number of test cases on the remote server.

Command Syntax

```

utils soap realservice test remote-ip remote-https-user remote-https-password

```

Parameters

- *remote-ip* specifies the IP address of the server under test.
- *remote-https-user* specifies a username with access to the SOAP API.
- *remote-https-password* specifies the password for the account with SOAP API access.

Requirements

Command privilege level: 0

Allowed during upgrade: No

utils system

This command allows you to restart the system on the same partition, restart the system on the inactive partition, or shut down the system.

Command Syntax

utils system { **restart** | **shutdown** | **switch-version** }

Parameters

restart restarts the system.

shutdown shuts down the system.

switch-version switches to the product release that is installed on the inactive partition.

Usage Guidelines

The **utils system shutdown** command provides a 5-minute timeout. If the system does not shut down within 5 minutes, the command gives you the option of doing a forced shutdown.

**Note**

Administrative changes made on the active partition, such as adding new phones, do not get synchronized when you switch versions. Data for user-facing features gets synchronized when you switch versions.

Requirements

Command privilege level: 1

Allowed during upgrade: No

utils system boot

This command redirects where the system boot output gets sent.

Command Syntax

utils system boot { **console** | **serial** | **status** }

Parameters

- **console** redirects the system boot output to the console.
- **serial** redirects the system boot output to the COM1 (serial port 1).
- **status** displays the where the serial boot output will currently get sent.

Requirements

Level privilege: 1

Command privilege: 1

Allowed during upgrade: Yes

utils system upgrade

This command allows you to install upgrades and Cisco Option Package (COP) files from both local and remote directories.

Command Syntax

utils system upgrade {initiate | cancel | status}

Parameters

- **cancel** cancels the active upgrade.
- **initiate** starts a new upgrade wizard or assumes control of an existing upgrade wizard. The wizard prompts you for the location of the upgrade file.
- **status** displays the status of an upgrade.

Usage Guidelines

To upgrade the system, follow these major steps:

1. Use the **utils system upgrade list** command to display a list of the .iso upgrade files that are available on the local disk or remote server from which you plan to upgrade.
2. Use the **utils system upgrade get** command to get the upgrade file that you want to use.
3. Use the **utils system upgrade start** command to start upgrading from the upgrade file you got.

Related Documentation

For further information about related Cisco IP telephony applications and products, refer to the *Cisco Unified Communications Manager Documentation Guide* for your release at

http://cisco.com/en/US/products/sw/voicesw/ps556/products_documentation_roadmaps_list.html

Obtaining Documentation, Obtaining Support, and Security Guidelines

For information on obtaining documentation, obtaining support, providing documentation feedback, security guidelines, and also recommended aliases and general Cisco documents, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Cisco Product Security Overview

This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute or use encryption. Importers, exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately.

Further information regarding U.S. export regulations may be found at

http://www.access.gpo.gov/bis/ear/ear_data.html

CCDE, CCENT, CCSI, Cisco Eos, Cisco Explorer, Cisco HealthPresence, Cisco IronPort, the Cisco logo, Cisco Nurse Connect, Cisco Pulse, Cisco SensorBase, Cisco StackPower, Cisco StadiumVision, Cisco TelePresence, Cisco TrustSec, Cisco Unified Computing System, Cisco WebEx, DCE, Flip Channels, Flip for Good, Flip Mino, Flipshare (Design), Flip Ultra, Flip Video, Flip Video (Design), Instant Broadband, and Welcome to the Human Network are trademarks; Changing the Way We Work, Live, Play, and Learn, Cisco Capital, Cisco Capital (Design), Cisco:Financed (Stylized), Cisco Store, Flip Gift Card, and One Million Acts of Green are service marks; and Access Registrar, Aironet, AllTouch, AsyncOS, Bringing the Meeting To You, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, CCVP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Lumin, Cisco Nexus, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Collaboration Without Limitation, Continuum, EtherFast, EtherSwitch, Event Center, Explorer, Follow Me Browsing, GainMaker, iLYNX, IOS, iPhone, IronPort, the IronPort logo, Laser Link, LightStream, Linksys, MeetingPlace, MeetingPlace Chime Sound, MGX, Networkers, Networking Academy, PCNow, PIX, PowerKEY, PowerPanels, PowerTV, PowerTV (Design), PowerVu, Prisma, ProConnect, ROSA, SenderBase, SMARTnet, Spectrum Expert, StackWise, WebEx, and the WebEx logo are registered trademarks of Cisco and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1002R)

Copyright © 2009, Cisco Systems, Inc. All rights reserved.

