




Features of your Cisco Unified SIP Phone 3905

This chapter describes the features of the Cisco Unified SIP Phone 3905.

- [Phone connections, page 1](#)
- [Buttons and hardware, page 3](#)
- [Phone screen, page 4](#)
- [Footstand, page 5](#)
- [Adjust handset rest, page 5](#)


Phone connections


For your phone to work, it must be connected to the corporate IP telephony network. Your system administrator can help you connect your phone.











1	DC adapter port (DC 4.2V).	4	Network port (10/100 SW) connection. IEEE 802.3af power enabled.
2	AC-to-DC power supply (optional).	5	Access port (10/100 PC) connection.
3	AC power wall connection.	6	Handset connection.


Buttons and hardware



1	Phone screen	Shows information about your phone such as directory number, active call, and phone menu listings.
2	Light strip	Indicates an incoming call (flashing red) or new voice message (steady red).
3	Navigation bar and Select/Feature button 	The Navigation bar allows you to scroll through menus and highlight items. The Select button (in the middle of the Navigation bar) allows you to select a highlighted item. When the phone is off-hook, the Select button functions as the Feature button. You can access these features: <ul style="list-style-type: none"> • Call Forward All—Allows you to forward a call. • Voice Mail—Allows you access voice mails. • Call Pickup—Allows you to answer a call that is ringing on a co-worker's phone.

		<ul style="list-style-type: none"> Group Call Pickup—Allows you to answer a call that is ringing in another call group.
4	Applications button 	Opens/closes the Applications menu. Use it to access call history, user preferences, phone settings, and phone model information.
5	Transfer button 	Transfers a call.
6	Hold/Resume button 	Places an active call on hold or resumes a held call.
7	Keypad	Allows you to dial phone numbers.
8	Speakerphone button 	Selects the speakerphone as the default audio path and initiates a new call, picks up an incoming call, or ends a call. The speakerphone audio path does not change until a new default audio path is selected (for example, by picking up the handset).
9	Volume button 	Controls the handset and speakerphone volume (off-hook) and the ringer volume (on hook).
10	Mute button 	Toggles the microphone on or off.
11	Redial button 	Dials the last dialed number.
12	Back button 	Returns to the previous screen or menu.
13	Handset	Phone handset.

Phone screen



1	Header	Displays date and time. Also displays line information such as voicemail and missed calls. When using the Applications menu, displays phone menu listings.
---	--------	--

2	Line details and other phone information	Displays the directory number. During a call, also displays details for the active line. If not on a call, also displays line text label and other information such as placed calls and phone menu listings.
---	--	--


Footstand

The Cisco Unified IP Phone 3905 has a foldable footstand. When the footstand is unfolded, it gives the phone an elevated viewing angle.



Adjust handset rest

Your system administrator may have mounted your phone on a wall. With a wall-mounted phone, you might need to adjust the handset rest to ensure that the receiver does not slip out of the cradle.



Procedure

-
- Step 1** Remove the handset from the cradle and pull the plastic tab from the handset rest.
 - Step 2** Rotate the tab 180 degrees.
 - Step 3** Hold the tab between two fingers, with the corner notches facing you. Make sure the tab lines up evenly with the slot in the handset cradle.
 - Step 4** Press the tab evenly into the slot. An extension protrudes from the top of the rotated tab.
 - Step 5** Return the handset to the handset rest.
-