



## **Errata for ASR 5000 Installation Guide and ASR 5000 Series Product Overview**

**Versions 12.0, 12.1, 12.2, 12.3 and 14.0**

**Last Updated January 24, 2013**

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks). Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

Errata for ASR 5000 Installation Guide and ASR 5000 Series Product Overview

© 2013 Cisco Systems, Inc. All rights reserved.

# CONTENTS

---

<b>About this Guide .....</b>	<b>v</b>
Conventions Used .....	vi
Contacting Customer Support .....	vii
<b>Errata .....</b>	<b>9</b>
ASR 5000 Installation Guide .....	10
ASR 5000 Series Product Overview .....	10
ASR 5000 Hardware Platform Overview Chapter .....	10







# About this Guide

---

This document describes content that was erroneous in previous versions of ASR 5000 user documentation. The content changes will appear in the next published releases of the identified Cisco ASR 5000 documentation.

## Conventions Used

The following tables describe the conventions used throughout this documentation.

Icon	Notice Type	Description
	Information Note	Provides information about important features or instructions.
	Caution	Alerts you of potential damage to a program, device, or system.
	Warning	Alerts you of potential personal injury or fatality. May also alert you of potential electrical hazards.
	Electro-Static Discharge (ESD)	Warns you to take proper grounding precautions before handling ESD sensitive components or devices.

Typeface Conventions	Description
Text represented as a <i>screen display</i>	This typeface represents displays that appear on your terminal screen, for example: Login:
Text represented as <b>commands</b>	This typeface represents commands that you enter, for example: <b>show ip access-list</b> This document always gives the full form of a command in lowercase letters. Commands are not case sensitive.
Text represented as a <b>command variable</b>	This typeface represents a variable that is part of a command, for example: <b>show card slot_number</b> slot_number is a variable representing the desired chassis slot number.
Text represented as menu or sub-menu names	This typeface represents menus and sub-menus that you access within a software application, for example: Click the <b>File</b> menu, then click <b>New</b>

Command Syntax Conventions	Description
{ <b>keyword</b> or <i>variable</i> }	Required keywords and variables are surrounded by grouped braces. Required keywords and variables are those components that are required to be entered as part of the command syntax.
[ <b>keyword</b> or <i>variable</i> ]	Optional keywords or variables, or those that a user may or may not choose to use, are surrounded by brackets.

Command Syntax Conventions	Description
	Some commands support alternative variables. These options are documented within braces or brackets by separating each variable with a vertical bar. These variables can be used in conjunction with required or optional keywords or variables. For example: <pre>{ nonce   timestamp }</pre> OR <pre>[ count number_of_packets   size number_of_bytes ]</pre>

## Contacting Customer Support

Use the information in this section to contact customer support.

Refer to the support area of <http://www.cisco.com> for up-to-date product documentation or to submit a service request. A valid username and password are required to access this site. Please contact your Cisco sales or service representative for additional information.



# Chapter 1

## Errata

---

This chapter identifies erroneous content in previous versions of ASR 5000 user documentation. This content change will appear in the next releases of the documentation.

Documentation updates provided in this errata pertain to the documents listed in the following table and correspond to the stated release date(s):

**Table 1. Affected Documents**

<b>Document</b>	<b>Part Number</b>	<b>Release Date</b>
<i>Cisco ASR 5000 Installation Guide, Version 12.0, 12.1, 12.2, 12.3</i>	OL-26450-03	September 28, 2012
<i>Cisco ASR 5000 Installation Guide, Version 14.0</i>	OL-27208-02	September 28, 2012
<i>Cisco ASR 5000 Series Product Overview, Release 12.0</i>	OL-24419-04	October 26, 2012
<i>Cisco ASR 5000 Series Product Overview, Release 12.1</i>	OL-25189-05	May 31, 2012
<i>Cisco ASR 5000 Series Product Overview, Version 12.2</i>	OL-25550-02	February 29, 2012
<i>Cisco ASR 5000 Series Product Overview, Version 12.3</i>	OL-26993-02	October 30, 2012
<i>Cisco ASR 5000 Series Product Overview, Version 14.0</i>	OL-27222-04	November 07, 2012

## ASR 5000 Installation Guide

In the *ASR 5000 Hardware Platform Overview* chapter, *Line Cards* section, *Optical Line Card (OLC2)* subsection, the sentence: “You may optionally install an OLC2 behind a redundant packet processing card (those operating in standby mode).” has been removed. This configuration is not supported on the ASR 5000 chassis.

This change already appears in the *Cisco ASR 5000 Installation Guide (OL-27965)* published on 1/14/2013 [OL-27965\_ASR5000\_Install.zip].

HTML document OL-27965 will be the only version of the *ASR 5000 Installation Guide* published going forward. All previous versions of the *ASR 5000 Installation Guide* can be considered obsolete.

## ASR 5000 Series Product Overview

### ASR 5000 Hardware Platform Overview Chapter

In the *ASR 5000 Hardware Platform Overview* chapter, *Line Cards* section, *Optical Line Card (OLC2)* subsection, the sentence: “You may optionally install an OLC2 behind a redundant packet processing card (those operating in standby mode).” has been removed. This configuration is not supported on the ASR 5000 chassis.

This change already appears in the *Cisco ASR 5000 Installation Guide (OL-27965)* published on 1/14/2013 [OL-27965\_ASR5000\_Install.zip].

The change will appear when the next versions of the Product Overviews are published.