



## Preface

---

This section describes the objectives, audience, organization, and conventions of the *Cisco Aironet 350 Series Bridge Hardware Installation Guide*.

## Objectives

This publication explains the steps for initial setup and configuration of the Cisco Aironet 350 Series Bridge (here after referred to as the bridge). This publication also provides troubleshooting information and detailed specifications.

## Audience

This publication is for the person installing and configuring a bridge for the first time. The installer should be familiar with network structures, terms, and concepts.

# Organization

This guide contains the following sections:

Chapter 1, “Overview,” describes the features and specifications of bridges.

Chapter 2, “Installation,” provides basic installation instructions.

Chapter 3, “Basic Configuration,” describes how to enter basic configuration settings.

Chapter 4, “Troubleshooting,” provides solutions to potential problems encountered during setup.

Appendix A, “Translated Safety Warnings,” lists translations of the safety warnings in this publication.

Appendix B, “Declarations of Conformity and Regulatory Information,” describes the regulatory conventions to which the bridge conforms and provides guidelines for operating bridges in Japan.

Appendix C, “Antenna Basics,” provides basic antenna information.

# Conventions

This publication uses the following conventions to convey instructions and information:

- Commands and keywords are in **boldface** type.



---

**Note**

Means *reader take note*. Notes contain helpful suggestions or references to materials not contained in this manual.

---



---

**Caution**

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

---

**Warning**

**The warning symbol means danger.** You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. To see translations of the warnings that appear in this publication, refer to Appendix A in this manual.

## Related Publications

For more information about bridges and related products, refer to the following publications:

- *Quick Start Guide: Cisco Aironet 350 Series Bridge* describes how to connect and power up the bridge, assign an IP address, and configure the bridge for basic operation.
- *Cisco Aironet 350 Series Bridge Software Configuration Guide* describes the bridge's management system and explains how to configure the bridge.
- *Release Notes for Cisco Aironet 350 Series Bridges* describes features and caveats for the 350 series bridges.
- *Cisco Secure Access Control Server for Windows 2000/NT Servers Version 2.6 User Guide* provides complete instructions for using Cisco Secure ACS, including steps for configuring Cisco Secure ACS to support Access Points and bridges.
- *Quick Start Guide: Cisco Aironet Wireless LAN Adapters* describes how to install and configure PC and PCI card client adapters for use in a wireless LAN.
- *Cisco Aironet Wireless LAN Adapters Hardware Installation Guide* provides hardware features, physical and performance characteristics, and installation instructions for PC and PCI card client adapters.
- *Cisco Aironet Wireless LAN Adapters Software Configuration Guide* provides instructions for installing and using the wireless client adapter utilities.
- *Mounting Instructions for the Cisco Aironet 350 Series Bridges*.

## Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.